

Laser and Optics

User's Manual



User's Manual

Agilent 5517A/5517B/5517C/5517D Laser Head Agilent 10736A-001 Three-Axis Interferometer with

Agilent 5519A/B Laser Head Beam Bender

Agilent 5529A Dynamic Calibrator Agilent 10737L, R Compact Three-axis Interferometers
Agilent 10567A Dual Beam Beam-Splitter Agilent 10753B Laser Tripod

Agilent 10700A 33% Beam Splitter
Agilent 10701A 50% Beam Splitter
Agilent 10766A Linear Interfero

Agilent 10701A 50% Beam Splitter

Agilent 10706A Linear Interferometer
Agilent 10702A Linear Interferometer (and 10702A-001

Agilent 10767A Linear Intererometer

gilent 10702A Linear Interferometer (and 10702A-001 Agilent 10767A Linear Intererometer with Windows)

Agilent 10767B Lightweight Retroreflector

Agilent 10703A Retroreflector
Agilent 10704A Retroreflector
Agilent 10705A Single Beam Interferometer
Agilent 10705A Angular Interferometer

Agilent 107/05A Single Beam Interferometer Agilent 107/05A Angular Interferometer

Agilent 107/05A Angular Interferometer Agilent 10771A Angular Retroreflector

Agilent 10706B High Stability Plane Mirror Interferometer
Agilent 10707A Beam Bender
Agilent 10773A Flatness Mirror

Agilent 10710B Adjustable Mount Agilent 10774A Short Range Straightness Optics
Agilent 10711A Adjustable Mount Agilent 10776A Straightness Accessory Kit

Agilent 10711A Adjustable Mount Agilent 10776A Straightness Accessory I Agilent 10713B/C/D Cube Corner Agilent 10777A Optical Square

Agilent 10713B/C/D Cube Corner Agilent 10777A Optical Square
Agilent 10715A Differential Interferometer (and Agilent 10780C Receiver

10715A-001 Turned Configuration)

Agilent 10700C Receiver
Agilent 10700C Receiver

Agilent 10716A High Resolution Interferometer (and 10716A-001 Turned Configuration)

Agilent 10790A/B/C Receiver Cable Agilent 10880A/B/C Receiver Cable

Agilent 10716A-001 Turned Configuration)

Agilent 10880A/B/C Receiver Cable

Agilent 10717A Wavelength Tracker

Agilent 10881A/B/C Laser Head Cable

Agilent 10719A One-axis Differential Interferometer

Agilent 10882A/B/C Laser Head Cable

Agilent 10721A Two-axis Differential Interferometer
Agilent 10721A Two-axis Differential Interferometer
Agilent 10722A Plane Mirror Converter
Agilent E1705A Fiber-Optic Cable

Agilent 10723A High Stability Adapter
Agilent 10724A Plane Mirror Reflector
Agilent 10724A Plane Mirror Reflector
Agilent E1708A Remote Dynamic Receiver

Agilent 10725A 50% Beam Splitter Agilent E1709A Remote High-Performance Receiver

Agilent 10726A Beam Bender Agilent N1203C Precision Beam Translator

Agilent 10726A Beam Bender Agilent N1203C Precision Beam Translator

Agilent 10728A Plane Mirror Agilent N1204C Precision Horizontal Beam Bender

Agilent 10735A Three-axis Interferometer
Agilent N1207C Precision Vertical Beam Bender
Agilent N1250A/B High Performance Receiver Cable
Agilent N1251A/B High Performance Laser Head Cable

PROPRIETARY INFORMATION

This manual contains proprietary information of Agilent Technologies, Inc. This information may not be used or reproduced without the express written permission of Agilent Technologies.

© Copyright AGILENT TECHNOLOGIES, INC. 1992, 1996, 2000, 2002 5301 Stevens Creek Boulevard Santa Clara, California 95052-8059

All rights reserved.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise without prior written permision of Agilent Technologies.

MANUAL PART NUMBER: 05517-90045 PRINTED: July 2002

Laser and Optics

Certification and Warranty

Certification

Agilent Technologies certifies that this product met its published specification at the time of shipment from the factory. Agilent further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology (formerly National Bureau of Standards), to the extent allowed by the Institute's calibration facility, and to the calibration facilities of other International Standards Organization members.

Warranty

Agilent warrants
Agilent hardware,
accessories and supplies
against defects in materials
and workmanship for a
period specified by each
product from date of
shipment. If Agilent receives
notice of such defects during
the warranty period, Agilent
will, at its option, either
repair or replace products
which prove to be defective.
Replacement products may
be either new or like-new.

Agilent warrants that Agilent software will not fail to execute its programming instructions, for the period specified above, due to defects in material and workmanship when properly installed and used. If Agilent receives notice of such defects during the warranty period, Agilent will replace software media which does not execute its programming instructions due to such defects.

For detailed warranty information, see back matter.

Safety Considerations General

This product and related documentation must be reviewed for familiarization with this safety markings and instructions before

operation.

This product is a safety Class I instrument (provided with a protective earth terminal).

Before Applying Power

Verify that the product is set to match the available line voltage and the correct fuse is installed.

Before Cleaning

Disconnect the product from operating power before cleaning.

Safety Earth Ground

An uninterruptible safety earth ground must be provided from the mains power source to the product input wiring terminals or supplied power cable.

Warning Symbols That May Be Used In This Book



Instruction manual symbol; the product will be marked with this symbol when it is necessary for the user to refer to the instruction manual.



Indicates hazardous voltages.



Indicates earth (ground) terminal.

Safety Considerations (contd)



 \mathbf{or}



Indicates terminal is connected to chassis when such connection is not apparent.



Indicates Alternating current.

Indicates Direct current.

WARNING _

BODILY INJURY OR
DEATH MAY RESULT
FROM FAILURE TO HEED
A WARNING. DO NOT
PROCEED BEYOND A
WARNING UNTIL THE
INDICATED CONDITIONS
ARE FULLY
UNDERSTOOD AND MET.

CAUTION

Damage to equipment, or incorrect measurement data, may result from failure to heed a caution. Do not proceed beyond a *CAUTION* until the indicated conditions are fully understood and met.

These CAUTION labels are required by the United States Center for Devices and Radiological Health. Failure to follow their instructions may result in personal injury.

This symbol indicates laser radiation.



CAUTION: Laser radiation when open-DO NOT STARE INTO THE BEAM

For additional safety and acoustic noise information, see back matter.

Contents

About This Manual
Introduction 1-2 How to Locate Information 1-2 Manual Organization 1-2 Manuals Available 1-6 How to Order Manuals 1-7
Familiarization and Initial Operation
A one-axis example is used for simplicity 2-2 Basic steps apply to all laser systems 2-2 Agilent laser inteferometer positioning systems at a glance 2-2 All Agilent laser systems share a similar configuration 2-3 A controller is required for all laser positioning systems 2-4 What follows? 2-4 Setting Up the System Electronics 2-5 To Install the Laser Electronics in the PC 2-5 To Connect the Electronics Cables 2-5 To Start the System 2-6 Aligning the Optics 2-6 Making a Measurement 2-7 Solving Problems 2-8
System Design Considerations
Introduction 3-2 Accuracy Considerations 3-4 Determining What Equipment is Needed 3-4 Electronic Components 3-9 Transducer Systems 3-9 PC-Based Electronics 3-9 VME Compatible Electronics 3-9 PC-Based PCI Electronics 3-9 Calibrator System Electronics 3-10 Agilent 5529A Dynamic Calibrator 3-10 Adjustment Considerations 3-11 Laser beam and optics protection 3-11 System Grounding 3-14 Laser Head 3-15
Orientation 3-15 User's Manual iii

Mounting plane tolerance 3-15
Pointing stability 3-16
Thermal isolation 3-16
Vibration isolation 3-16
Magnetic shielding 3-17
Mounting 3-17
Optics 3-17
Plane of orientation with respect to laser head 3-17
Effect of optics on measurement direction sense 3-17
Configuration effects 3-18
Vibration isolation for optics 3-19
Adjustable mounts for optics 3-19
Fasteners for optics 3-20
Vacuum applications 3-20
Differential measurements with interferometers 3-21
Moving interferometer instead of reflector 3-22
Introducing an offset into the laser beam 3-22
Beam Path Loss Computation 3-23
Considerations 3-23
Calculation of signal loss 3-25
Axis component efficiencies (worst case) 3-26
Axis component efficiencies (typical) 3-27
Receivers 3-28
General 3-28
Clearance for laser beam 3-28
Alignment adjustment required 3-28
Example Configurations 3-29
Single-axis system for servo-track writing 3-29
Multiaxis configurations 3-30
Multiaxis system for a precision x-y stage 3-31
Four-axis linear configuration 3-32
Two-axis plane mirror 3-33
Two-axis plane mirror in a vacuum 3-33
Two-axis measurement system using two Agilent 10715A
differential interferometers 3-35
Three-axis measurement system using discrete plane mirror interferometers (X, Y, YAW) 3-35
Multiaxis systems using Agilent 10719A and
Agilent 10721A inteferometers 3-39
Multiaxis systems using Agilent 10735A and
Agilent 10736A three-axis inteferometers 3-39

iv User's Manual

Optical Device Troubleshooting 3-39 Site Preparation 3-40 Site preparation for laser head 3-40 Site preparation for optical devices 3-40 Site preparation for referenced interferometers 3-41 **System Installation and Alignment** Introduction 4-2 **Pre-Installation Checklist** 4-2 **System Grounding External Cabling** Laser head cables For use with Agilent 10895A VME, 10889B PC, 10896B VME, 10897B VME, 10898A VME, or N1231A PCI axis board 4-3 Receiver cables 4-4 For use with Agilent 10895A VME Axis Board For use with Agilent 10895A VME, 10889B PC, 10896B VME, 10897B VME, 10898A VME, or N1231A PCI axis board 4-5 **Mounting Optics** Adjustable mounts 4-6 Typical mounting of optics which use adjustable mounts 4-6 Fasteners 4-7 **Aligning Optics** 4-10 General 4-10 Alignment principles 4-12 **Receiver Alignment and Gain Adjustment Autoreflection Method Summary Overlapping Dots Method Summary** Aligning the Agilent 10702A Linear, Agilent 10766A Linear, and Agilent 10705A Single Beam Interferometers Alignment aids (for Agilent 10702A, Agilent 10766A, Agilent 10705A) 4-19 Autoreflection alignment procedure (for Agilent 10702A, Agilent 10766A, Agilent 10705A) Overlapping dot alignment procedure (for Agilent 10702A,

User's Manual v

4-24

Agilent 10766A, Agilent 10705A)

5 Laser Heads

General 5-2 **Frequencies and Polarizations** 5-3 **Number of Measurement Axes** 5-4 **Measurement Range** 5-4 **Heat Generation Accuracy Considerations** 5-5 **Vibration Isolation** 5-6 **Automatic Tuning and Warmup Period** 5-6 **Beam Shutters** 5-6 Orientation 5-7 **Magnetic Shielding Pointing Stability Maintenance Requirements** 5-9 **Laser Head Descriptions** Comparison of Laser Heads 5-9 Agilent 5517A Laser Head 5-10 Description 5-10 Mounting and Clearance 5-11 Agilent 5517A Laser Head Specification 5-13 Agilent 5517B Laser Head 5-14 Description 5-14 **Mounting and Clearance** 5-14 **Agilent 5517B Laser Head Specifications** 5-17 Agilent 5517C Laser Head 5-18 Description 5-18 **Mounting and Clearance** 5-19 Agilent 5517C Laser Head Specifications (Standard and 5517C-003) 5 - 21Agilent 5517C-009 Laser Head Specifications 5-22 Agilent 5517D Laser Head 5-23 Description 5-23 **Mounting and Clearance** 5-24 Agilent 5517D Laser Head Specifications (Standard and 5517D-003) 5-26 Agilent 5519A/B Laser Head and Receiver 5-27 Description 5-27 5-29 **Functional Description Mounting and Clearance** 5-32 Agilent 5519A/B Laser Head Specifications 5-33

vi User's Manual

6 Beam-Directing Optics

Introduction 6-2
Use of the Adjustable Mounts 6-4
Vacuum Applications 6-4
Agilent 10567A Dual Beam Beam-Splitter 6-5
Agilent 10567A Dual Beam Beam-Splitter Specifications 6-6
Agilent 10700A 33% Beam Splitter and 10701A 50% Beam
Splitter 6-7
Agilent 10700A 33% Beam Splitter Specifications 6-8
Agilent 10701A 50% Beam Splitter Specifications 6-9
Agilent 10707A Beam Bender 6-10
Agilent 10707A Beam Bender Specifications 6-11
Agilent 10725A 50% Beam Splitter and 10726A Beam
Bender 6-12
Agilent 10725A Beam Splitter Specifications 6-12
Agilent 10726A Beam Bender Specifications 6-13
Agilent N1203C, N1204C, and N1207C Beam
Manipulators 6-14
Overview 6-14
Application simplified 6-14
Stability 6-15
Thermal 6-15
Mechanical 6-15
Optical Input/Output ports and adjustment access 6-167
Agilent N1203C Precision Beam Translator Specifications and
Characteristics 6-17
Agilent N1204C Precision Horizontal Beam Bender
Specifications and Characteristics 6-19
Agilent N1207C Precision Vertical Beam Bender Specifications
and Characteristics 6-21

User's Manual vii

7 Measurement Optics

General 7-2 Resolution 7-6 Range 7-6 **Measurement Direction Sense** 7-6 **Vibration Isolation** 7-9 **Fasteners** 7-9 **Vacuum Applications** 7-10 **Use Through Window** 7-10 **Differential Measurements with Interferometers** 7-10 **Moving Interferometer Instead of Reflector**

7A Agilent 10702A and 10766A Linear Interferometers, and Agilent 10703A and 10767A Retroreflectors

Introduction 7A-2
Description 7A-3
Laser Beam Path 7A-8

Differential measurements 7A-9

Special Considerations 7A-10

Effect of optics on measurement direction sense 7A-10 Configuration effects 7A-10 Moving interferometer instead of reflector 7A-10

Mounting 7A-11

Vibration considerations 7A-11 Adjustable mounts 7A-11

Fasteners 7A-11

Installation 7A-12

Pre-installation checklist 7A-12 Alignment 7A-13 Alignment aids 7A-13

Procedure 7A-13

Specifications and Characteristics 7A-13

Agilent 10702A Linear Interferometer Specifications 7A-14
Agilent 10702A-001 Linear Interferometer with Windows
Specifications 7A-15
Agilent 10703A Retroreflector Specifications 7A-16
Agilent 10713B Cube Corner Specifications 7A-16
Agilent 10766A Linear Interferometer Specifications 7A-17
Agilent 10767A Retroreflector Specifications 7A-18

viii User's Manual

7B Agilent 10705A Single Beam Interferometer and Agilent 10704 Retroreflector

Agilent 10705A Single Beam Interferometer and Agilent 10704A Retroreflector

Description 7B-2

Laser beam path 7B-3

Differential measurements 7B-4

Plane mirror measurements 7B-4

Special Considerations 7B-5

Effect of optics on measurement direction sense 7B-5

Configuration effects 7B-5

Mounting 7B-5

Adjustable mounts 7B-5

Fasteners 7B-5

Installation 7B-6

Pre-installation checklist 7B-6

Alignment 7B-7

Alignment aids 7B-7

Procedure 7B-7

Specifications and Characteristics 7B-7

Agilent 10705A Single Beam Interferometer Specifications

7B-8

Agilent 10704A Retroreflector Specifications 7B-9

Agilent 10713C Cube Corner Specifications 7B-9

Agilent 10713D Cube Corner Specifications 7B-10

7C Agilent 10706A Plane Mirror Interferometer

Description 7C-2

Laser beam paths 7C-4

Special Considerations 7C-6

Differential measurements 7C-6

Turned configuration 7C-6

Mounting 7C-8

Adjustable mounts 7C-8

Fasteners 7C-8

Installation 7C-9

Pre-installation check 7C-9

User's Manual ix

Alignment 7C-10 General 7C-10 Alignment aids 7C-10 Alignment procedure 7C-11 **Specifications and Characteristics** 7C-16 Agilent 10706A Plane Mirror Interferometer Specifications 7C-17 Agilent 10722A Plane Mirror Converter Specifications 7C-18 Agilent 10723A High Stability Adapter Specifications 7C-18 Agilent 10724A Plane Mirror Reflector Specifications 7C-19 **Converting to High-Stability Plane Mirror** Interferometer 7C-20 General To convert an Agilent 10706A Plane Mirror Interferometer to the Agilent 10706B configuration 7C-20 **Agilent 10706B High Stability Plane Mirror** Interferometer **Description** 7D-2 Laser beam paths 7D-2 **Special Considerations** 7D-5 Mounting **7D-5** Adjustable mounts 7D-5 **Fasteners** 7D-5 Installation 7D-5 **7D-5** Alignment **Straight-Through Configuration** 7D-6 **Turned Configuration** 7D-6 Alignment aids 7D-8 **Alignment Procedures** 7D-9 Straight-Through Configuration (Signal-Axis Alignment) 7D-9 Turned Configuration (X-Y Stage Example) Alignment

x User's Manual

7D-19

Specifications and Characteristics

Specifications

Agilent 10706B Plane Mirror Interferometer

7D-20

7E	Reserved for later user 7E-1
7F	Reserved for later user 7F-1
7 G	Agilent 10715A Differential Interferometer
	Description 7G-2
	Special Considerations (Configuration Effects) 7G-5
	Configurations with the same direction sense 7G-5
	Standard configuration Agilent 10715A 7G-5
	Turned configuration Agilent 10715A-001 7G-5
	Agilent 10715A upside down 7G-5
	Configurations that change the direction sense 7G-5
	Agilent 10715A Input and Output Apertures 7G-5
	Agilent 10715A orientation (horizontal or vertical) 7G-7
	Mounting 7G-7
	Adjustable mounts 7G-7
	Fasteners 7G-7
	Installation and Alignment 7G-8
	Configurations 7G-8
	Reference mirror mounting 7G-9
	Alignment aid 7G-10
	Alignment procedure 7G-10
	Specifications and Characteristics 7G-15
	Agilent 10715A Differential Interferometer (and 10715A-001 Turned Configuration) Specifications 7G-16
7H	Agilent 10716A High-Resolution Interferometer
	Description 7H-2
	Special Considerations 7H-5
	Mounting 7H-5
	Adjustable mounts 7H-5
	Fasteners 7H-5
	Installation 7H-5
	Pre-installation checklist 7H-5
	Alignment 7H-6
	Configurations 7H-6
	Alignment Aids 7H-7
	Alignment Overview 7H-8

User's Manual xi

Alignment Procedure 7H-9 **Specifications and Characteristics** 7H-13 Agilent 10716A High Resolution Interferometer (and 10716A-001 Turned Configuration) Specifications 7I Agilent 10717A Wavelength Tracker **Description** 7I-2 **Special Considerations** 7I-6 **Installation and Alignment** 7I-7 Pre-installation checklist Alignment aid 7I-7 Procedure 7I-7 Agilent 10717A Wavelength Tracker Specifications and Characteristics 7I-15 **Agilent 10719A One-Axis Differential** Interferometer **Description** 7J-2 General 7J-2 7J-2 Applications 7J-2 Differential measurements **Angular measurements** 7J-3 Multiaxis configurations 7J-4 **Three-Axis System** 7J-5 Five-Axis System Using Agilent 10719A and Agilent 10721A **Interferometers** 7J-7 7J-7 Optical schematic **Special Considerations** 7J-10 Configuration and beam locations 7J-10 Beam diameter 7J-10 Receiver considerations 7J-10 Spacing to beam-directing optic 7J-11 Input and output apertures 7J-12 Direction sense Deadpath 7J-12 Reference and measurement mirror requirements 7J-13 Mounting 7J-14 Vibration considerations 7J-14 Interferometer mounting system (user-supplied) 7J-14

xii User's Manual

Installation 7J-17 Pre-installation checklist 7J-17 Receivers 7J-17 Alignment 7J-18 Alignment aid 7J-18 Alignment procedure 7J-18 Operation 7J-21 Reset considerations 7J-21 Deadpath compensation considerations 7J-21 Specifications and Characteristics 7J-21 Agilent 10719A One-Axis Differential Interferometer Specifications 7J-22
Receivers 7J-17 Alignment 7J-18 Alignment aid 7J-18 Alignment procedure 7J-18 Operation 7J-21 Reset considerations 7J-21 Deadpath compensation considerations 7J-21 Specifications and Characteristics 7J-21 Agilent 10719A One-Axis Differential Interferometer
Alignment 7J-18 Alignment aid 7J-18 Alignment procedure 7J-18 Operation 7J-21 Reset considerations 7J-21 Deadpath compensation considerations 7J-21 Specifications and Characteristics 7J-21 Agilent 10719A One-Axis Differential Interferometer
Alignment aid 7J-18 Alignment procedure 7J-18 Operation 7J-21 Reset considerations 7J-21 Deadpath compensation considerations 7J-21 Specifications and Characteristics 7J-21 Agilent 10719A One-Axis Differential Interferometer
Alignment procedure 7J-18 Operation 7J-21 Reset considerations 7J-21 Deadpath compensation considerations 7J-21 Specifications and Characteristics 7J-21 Agilent 10719A One-Axis Differential Interferometer
Alignment procedure 7J-18 Operation 7J-21 Reset considerations 7J-21 Deadpath compensation considerations 7J-21 Specifications and Characteristics 7J-21 Agilent 10719A One-Axis Differential Interferometer
Operation 7J-21 Reset considerations 7J-21 Deadpath compensation considerations 7J-21 Specifications and Characteristics 7J-21 Agilent 10719A One-Axis Differential Interferometer
Reset considerations 7J-21 Deadpath compensation considerations 7J-21 Specifications and Characteristics 7J-21 Agilent 10719A One-Axis Differential Interferometer
Specifications and Characteristics 7J-21 Agilent 10719A One-Axis Differential Interferometer
Specifications and Characteristics 7J-21 Agilent 10719A One-Axis Differential Interferometer
Agilent 10719A One-Axis Differential Interferometer
S Comments of the comments of
οριαπιατίστο 13-ωω
•
7K Agilent 10721A Two-Axis Differential
Interferometer
Description 7K-2
General 7K-2
Applications 7K-2
Differential measurements 7K-2
Angular measurements 7K-3
Multiaxis configurations 7K-4
Optical schematic 7K-5
Special Considerations 7K-7
Laser beam power consideration 7K-7
Configuration and beam locations 7K-7
Beam diameter 7K-7
Receiver considerations 7K-7
Spacing to beam-directing optic 7K-9
Input and output apertures 7K-9
Direction sense 7K-9
Deadwards 7V 10
Deadpath 7K-10
•
Reference and measurement mirror requirements 7K-10
Reference and measurement mirror requirements 7K-10
Reference and measurement mirror requirements 7K-10 Mounting 7K-11 Vibration isolation 7K-11
Reference and measurement mirror requirements 7K-10 Mounting 7K-11 Vibration isolation 7K-11
Reference and measurement mirror requirements 7K-10 Mounting 7K-11 Vibration isolation 7K-11 Interferometer mounting system (user-supplied) 7K-11
Reference and measurement mirror requirements 7K-10 Mounting 7K-11 Vibration isolation 7K-11 Interferometer mounting system (user-supplied) 7K-11 Designing the mounting system 7K-12

User's Manual xiii

Alignment 7K-15 Alignment aid 7K-15 Alignment procedure 7K-15 Operation 7K-18 Reset considerations 7K-18 Deadpath compensation considerations 7K-18 **Specifications and Characteristics** 7K-19 Agilent 10721A Two-Axis Differential Interferometer Specifications 7K-19 **7**L Reserved for later user 7L-1 **7M** Reserved for later user 7M-17N Agilent 10735A, 10736A, and 10736A-001 Three-Axis **Interferometers** Description 7N-2 **Applications** 7N-5 7N-5 General X-Y stage 7N-6 **Optical Schematics** 7N-8 **Special Considerations** 7N-9 Laser beam power consideration 7N-9 9-mm laser beam considerations 7N-9 Orientation 7N-9 Mounting 7N-10 General 7N-10 Installation 7N-15 Pre-installation checklist 7N-15 Procedure 7N-16 Alignment 7N-16 Laser beam alignment 7N-17 7N-17 Objective Procedure 7N-17 **Operation** 7N-20 Measurements 7N-20 7N-20 Displacement Pitch 7N-20 Yaw 7N-21 Error 7N-21

xiv User's Manual

General 7N-21 Agilent 10736A-001 Interferometer — Bent Axis

7N-21

Specifications and Characteristics 7N-22

Agilent 10735A Three-Axis Interferometer Specifications 7N-22

Agilent 10736A Three-Axis Interferometer and Agilent 10736A-001 Three-axis Interferometer with Beam Bender Specifications 7N-24

70 Agilent 10737L and 10737R Compact Three-Axis Intefereometers

Description 70-2

Applications 70-6

General 70-6

X-Y Stage 70-6

Optical Schematics 70-7

Special Considerations 70-9

Laser beam power consideration 70-9

Orientation 70-9

Mounting 70-12

Adjustable mounts 70-12

Fasteners 70-12

Installation and Alignment 70-13

Summary 70-13

General 70-13

Tools and Equipment Required or Recommended 70-13

Procedure 70-16

Planning the measurement setup 70-16

Initial installation and setup 70-16

Installing and aligning an interferometer 70-17

Removing the receiver assembly 70-17

Removing the high stability adapter (reference

mirror) 70-18

Aligning the measurement beam path 70-19

Aligning the reference beam path 70-21

Comparing beam path alignments 70-22

Operation 70-23

Measurements 70-23

Displacement 23

Pitch 70-23

Yaw 70-23

User's Manual xv

	Error 70-23
	Specifications and Characteristics 70-24
	Agilent 10737L/R Compact Three-Axis Interferometer Specifications 70-25
7P	Reserved for later user 7P-1
7Q	Reserved for later user 7Q-1
7R	Reserved for later user 7R-1
7S	Reserved for later user 7S-1
7T	Reserved for later user 7T-1
7U	Reserved for later user 7U-1
7V	Agilent 10770A Angular Interferometer with Agilent 10771A Angular Reflector
	Description 7V-2 Optical schematic 7V-2 Installation and Alignment 7V-4 General considerations 7V-4 Alignment target 7V-4 Alignment procedure 7V-4 Autoreflection Method 7V-5 Moving Dot Method 7V-6 Operation 7V-8 Specifications 7V-8 Agilent 10770A Angular Inteferometer Specifications 7V-9 Agilent 10771A Angular Reflector Specifications 7V-10
7W	Reserved for later user 7W-1
7X	Reserved for later user 7X-1
7 Y	Agilent 10774A Short Range Straightness Optics and Agilent 10775A Long Range Straightness Optics

xvi User's Manual

Introduction 7Y-2
Squareness and and Parallelism 7Y-3
Principles of Operation 7Y-4
Installation and Alignment 7Y-6
Pre-installation checklist 7Y-6
Alignment targets 7Y-6
General considerations 7Y-6
Principal alignment steps 7Y-9
Alignment procedures 7Y-10
Autoreflection method 7Y-12
Gunsight method 7Y-13
Slope removal 7Y-15
Operation 7Y-17
Accuracy considerations 7Y-17
Specifications 7Y-17
Agilent 10774A Short Range Straightness Optics and
Agilent 10775A Long Range Straightness Optics Specifications 7Y-18
Receivers
General 8-2
Comparison of Agilent Laser Receiver Families 8-2
Agilent 10780C and Agilent 10780F Receivers 8-5
Description 8-5
General 8-5
Lens and polarizer 8-5
Photodiode 8-6
Agilent 5519A/B Laser Head Receiver 8-7
Special considerations 8-7
Cables 8-7
Effects of motion and orientation 8-8
Mounting 8-9
Offset aperture 8-9
Agilent 10780F Remote Receiver sensor head 8-9 Installation 8-9
Cable connection 8-9
Fasteners 8-10
Clearance for laser beam 8-10
Alignment 8-12
General 8-12
Alignment target 8-12
Principle 8-12

User's Manual xvii

Operation 8-16
Specifications and characteristics 8-16
Sensitivity 8-16
Agilent 10780C Receiver Specifications 8-17
Agilent 10780F Remote Receiver Specifications 8-18
Agilent E1708A Remote Dynamic Receiver 8-19
Description 8-19
Principles of operation 8-20
Installation 8-21
Cables for electronics 8-22
Agilent E1705A Fiber-Optic Cable considerations 8-23
Alignment and adjustments 8-25
Operation 8-26
Specifications and characteristics 8-26
Agilent E1708A Remote Dynamic Receiver Specifications 8-27
Agilent E1709A Remote High-Performance Receiver 8-28
Description 8-28
Key definitions and concepts 8-29
Features 8-33
Agilent E1706A Remote Sensor 8-33
Application characteristics 8-33
Agilent E1709A relationship to Agilent E1708A 8-34
Technical enhancements 8-34
Adjustment and additional alignment requirements 8-34 Retrofit issues 8-34
Specifications and characteristics 8-35
Agilent E1709A Remote High-Performance Receiver Specifications 8-36
Accessories
General 9-2
Adjustable Mounting Hardware 9-2
Adjustable mounts 9-2
Height adjuster and post, and base 9-4
Specifications 9-4
Agilent 10710B/10711A Adjustable Mount Specifications 9-5
Agilent 10785A Height Adjuster/Post and the Agilent 10784A
Base Specifications 9-7 Cables 9-8
Agilent 10790A/B/C Receiver Cable 9-11
Agilent 10790A/B/C Receiver Cable 9-11 Agilent 10880A/B/C Receiver Cable 9-12
Agricul 10000A/D/C Receiver Cable 3-12

xviii User's Manual

Agilent 10881A/B/C Laser Head Cable 9-13
Agilent 10881D/E/F Laser Head Cable 9-14
Agilent 10882A/B/C Laser Head Cable 9-15
Agilent N1250A/B High Performance Receiver Cable 9-16
Agilent N1251A/B High Performance Laser Head Cable 9-17
Alignment Targets and Aids 9-18
Agilent 10753B Laser Tripod 9-20
Agilent 10759A Footspacing Kit 9-20
Optics 9-20
Vacuum applications 9-21
Agilent 10724A Plane Mirror Reflector 9-21
Agilent 10724A Plane Mirror Reflector Mounting 9-22
Agilent 10724A Plane Mirror Specifications 9-24
Agilent 10728A Plane Mirror 9-25
Agilent 10728A Plane Mirror Specifications 9-25
Agilent 10772A Turning Mirror 9-26
Agilent 10772A Turning Mirror Specifications 9-27
Agilent 10773A Flatness Mirror 9-27
Agilent 10773A Flatness Mirror Specifications 9-28
Agilent 10776A Straightness Accessory Kit 9-29
Agilent 10776-67001 Straightness Retroreflector Specifications 9-30
Agilent 10777A Optical Square 9-31
Agilent 10777A Optical Square Specifications 9-32
Agilent N1203C/04C/07C Beam Manipulator Accessories
9-33
Adjustment tools 9-33
Adjustment tool kit (Agilent N1206T) 9-33
Customer-supplied hardware 9-33
Agilent 10884A Power Supply 9-34
Agilent 10881A/B/C Laser Head Cable 9-34
Agilent 10884A and Agilent 10881A/B/C Installation and Use 9-35
Agilent 10884A Power Supply Specifications and
Characteristics 9-36
Maintenance
General 10-2
Procedures for Cleaning Optics 10-2
Agilent Receivers 10-3
Measurement optics and beam-directing optics 10-3
Lens tissue 10-4

User's Manual xix

Maintenance Procedures 10-7 Before and After Service Product Safety Check 10-7 11 Troubleshooting Introduction 11-2 Troubleshooting Assumptions 11-3 Electrostatic Discharge (ESD) 11-4 Required Test Equipment 11-4 Troubleshooting Information 11-5 Laser Head troubleshooting 11-6 Agilent 5517A/B/C/D Laser Head 11-6 Agilent 5519A/B Laser Head 11-8 Receiver troubleshooting 11-8 Receiver troubleshooting 11-8 Agilent 10780C, 10780F, E1708A, E1709A Receiver 11-8 Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Introduction 11-2 Troubleshooting Assumptions 11-3 Electrostatic Discharge (ESD) 11-4 Required Test Equipment 11-4 Troubleshooting Information 11-5 Laser Head troubleshooting 11-6 Agilent 5517A/B/C/D Laser Head 11-6 Agilent 5519A/B Laser Head 11-8 Receiver troubleshooting 11-8 Agilent 10780C, 10780F, E1708A, E1709A Receiver 11-8 Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Introduction 11-2 Troubleshooting Assumptions 11-3 Electrostatic Discharge (ESD) 11-4 Required Test Equipment 11-4 Troubleshooting Information 11-5 Laser Head troubleshooting 11-6 Agilent 5517A/B/C/D Laser Head 11-6 Agilent 5519A/B Laser Head 11-8 Receiver troubleshooting 11-8 Agilent 10780C, 10780F, E1708A, E1709A Receiver 11-8 Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Troubleshooting Assumptions 11-3 Electrostatic Discharge (ESD) 11-4 Required Test Equipment 11-4 Troubleshooting Information 11-5 Laser Head troubleshooting 11-6 Agilent 5517A/B/C/D Laser Head 11-6 Agilent 5519A/B Laser Head 11-8 Receiver troubleshooting 11-8 Agilent 10780C, 10780F, E1708A, E1709A Receiver 11-8 Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Electrostatic Discharge (ESD) 11-4 Required Test Equipment 11-4 Troubleshooting Information 11-5 Laser Head troubleshooting 11-6 Agilent 5517A/B/C/D Laser Head 11-6 Agilent 5519A/B Laser Head 11-8 Receiver troubleshooting 11-8 Agilent 10780C, 10780F, E1708A, E1709A Receiver 11-8 Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Required Test Equipment 11-4 Troubleshooting Information 11-5 Laser Head troubleshooting 11-6 Agilent 5517A/B/C/D Laser Head 11-6 Agilent 5519A/B Laser Head 11-8 Receiver troubleshooting 11-8 Agilent 10780C, 10780F, E1708A, E1709A Receiver 11-8 Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Troubleshooting Information 11-5 Laser Head troubleshooting 11-6 Agilent 5517A/B/C/D Laser Head 11-6 Agilent 5519A/B Laser Head 11-8 Receiver troubleshooting 11-8 Agilent 10780C, 10780F, E1708A, E1709A Receiver 11-8 Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Laser Head troubleshooting 11-6 Agilent 5517A/B/C/D Laser Head 11-6 Agilent 5519A/B Laser Head 11-8 Receiver troubleshooting 11-8 Agilent 10780C, 10780F, E1708A, E1709A Receiver 11-8 Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Agilent 5517A/B/C/D Laser Head 11-6 Agilent 5519A/B Laser Head 11-8 Receiver troubleshooting 11-8 Agilent 10780C, 10780F, E1708A, E1709A Receiver 11-8 Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Agilent 5519A/B Laser Head 11-8 Receiver troubleshooting 11-8 Agilent 10780C, 10780F, E1708A, E1709A Receiver 11-8 Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Receiver troubleshooting 11-8 Agilent 10780C, 10780F, E1708A, E1709A Receiver 11-8 Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Agilent 10780C, 10780F, E1708A, E1709A Receiver 11-8 Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Agilent 5519A/B Laser Head internal receiver 11-12 Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Optical device troubleshooting 11-12 Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Agilent 10717A Wavelength Tracker troubleshooting 11-12 Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Before and After Service Product Safety Check 11-15 12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
12 Unpacking and Incoming Inspection Introduction 12-2 Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Unpacking and Incoming Inspection 12-2 Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Warranty Claims 12-2 13 Packaging for Storage or Shipment Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Laser Tube 13-2 Tagging for Service 13-2 Original Packaging 13-2
Tagging for Service 13-2 Original Packaging 13-2
Original Packaging 13-2
Other Packaging 13-2
14 Principles of Operation
Introduction 14-2
Measurement Technique 14-3
Introduction 14-3
Creating the two-frequency laser beam 14-4
Using the two-frequency laser beam at the interferometer
Using the two-frequency laser beam at the interferometer 14-4 Doppler frequency shifting 14-5

xx User's Manual

Basic Measurement System 14-5 **Basic Agilent Laser Measurement System Components** 14-6 Laser head 14-7 **System optics** 14-7 Receiver 14-8 **Environment sensors** 14-8 **Accuracy and Repeatability** Introduction 15-2 The Components of System Accuracy and Repeatability **15-2** Laser wavelength 15-4 **Electronics** error 15-4 **Optics nonlinearity** 15-7 Atmospheric compensation 15-8 Material thermal expansion 15-11 Optics thermal drift 15-12 Deadpath error 15-16 15-22 Abbé error 15-24 Cosine error **Determining System Accuracy and Repeatability** 15-25 Examples — Determining System Accuracy and Repeatability **15-26** Precision Coordinate Measuring Machine (CMM) example 15-27 Laser wavelength error Atmospheric compensation 15-29 Material thermal expansion 15-30 Deadpath error 15-31 **Electronics error** 15-31 **Optics** nonlinearity 15-31 Optics thermal drift 15-31 15-31 Abbé error Cosine error 15-32 CMM system accuracy calculation CMM system repeatability calculation IC Wafer Stepper example 15-35 Laser wavelength error 15-37 15-37 Atmospheric compensation Material thermal expansion 15-38 Deadpath error 15-38 **Electronics error** 15-38

User's Manual xxi

Optics nonlinearity 15-38
Optics thermal drift 15-38
Abbé error 15-39
Cosine error 15-39
IC Stepper System accuracy calculation 15-39
IC Stepper system repeatability calculations 15-42
Achieving Optimum System Accuracy and
Repeatability 15-44
Minimizing environmental effects 15-44
Laser compensation capability 15-46
Manual compensation 15-47
Automatic compensation 15-47
Sensor placement 15-48
Agilent 10717A Wavelength Tracker 15-48
Agilent 10751C/D Air Sensor 15-48
Agilent 10757D/E/F Material Temperature Sensor 15-4
WOL compensation method comparison 15-49
Non-Uniform Environments 15-50
Changing temperature conditions 15-50
Air turbulence 15-50
Reducing air turbulence 15-51
Avoiding thermal gradients 15-51
Optics installation effects 15-51
Minimizing deadpath errors 15-52
Compensation for deadpath errors 15-54
Minimizing Abbé error 15-56
References 15-58
We do all off date and all a
Wavelength-of-Light Compensation
Introduction 16-2
"Absolute" Pressure Versus "Barometric" Pressure 16-
Calculation of Exact Wavelength-of-Light (WOL)
Compensation Factor 16-3

xxii User's Manual

Wavelength-of-Light (WOL) Compensation Tables

16-5

17 Material Expansion Coefficients

Linear Thermal Expansion Coefficients of Metals and Alloys 17-2

18 Glossary

18-2

Index

User's Manual xxiii

Contents

xxiv User's Manual

List of Figures

Figure 2-1.	Typical single-axis Agilent Laser Interferometer Positioning System 2-3
Figure 3-1.	Possible component motions 3-3
Figure 3-2.	Protective covers for optics and laser beam 3-12
Figure 3-3.	Collapsible spiral cover for movable retroreflector 3-13
Figure 3-4.	Laser position transducer mounting 3-16
Figure 3-5.	Direction sense - fringe counts increase as optics move apart 18
Figure 3-6.	Introducing an offset into the laser beam 3-24
Figure 3-7.	Single-axis system for servo-track writing 3-30
Figure 3-8.	Multiaxis system for a precision x-y stage 3-31
Figure 3-9.	Four-axis configuration 3-33
Figure 3-10.	Two-axis plane mirror interferometer configuration 3-34
Figure 3-11.	X-Y stage installed in a vacuum chamber 3-34
Figure 3-12.	Two-axis system using two Agilent 10715A differential interferometers 3-36
Figure 3-13.	Yaw measurement of x-y stage using discrete plane mirror interferometers 3-36
Figure 3-14.	Optical Method for Yaw Measurement 3-38
Figure 3-15.	Optical Method for Yaw Measurement 3-38
Figure 3-16.	Agilent 5517C-009 Mounting Location - Dimensions 3-41
Figure 4-1.	Agilent 10710B and Agilent 10711A adjustable mounts 4-6
Figure 4-2.	Horizontal plane mounting using the Agilent 10710B adjustable mount 4-7
Figure 4-3.	Vertical plane mounting using the Agilent 10710B adjustable mount 4-8
Figure 4-4.	Horizontal plane mounting using the Agilent 10711A adjustable mount 4-9
Figure 4-5.	Vertical Plane Mounting Using the Agilent 10711A Adjustable Mount 4-9
Figure 4-6.	Optimum alignment 4-10
Figure 4-7.	Effect of optics misalignment 4-11
Figure 4-8.	Effects of angular misalignment to the direction of travel 4-12
Figure 4-9.	Using reference surfaces to align mirror 4-15
-	Measurement beam dot movement 4-17
Figure 4-11.	Results of reflector movement 4-18

User's Manual xxv

Figure 4-12.	Linear and single-beam interferometer alignment aids 4-19
Figure 4-13.	Autoreflection alignment 4-20
Figure 4-14.	Overlapping dot alignment 4-25
Figure 5-1.	Laser position Transducer mounting 5-8
Figure 5-2.	Agilent 5517A Laser Head 5-11
Figure 5-3.	Agilent 5517A Laser Head dimensions 5-13
Figure 5-4.	Agilent 5517B Laser Head 5-15
Figure 5-5.	Agilent 5517B Laser Head dimensions 5-17
Figure 5-6.	Agilent 5517C Laser Head 5-20
Figure 5-7A.	Agilent 5517C Laser Head, (Standard and 5517C-003) dimensions 5-21
Figure 5-7B.	Agilent 5517C-009 Laser Head dimensions 5-22
Figure 5-8.	Agilent 5517D Laser Head 5-25
Figure 5-9.	Agilent 5517D Laser Head dimensions 5-26
Figure 5-10.	Agilent 5519A/B Laser Head 5-27
Figure 5-11.	Agilent 5519A/B Laser Head Block Diagram 5-31
Figure 5-12.	Agilent 5519A/B Laser Head dimensions 5-33
Figure 6-1.	Agilent 10567A Dual Beam Beam-Splitter 6-5
Figure 6-2.	Agilent 10567A Dual Beam Beam-Splitter — laser beam path 6-5
Figure 6-3.	Agilent 10567A Dual Beam Beam-Splitter — dimensions 6-6
Figure 6-4.	Agilent 10700A 33% Beam Splitter and Agilent 10701A 50% Beam Splitter 6-7
Figure 6-5.	Agilent 10700A 33% Beam Splitter — dimensions 6-8
Figure 6-6.	Agilent 10701A 50% Beam Splitter — dimensions 6-9
Figure 6-7.	Agilent 10707A Beam Bender 6-10
Figure 6-8.	Agilent 10707A Beam Bender — dimensions 6-11
Figure 6-9.	Agilent 10725A 9mm Laser Beam Splitter — dimensions 6-13
Figure 6-10.	Agilent 10726A 9mm Laser Beam Bender — dimensions 6-13
Figure 6-11.	Agilent precision beam manipulators 6-15
Figure 6-12.	Agilent N1203C/N1204C/N1207C beam manipulator dimensions 6-23
Figure 7-1.	Effect of beam-directing optics on laser beam polarization orientations 7-8
Figure 7A-1.	Agilent 10702A Linear Interferometer Agilent 10702A-001 Linear Interferometer with Windows 7A-3
Figure 7A-2.	Agilent 10702A-001 Linear Interferometer with Windows 7A-5

xxvi User's Manual

Figure 7A-3. Three-axis machine tool Installation 7A-6 Figure 7A-4. Agilent 10766A Linear Interferometer and Agilent 10767A Linear Retroreflector Figure 7A-5. Agilent 10722A Plane Mirror Converter 7A-7 Figure 7A-6. Linear interferometer laser beam path 7A-8 Figure 7A-7. Differential measurements with the Agilent 10702A 7A-9 Figure 7A-8. Agilent 10702A Linear Interferometer dimensions 7A-14 Figure 7A-9. Agilent 10702A-001 Linear Interferometer with Windows dimensions 7A-15 Figure 7A-10. Agilent 10703A Retroreflector — dimensions Figure 7A-11. Agilent 10713B 1-Inch Cube Corner, no housing dimensions 7A-16 Figure 7A-12. Agilent 10766A Linear Interferometer dimensions 7A-17 Figure 7A-13. Agilent 10767A Linear Retroreflector — 7A-18 dimensions Figure 7B-1. Agilent 10705A Single Beam Interferometer and Agilent 10704A Retroreflector 7B-2 Figure 7B-2. Single Beam Interferometer — laser beam path Figure 7B-3. Agilent 10705A Single Beam Interferometer dimensions 7B-8 Figure 7B-4. Agilent 10704A Retroreflector — dimensions Figure 7B-5. Agilent 10713C 1/2-Inch Cube Corner, no housing dimensions 7B-9 Figure 7B-6. Agilent 10713D 1/4-Inch Cube Corner, no housing dimensions 7B-10 Figure 7C-1. Agilent 10706A Plane Mirror Interferometer 7C-3 Figure 7C-2. X-Y Stage measurement with Agilent 10706A Plane Mirror Interferometer 7C-3 Figure 7C-3. Plane mirror interferometer laser beam path 7C-5 Figure 7C-4. Differential measurements with the Agilent 10706A 7C-7 Figure 7C-5. Differential measurements with the Agilent 10706A 7C-7 Figure 7C-6. Agilent 10706A Plane Mirror Interferometer alignment 7C-8 Figure 7C-7. Agilent 10706A Interferometer — alignment aids 7C-11

User's Manual xxvii

7C-12

Figure 7C-8. Receiver and receiver alignment target

dimensions

Figure 7C-9. Agilent 10706A Plane Mirror Interferometer —

7C-17

- Figure 7C-10.Agilent 10722A Plane Mirror Converter dimensions 7C-18
- Figure 7C-11. Agilent 10723A High Stability Adapter dimensions 7C-18
- Figure 7C-12. Agilent 10724A Plane Mirror Reflector dimensions 7C-19
- Figure 7C-13. Agilent 10723A High Stability Adapter 7C-21
- Figure 7C-14. Agilent 10706A Conversion Using the Agilent 10723A 7C-21
- Figure 7D-1. Agilent 10706B High Stability Plane Mirror Interferometer 7D-3
- Figure 7D-2. Agilent 10706B High Stability Plane Mirror Interferometer, optical schematic 7D-4
- Figure 7D-3. Agilent 10706B Interferometer configurations 7D-7
- Figure 7D-4. Agilent 10706B Interferometer alignment aids 7D-8
- Figure 7D-5. Using the Agilent 10706-60202 Alignment Aid 7D-9
- Figure 7D-6. Agilent 10706B High Stability Plane Mirror Interferometer in an X-Y Stage Application 7D-13
- Figure 7D-7. Agilent 10706B Plane Mirror Interferometer dimensions 7D-20
- Figure 7G-1. Agilent 10715A Differential Interferometer 7G-3
- Figure 7G-2. Agilent 10715A Differential Interferometer laser beam path 7G-4
- Figure 7G-3. Agilent 10715A Standard Configuration 7G-6
- Figure 7G-4. Agilent 10715A-001 Turned Configuration 7G-6
- Figure 7G-5. Beam locations for standard Agilent 10715A Differential Interferometer 7G-8
- Figure 7G-6. Beam locations for Agilent 10715A-001 Turned Configuration 7G-9
- Figure 7G-7. Agilent 10715A Interferometer (reference mirror) 7G-10
- Figure 7G-8. Agilent 10715A with gage block in position 7G-11
- Figure 7G-9. Differential interferometer as viewed from plane mirrors 7G-12
- Figure 7G-10.Agilent 10715A with alignment aid attached over measurement beam 7G-13
- Figure 7G-11.Differential interferometer as viewed from plane mirrors with measurement beams aligned 7G-13
- Figure 7G-12. Alignment aid attached over reference beam 7G-14
- Figure 7G-13.Differential interferometer as viewed from plane mirrors with proper alignment 7G-15
- Figure 7H-1. Agilent 10716A High Resolution Interferometer 7H-3

xxviii User's Manual

- Figure 7H-2. Agilent 10716A High Resolution Interferometer, optical schematic 7H-4
- Figure 7H-3. Beam Locations for standard Agilent 10716A Interferometer 7H-6
- Figure 7H-4. Beam Locations for Agilent 10716A-001 Turned Configuration 7H-7
- Figure 7H-5. Alignment Aids for the Agilent 10716A Interferometer 7H-8
- Figure 7H-6. Agilent 10716A with gage block attached 7H-10
- Figure 7H-7. Agilent 10716A with alignment aid attached over measurement beam 7H-10
- Figure 7H-8. Using the Agilent 10706-60202 Alignment Aid 7H-12
- Figure 7H-9. Agilent 10716A High Resolution Interferometer (and Agilent 10716A-001 Turned Configuration) 7H-14
- Figure 7I-1. Agilent 10717A Wavelength Tracker 7I-2
- Figure 7I-2. Agilent 10717A Wavelength Tracker laser beam path 7I-3
- Figure 7I-3. Two-axis differential interferometer with wavelength tracker 7I-5
- Figure 7I-4. Wavelength tracker mounting hardware 7I-9
- Figure 7I-5. Agilent 10717A Wavelength Tracker adjustment hardware 7I-10
- Figure 7I-6. Installation of alignment aid 7I-12
- Figure 7I-7. Agilent 10717A Wavelength Tracker dimensions 7I-15
- Figure 7J-1. Agilent 10719A One-axis Differential Interferometer 7J-3
- Figure 7J-2. Agilent 10719A Interferometer Measurements 7J-4
- Figure 7J-3. Three axes with Agilent 10719A and Agilent 10721A interferometers 7J-6
- Figure 7J-4. Five-axis system with Agilent 10719A and Agilent 10721A interferometers 7J-8
- Figure 7J-5. Agilent 10719A One-Axis Differential Interferometer optical schematic 7J-9
- Figure 7J-6. Agilent 10719A Interferometer Reference and Measurement beams 7J-11
- Figure 7J-7. Agilent 10719 One-Axis Differential Interferometer dimensions 7J-23
- Figure 7K-1. Agilent 10721A Two-Axis Differential Interferometer 7K-3
- Figure 7K-2. Agilent 10721A Two-Axis Differential Interferometer measurements 7K-4
- Figure 7K-3. Agilent 10721A Two-Axis Differential Interferometer laser beam path 7K-6

User's Manual xxix

- Figure 7K-4. Agilent 10721A Two-Axis Differential Interferometer Reference and Measurement beams 7K-8
- Figure 7K-5. Agilent 10721A Two-Axis Differential Interferometer dimensions 7K-20
- Figure 7N-1. Agilent 10735A Three-Axis Interferometer 7N-3
- Figure 7N-2. Agilent 10736A Three-Axis Interferometer 7N-4
- Figure 7N-3. Agilent 10736A-001 Three-Axis Interferometer 7N-5
- Figure 7N-4. Measuring Using Agilent 10735A and Agilent 10736A-001 Interferometers 7N-6
- Figure 7N-5A. Agilent Three-Axis interferometers beam paths 7N-7
- Figure 7N-5B.Agilent Three-Axis Interferometers beam paths (continued) 7N-8
- Figure 7N-6. Three-Axis interferometers beam patterns 7N-11
- Figure 7N-7. Three-Axis interferometer mounting 7N-12
- Figure 7N-8. Agilent 10735A Three-Axis Interferometer dimensions 7N-23
- Figure 7N-9. Agilent 10736A Three-Axis Interferometer dimensions 7N-25
- Figure 7N-10.Agilent 10736A Three-Axis Interferometer with Beam Bender dimensions 7N-26
- Figure 70-1. Agilent 10737L Compact Three-axis Interferometer 70-3
- Figure 7O-2. Agilent 10737L Compact Three-Axis Interferometer 7O-4
- Figure 70-3. Agilent 10737R Compact Three-Axis Interferometer 70-5
- Figure 70-4. Measurement using two Agilent 10737R interferometers 70-7
- Figure 70-5. Agilent 10737L/R Compact Three-Axis interferometers beam paths 70-8
- Figure 7O-6A.Agilent 10737L Interferometer beam patterns 7O-10
- Figure 70-6B.Agilent 10737R Interferometer—beam patterns 70-11
- Figure 70-7. Agilent 10737L/R interferometers—alignment aids 70-15
- Figure 70-8. Agilent 10737L Compact Three-Axis Interferometer with Agilent 10706-60001 Alignment Aid 70-18
- Figure 7O-9. Agilent 10737L Compact Three-Axis Interferometer return beam pattern 7O-20
- Figure 7O-10.Agilent 10737L Compact Three-Axis Interferometer with 10706-60202 Alignment Aid 7O-21
- Figure 7O-11. Agilent 10737L/R Compact Three-Axis Interferometer dimensions 7O-26

xxx User's Manual

Figure 7V-1	. Agilent 10770A Angular Interferometer and Agilent 10771A Angular Reflector 7V-2
Figure 7V-2	. Angular optics — laser beam paths 7V-3
Figure 7V-3	. Measurement beam dots movement 7V-7
Figure 7V-4	. Agilent 10770A Angular Interferometer 7V-9
-	. Agilent 10771A Angular Reflector 7V-10
Figure 7Y-1	. Straightness optics 7Y-2
Figure 7Y-2	. Straightness optics — beam paths 7Y-5
Figure 7Y-3	. Alignment Targets for use with straightness
	interferometers 7Y-6
Figure 7Y-4	. Single axis system 7Y-7
Figure 7Y-5	. One linear and one straightness axis 7Y-8
Figure 7Y-6	. One linear and one straightness axis 7Y-9
Figure 7Y-7	. Reflected semicircular beams 7Y-11
Figure 7Y-8	. Agilent 10774A or Agilent 10775A Interferometer scribe line 7Y-13
Figure 7Y-9	. Initial Positioning of Reflector 7Y-14
Figure 7Y-1	0. Slope Error 7Y-15
Figure 7Y-1	1. Manual Slope Reduction 7Y-16
Figure 7Y-1	2. Agilent 10774A Short Range Straightness optics and Agilent 10775A Long Range Straightness optics 7Y-19
Figure 8-1.	Agilent 10780C Receiver and Agilent 10780F Remote Receiver 8-6
Figure 8-2.	Agilent 10780C and Agilent 10780F Receiver beam clearances and alignment targets 8-11
Figure 8-3.	
Figure 8-4.	Effects of Angular Misalignment to the Direction of Travel 8-14
Figure 8-5.	Agilent 10780C Receiver — dimensions 8-17
Figure 8-6.	Agilent 10780F Remote Receiver — dimensions 8-18
Figure 8-7.	Agilent E1708A Remote Dynamic Receiver 8-20
Figure 8-8.	Agilent E1708A Receiver—block diagram 8-21
Figure 8-9.	Grip and fiber-optic cable connector 8-23
O	Agilent E1708A receiver — dimensions 8-27
· ·	Agilent E1709A Remote High-Performance
<u> </u>	Receiver 8-28
Figure 8-12.	AC/DC light power relationship 8-29
Figure 8-13.	Agilent E1709A Receiver block diagram 8-31
Figure 8-14.	Agilent E1709A with fiber and lens assembly 8-32
Figure 8-15.	Agilent E1709A receiver — dimensions 8-37
Figure 9-1.	Agilent 10710B and Agilent 10711A adjustable mounts 9-3

User's Manual xxxi

Figure 9-2.	Agilent 10785A Height Adjuster and Post and Agilent 10784A Base 9-4
Figure 9-3.	Agilent 10710B Adjustable Mount — dimensions 9-5
Figure 9-4.	Agilent 10711A Adjustable Mount — dimensions 9-6
Figure 9-5.	Agilent 10785A Height Adjuster and Post and Agilent 10784A Base — dimensions 9-7
Figure 9-6.	Agilent 10790A/B/C Cable 9-11
Figure 9-7.	
· ·	Agilent 10881A/B/C Laser Head Cable 9-13
•	Agilent 10881D/E/F Laser Head Cable 9-14
Figure 9-9.	Agilent 10882A/B/C Laser Head Cable 9-15
-	Agilent N1250A/B High Performance Receiver Cable 9-16
Figure 9-11.	Agilent N1251A/B High Performance Laser Head Cable 9-17
Figure 9-12.	Alignment targets and aids 9-18
Figure 9-13.	Agilent 10724A Plane Mirror Reflector 9-22
Figure 9-14.	Agilent 10724A Plane Mirror Reflector — mounting requirements and installation 9-23
Figure 9-15.	Agilent 10724A Plane Mirror — dimensions 9-24
Figure 9-16.	Agilent 10728A Plane Mirror — specifications 9-25
Figure 9-17.	Agilent 10772A Turning Mirror 9-26
Figure 9-18.	Agilent 10772A Turning Mirror — dimensions 9-27
-	Agilent 10773A Flatness Mirror 9-28
-	Agilent 10773A Flatness Mirror — dimensions 9-28
-	Agilent 10776A Straightness Accessory Kit 9-29
Figure 9-22.	Agilent 10776-67001 Straightness Retroreflector — dimensions 9-30
Figure 9-23.	Agilent 10777A Optical Square 9-31
-	Agilent 10777A Optical Square — dimensions 9-32
-	Agilent N1206T Adjustment Tool Kit 9-33
_	Agilent 10884A and Agilent 10881A,B,C installation and use $$ 9-35 $$
Figure 9-27.	Agilent 10884A Power Supply — dimensions 9-36
_	Agilent 5517A/B/C/D Laser Head—troubleshooting tree 11-7
Figure 11-2.	Agilent Receiver troubleshooting tree 11-11
Figure 11-3.	Agilent 10717A Wavelength Tracker troubleshooting tree 11-14
Figure 14-1.	Typical Agilent Laser Position Transducer block diagram 14-6
Figure 15-1.	Worst-case error resulting from imperfect separation of two beam components 15-8

xxxii User's Manual

- Figure 15-2. Conventional plane mirror interferometer with unequal path lengths that result in optics thermal drift 15-12
- Figure 15-3. Agilent 10706B High Stability Plane Mirror Interferometer Beam Paths 15-14
- Figure 15-4. Comparison of optics thermal drift between Interferometers 15-15
- Figure 15-5. Deadpath caused by unequal lengths from initial point 15-17
- Figure 15-6. Optical configuration with and without deadpath 15-20
- Figure 15-7. Abbé error 15-23
- Figure 15-8. Cosine error 15-24
- Figure 15-9. Laser system configuration for a precision Coordinate Measuring Machine (CMM) 15-28
- Figure 15-10. Worst-case System Accuracy with and without Atmospheric Compensation for the CMM example 15-33
- Figure 15-11. Worst-case System Accuracy with Atmospheric Compensation for the CMM example 15-33
- Figure 15-12. Worst-case System Repeatability with and without Atmospheric Compensation for the CMM example 15-34
- Figure 15-13. Worst-case System Repeatability with Atmospheric Compensation for the CMM example 15-35
- Figure 15-14.Laser System Configuration for an Integrated Circuit Wafer Stepper 15-36
- Figure 15-15. Worst-case System Accuracy with and without Atmospheric Compensation for the Wafer Stepper example 15-40
- Figure 15-16. Worst-case System Accuracy with Atmospheric Compensation for the Wafer Stepper example 15-41
- Figure 15-17. Worst-case System Long-term Repeatability with and without Atmospheric Compensation for the Wafer Stepper example 15-42
- Figure 15-18. Worst-case System Long-term Repeatability with Atmospheric Compensation for the Wafer Stepper example 15-43
- Figure 15-19. Relative effect of errors in atmospheric and material temperature 15-45
- Figure 15-20. Air sensor orientation 15-48
- Figure 15-21. Equal path length correction 15-53
- Figure 15-22. Positioning of measurement axis to minimize Abbé error 15-57
- Figure 15-23.X-Y Stage measurement with Agilent 10706A Plane
 Mirror Interferometer 15-58

User's Manual xxxiii

Figure 18-1. Degrees of freedom (for X-Axis) 18-3

xxxiv User's Manual

List of Tables

Table 1-1.	Laser Head and Receiver Manuals 1-6
Table 3-1.	Equipment choices 3-5
Table 5-1.	Laser Heads Summary 5-2
Table 5-2.	Comparison of Agilent 5517A/B/C/D Laser Heads (Summary) 5-9
Table 6-1.	Beam-direction optics 6-3
Table 7-1.	Measurement Optics Summary 7-3
Table 7-2.	Interferometer Resolutions 7-6
Table 7G-1.	Agilent 10715A direction sense 7G-7
Table 7I-1.	Agilent 10717A direction sense 7I-6
Table 70-1.	Tools and Equipment Required or Recommended 70-14
Table 8-1.	Comparison of Agilent Laser Receiver families 8-3
Table 8-2.	Cables for use with an E1708A receiver 8-22
Table 8-3.	Fiber optic cable considerations 8-23
Table 9-1.	Adjustable mounting hardware 9-2
Table 9-2.	Summary of available laser system cables 9-8
Table 9-3.	Cables 9-9
Table 9-4.	Alignment targets and aids 9-19
Table 9-5.	Optics 9-21
Table 10-1.	Optics Shipped with or without lens tissue 10-6
Table 11-1.	Chapter content summary 11-2
Table 11-2.	Recommended test equipment 11-5
Table 11-3.	Agilent 10780C or Agilent 10780F Receiver signal chart 11-9
Table 15-1.	Error components for accuracy and long- and short-term repeatability error budgets 15-3
Table 15-2.	System measurement resolution for each interferometer 15-6
Table 15-3.	Deadpath mirror positions and values for Agilent interferometers 15-18
Table 15-4.	Laser interferometer system accuracy and repeatability error 15-25
Table 15-5.	Parameters needed to calculate each error component 15-27
Table 15-6.	System accuracy with and without atmospheric compenstation 15-32
Table 15-7.	IC Stepper System Accuracy with and without Atmospheric Compenstation 15-39
Tahla 15-8	Laser system measurement accuracy comparison 15-40

User's Manual xxxv

- Table 16-1. Metric—Wide-Range (Temp = 2 to 50° C, Press = 525 to 800 mm, 50% Humidity) 16-6
- Table 16-2. Metric—Low Alt, Low Temp, Low Humidity (Temp = 5 to 13° C, Press = 720 to 800 mm, 20% Humidity) 16-7
- Table 16-3. Metric—Low Alt, Low-Mid Temp, Low Humidity (Temp = 13.5 to 21.5° C, Press = 720 to 800 mm, 20% Humidity) 16-8
- Table 16-4. Metric—Low Alt, Mid Temp, Low Humidity (Temp = 22 to 30° C, Press = 720 to 800 mm, 20% Humidity) 16-9
- Table 16-5. Metric—Low Alt, High-Mid Temp, Low Humidity (Temp = 30.5 to 38.5° C, Press = 720 to 800 mm, 20% Humidity) 16-10
- Table 16-6. Metric—High Alt, Low Temp, Low Humidity (Temp = 5 to 13° C, Press = 640 to 720 mm, 20% Humidity) 16-11
- Table 16-7. Metric—High Alt, Low-Mid Temp, Low Humidity (Temp = 13.5 to 21.5° C, Press = 640 to 720 mm, 20% Humidity) 16-12
- Table 16-8. Metric—High Alt, Mid Temp, Low Humidity (Temp = 22 to 30° C, Press = 640 to 720 mm, 20% Humidity) 16-13
- Table 16-9. Metric—High Alt, High-Mid Temp, Low Humidity (Temp = 30.5 to 38.5° C, Press = 640 to 720 mm, 20% Humidity) 16-14
- Table 16-10.Metric—Low Alt, Low Temp, Med Humidity (Temp = 5 to 13° C, Press = 720 to 800 mm, 50% Humidity) 15
- Table 16-11.Metric—Low Alt, Low-Mid Temp, Med Humidity (Temp = 13.5 to 21.5° C, Press = 720 to 800 mm, 50% Humidity) 16-16
- Table 16-12.Metric—Low Alt, Mid Temp, Med Humidity (Temp = 22 to 30° C, Press = 720 to 800 mm, 50% Humidity) 16-17
- Table 16-13.Metric—Low Alt, High-Mid Temp, Med Humidity (Temp = 30.5 to 38.5° C, Press = 720 to 800 mm, 50% Humidity) 16-18
- Table 16-14.Metric—High Alt, Low Temp, Med Humidity (Temp = 5 to 13° C, Press = 640 to 720 mm, 50% Humidity) 16-19
- Table 16-15.Metric—High Alt, Low-Mid Temp, Med Humidity (Temp = 13.5 to 21.5° C, Press = 640 to 720 mm, 50% Humidity) 16-20

xxxvi User's Manual

- Table 16-16.Metric—High Alt, Mid Temp, Med Humidity (Temp = 22 to 30° C, Press = 640 to 720 mm, 50% Humidity) 16-21
- Table 16-17.Metric—High Alt, High-Mid Temp, Med Humidity (Temp = 30.5 to 38.5° C, Press = 640 to 720 mm, 50% Humidity) 16-22
- Table 16-18.Metric—Low Alt, Low Temp, High Humidity (Temp = 5 to 13° C, Press = 720 to 800 mm, 80% Humidity) 16-23
- Table 16-19.Metric—Low Alt, Low-Mid Temp, High Humidity (Temp = 13.5 to 21.5° C, Press = 720 to 800 mm, 80% Humidity) 16-24
- Table 16-20.Metric—Low Alt, Mid Temp, High Humidity (Temp = 22 to 30° C, Press = 720 to 800 mm, 80% Humidity) 16-25
- Table 16-21.Metric—Low Alt, High-Mid Temp, High Humidity (Temp = 30.5 to 38.5° C, Press = 720 to 800 mm, 80% Humidity) 16-26
- Table 16-22.Metric—High Alt, Low Temp, High Humidity (Temp = 5 to 13° C, Press = 640 to 720 mm, 80% Humidity) 16-27
- Table 16-23.Metric—High Alt, Low-Mid Temp, High Humidity (Temp = 13.5 to 21.5° C, Press = 640 to 720 mm, 80% Humidity) 16-28
- Table 16-24.Metric—High Alt, Mid Temp, High Humidity (Temp = 22 to 30° C, Press = 640 to 720 mm, 80% Humidity) 16-29
- Table 16-25.Metric—High Alt, High-Mid Temp, High Humidity (Temp = 30.5 to 38.5° C, Press = 640 to 720 mm, 80% Humidity) 16-30
- Table 16-26.English—Wide Range (Temp = 40 to 120° F, Press = 20 to 31 inches, 50% Humidity) 16-31
- Table 16-27.English—Low Alt, Low Temp, Low Humidity (Temp = 40 to 56° F, Press = 27 to 31 inches, 20% Humidity) 16-32
- Table 16-28.English—Low Alt, Low-Mid Temp, Low Humidity (Temp = 57 to 73° F, Press = 27 to 31 inches, 20% Humidity) 16-33
- Table 16-29.English—Low Alt, Mid Temp, Low Humidity (Temp = 74 to 90° F, Press = 27 to 31 inches, 20% Humidity) 16-34
- Table 16-30.English—Low Alt, High-Mid Temp, Low Humidity (Temp = 91 to 107° F, Press = 27 to 31 inches, 20% Humidity) 16-35

User's Manual xxxvii

- Table 16-31.English—High Alt, Low Temp, Low Humidity (Temp = 40 to 56° F, Press = 23 to 27 inches, 20% Humidity) 16-36
- Table 16-32.English—High Alt, Low-Mid Temp, Low Humidity (Temp = 57 to 73° F, Press = 23 to 27 inches, 20% Humidity) 16-37
- Table 16-33.English—High Alt, Mid Temp, Low Humidity (Temp = 74 to 90° F, Press = 23 to 27 inches, 20% Humidity) 16-38
- Table 16-34.English—High Alt, High-Mid Temp, Low Humidity (Temp = 91 to 107° F, Press = 23 to 27 inches, 20% Humidity) 16-39
- Table 16-35.English—Low Alt, Low Temp, Med Humidity (Temp = 40 to 56° F, Press = 27 to 31 inches, 50% Humidity) 16-40
- Table 16-36.English—Low Alt, Low-Mid Temp, Med Humidity (Temp = 57 to 73° F, Press = 27 to 31 inches, 50% Humidity) 16-41
- Table 16-37.English—Low Alt, Mid Temp, Med Humidity (Temp = 74 to 90° F, Press = 27 to 31 inches, 50% Humidity) 16-42
- Table 16-38.English—Low Alt, High-Mid Temp, Med Humidity (Temp = 91 to 107° F, Press = 27 to 31 inches, 50% Humidity) 16-43
- Table 16-39.English—High Alt, Low Temp, Med Humidity (Temp = 40 to 56° F, Press = 23 to 27 inches, 50% Humidity) 16-44
- Table 16-40.English—High Alt, Low-Mid Temp, Med Humidity (Temp = 57 to 73° F, Press = 23 to 27 inches, 50% Humidity) 16-45
- Table 16-41.English—High Alt, Mid Temp, Med Humidity (Temp = 74 to 90° F, Press = 23 to 27 inches, 50% Humidity) 16-46
- Table 16-42.English—High Alt, High-Mid Temp, Med Humidity (Temp = 91 to 107° F, Press = 23 to 27 inches, 50% Humidity) 16-47
- Table 16-43.English—Low Alt, Low Temp, High Humidity (Temp = 40 to 56° F, Press = 27 to 31 inches, 80% Humidity) 16-48
- Table 16-44.English—Low Alt, Low-Mid Temp, High Humidity (Temp = 57 to 73° F, Press = 27 to 31 inches, 80% Humidity) 16-49
- Table 16-45.English—Low Alt, Mid Temp, High Humidity (Temp = 74 to 90° F, Press = 27 to 31 inches, 80% Humidity) 16-50

xxxviii User's Manual

- Table 16-46.English—Low Alt, High-Mid Temp, High Humidity (Temp = 91 to 107° F, Press = 27 to 31 inches, 80% Humidity) 16-51
- Table 16-47.English—High Alt, Low Temp, High Humidity (Temp = 40 to 56° F, Press = 23 to 27 inches, 80% Humidity) 16-52
- Table 16-48.English—High Alt, Low-Mid Temp, High Humidity (Temp = 57 to 73° F, Press = 23 to 27 inches, 80% Humidity) 16-53
- Table 16-49.English—High Alt, Mid Temp, High Humidity (Temp = 74 to 90° F, Press = 23 to 27 inches, 80% Humidity) 16-54
- Table 16-50.English—High Alt, High-Mid Temp, High Humidity (Temp = 91 to 107° F, Press = 23 to 27 inches, 80% Humidity) 16-55
- Table 17-1. Linear thermal expansison coefficients of metals and alloys 17-2
- Table 18-1. Number systems 18-5

User's Manual xxxix

Product specifications and descriptions in this document subject to change without notice. Copyright (C) 2002 Agilent Technologies Printed in U.S.A. 07/02

This is a chapter from the manual titled: Laser and Optics User's Manual For complete manual, order: Paper version: p/n 05517-90045

CD version: p/n 05517-90063

This chapter is p/n 05517-90100

xl User's Manual