LEDR DIGITAL MICROWAVE RADIOS



LEDR 400S/F, 900S/F, 1400S/F Series

Including Protected (1+1) and Space Diversity Versions

P/N 05-3627A01, Rev. C MARCH 2001



Microwave Data Systems Inc.

QUICK START GUIDE

LEDR Series radios are supplied from the factory in matched pairs and will be configured to user's specifications. There are a few steps necessary to place the pair on-the-air communicating with each other. Once this is done, system-specific parameters will need to be reviewed and changed to match your requirements. Below are the basic steps for installing the LEDR radio. For a more detailed installation procedure, please see "INITIAL STARTUP AND CONFIG-URATION" on page 24. When making cable connections, refer to Section 3.6, Rear Panel Connectors, on page 16 for a rear panel view of the radio.

1. Install and connect the antenna system to the radio

- Ensure a path study has been conducted and that the radio path is acceptable.
- Use good quality, low loss coaxial cable. Keep the feedline as short as possible.
- Preset directional antennas in the direction of desired transmission/reception.

2. Connect the data equipment to the rear panel data interface

- The data interface should be an RJ-45 connector for Fractional-T1, Fractional-E1, or E1, and DB-25 for EIA-530.
- Verify the customer premises data equipment is configured as DTE. (By default, the LEDR radio is configured as DCE.)

3. Apply DC power to the radio

- Verify that the line voltage matches the power supply input range (24 Vdc or 48 Vdc).
- The power connector is a three-pin keyed connector. The power source can be connected with either polarity. The center conductor is *not* connected.

4. Change SUPER password and set up user access

- Login to Network Management System as **SUPER**, using password **SUPER**. (See "login" on page 68.)
- Change the password using the **PASSWD** command. (See "passwd" on page 73)
- Set up required users, passwords and access levels using the USER command, as required. (See "user" on page 86)

5. Set the radio's basic configuration using front panel or Console interface

- Set the transmit/receive frequencies (TX xxx.xxx/RX xxx.xxxx) if they need to be changed from the factory settings. (See "freq" on page 58.)
- Refer to this manual for other configuration settings.

6. Verify and set as necessary the following parameters to allow data throughput and interconnection with the network.

- RF transmit and receive frequencies. (See "freq" on page 58.)
- Radio modulation type and data rate parameters. (See "modem" on page 72).
- Data interface clocking. (See "clkmode" on page 54).
- Data framing. (See "fstruct" on page 59).

The Quick Start Guide is continued on the rear cover of this manual.



TABLE OF CONTENTS

1.0 IN	ITRODUCTION	1
1.1	Product Description	······
1.2	LEDR Features	
1.3	Typical Applications	
1.4	Protected Configuration	
2.0 M	ODEL NUMBER CODES	
3.0 H/	ARDWARE INSTALLATION & BASIC INTERFACE	-
ĸ	EQUIREMENTS	
3.1	Introduction	
3.2	General Requirements	······································
	Site Selection	8
	Terrain and Signal Strength	8
	On-the-Air Test	
	A Word About Interference	
3.3	Antenna and Feedline Selection	1(
	Antennas	1
	Feedlines	1 [.]
3.4	Radio Mounting	
-	Maximizing RSSI	
	Attaching the Rack Mounting Brackets	1
3.5	Front Panel	1
	Indicators. Text Display and Navigation Keys	
	Connectors	
36	Rear Panel Connectors	1(
0.0	Connector Locations	1.
	Ground Stud	1 [.]
	Antenna/TX—RF Connector	1
	BX—RE Connector	1
	G 703/Expansion Data	1
	Ethernet	19
	FIA-530-A	
	Service Channel	
		ייןויי יי
	DC Power Input (Primary Power)	2 2
	Protected Configuration Connections	∠۲
27	Bandwidths Data Rates and Modulation Types	،
J./	Transmit Cleak Selection (Subsets Dedies Orth)	Z.
3.8	ITANSITIL CLOCK Selection (Subrate Radios Unly)	2



4.0 IN	IITIAL STARTUP AND CONFIGURATION	24
4.1	Introduction	24
4.2	STEP 1—Power up the LEDR Radios	24
4.3	STEP 2—Establish Communications with the Radio	25
4.4	STEP 3—Make Initial Login to Radio	25
4.5	STEP 4—Change the SUPER Password	26
4.6	STEP 5—Review Essential Operating Parameters	27
4.7	STEP 6—Set TCP/IP Settings to Enable SNMP and/or Telnet	
	Management (If required)	28
4.8	STEP 7—Set User Configurable Fields	28
4.9	STEP 8—Verify Radio Performance	28
4.10) STEP 9—Install the Link	28
4.11	I STEP 10—Verify the Link Performance	29
5.0 C	ONFIGURATION & CONTROL VIA THE FRONT PANEL	.29
5.1	Front Panel LCD Menu Descriptions	32
	CONSOLE	32
	Default Screen	32
	Diagnostics	32
	Front Panel	33
	G.821	33
	General	34
	IO Configuration	35
	Line Configuration	36
	Login	38
	Logout	38 20
	Network	30 20
	Performance	40
	Redundant	41
	Remote Status	42
	RF Configuration	42
6.0 C	ONFIGURATION & CONTROL VIA THE CONSOLE PORT	.43
6.1	Introduction	43
6.2	Initial Connection to the CONSOLE Port	44
6.3	NMS Commands	44
6.4	Command Detailed Descriptions	47
0.1	Introduction	47
6.5	Disabling the Front Panel Alarm LED for Unused E1 Option Ports	89
7.0 S	TANDARDIZING RADIO CONFIGURATIONS	. 90
7 1	Introduction	۵۸
7.7	Setup by TETP	
1.2	Downloading Procedure	



	Uploading Procedure	91
7.3	Setup Through the DB-9 CONSOLE Port	92
8.0 l	IPGRADING LEDR FIRMWARE	93
8 1	Introduction	93
8.2	OPTION 1: Uploading Firmware via the CONSOLE Port	94
0.2	Setup	94
	Download Procedure	94
	Verification and Reboot	95
8.3	OPTION 2: Uploading Firmware Locally by Telnet via Ethernet	95
	Setup	96
	Download Procedure	96
	Verification and Reboot	97
8.4	OPTION 3: Uploading Firmware from a Remote Server	07
	Via Ethernet	97
	Selup	97 QQ
	Verification and Reboot	
9.0 l	JSING ORDERWIRE	99
9.1	Introduction	99
9.2	Setup	99
9.3	Operation	100
9.4	Related NMS Commands	101
10.0		
10.0	USING THE SERVICE CHANNEL	101
10.0	USING THE SERVICE CHANNEL	101
10.0	1 Concept	101
10.0 10 10	1 Concept	101 101 102
10.0 10 10 10	1 Concept	101 101 102 102
10.0 10 10 10	1 Concept 2 Setup 3 Usage 4 NMS Commands	101 101 102 102 103
10.0 10 10 10 10 11.0	1 Concept 2 Setup 3 Usage 4 NMS Commands	101 101 102 102 103 103
10.0 10 10 10 10 11.0 11.0	1 Concept 2 Setup 3 Usage 4 NMS Commands PROTECTED CONFIGURATION	101 101 102 102 103 103 103
10.0 10 10 10 10 10 11.0 11 11	USING THE SERVICE CHANNEL	101 101 102 102 103 103 103 104
10.0 10 10 10 10 11.0 11 11	1 Concept 2 Setup 3 Usage MS Commands PROTECTED CONFIGURATION Introduction Protected Operation Transmitter Failure.	101 101 102 102 103 103 103 104 105
10.0 10 10 10 10 10 11.0 11 11	1 Concept 2 Setup 3 Usage 4 NMS Commands PROTECTED CONFIGURATION 1 Introduction 2 Protected Operation Transmitter Failure Receiver Failure	101 101 102 102 103 103 103 104 105 105
10.0 10 10 10 10 10 11.0 11 11	1 Concept 2 Setup 3 Usage 4 NMS Commands PROTECTED CONFIGURATION 1 Introduction 2 Protected Operation Transmitter Failure Receiver Failure 3 Configuration Options	101 101 102 102 103 103 103 104 105 105 105
10.0 10 10 10 10 11.0 11 11	 USING THE SERVICE CHANNEL. Concept	101 101 102 102 103 103 103 104 105 105 105 105
10.0 10 10 10 10 10 10 11 11 11	 USING THE SERVICE CHANNEL. 1 Concept	101 101 102 102 103 103 103 105 105 105 105 106
10.0 10 10 10 10 10 10 10 10 10 10 10 10 10	 USING THE SERVICE CHANNEL. Concept	101 101 102 102 103 103 103 103 105 105 105 106 106
10.0 10 10 10 11.0 11 11 11	 USING THE SERVICE CHANNEL. 1 Concept	101 101 102 102 103 103 103 103 105 105 105 105 105 106 106 106
10.0 10 10 10 10 10 10 10 10 10 11 11 11	USING THE SERVICE CHANNEL. 1 Concept 2 Setup 3 Usage 4 NMS Commands PROTECTED CONFIGURATION 1 Introduction 2 Protected Operation Transmitter Failure Receiver Failure 3 Configuration Options 1+1 Operation—Warm or Hot Standby Symmetrical or Asymmetrical Receiver Splitters 4 PSC Rear Panel Connectors RxB. Actement	101 101 102 102 103 103 103 103 105 105 105 105 106 106 106 106
10.0 10 10 10 10 10 10 10 10 10 11 11 11	 USING THE SERVICE CHANNEL. Concept	101 101 102 102 103 103 103 103 105 105 105 105 106 106 106 106 106 106
10.0 10 10 10 10 11.0 11 11 11	 USING THE SERVICE CHANNEL. 1 Concept	101 101 102 102 103 103 103 103 105 105 105 105 106 106 106 106 107
10.0 10 10 10 10 10 10 10 10 10 10 10 10 10	USING THE SERVICE CHANNEL. 1 Concept 2 Setup 3 Usage 4 NMS Commands PROTECTED CONFIGURATION 1 Introduction 2 Protected Operation Transmitter Failure Receiver Failure 3 Configuration Options 1+1 Operation—Warm or Hot Standby Symmetrical or Asymmetrical Receiver Splitters. 4 PSC Rear Panel Connectors RxA RxB Antenna TxA TxB Protected (Data)	101 101 102 102 103 103 103 103 105 105 105 105 106 106 106 106 106 106 107 107 107
10.0 10 10 10 10 10 10 10 10 10 10 10 10 10	USING THE SERVICE CHANNEL. 1 Concept 2 Setup 3 Usage 4 NMS Commands PROTECTED CONFIGURATION 1 Introduction 2 Protected Operation Transmitter Failure Receiver Failure 3 Configuration Options 1+1 Operation—Warm or Hot Standby Symmetrical or Asymmetrical Receiver Splitters. 4 PSC Rear Panel Connectors RxA. RxB. Antenna TxA TxB Protected (Data) F1	101 101 102 102 103 103 103 103 105 105 105 105 106 106 106 106 106 107 107 107 107
10.0 10 10 10 10 10 10 10 10 10 10 10 10 10	USING THE SERVICE CHANNEL 1 Concept 2 Setup 3 Usage 4 NMS Commands PROTECTED CONFIGURATION 1 Introduction 2 Protected Operation Transmitter Failure Receiver Failure 3 Configuration Options 1+1 Operation—Warm or Hot Standby Symmetrical or Asymmetrical Receiver Splitters 4 PSC Rear Panel Connectors RxA. RxB. Antenna TxA TxB Protected (Data) E1 Ethernet	101 101 102 102 103 103 103 103 105 105 105 105 105 106 106 106 106 106 107 107 107 107 107 107



	530 (A&B)107
	EIA-530-A107
	Service Channel107
11.5	Inter-Unit Cabling for Protected Stations108
11.6	Configuration Commands for a Protected System
	Redundant Specific Parameters109
	Sample Redundant Configuration Session
	Iransmit Clock Selection (Subrate Models Only)
12.0 S	PACE DIVERSITY OPERATION112
12.1	Introduction
12.2	User Interface & Control112
12.3	Transmit Clock Selection
12.4	Inter-Unit Cabling for Space Diversity Stations
13.0 SI	PARE PARTS, UNITS AND ACCESSORIES
13.1	Spares115
13.2	Accessories116
14.0 Fr	actional-T1 INTERFACE CARD 03-3846A01
Fr	actional-E1 INTERFACE CARD 03-3846A02117
14.1	Introduction117
14.2	Fractional-T1/E1 Performance117
14.3	Configurable Parameters117
	Timeslots and Framing117
	Line Codes
	Diagnostics
	Clocking
14.4	
15.0 IN	ICREASE BANDWIDTH BY CHANGING TRANSMITTER &
15.1	Introduction
15.2	Filter Removal and Replacement122
15.3	Software Commands
16.0 B	ENCH TESTING OF RADIOS 124
10.0 D	
17.0 TE	ECHNICAL REFERENCE 125
17 1	Specifications—
Mode	els: LEDR 400S, LEDR 900S & LEDR 1400S
17.2	Specifications—
Mode	els: LEDR 400F, 900F, 1400F
17.3	Specifications-
Prote	ected Switch Chassis128
17.4	Optional Equipment (Consult factory for details)
17.5	Accessories



	17.6 I/O Connector Pinout Information	
	Orderwire—Front Panel	
129	CONSOLE Port—Front Panel	
130	Ethernet—Rear Panel	
130	EIA-530-A Data—Rear Panel	
130	G.703 Data Connectors (4)—Rear Panel	
131	Service Channel—Rear Panel	
131	Alarm—Rear Panel	
132	17.7 Watts-dBm-Volts Conversion	
	8.0 RADIO EVENT CODES	18
140	9.0 IN CASE OF DIFFICULTY	19
	19.1 FACTORY TECHNICAL ASSISTANCE	
	19.2 FACTORY REPAIRS	

Copyright Notice

This document and all software described herein are protected by copyright. Copyright 2001, Microwave Data Systems Inc. All rights reserved. Trademarks held by other companies used in this publication are acknowledged to be property of the holder.

Antenna Installation Warning



- 1. All antenna installation and servicing is to be performed by qualified technical personnel only. When servicing the antenna, or working at distances closer than those listed below, ensure the transmitter has been disabled.
- 2. Typically, the antenna connected to the transmitter is a directional (high gain) antenna, fixed-mounted on the side or top of a building, or on a tower. Depending upon the application and the gain of the antenna, the total composite power could exceed 20 to 50 watts EIRP. The antenna location should be such that only qualified technical personnel can access it, and that under normal operating conditions no other person can touch the antenna or approach within 2.68 meters of the antenna.

Antenna Gain vs. Recommended Safety Distance (LEDR 400 Series)

	Station Antenna Gain (LEDR 400 Series)			
	0–5 dBi	5–10 dBi	10–20 dBi	20–30 dBi
Minimum RF Safety Distance	0.15 meter	0.26 meter	0.85 meter	2.68 meters



Antenna Gain vs. Recommended Safety Distance (LEDR 900 Series)

	Antenna Gain (LEDR 900 Series)			
	0–5 dBi	5–10 dBi	10–20 dBi	20–30 dBi
Minimum RF Safety Distance	0.1 meter	0.17 meter	0.54 meter	1.71 meters

Antenna Gain vs. Recommended Safety Distance (LEDR 1400 Series)

	Antenna Gain (LEDR 1400 Series)			
	0–5 dBi	5–10 dBi	10–20 dBi	20–30 dBi
Minimum RF Safety Distance	0.1 meter	0.13 meter	0.42 meter	1.32 meter

Accuracy of Documentation

While every reasonable effort has been made to ensure the accuracy of this manual, product improvements may result in minor differences between the manual and the product shipped to you. If you have additional questions or need an exact specification for a product, please contact our Technical Services group using the information at the back of this guide. Microwave Data Systems reserves its right to correct any errors and omissions. Updated information may also be available on our Web site at **www.microwavedata.com**.

Distress Beacon Warning

In the U.S.A., the 406 to 406.1 MHz band is reserved for use by distress beacons. Since the LEDR 400 radio is capable of transmitting in this band, take precautions to prevent the radio from transmitting between 406 to 406.1 MHz.

RF Emissions

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules or ETSI specification ETS 300 385, as appropriate. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area may to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



1.0 INTRODUCTION

This manual is intended to help an experienced technician install, configure, and operate one of the digital radios in the MDS LEDR Series: 400S/F, 900S/F or 1400S/F. The manual begins with an overall description of product features and is followed by the steps required to mount the radio and place it into normal operation.

After installation, we suggest keeping this guide near the radio for future reference.

1.1 Product Description

The LEDR radio (Figure 1) is a full-duplex, point-to-point digital radio operating in one of three radio frequency bands and at several band-widths as summarized in Table 1.

MODEL(S)	BANDWIDTH(S)	FREQ. RANGE	INTERFACE
LEDR 400S	25/50/100/200 kHz	330-512 MHz	EIA-530
LEDR 400F	0.5/1/2 MHz	330-512 MHz	E1/G.703
LEDR 900S	25/50/100/200 kHz	800-960 MHz	EIA-530 or FT1/G.703
LEDR 900F	0.5/1/2 MHz	800–960 MHz	E1/G.703
LEDR 1400S	25/50/100/200 kHz	1350–1535 MHz	EIA-530
LEDR 1400F	0.5/1/2 MHz	1350–1535 MHz	E1/G.703

Table 1. Key LEDR Radio Characteristics

With the addition of an optional Fractional-T1 Interface card, a LEDR 900S Series radio can be connected to industry-standard G.703 T1 data interface equipment. See Page 117 for a complete description of the Fractional-T1, Fractional-E1 and Full Rate E1 options.

All LEDR Series radios are available in a protected "1+1" configuration (Figure 2). The protected configuration consists of two identical LEDR radios and a Protected Switch Chassis. The protected configuration is designed to perform automatic switchover to a secondary radio in the event of a failure in the primary unit. See *PROTECTED CONFIGURA-TION* on Page 103 for detailed information on the protected version.

In addition, the LEDR Series is available in a space-diversity configuration to allow dual receive paths to improve system availability.



1.2 LEDR Features

- General—*Common to all models*
 - Network Management via SNMPc version 1
 - Protected Operation (1+1) Compatible
 - 1.0 Watt Transmit Power
 - Space-Efficient Rack Size (1RU)
 - Rugged, Reliable Design
 - Voice Orderwire (DTMF compliant)
 - Service Channel (Data)
- Subrate Models—LEDR 400S/900S/1400S
 - 64, 128, 256, 384, 512 and 768 kbps Data Rates
 - 12 x 64 kbps Data Rate with the FT1 or FE1 Interface Board (LEDR radio with optional PCB installed)
- Fullrate Models—LEDR 400F/900F/1400F
 - 1 x E1 to 4 x E1 data rates





1.3 Typical Applications

- Point-to-point transmission applications
- Cost-effective, "thin route" applications
- Long haul telecommunications links
- Cellular backhaul
- Last-mile links
- Trunked radio links
- SCADA systems



1.4 Protected Configuration

A second configuration of the LEDR Series radios is the protected configuration in which two LEDR radios are monitored and controlled by a third unit, the Protected Switch Chassis (PSC). The PSC provides a gateway for data and radio frequency paths to the LEDR data radio transceivers. Unit performance is continuously measured and should it fall below user definable standards, the off-line LEDR radio will be placed on-line and an alarm condition generated that can be remotely monitored. Figure 2 shows a front view of the Protected version arrangements. Details on the Protected Configuration hardware and set-up can be found in Section 11.0 on page 103.



Figure 2. LEDR Digital Radio (Protected Version)



2.0 MODEL NUMBER CODES

The radio model number is printed on the serial number label affixed to the chassis. The following series of figures (Figure 3, Figure 4 and Figure 5) show the significance of each character in the model number strings. Contact the factory for specific information on optional configurations.



Figure 3. LEDR 400 Series Model Number Codes





% = Available in subrate radios

Figure 4. LEDR 900 Series Model Number Codes













3.0 HARDWARE INSTALLATION AND BASIC INTERFACE REQUIREMENTS

3.1 Introduction

Installation of the LEDR radio transceiver is not difficult, but it does require some planning to ensure optimal efficiency and reliability. There are two major installation objectives; first, obtain good radio communications between LEDR sites, and second, configure the data interface to complement your data equipment.

This section provides information to assist you in successfully completing the first phase of installation. You will find tips for selecting an appropriate site, choosing antennas and feedlines, minimizing the chance of interference, and the basics of equipment installation. This material should be reviewed before beginning the radio hardware equipment installation.

When the radio installation is successfully complete, you will need to address the data interface and operational configuration of the LEDR radio. It is likely that the radio has been configured by the factory to meet your basic data interface requirements. Please review the factory documentation accompanying your shipment for the radios current configuration.

What ever your situation, it is recommended you review the material in the rest of the manual to gain insight to additional configuration options and user functions.

3.2 General Requirements

There are four main requirements for installing the radio transceiver—a suitable installation environment, adequate and stable primary power, a good antenna system, and the correct interface between the transceiver and the external data equipment. Figure 6 shows a typical station arrangement.





Figure 6. Typical Station Arrangement

Site Selection

For a successful installation, careful thought must be given to selecting proper sites for the radios and antenna systems. Suitable sites should offer:

- An antenna location that provides an unobstructed path in the direction of the associated station
- A source of adequate and stable primary power
- Suitable entrances for antenna, interface or other required cabling
- Adequate clearance around the radio for ventilation

These requirements can be quickly determined in most cases. A possible exception is the first item—verifying that an unobstructed transmission path exists. Microwave radio signals travel primarily by line-of-sight, and obstructions between the sending and receiving stations will affect system performance.

If you are not familiar with the effects of terrain and other obstructions on radio transmission, the following discussion will provide helpful background.

Terrain and Signal Strength

A line-of-sight path between stations is highly desirable, and provides the most reliable communications link in all cases. A line-of-sight path can often be achieved by mounting each station antenna on a tower or other elevated structure that raises it to a level sufficient to clear surrounding terrain and other obstructions.



The requirement for a clear transmission path depends upon the distance to be covered by the system. If the system is to cover only a limited distance, say 5 km (3.1 miles), then some obstructions in the transmission path may be tolerable. For longer-range systems, any obstruction could compromise the performance of the system, or block transmission entirely.

The signal strength at the receiver must exceed the receiver sensitivity by an amount known as the fade margin to provide reliable operation under various conditions.

Detailed information on path planning should be reviewed before beginning an installation. Computer software is also available for this purpose that can greatly simplify the steps involved in planning a path.

Microwave Data Systems offers path analysis (for paths in the USA) as an engineering service. Contact the factory for additional information.

On-the-Air Test

If you've analyzed the proposed transmission path and feel that it is acceptable, an on-the-air test of the equipment and path should be conducted. This not only verifies the path study results, but allows you to see firsthand the factors involved at each installation site.

The test can be performed by installing a radio at each end of the proposed link and checking the Received Signal Strength Indication (RSSI) value reported at the front panel LCD screen of each radio. If adequate signal strength cannot be obtained, it may be necessary to mount the station antennas higher, use higher gain antennas, or select a different site for one or both stations.

A Word About Interference

Interference is possible in any radio system. However, since the LEDR radio is designed for use in a licensed system, interference is less likely because frequency allocations are normally coordinated with consideration given to geographic location and existing operating frequencies.

The risk of interference can be further reduced through prudent system design and configuration. Allow adequate separation between frequencies and radio systems.

C/I Curves A carrier to interference (C/I) curve can help in frequency and space coordination. The information in this curve can aid greatly in helping plan geographic locations and frequency usage for radio systems. Contact the factory for additional information on carrier to interference curves. A white paper on the subject is available on request. Ask for Publication No. 05-3638A01.



Keep the following points in mind when setting up your point-to-point system:

- 1. Systems installed in lightly populated areas are least likely to encounter interference; those in urban and suburban environments are more likely to be affected by other devices operating in the radio's frequency band and adjacent services.
- 2. Directional antennas must be used at each end of a point-to-point link. They confine the transmission and reception pattern to a comparatively narrow beam, which minimizes interference to and from stations located outside the pattern. The larger the antenna, the more focused the transmission and reception pattern and the higher the gain.
- 3. If interference is suspected from another system, it may be helpful to use antenna polarization that is opposite to the interfering system's antennas. An additional 20 dB (or more) of attenuation to interference can be achieved by using opposite antenna polarization. Refer to the antenna manufacturer's instructions for details on changing polarization.

3.3 Antenna and Feedline Selection

Antennas

The antenna system is perhaps the most crucial part of the system design. An antenna system that uses poor quality feedline, or is improperly aligned with the companion site, will result in poor performance, or no communication at all.

A directional antenna must be used for point-to-point systems to minimize interference both to and from nearby systems. In general, cylindrical or dish type antennas with a parabolic reflector must be used. Yagi or corner reflector types may be acceptable in some applications. Check government regulations for your region.

The exact style of antenna used depends on the size and layout of a system. In most cases, a directional "dish" type of antenna is used with the radio (Figure 7). Dish antennas maximize transmission efficiency and restrict the radiation pattern to the desired transmission path.





Figure 7. Typical Grid Dish Antenna

Table 2 lists common grid dish antenna sizes and their approximate gains. Note: Each antenna is designed to operate within only one frequency band.

Antenna Size Meters (feet)	400 MHz Gain	900 MHz Gain	1400 MHz Gain
1.2 meters (4 feet)	13.1 dBi	18.4 dBi	23.7 dBi
2.0 meters (6 feet)	16.3 dBi	22.0 dBi	26.1 dBi
3.0 meters (10 feet)	19.6 dBi	26.4 dBi	30.6 dBi
4.0 meters (12 feet)	22.2 dBi	28.0 dBi	32.1 dBi

Table 2. Dish antenna size versus gain (dBi)

MDS can furnish antennas for use with your LEDR radio. Consult your sales representative for details.

Feedlines

For maximum performance, a good quality feedline must be used to connect the radio transceiver to the antenna. For short-range transmission, or where very short lengths of cable are used (up to 8 meters/26 feet), an inexpensive coax cable such as Type RG-213 may be acceptable.

For longer cable runs, or for longer-range communication paths, we recommend using a low-loss cable suited for the frequency band of operation. Helical transmission lines, such as Andrew Heliax[™] or other high-quality cable will provide the lowest loss and should be used in systems where every dB counts.

Whichever type of cable is used, it should be kept as short as possible to minimize signal loss.



The following tables (3, 4 & 5) can be used to select an acceptable feedline. A table is provided for each of the three bands for which the LEDR radios are available.

Cable Type	3.05 Meters (10 Feet)	15.24 Meters (50 Feet)	30.48 Meters (100 Feet)	152.4 Meters (500 Feet)
RG-8A/U	0.51 dB	2.53 dB	5.07 dB	25.35 dB
1/2 in. HELIAX	0.12 dB	0.76 dB	1.51 dB	7.55 dB
7/8 in. HELIAX	0.08 dB	0.42 dB	0.83 dB	4.15 dB
1-1/4 in. HELIAX	0.06 dB	0.31 dB	0.62 dB	3.10 dB
1-5/8 in. HELIAX	0.05 dB	0.26 dB	0.52 dB	2.60 dB

Table 3. Feedline Loss Table (450 MHz)

Table 4. Feedline Loss Table (960 MHz)

Cable Type	3.05 Meters (10 Feet)	15.24 Meters (50 Feet)	30.48 Meters (100 Feet)	152.4 Meters (500 Feet)
RG-8A/U	0.85 dB	4.27 dB	8.54 dB	42.70 dB
1/2 in. HELIAX	0.23 dB	1.15 dB	2.29 dB	11.45 dB
7/8 in. HELIAX	0.13 dB	0.64 dB	1.28 dB	6.40 dB
1-1/4 in. HELIAX	0.10 dB	0.48 dB	0.95 dB	4.75 dB
1-5/8 in. HELIAX	0.08 dB	0.40 dB	0.80 dB	4.00 dB

Table 5. Feedline Loss Table (1400 MHz)

Cable Type	8 Meters (26 Feet)	15 Meters (49 Feet)	30 Meters (98 Feet)	61 Meters (200 Feet)
RG-213	3.0 dB	6.03 dB	12.05 dB	24.1 dB
1/2 in. HELIAX	0.73 dB	1.47 dB	2.93 dB	5.9 dB
7/8 in. HELIAX	0.42 dB	0.83 dB	1.66 dB	3.32 dB
1-5/8 in. HELIAX	0.26 dB	0.26 dB	1.05 dB	2.1 dB

3.4 Radio Mounting

The radio can be mounted either in a 19-inch equipment rack or on a table top. It should be located in a relatively clean, dust-free environment that allows easy access to the rear panel connectors as well as front panel controls and indicators. Air must be allowed to pass freely over the ventilation holes and heat sink on the side panel.

The dimensions of LEDR Series radios are:

- 305 mm (12 in) deep
- 426 mm (16.75 in) wide—Excluding rack mounting brackets
- 45 mm (1.75 in) high—1RU



Maximizing RSSI

For newly installed systems, one of the first tasks is to orient the station antenna for a maximum Received Signal Strength Indication (RSSI) as shown on the LCD screen. See "Performance" on Page 40 for details. A maximum RSSI ensures the antenna is properly aimed at the associated station. Move the antenna slowly while an assistant observes the RSSI display for a maximum reading.

Attaching the Rack Mounting Brackets

The radio is normally shipped with the rack mounting brackets uninstalled. To attach them, select the desired mounting position on the sides of the chassis. (The brackets may be mounted flush with the front panel, or near the middle of the chassis.)

3.5 Front Panel

Indicators, Text Display and Navigation Keys

Figure 8 shows the details of the LEDR radio's front panel indicators, an LCD text display and a menu navigation keys.



Figure 8. Front Panel Indicators, Text Display and keys

NOTE: Both short and long screws are provided with the brackets. Use the long screws for the heatsink (left) side of the chassis and the short screws for the right side of the chassis. Tighten the screws securely.



LED Indicators

The front panel LEDs indicate various operating conditions as outlined in Table 6.

LED	Indications
POWER	Primary power is applied to radio
ACTIVE	This radio is the on-line/active unit in a redundant configuration.
ALARM	A general alarm condition is present
RX ALARM	The modem is not locked to a receive signal
TX ALARM	There is a problem with the transmitter
I/O ALARM	There is a payload data interface error

Table 6. Front Panel LED Functions

LCD Display & Keys

The LCD display provides a two line by 16-character readout of radio status and parameter settings. It is used with the menu navigation keys on the right side of the front panel to control the radio's operation and access diagnostic information.

Use of the navigation keys (Figure 9) is simple, and allows many basic operating tasks to be performed without connecting an external terminal or using additional software.



Figure 9. Menu Navigation Keypad

The keys can be used for two tasks—navigating though menus, and editing user controllable parameters. The functions of the keys are automatically selected according to the screen that is being viewed by the user.

Menus

The LEDR radio contains 16 primary menus as listed below. These primary menus serve as entry points to a variety of submenus that can be used to view or adjust operating parameters and diagnose the radio link.

•

•

•

- Login
- Logout

Performance G.821

Diagnostics

Front Panel

Redundant

Orderwire

- Network •
- General ٠
- RF Config(uration) •
- IO Config(uration)
 - **Remote Status** •
 - Line Config(uration)
- MDS 05-3627A01, Rev. C



Detailed descriptions of each front panel LCD display is covered in-depth later in this manual. For details, see *Front Panel LCD Menu Descriptions* on Page 32.

Menu Navigation The left and right keys () provide navigation through the available top level menus (see menu tree, Figure 9) and through series of subordinate menus.

The ENTER key allows entry into each primary menu's subordinate menus, exposing another menu level. The Escape key always exits the current screen, causing the program to "pop up" one level.

Parameter Selection and Data Entry With an editable menu, such as Login, pressing the ENTER key puts the screen into a data entry mode. Front panel keys are used in one of three ways: A. character and string creation/selection, B. scrolling through lists, and C. adjusting horizontal slider bars.

> A. Character and String Creation/Selection— With some menus, it is necessary to enter a string of alphanumeric characters. A good example is entering a password at the user login menu. In this example, the string is built one character at a time, and the string is built from left to right on the display.

> The left and right arrow keys move the cursor in the corresponding direction. When the cursor is below the character you wish to change, press $\underbrace{\texttt{ENTER}}$. The arrow keys are then used to step though the character set, beginning with numbers, next uppercase letters and finally lowercase letters. Each time you press one of the arrow keys, the display will step to the next character. If you press and hold the arrow key for several seconds, the characters will scroll by very quickly.

> After you have built the string of characters you need, press the (ENTER) key to save the string on the display and return to cursor navigation mode. To save all changes you have made, place the cursor under the special carriage return symbol $(\underline{+})$ and press (ENTER). Pressing (ENTER) will revert the arrow keys to the cursor navigation mode. Pressing (ENTER) in cursor navigation mode cancels character edit mode without saving any changes.

B. Scrolling Lists/Values— Uses left and right keys (O) to scroll through a list of choices or adjust a numeric value, such as **power output**. When you are in a menu of with a series of fixed parameters, the vertical scroll character (O) will appear while you are in the editing/selection mode. If you are asked to select or change more than one character, you will see a horizontal scroll symbol (O) in the bottom right-hand corner of the display and a cursor will appear under the character being edited or changed.



When the desired parameter is in view, move the cursor to the
right as far as it will go, until a carriage return symbol (1)
appears. Pressing the <i>ENTER</i> key will save the selection to its left,
if your access privileges permit. Pressing (ESCAPE) cancels the selec-
tion and exits without saving the change.

C. Slider Bar Adjustment—Some menus display a horizontal bar that changes its length to indicate the level for parameters that use relative values such as the Orderwire Volume and VOX threshold. (See VOX and O/W on Page 40.) Pressing the key will increase the value and the will lower the value. Pressing saves the current setting.

Connectors

The front panel of the LEDR radio (Figure 10) has two connectors; both of them are located on the lefthand side of the panel.

Orderwire The RJ-11 jack with the telephone symbol above it is to connect an orderwire handset. The orderwire is used by service personnel to communicate through the Service Channel to coordinate system activities with personnel at another site in the network. The orderwire will not interrupt the normal data flow through the LEDR data communication channel, however, it will reduce the throughput efficiency of any data communications on the Service Channel during periods of voice transmission. See "USING ORDERWIRE" on Page 99 for more information.

CONSOLE The second connector is a DB-9 type with a computer icon over it. Here is where you can connect a computer's serial port for unit configuration,



diagnostics and firmware upgrades to the radio.

Figure 10. LEDR Front Panel (All models Identical.)

3.6 Rear Panel Connectors

The rear panel of the LEDR radio transceiver contains a number of connectors to interface with the radio's antenna system, data equipment, and user remote data network monitoring and control equipment.



Connector Locations

LEDR "S" Series The rear panel of the LEDR "S" Series radios is shown in Figure 11. Refer to the descriptions that follow for specific information regarding rear panel connections.



Note: RX Connector present with external duplexer only.

Figure 12. LEDR 400F/900F/1400F Rear Panel

Ground Stud

The ground stud on the rear panel provides a point to tie the radio's chassis ground to earth ground for safety purposes.



Antenna/TX—RF Connector

The ANTENNA/TX connector is an N-type coaxial connector. When an *internal* duplexer is installed, it serves as the connection point for the station antenna. When an *external* duplexer is used, it acts as the transmitter RF output (TX) connector to the duplexer.

RX—**RF** Connector

The RX (receive) connector is an N-type coaxial connector. It is only installed if the radio is supplied for use with an external duplexer. It carries receive signals (RX) from the duplexer to the LEDR radio's receiver.

When an external duplexer is used, ensure that the higher frequency (transmit or receive) is connected to the duplexer connector marked HI and the lower frequency (transmit or receive) is connected to the duplexer marked LO.

G.703/Expansion Data

The type of connector(s) at this location on the rear panel depends on several factors: the type of interface required by the customer premises equipment (CPE) and whether or not the radio is part of a protected (redundant) configuration. See Table 7 for details.

Model(s)	Configuration	Data Interface	G.703/Expansion Connector
LEDR 400S LEDR 900S LEDR 1400S	Stand-alone	EIA-530	Blank. No connector(s) installed.
LEDR 900S	Stand-alone	FT1	4 x RJ-45—Only one port is active based on linename selection. (See Note 2)
LEDR 400S LEDR 900S LEDR 1400S	Stand-alone	FE1	4 x RJ-45—Only one port is active based on linename selection. (See Note 2)
LEDR 400F LEDR 900F LEDR 1400F	Stand-alone	4E1	4 x RJ-45—All four jacks (A, B, C & D) are active. (See Notes 1 & 2)
LEDR 400F/S LEDR 900S LEDR 1400F/S	Protected	All	DB-68 (See Note 3)

Table 7. G.703/Expansion Data Connector

NOTES:

- 1. The capacity of the 4E1 interface can be reduced to one (1E1) or two circuits (2E1). See **linemap** command on Page 66, for configuration information.
- 2. For RJ-45 pinout information, see Figure 36 on Page 130.
- 3. This 68-pin interface connector is used only to pass the user data interface, the Service Channel, and the orderwire circuits to the Protected Switch Chassis for distribution. Fully-wired DB-68 computer cables (commonly used to interconnect SCSI devices) can be used with this data port connector.



Ethernet

The ETHERNET connector provides access to the embedded SNMP agent and other elements of the TCP/IP network-management interface. The connector is a standard 10Base-T connection with an RJ-45 modular connector. The LEDR Ethernet connections are provided for remote equipment management (NMS). Ethernet in At a repeater site with two LEDR radios, the ETHERNET connectors of a Repeater each chassis must be connected to each other through a cross-connect Configuration cable or using standard cables to an Ethernet hub. This inter-chassis Ethernet connection must be made in order for the Orderwire and Service Channel to function properly. (See Figure 13 on Page 20 for further information.) Ethernet in The Ethernet connections on the LEDR radio chassis in a protected cona Protected figuration should *not* be used. The Ethernet connector of the Protected Configuration Switch Chassis (PSC) provides a connection to the two radio units. Each radio has a unique IP address and is individually addressable/controllable using SNMP over IP. See "PROTECTED CONFIGURATION" on Page 103 for general information and Figure 34 on Page 130 for ETHERNET connector pinout. EIA-530-A The EIA-530-A connector is the main data input/output connector for

The EIA-530-A connector is the main data input/output connector for the subrate radio. The EIA-530 interface is a high-speed serial data connector. For detailed pin information, see "EIA-530-A Data—Rear Panel" on Page 130.

NOTE: This connector is not operational on LEDR "F" Series (fullrate) models.

Service Channel

The Service Channel provides a transparent ASCII "pipe" to which any RS-232/EIA-232 device can be connected at data rates between 300 and 9600 bps. Whatever ASCII data is entered onto the network through the Service Channel Port will be sent to the local radio and broadcast to any other device connected to the Service Channel Port on other associated LEDR radios in the network.

The Service Channel's function is identical for all LEDR configurations—stand-alone, repeater, and redundant.

NOTE: Use of the orderwire will slow down data communications on the Service Channel. It will not effect data traffic on the primary data interface.

For detailed information on this 9-pin connector, see "Service Channel—Rear Panel" on Page 131.



Repeater Configuration





Figure 13. Inter-unit Cabling—Repeater Configuration

Protected Configuration The Service Channel connections on the LEDR radio chassis in a protected configuration should *not* be used. The SERVICE CHANNEL connector of the Protected Switch Chassis (PSC) provides a connection to the two radio units. For further information on protected configurations please see "PROTECTED CONFIGURATION" on Page 103.

Alarm I/O

This is a 9-pin connector that has both inputs and outputs.

Output ContactsThe ALARMS Port is outfitted with four optically-isolated relays that are
controlled by the LEDR radio's CPU. The contacts (Pins 6, 7, 8, & 9)
are normally open and can handle a non-inductive load of ± 60 Volts
Peak (AC/DC) at a maximum current of 1 Ampere. These are suitable
for the control of an external device or indicator when a radio event
occurs.

An alarm output could be used, for example, to sound a claxon when the radio link goes down, or when the battery for the real-time clock is low. Another example is to use the alarm outputs to drive the inputs of an external monitoring system. (See the list of radio events for more options.) These outputs are not suitable for data interface without the use of an external "debouncing" circuit.



Input Connections In addition, four external alarm input lines (Pins 1, 2, 3 & 4) are provided. Normally, the input is either left open or shorted to ground, to indicate an alarm condition.

> Each alarm input is diode-clamped to +3.3 Vdc or chassis ground, and can tolerate inputs from -4 to +6 Vdc without drawing excessive current. If left open, each input is pulled up. To indicate an alarm condition, short the input pin to the ground provided on the alarm connector (Pin 5). The maximum DC loop resistance is 2 K Ω . These alarm input lines can tolerate circuit "bounce" common with mechanical relays.

> **NOTE:** The normal (unalarmed) state of the contacts (open or closed) or input alarm state (high or low) can be selected by a software subcommand. See "alarm" on Page 49 for details.

Alarm Events The events that cause alarm output signals can be configured in the radio software. See "evmap" on Page 57 for information on programming which events trigger an alarm.

See Figure 38 on Page 131 for Alarm I/O pinout information.

DC Power Input (Primary Power)

The DC POWER INPUT connector is a three-pin keyed connector used to connect an external DC power source that will provide the unit's primary power. The DC power source can be connected with the negative lead connected to either the left or right pin of the chassis connector. The center conductor is not connected within the LEDR chassis. A label next to the connector will indicate the nominal voltage of the radio. Table 8 lists the actual operating voltage ranges.

Table 8. Primary Power Input Option	S
-------------------------------------	---

Nominal Voltage	Operating Range
24 Vdc	19.2 to 28.8 Vdc
48 Vdc	38.4 to 57.6 Vdc

Refer to the model number codes in Figure 3 to determine the radio's power supply range.

Before connecting primary power to the radio, verify that the source provides a voltage within the operating range. Improper voltages may damage the equipment. Permissible voltage limits are shown in Table 8.





Protected Configuration Connections

There are several connections between the LEDR radio chassis and the Protected Switch Chassis. They include the primary data interface, RF, Ethernet, orderwire and Service Channel. Details on cabling and other items relating to the protected (redundant) configuration can be found in *PROTECTED CONFIGURATION* on Page 103.

3.7 Bandwidths, Data Rates and Modulation Types

The hardware in the LEDR chassis is configured at the factory for a specific bandwidth. However, the modulation type and data rate can be changed *provided the bandwidth is sufficient to support the modulation type and data rate.* (If you need to change your radio's bandwidth, please see "INCREASE BANDWIDTH BY CHANGING TRANS-MITTER AND RECEIVER FILTERS" on Page 122 for details.)

Use of the **modem** command (Page 72) and configuration ([argument]) code automatically sets the combination of data rate, bandwidth and modulation type if the radio is capable of supporting it

Table 9 shows the combinations of radio bandwidth, data rates and modulation types that are available for subrate radios at the time of publication. Table 10 shows the combinations available for fullrate radios.

Radio Bandwidth	Configura- tion Code	Data Rate(s)	Modulation
25 kHz	B1	64 kbps	16-QAM
	C1	64 kbps	32-QAM
50 kHz	A1	64 kbps	QPSK
	B2	128 kbps	16-QAM
100 kHz	A1	64 kbps	QPSK
	A2	128 kbps	QPSK
	B3	256 kbps	16-QAM
200 kHz	A1	64 kbps	QPSK
	A2	128 kbps	QPSK
	B3	256 kbps	16-QAM
	B4	384 kbps	16-QAM
	B5	512 kbps	16-QAM
	C6	768 kbps	32-QAM

Table 9. Subrate Bandwidth vs. Modem Selection Code



Radio Bandwidth	Configura- tion Code	Data Rate(s)	Modulation
500 kHz	C7	E1	32-QAM
1000 kHz	B7	E1	16-QAM
	C7	E1	32-QAM
	C8	2E1	32-QAM
2000 kHz	A7	E1	QPSK
	B7	E1	16-QAM
	B8	2E1	16-QAM
	C8	2E1	32-QAM
	C10	4E1	32-QAM

Table 10. Fullrate Bandwidth vs. Modem Selection Code

3.8 Transmit Clock Selection (Subrate Radios Only)

For a subrate radio, transmit clock arrangement must be set by the user. Clocking arrangements for fullrate radios is automatically handled by the LEDR radios.

It is essential that there be only *one* master clock in a subrate radio network. The master clock can originate from the radio or from the Customer Premises Equipment (CPE).

LEDR radios are capable of several different clocking modes. Refer to Figure 14 and Figure 24 for typical system clocking arrangements.

Refer to the **Clock Mode** screen description on Page 35 for setting the radio transmit clocking from the front panel. Refer to the **clkmode** description on Page 54 for setting the radio transmit clocking mode from the front panel CONSOLE Port.

NOTE: When customer premises equipment (CPE) is operated in looped clock mode, it is recommended that the radio *not* be set to line clock mode. To do so may cause the transmitting radio's PLL to be pulled out-of-lock, especially when operating at 4E1 data rates.





Figure 14. EIA-530 Clocking Arrangements for Protected (1+1) LEDR Radio Operation

4.0 INITIAL STARTUP AND CONFIGURATION

4.1 Introduction

The radio is commonly configured to parameters provided by the customer at the time the order was placed. Even so, there are some parameters that must be reviewed and set during the installation. The following steps summarize the initial set-up of a LEDR radio link. If this is your first installation of a LEDR radio system, it is recommended the equipment be setup on a test bench.

4.2 STEP 1—Power up the LEDR Radios

There is no primary power switch; simply connecting primary power to the unit will start the radio operating. After a short self-test, a "default screen" similar to the following appears on the radio's LCD display:



NOTE: The LEDR radio is normally keyed continuously, and the radio will transmit whenever power is applied. Ensure there is a suitable load on the antenna connector before connecting power.



4.3 STEP 2—Establish Communications with the Radio

There are four different methods available to set radio parameters and query the radio. They are:

- **Front Panel**—The front panel is intended to serve as a convenient user interface for local radio management. Most, but not all, parameters and functions are accessible from the front panel. (See "Front Panel LCD Menu Descriptions" on Page 32.)
- NMS (Network Management System)—The NMS is used via a terminal connected to the front panel CONSOLE Port. It may be used to configure and query every manageable radio parameter on a given network using the out-of-band Service Channel. The Element Management System (EMS) may be used on the local radio (login command) or through any remote radio in the network using the rlogin command.
- **Telnet**—A standard network application protocol which provides a NMS-type interface to configure and query most radio parameters.
- SNMP Network Management System—The SNMP agent interface is optimized to fulfill the fault configuration, performance and user access requirements of the LEDR radio system. A separate manual, P/N 05-3532A01 explains SNMP in more detail.

4.4 STEP 3—Make Initial Login to Radio

When the radio is first powered up, it defaults to a read-only condition. That is, the radio parameters may be viewed, but cannot be changed. To enable changes to radio settings, a valid user name and password must be entered.

When the radio is shipped from the factory, it is pre-programmed with the following temporary login credentials:

Username:**SUPER** Password:**SUPER**

 NOTE: User names and passwords are case sensitive. Do not use punctuation mark characters. Use a maximum of eight characters.

 Navigation Key
 To log in from the front panel using the temporary credentials, follow these steps:

 1. Go to the Login screen and press the front panel ENTER key. The Username screen appears with SUPER displayed.



- 2. Press the ENTER key again to access the Password screen. Use the arrow keys to scroll through the list of characters and individually select the letters spelling out the word **SUPER**. Press ENTER after each character selection. (For more information on character selection using the navigation keys, see "INITIAL STARTUP AND CON-FIGURATION" on Page 24.)
- 3. When all of the characters have been entered, press again. The screen briefly displays Login Success and returns to the Login entry screen.

The user may now access any of the screens shown in Figure 15 with Administrator level privileges (the highest allowable user level).

CONSOLE Method To login using a terminal connected to the front panel CONSOLE Port, follow the steps below.

- 1. Connect a terminal data port or a PC's serial port to the radio's front panel CONSOLE Port .
- 2. Open an ANSI terminal program, such as HyperTerminal[™] in the Windows O/S. Press **ENTER**. The **LEDR>** prompt should appear on the terminal's display.
- 3. Enter login SUPER. The Password > prompt will appear.
- 4. Enter the password **SUPER**. The following response appears: login: SUPER logged in.

The user may now access any of the NMS commands listed in Table 14 on Page 44 with Administrator level privileges (the highest allowable user level).

4.5 STEP 4—Change the SUPER Password

The factory-programmed username and password (**SUPER**) is provided to enable a System Administrator to operate a newly installed radio. It is highly recommended that the password for **SUPER** be changed as soon as possible to maintain system security.

Follow these steps to change the factory-programmed password.

- 1. Login as **SUPER** using the NMS method described above.
- 2. Enter the command **passwd**. At the next prompt, enter a new password with a maximum of eight characters. (See *passwd* on Page 73.)

NOTE: Passwords cannot be changed using the front panel navigation buttons.



- 3. Re-enter your new password (for verification purposes). If the entry is correct, the radio responds with user: Command Complete.
- 4. Set up user accounts as required beyond the factory default of SUPER.

Create accounts, set permission levels, or delete accounts as desired using the user command. See Page 86 for complete description of user command.

NOTE: It is recommended that users log out when finished using the front panel navigation keys or console terminal. This can be done using the Logout screen on the radio, or the logout command from a console terminal as appropriate. *If there is no key or terminal activity for 10 minutes, the radio automatically logs out and reverts to read-only status.*

4.6 STEP 5—Review Essential Operating Parameters

Review and set the following parameters to allow data throughput and interconnection with the network. These are radio operating frequencies, data interface clocking, and data framing. Table 1 outlines these based on each model group and configuration.

Model Group	Data Interface	Parameter	Setting
Subrate	EIA-530	RF TX/RX Frequency	Factory configured for customer frequencies.
		Clocking	Use clkmode command (Page 54) to match interface equipment.
		Framing	Does not apply.
	FT1/FE1	RF TX/RX Frequency	Factory configured for customer frequencies.
		Clocking	Use clkmode command (Page 54) to match interface equipment.
		Framing	Set as appropriate using fstruct command (Page 59).
		Time Slot	Set as appropriate using timeslot command (Page 84).
		Line Code	Set as appropriate using linecode command (Page 66).

Table 11. Essential Parameters for Standalone & Protected



Model Group	Data Interface	Parameter	Setting
Fullrate	E1	RF TX/RX Frequency	Factory configured for customer frequencies.
		Clocking	No settings are necessary. Radio automatically detects clock and sets mode.
		Framing	Radio set to unframed (default).
			 Make changes as appropriate using fstruct command (Page 59) to match interface equipment.
		Line Code	Set as appropriate using linecode command (Page 66).

Table 11. Essential Parameters for Standalone & Protected (Continued)

4.7 STEP 6—Set TCP/IP Settings to Enable SNMP and/or Telnet Management (If required)

- The unit IP address is factory configured with a unique address based on the last three digits of the radio's serial number.
- Use ip command (Page 63) to change the IP address, set netmask, gateway and IP Port as necessary.
- In a protected radio, change the rdnt settings (Page 74) to match the user-assigned IP addresses.

4.8 STEP 7—Set User Configurable Fields

Many items are user configurable, to ease customer use. These include, and are not limited to the following. See the NMS command description in the manual for more detail:

- Set user information fields using info command (Page 62)
- Set alarms and alarm mappings using the alarm command (Page 49)
- Set event mappings using the evmap command (Page 57)
- Set alarm thresholds using the threshold command (Page 83)
- Set the SNMP community using the snmpcomm command (Page 81)

4.9 STEP 8—Verify Radio Performance

The data performance and NMS should be verified. Use the **loop-back** command (Page 69) to verify data throughput.

4.10 STEP 9—Install the Link

Peak the antennas for maximum RSSI using the continuously

Change only if required.


updated **rssi** command (Page 80), either the front panel screen or using the **trend** command (Page 86) via the NMS.

4.11 STEP 10—Verify the Link Performance

Connect and verify the proper operation of external equipment connected to the LEDR radio link.

5.0 CONFIGURATION AND CONTROL VIA THE FRONT PANEL

Figure 9 on the following pages are a pictorial view of the front panel menu tree. Detailed explanations of the screens are provided in *Section 5.1, Front Panel LCD Menu Descriptions*.









Figure 15. Front Panel LCD Menu Navigation



5.1 Front Panel LCD Menu Descriptions

NOTE: The menus in this section are listed in alphabetical order.

CONSOLE

Baud Rate 9600 This menu allows you to set or view the current data rate setting for the CONSOLE Port serial interface. Refer to Figure 33 on Page 129 for pinout information of this Port. See "OPTION 1: Uploading Firmware via the CONSOLE Port" on Page 94 for more information.



For the NMS command-line equivalent, see "con" on Page 56.



This menu allows you to set or view the current parity setting for the CONSOLE Port serial interface. Refer to Figure 33 on Page 129 for pinout information for this Port. Typically, this will be set to **NONE**.



For the NMS command-line equivalent, see "con" on Page 56.

Default Screen

LEDR Link Default Screen This menu allows you to view the default screen that appears on the LCD display. If desired, the default screen may be changed (See " Default Screen" on Page 33).

Diagnostics



This menu is used to start the loopback mode for testing purposes. Remote loopback port selection is relative to the local port. The radio link will translate any line mapping to select the correct physical remote port to loop back, based on the selected local port.

When conducting RF loopback testing, see Page 69 (**loopback** NMS command) for additional information.

 _
יון
j

For the NMS command-line equivalent, see "loopback" on Page 69.

Built in Test Start? This menu is used to start the loopback mode to check radio functions. When conducting RF loopback testing, see Page 69 (loopback) for important information.



For the NMS command-line equivalent, see "test" on Page 83.



Front Panel

Backlight ENABLED	This screen provides control of the front panel LCD illumination. The LCD illumination may need to be enabled to view the LCD depending
	on ambient lighting conditions.



This screen allows the radio beeper to be disabled or enabled. The beeper provides a short "chirp" whenever a front panel key is pressed.



This screen allows you to set the time delay that occurs before a key will start repeating its function when held down.



This screen allows you to set the default screen that appears when the radio is first turned on, or is left idle for more than 10 minutes. The RSSI screen is commonly chosen, but any screen may be selected as a default.

G.821

```
LEDR Link
G.821
```

This menu contains radio link performance information. The G.821 standard defines descriptive words associated with bit-error rate performance. Refer to the ITU-T G.821 recommendations for definitions and standards.

```
G.821 Status
Error Free (BER) status of the radio.
```

Available
 $0 \ sec$ This screen shows the available seconds of the radio link. The G.821
standard defines Available Seconds as the period of time following a
period of 10 consecutive seconds, each of which has a BER of less than
 $1x10^{-3}$.

Unavailable This screen shows the unavailable seconds of the radio link. The G.821 standard defines Unavailable Seconds as the period of time following a period of 10 consecutive seconds, each of which has a BER of higher than 1×10^{-3} .

 Errored
 O
 This screen shows the errored seconds of the radio link. The G.821 standard defines Errored Seconds as a one second period in which one or more bits are in error.



Severely Erred 0

This screen shows the severely errored seconds of the radio link. The G.821 standard defines Severely Errored Seconds as a one second period that has a BER higher than 1×10^{-3} .

Reset 6.821?	This screen allows the user to reset the G.821 performance monitoring
NO	screens.

General

	Unit	ID
l	000	

This menu allows the Unit ID of the radio to be displayed or changed. The Unit ID allows an individual radio to be signaled for Orderwire use.

For the NMS command-li	ine
equivalent, see "unitid" of Page 86.	on

Г	Model	Number
l	LEDR	14005

This menu displays the radio model number. The user cannot change the radio type.

(

For the NMS command-line equivalent, see "model" on Page 71.

Serial Number XXXXXXXXXXXXX

This menu displays the radio serial number and matches the serial number on the chassis sticker. The user cannot change the radio's serial number.

FO
eq
Pa

or the NMS command-line uivalent, see "sernum" on iqe 81.

This menu displays the firmware revision level of the internal radio soft-Firmware Rev. ware. XXXXXXXX



For the NMS command-line equivalent, see "ver" on Page

This menu displays the hardware revision level of the main PC board in Hardware Rev. XXXXXXXXX the radio.

ſ	
լլ	
C	8

For the NMS command-line equivalent, see "ver" on Page 87.



IO Configuration

Clock Mode INTERNAL This screen is used to set or display the data clocking method. For synchronization purposes, several different clocking schemes can be used. See "Transmit Clock Selection (Subrate Radios Only)" on Page 23.



For the NMS command-line equivalent, see "date" on Page 56.

NOTE: For subrate models: LEDR 400S/900S/1400S Earlier versions of the software may display the Clock Mode as NORMAL instead of INTERNAL.

Interface E1 This screen is used to set or display the payload data interface. The available selections are E1 and T1, depending on hardware configuration of the LEDR radio.

(
1

For the NMS command-line equivalent, see "interface" on Page 62.



This screen is used to set or display the Channel Associated Signaling (CAS) status. The available selections are Enabled and Disabled.

This screen will only be functional in radios factory-equipped to support CAS. Consult the factory if you require this service.



For the NMS command-line

equivalent, see "modem" on Page 72.

Line map 1a 2b 3c 4d This screen is used to set or display the current span mapping configuration. The entry consists of from 1 to 4 alpha-numeric characters specifying line interface to span mapping. Valid numbers are 1–4. Valid span characters are a–d.

Example: Entering 1a 2b 3c 4d asserts the following:

maps line 1 to span a maps line 2 to span b maps line 3 to span c maps line 4 to span d



For the NMS command-line equivalent, see "linemap" on Page 66.



Line Configuration

3–SF

4-SF + JYEL

5-ESF + CRC

6-ESF + CRC + PRM

Choose Line 1 LINE1

This screen is used to choose or display the line (1-4) that is selected. This selection will be active for all of the screens that follow in the Line Configuration menu and will be displayed in the upper right hand corner of each screen.



3-FAS + CRC + BSLIP

5-FAS + CAS + BSLIP

6-FAS + CRC + CAS

7-FAS +CRC + CAS +BSLIP

For the NMS command-line equivalent, see "linename" on Page 67.



This screen is used to set or display the span(s) frame structure. The allowable selections are shown in Table 11.

T1 Operation	E1 Operation	
0–FT only (Default)	0–FAS Only (Default)	
1–ESF	1–FAS + BSLIP	
2–ESF + PRM	2–FAS + CRC	

Table 11 Frame Structure_Allowable Selections

Fc
eq Pa

4-FAS + CAS

or the NMS command-line quivalent, see "fstruct" on age 59.

This screen is used to set or display the Alarm Indication Signal (AIS) AIS Generate 1 OFF status. It may be set to ON or OFF. When generation is enabled, fault conditions within the link or at the line interface will cause the appropriate AIS signaling to occur.



For the NMS command-line equivalent, see "ais" on Page 48.

(AIS Forwarding 1 **OFF**

This screen is used to set or display the Alarm Indication Signal (AIS) forwarding status. It may be set to ON or OFF. When forwarding is enabled, AIS/RAI signaling at the line interfaces will be detected and passed to the other end of the radio link.



For the NMS command-line equivalent, see "ais" on Page 48.



Line Code AMI

1

This screen is used to set or display the linecode used by the radio. The available selections are AMI or HDB3.



For the NMS command-line equivalent, see "linecode" on Page 66.

Reframe 1This screen is used to set or display the reframe criteria of the LEDR3 cons. FASradio. The setting is based on the number of errors encountered. The
available selections for T1 and E1 operation are listed in Table 12
below.

Table 12. Reframe Criteria Selections

T1 Operation	E1 Operation
2 out of 4 Fbit errors (Default)	3 consecutive FAS errors (Default)
2 out of 5 Fbit errors	915 CRC errors
2 out of 6 Fbit errors	

I
•

For the NMS command-line equivalent, see "reframe" on Page 76.

Pulse Shape 1 9.775

This command is used to select or display the pulse shape used with the data interface cable. Table 13 below shows the available selections for T1 and E1 operation.

Table 13. ITU Cable Specifications



For the NMS command-line
equivalent, see "line" on
Page 65.

Cable Len9th 1 1-133 ft This command is used to set or display the cable length being used for the data interface. The available selections are:

> 1 to 133 feet (Default) 133 to 266 feet 266 to 399 feet 399 to 533 feet 533 to 655 feet

For the NMS command-line equivalent, see "line" on Page 65.

MDS 05-3627A01, Rev. C



Login

LEDR LINK Login The login menus allows you to log in to the radio's operating system and gain access to configuration and diagnostics functions permitted for your assigned access level.

Username Admin The username menu is where you specify the user name assigned by the user access administrator.



For the NMS command-line equivalent, see "login" on Page 68.



The password screen is where you specify the password associated with your user name to gain access to the login account. A maximum of eight characters is allowed.



For the NMS command-line equivalent, see "passwd" on Page 73.

Logout

LEDR Link Lo9out The logout menu allows you to terminate your session with the LEDR radio. When this screen is displayed, press (EVTER) to finish your session.

Modem

Rx Lock LOCKED This menu indicates whether the receiver demodulator has detected a signal, acquired the carrier, and data rate, as well as achieved a Forward Error Correction (FEC) lock.

Freq. Offset This screen shows the frequency offset of the LEDR radio as measured in Hertz.

Corrected 0 bytes This menu shows how many bytes have been corrected by the radio's FEC capability.

Uncorrectable This menu shows how many frames (blocks) could *not* be corrected by the radio's FEC capability.

Bit Error Rate $\langle 1 \times 10^{-6} \rangle$ This menu shows the current bit error rate (BER) of the LEDR radio.



Network

IP Address 000.000.000.000	This menu allows changes to the radio's IP address. The IP address is used for network connectivity. The IP address also allows new radio software to be downloaded over-the-air. For the NMS command-line equivalent, see "ip" on Page 63.
Netmask 000.000.000.000	This menu allows the subnet mask to be viewed and changed. The subnet mask specifies which bits of the host IP address can be re-used for increased network addressing efficiency.
	Example: Consider an IP address in a Class C network, such as 150.215.017.009. The Class C network means that the right-most group of numbers (009) identifies a particular host on this network. The other three groups of numbers (150.215.017) represent the network address.
	Subnetting allows the further division of the host part of the address (right-most group of numbers) into two or more subnets. A subnet mask of 255.255.255.127 allows half of the host portion of the IP address to be reused to define sub-networks.
	equivalent, see "ip" on Page
Gateway 000.000.000.000	This menu allows the Gateway IP address to be viewed or set. The Gateway IP address is the address of the radio that connects the radio network to an IP network. For the NMS command-line equivalent, see "ip" on Page 63.
Default IP Port Ethernet	This menu allows selection of the Default IP port for networking con- nections to the LEDR radio. The Ethernet selection is used for cable con- nection to a Local Area Network (LAN) or repeater via the radio's rear panel ETHERNET connector.

The AIR selection is commonly used for over-the air (RF) networking between radios, but may also be used with a back-to-back cable connection between two radios via the radio's rear panel ETHERNET NMS connector. This type of communication uses the SNAP protocol and requires the use of an ethernet crossover cable.



For the NMS command-line equivalent, see "ip" on Page 63.





F
e
Ρ

For the NMS command-line equivalent, see "vox" on Page 88.

Performance

The Performance menu items provide diagnostics information regarding the radio. The following diagnostic parameters are available on a continuous, updating basis:

- RSSI—Received Signal Strength Indicator
- SNR—Signal/Noise Ratio (not valid if there is an RX Alarm)
- **POUT**—Power Output
- PA Temperature—Power amplifier temperature

RSSI -60 dBm The RSSI display indicates the strength of the radio signal being received at the radio receiver. The measurement is in dBm. Therefore, an RSSI of -80 dBm is stronger than a -100 dBm signal.



For the NMS command-line equivalent, see "rssi" on Page 80.





The SNR display indicates the relationship of the amount of intelligence versus noise on the radio signal. The higher the SNR, the better the quality of the radio signal.

For the NMS command-line
equivalent, see "snr" on Page 82.

Power Out +30 dBm

The Power Output display indicates the transmitter power output in dBm. (+30 dBm is equal to 1.0 watt; +20 dBm is 100 mW.)

The power output level can be set from this display by pressing the (IIIII)key, and through use of the arrow keys, increase or decrease the power level. When the desired value is displayed, press the *(ENTER)* key to save the setting.



(PA Temperature +37 °C

The PA Temperature display indicates the internal temperature (degrees Celsius) at the hottest point on the radio's printed circuit board (near the power amplifier section of the radio).

For the N
equivaler Page 83.

MS command-line nt, see "temp" on

NOTE: It is normal for the PA temperature to be 30 to 40° C above the ambient room temperature.

Redundant

My Status OK.

This screen is used to display the status of the radio currently being used. "OK" is displayed when no problems are detected.

Sibling Status OK.

This screen is used to display the status of the "other" radio in a protected configuration (the one not currently being used). "OK" is displayed when no problems are detected.

Active NO

This screen is used to set or display whether the currently selected radio is the active unit.



Mode 1 + 1 HOT This screen is used to set or display the radio's redundancy mode. The available selections are: 1+1 HOT (redundant hot standby), 1+1 WARM (redundant warm standby) or **STANDALONE** (non-redundant) configuration.

Sibling IP 000.000.000.000 This screen is used to set or display the sibling radio's Internet Protocol (IP) address. (See note below.)

NOTE: The associated radio IP address should be programmed to the IP address of the other radio connected to the protected switching chassis. The associated radio IP address is used by the redundant radio to share information between the units. This address is necessary for proper operation. The associated radio IP address does not affect IP routing and forwarding, SNMP, or Telnet.

Hitless	This screen sets or displays whether the radio is set to perform error-free
ON	"hitless" switchover in the event of an alarm condition.

This screen displays whether or not the radio is the default radio in a pro-Default Radio Yes tected configuration. The default radio is determined by which one is connected to the top connector of the Protected Switch Chassis rear panel. (See Figure 12 on Page 17.)

Switch Xovr This screen is used to force a switchover to the non-active radio trans-Switch? ceiver. (The newly selected unit becomes the active transceiver).

Remote Status

This screen is used to set or display the unit identification for the remote Remote UnitID <none> radio.

RF Configuration

This menu is used to set or view the transmit (TX) frequency of the Tx Frequency radio.



For the NMS command-line equivalent, see "freq" on Page 58.



This menu is used to set or view the receive (RX) frequency of the radio. Rx Frequency



For the NMS command-line equivalent, see "freq" on Page 58.

This menu is used to enable (key) or disable (dekey) the transmitter or Tx Key Enable to verify that the radio is keyed and the transmitter is active. The radio is normally keyed and transmitting whenever power is applied.



For the NMS command-line equivalent, see "txkey" on Page 86.

This menu displays the bandwidth setting of the radio. The bandwidth is Bandwidth set at the factory and cannot be changed by the user. Refer to Table 9 on Page 22 for allowable combinations of bandwidth, data rates, and modulation types.

Mod/Data rate 32-QAM 768 kbps

This menu displays the modulation type and the aggregate link data rate. The available modulation types are QPSK, 16 QAM, and 32 QAM. The data rate can be changed, but is dependent on the modulation type. See "Bandwidths, Data Rates and Modulation Types" on Page 22.



For the NMS command-line equivalent, see "modem" on Page 72.

CONFIGURATION AND CONTROL 6.0 VIA THE CONSOLE PORT 🛄

Introduction 6.1

The CONSOLE Port on the front panel provides full access to configuration and diagnostics information. It is the most common way to access the LEDR radio for its initial configuration. The CONSOLE Port is an EIA-232 connection that provides ASCII text communications to a connected terminal.

Most of the commands listed on the following pages are available through other communication channels. These include Ethernet, IP, Telnet and the rear panel Service Channel.

Refer to *I/O Connector Pinout Information* on Page 129 for connector wiring details.



NOTE: It is important to use a terminal or terminal-emulator that supports 80 characters-per-line and 25 lines-per-screen. The display will be distorted if terminals with different line characteristics are used.

6.2 Initial Connection to the CONSOLE Port

- 1. Connect a terminal to the front panel DB-9 connector labeled \square .
- 2. Open an ANSI terminal application on the terminal. (If using the Windows operating system, a HyperTerminal session can be started by selecting **Programs>>Accessories>>HyperTerminal**.)
- 3. Press **ENTER** a few times. When communications are established with the radio, an **LEDR>** text prompt appears on the terminal screen.
- 4. Type login <your username> (or rlogin <your username> for remote access) and press **ENTER**. At the **password>** prompt, type your password (Eight characters maximum; case sensitive).
- 5. You now have access to the command line interface. It can be used to configure and query the radio parameters and setup information. The available commands can be listed on the display by typing help at the LEDR> prompt, then **ENTER**.

6.3 NMS Commands

Once you are successfully logged in, the Network Management System (NMS) commands shown in Table 14 are available at the command line prompt (LEDR>) NOTE: Some commands are model and/or feature specific. (See Table 15 on Page 48 for Interface icons.)

Command	Description Summary	Details
?	Displays the available NMS commands. May also be entered after any other command to obtain context sensitive help. (Note: the word help may be entered in place of ?).	Page 48
ais	Echoes/enables/disables Alarm Indication Signal (AIS) generation and Remote Alarm Indication (RAI) detection, AIS and RAI Signal (RAIS) forwarding on given span(s).	Page 48
alarm	Provides control of alarm outputs and displays state of alarm inputs.	Page 49
alert	Sends an alert sound to the specified radio	Page 51
arp	Set/display ARP Setting of Ethernet Port	Page 51
ber	Bit-Error Rate report for the RF link.	Page 51

Table 14. NMS Commands



Command	Description Summary	Details
bert	Bit-Error Rate test of data interface	Page 52
boot	Displays the active image (firmware) or reboots	Page 54
buzzer	Briefly sounds the radio's piezo buzzer to test its operation	Page 54
clkmode	Set/display data clocking mode	Page 54
coffset	Displays modem carrier frequency offset in Hz	Page 55
con	Set/display CONSOLE Port communications parameters	Page 56
config	Used to get or send a radio configuration file	Page 56
date	Set/display current date	Page 56
dtren	Set/display DTR enable	Page 57
ethernet	Displays Ethernet address	Page 57
events	Event log commands	Page 57
evmap	Set/display alarm port and alarm LED settings	Page 57
fec	Display corrected and Uncorrectable FEC errors	Page 58
freq	Set/display operating frequencies	Page 58
fset	Display absolute frequency limits	Page 59
fstruct	Set/display current span(s) frame structure	Page 59
g821	Show/Reset G.821 information	Page 60
group	Set/display network group	Page 60
help	Displays the available NMS commands. May also be entered after any other command to obtain context sensitive help. (Note: A question mark (?) may be entered in place of help).	Page 48
http	Check or boot the internal HTTP/IP server	Page 61
ісору	Firmware image copy	Page 61
idlepat	Set/display timeslot idle pattern	Page 61
info	Set/display radio/owner information	Page 62
interface	Set/display the payload data interface	Page 62
interleave	Set/display interleave depth	Page 63
ір	Set/display the radio's IP configuration	Page 63
iverify	Firmware image verify	Page 64
lcd	Tests radio's front panel LCD display	Page 64
led	Tests radio's front panel LEDs	Page 64
line	Set/display pulse shape settings	Page 65
linecode	Set/display the linecode used by span(s)	Page 66
linerr	Show/enable/clear line errors	Page 67
linemap	Set/display current linemapping configuration	Page 66
linename	Set/display names for line interfaces	Page 67

Table 14. NMS Commands (Continued)



Data ems Inc.		

Command	Description Summary	Details
log	View, sort, clear, send event log information	Page 68
login	Console user level access	Page 68
logout	Console user exit	Page 69
loopback	Set/display loopback modes	Page 69
model	Display radio model number	Page 71
modem	Set/display radio modulation type and data rate	Page 72
network	Display radios in the network	Page 73
passwd	Sets new user password (8 characters max.)	Page 73
ping	Test link to IP address on network	Page 73
pll	Displays Phase Lock Loop status	Page 74
pmmode	Enables/disables modem modulator power measurement mode (on/off)	Page 74
rdnt	Set/display redundant operating configuration	Page 74
reframe	Set/display the reframe criteria	Page 76
reprogram	Reprograms radio software	Page 76
rfocal	Set/display RF power output calibration sequence	Page 76
rfout	Displays transmit power	Page 77
rlogin	Log in to remote radio	Page 77
route	Add/delete/modify IP routing table entries	Page 78
rssi	Displays received signal strength	Page 80
rssical	Set/display RSSI calibration table	Page 80
rxlock	Displays current modem lock status	Page 81
sabytes	Echo/set sa bytes in E1 multi-frame	Page 81
sernum	Displays radio serial number	Page 81
snmpcomm	Set/display SNMP community names	Page 81
snr	Displays signal to noise ratio	Page 82
status	Displays performance and configuration data	Page 82
svch	Set/display Service Channel configuration	Page 82
telnetd	Displays or kills (terminates) Telnet session(s)	Page 82
temp	Displays PA temperature	Page 83
test	Runs self-test of LEDR hardware	Page 83
threshold	Set/display performance degradation threshold(s)	Page 83
time	Set/display system time	Page 84
timeslot	Selects which timeslots to transmit for a span(s). Default action is to enable.	Page 84
trapfilter	Set/display which events cause SNMP traps	Page 85
trapmgr	Set/display the trap manager IP address	Page 85

Table 14. NMS Commands (Continued)



Command	Description Summary	Details
trend	Displays continuously updated readings of: RSSI, radio temperature, RF output, signal-to-noise ratio, and FEC errors (corrected and uncorrectable)	Page 86
txkey	Key or unkey radio	Page 86
unitid	Displays the three-digit unit identification	Page 86
uptime	Displays how long the radio has been operating	Page 86
user	Administration tool for adding, modifying or deleting user accounts	Page 86
ver	Displays software version	Page 87
volume	Set/display orderwire handset volume	Page 88
vox	Set/display orderwire VOX threshold	Page 88
who	Displays the currently logged in radio users/accounts	Page 89

Table 14. NMS Commands (Continued)

NOTE: The NMS commands listed in this manual show the full set of commands from all radio versions. Different hardware configurations may have fewer selections.

6.4 Command Detailed Descriptions

Introduction

The following commands are available through the CONSOLE Port. These commands all require the Enter or Return key be pressed after the command.

The following conventions are used to help describe the usage of the commands.

Square brackets [] contain subcommands that may or may not be needed as part of the desired command. If there is more than one possible subcommand a vertical line | separates the commands within the square brackets. A subcommand is an optional extension of the command and changes the basic command.

Angle brackets <> contain arguments. The arguments are values needed to carry out the command such as a frequency value or option.

Some commands are limited to use in certain radio models or configurations. These include subrate and fullrate. One or more of the symbols as listed in Table 15 will identify these commands.



	-	Symbol	Interface/Group	
		530	EIA-530	
	-	FT1	Fractional-T1/G.703	
	-	FE1	Fractional-E1/G.703	
	-	E1	E1/G.703	
? or help	Help			
	Usage: help			
	This command ration, entering held usage informationalso be used to in Command Exam	eturns a list p as a subcon n regarding nvoke help. ple:	t of currently available comm ommand before or after a con g the command. A? (question	nands. In addi- nmand returns n mark) can be
	rssi help ENTER	-		
	Returns:			
	Usage: command [subcomman	d] <argument></argument>	
ais	Alarm Indication	signal		
FT1	Usage: ais [linelist	t] [-g <on off< td=""><td>>] [-f <on off>]</on off></td><td></td></on off<>	>] [-f <on off>]</on off>	
E1 FE1	This command en warding [-f] on sj enabled, fault con the appropriate A enabled, AIS/RA passed to the oth	nables or d pecified E1 nditions wit MS/RAI sig I signaling er end of th	isables alarm signal generation /T1 interface lines. When generation thin the link or at the line inter- gnaling to occur. When forward at the line interfaces will be the link.	on [-g] and for- neration is face will cause arding is detected and
	Command Exam	ple:		
	ais -f on -g on			
	Returns:			
	AIS on RAI on			
	NOTE: For pro alarm g	tected configuration t	igurations and full-rate radio hrough the use of the ais -g of	os, disable the

Table 15. Symbols for Interface-Specific Commands



Background on AIS command:

In fractional operation, the radio extracts the required timeslots and data at the input to a link, and reconstructs the full frame at the output end. The AIS <-g (generation)> command, when enabled, allows the radio to override the frame reconstruction process in order to generate a proper all-ones alarm signal. For example, modem loss of synchronization will cause all-ones to be transmitted from the active G.703 ports. When AIS <-g is disabled, the output will consist of a framed signal with all-ones in the active timeslots. In Fractional operation, AIS generation also creates a yellow alarm/RAI back to the defective source when a problem is found at the input. In FE1 mode, when AIS <-g is enabled, loss of Multi-Framing Alignment Sequence (MFAS) at the line receiver will generate a Multi-frame Yellow Alarm (MYEL) or Multi-frame Remote Alarm Indication (MRAI) at the line transmitter.

AIS <-f (forwarding)> is the act of detecting a condition at the input and causing an appropriate response at the other end. For example, with forwarding enabled, an all-ones signal applied at one end causes all-ones to be output at the other. A Remote Alarm Indication (RAI) applied will likewise appear at the opposite end. Disabling the forwarding function limits the presentation of alarm signaling to the active timeslots at the remote end. It is recommended that the ais -f on or ais --g on command be used for Fractional operation, to enable alarm generation and forwarding.

In full-rate modes, the radio will always output AIS when the unit is unlocked—received radio signal is lost. When the modem is locked, and the input is removed from one end, you will get all-zeros at the other end unless AIS generation is enabled. Yellow alarms/RAI are not generated in the full-rate LEDR radio models; however AIS and RAI forwarding are available. It may be desirable to have alarms generated (**ais -g on**) in full rate models, depending on the user's requirements as outlined in the next paragraph.

Since the generation and forwarding operations require use of the Service Channel, the AIS/RAI response times are on the order of a few seconds. Generation and forwarding can be very helpful in correcting problems with the network when they arise. However, in systems where the response time is critical, these modes should be disabled: In fractional mode, enter **ais -f off -g off**. In full-rate mode, enter **ais -g off**.

alarm Alarm I/O

Usage: alarm [in|out] [1-4|all] [subcommand] [arguments]

This command is used to control the four (4) external alarm contacts and to display the state of the four (4) external alarm inputs.

Outputs (Relays)—Alarm outputs may be directly driven to a state, or be mapped to, internal events via the **evmap** command



(Page 57). When mapped to events, the active level may reprogrammed to be either active-open or active-closed. Active means that an event is mapped to an external alarm output that is currently active. (See "Alarm I/O" on Page 20 for electrical parameters and typical examples of alarm usage.)

Inputs—Alarm inputs are used to generate events in the event log and also generate SNMP traps if so programmed by the events filter command. They may be directly read via the **alarm** command, as well. They may also have their active level set to be either active high or low. (**alarm active high**; **alarm active low**)

Naming—Finally, both inputs and outputs may be named by users to allow for easy identification. For example, "Fire Alarm" could be used as the name for Alarm Input 1. Traps are sent with this name so that users may more easily identify the source of the alarm.

Subcommands:

active [open|closed]—Set alarm input/outputs active state.

- set [open|closed] —Latch alarm outputs to one state to ignore events which are assigned to them.
- name [name_string]—Create a user defined "name" for each alarm. 16 characters maximum, no spaces; not compatible with "all".

Command Example #1:

alarm in all

Returns:

alarm:				Active	Current
alarm:	Type	#	Name	Level	Reading
alarm:	=====	=	==================	=====	======
alarm:	Input	1	AlarmInput1	closed	open
alarm:	Input	2	AlarmInput2	closed	open
alarm:	Input	3	AlarmInput3	closed	open
alarm:	Input	4	AlarmInput4	closed	open

Command Example #2:

alarm out 2 set closed

Returns:

alarm:				Active	Current
alarm:	Type	#	Name	Level	Reading
alarm:	======	=		=====	======
alarm:	Output	2	AlarmOutput2	closed	closed

Command Example #3:

alarm in 3

Returns:



	alarm: alarm: alarm: alarm:	Type ===== Input	# = = 3 <i>P</i>	Name ====================================	Active Level ====== closed	Current Reading ====== open
alert	Alert an	other LE	DR F	Radio		-
	Usage: a	lert <3 dig	jit uni	t ID> all		
	This cor function wire har	nmand is allows y idset show	used ou to uld b	l to sound the ale signal a radio ar e picked up.	rt buzzer o id alert sor	n another radio. This neone that the Order-
	The thre the radio determin WIRE"	e-digit no that wil ned by iss on Page	umbe l be s suing 99 fo	er following the co signaled. Radios a the network com r more information	ommand in available fo nand. See on.	dicates the unit ID of or signaling can be "USING ORDER-
arp	Address	Resoluti	on Pi	rotocol (ARP) Se	tting of Etl	hernet Port
	Usage: a	rp [-a -s	[ip ad	dress] -d [ip addre	ess]	
	-a V	view the A	ARP	table		
	-s A f	dd the Il or any ac	P add Idres	ress to the ARP t ses that are added	able. The r l	adio will proxy ARP
	-d C	lelete the	IP ad	ddress from the A	RP table	
	This con a listing figured to are mana connected with a L to allow responding devices.	nmand di of IP add to "spoof aged usin ed at som EDR radi seamless ing to AF	isplay dresso ," or g the e poi io. In s inte RP rec	ys the contents of es of which the ra proxy, for other (radio's out-of-ba nt to a radio's Etl other words, the gration of other I quests and/forwar	the radio's adio is awa (non-LEDF nd Service hernet port radio netwo P-managea rding IP tra	s ARP table, which is re. It can also be con- R radio) devices that channel and directly , or to a common hub ork can be configured able devices by affic directed to those
	See the configur	oute com ation ste ed device	nman ps to es usi	d on Page 78 for allow for IP com ng the radio's net	informatio nectivity to twork-man	n on other necessary LEDR radios and agement channel.
ber	Bit-Erro	r Rate of	the I	RF Link		
	Usage: b	er				
	This cor between	nmand di the LED	isplay OR rae	ys pre-FEC and p dios in the first li	ost-FEC B nk.	it-Error Rate (BER)
	NOTE:	The BE mation	R me on th	easurement limit e link-error rate,	is 1E-8. Fo use the g82	or more reliable infor- 1 demod command.



bert

FT

E1

FE1

Bit-Error Rate Test of Data Interface

Usage: bert [linelist] [-e [pattern] | -d | -i [error] | -lp | -le | stats]

bert is used for diagnostic purposes by causing the selected line of the FT1/E1 interface port lines to output a user-selectable pseudo-random bit sequence, either framed or unframed. This command also allows the user to measure the bit error rate, number of errors, etc. This command tests all T1/E1 timeslots without regard to the timeslot command's configuration.

linelist—List of local line interfaces. Can be single line number or linename (see **linename** command), comma-separated list of line numbers or linenames, a range of line numbers (for example: 1-4), or if **linelist** is not given, all lines will be tested.

NOTE: The hyphen is part of the argument string and must be included for the command to function.

Subcommands:

Control-

-e Enable bert generation/monitoring for line(s)

Can be immediately followed by the test pattern index value (See -lp below). If none is included in the command, the last-used pattern will be implemented.

- -d Disable bert generation/monitoring for line(s)
- -i Inject error. Index specifying type of error to inject. If no error is specified, last error selected is used.

Reference-

- -Ip List available pseudo-random bit patterns (See Table 16 on Page 52 for options.)
- -le List available errors to inject (See Table 17 on Page 53 for options.)

stats Display bert statistics

Table 16. Pseudo-Random Bit Patterns

Index	Description	Data Inversion
0	Unframed 2^11 (Factory Default)	No
1	Unframed 2^15	Yes
2	Unframed 2^20	No
3	Unframed 2^23	Yes
4	Unframed 2^11 with 7 zero limit	No



Index	Description	Data Inversion
5	Unframed 2^15 with 7 zero limit	No
6	Unframed 2^20 with 14 zero limit (QRSS/QRS/QRTS)	No
7	Unframed 2^23 with 14 zero limit (non-standard)	No
8	Framed 2^11	No
9	Framed 2^15	Yes
10	Framed 2^20	No
11	Framed 2^23	Yes
12	Framed 2^11 with 7 zero limit	No
13	Framed 2^15 with 7 zero limit	No
14	Framed 2^20 with 14 zero limit (QRSS/QRS/QRTS)	No
15	Framed 2^23 with 14 zero limit (non-standard)	No

Table 16. Pseudo-Random Bit Patterns

Table 17. Errors to Inject

Index	Description
1	CAS multiframe (MAS) pattern error (E1 only)
2	Fs (T1) or MFAS (E1)
3	PRBS error
4	Change of frame alignment, 1 bit minus
5	Change of frame alignment, E1, 1 bit plus
6	CRC6 for T1, CRC4 for E1
7	Frame bit errorFt, FPS, or FAS bit error depending on current framer mode
8	Linecode violation

Background on BERT command:

The bit error-rate test command, **bert**, is used to evaluate the link between the LEDR data interface and the customer premises equipment (CPE). When used, the LEDR radio will send a test pattern out of the LEDR FT1/E1 Data Interface lines towards the CPE while simultaneously attempting to receive the same pattern back from the CPE. For example, you can loopback the CPE's external data device's I/O, then issue a **bert** command to the LEDR radio to check the integrity of the wire connection. The test pattern can be user-selectable. (See bert command Options above for further information.)

NOTE: The **bert** command will not test or evaluate the integrity of the LEDR radio link. (See "BENCH TESTING OF RADIOS" on Page 124 for further information.)



	NOTE: When operating FT1 or FE1 interfaces, this command tests all T1/E1 timeslots without regard to the timeslot command's configuration.				
boot	Boot from Active/Archive Software				
	Usage: boot [<1 2 -s -o>]				
	This command is used to view or change the radio's active software image. If boot is entered alone, the currently active firmware image (1 or 2) is displayed. A selection of 1 or 2 after the command (e.g., boot 2) ini- tiates a reboot from that image. (A message appears to confirm that you wish to reboot the radio firmware.) Upon reboot, the radio and all radio functions are restarted in a manner similar to turning the radio power off and then on again. The radio is taken out of service until it re-initializes, and the link loses synchronization until the reboot process completes and the demodulators at both ends reacquire the radio signals.				
	A choice of software images allows booting an alternate version of radio software. The ability to have two radio-resident software images allows radio software reprogramming over-the-air and the ability to restore operation to the original software if required.				
	Subcommands:				
	1 Boot from Image 1				
	2 Boot from Image 2				
	-s Boot from the active (<u>s</u> ame) image				
	-o Boot from the inactive (<u>o</u> ther) image				
buzzer	Buzzer				
	Usage: buzzer				
	This command briefly sounds the radio's piezo buzzer for testing. It should be used only from the CONSOLE Port.				
	Example Response:				
	buzzer: Starting test buzzer: Test complete				
clkmode	Clock Mode (Subrate Radios Only)				
530	Usage: clkmode [<internal exttx looped extdce>]</internal exttx looped extdce>				
	This command displays or sets the source of the radio's transmit clock. For synchronization purposes, several different clocking schemes can be used. See "Transmit Clock Selection (Subrate Radios Only)" on Page 23.				



Subcommands:

internal—Internal oscillator sources TC; RC derived from far end of radio link (default).

exttx—ETC accepted from external equipment on EIA-530 interface; RC derived from far end of radio link.

looped—Recovered RF (RX) clock; TC is synchronized to RC; RC is derived from far end of radio link. Note: Do not use looped clocks at both ends of any radio link.

extdce—ETC and ERC are accepted as inputs on the EIA-530 interface.

NOTE: Earlier versions of the software may display the Clock Mode as **NORMAL** instead of **INTERNAL**.

Firmware Version 2.4.0 and Later – Use the **clkmode** command to determine which port has been selected to drive the timing at the interface.

Firmware Version 2.3.1 and Earlier – This command allows the various possible clock sources to be prioritized. As timing sources become available, the highest-priority source will be chosen by the system. If attaching to the network or equipment that provides timing, a universal form of the command would be **clkmode 1 2 3 4** internal. If attaching to equipment that will provide looped-back timing, a universal form of the command would be **clkmode remote internal**. If both ends of the link provide looped timing, the internal clock source should be selected at one end by entering **clkmode internal**. Note that at least one end of the link should have either network or internal timing selected.

NOTE: Firmware versions 2.3.1 and earlier, require that this parameter be properly configured for correct operation of the link. More recent firmware versions do not require that this item be manually configured. However, the **clkmode** command may still be used to determine which port is being used to drive the timing.

Firmware Version 3.0.0 and Later– The **clkmode** command applies only to the EIA-530 interface.

Carrier Offset of Radio Modem

Usage: coffset

This command displays the Modem Carrier Frequency Offset.



coffset



con	Console port configuration on LEDR front panel
	Usage: con (baud [300 1200 2400 4800 9600 19200 38400 115200]) (parity [none even odd])
	This command sets or displays the CONSOLE Port's operating parame- ters. The CONSOLE Port data rate is set or displayed using the baud sub- command. The parity is set or displayed using the parity subcommand.
	The default setting is 9600 bps, no parity, 8 data bits and 1 stop bit.
config	Configuration
	Usage: config [get send getall] [filename console] [hostIP]
	This command is used to get or send a radio configuration file.
	The radio stores its configuration data in a file that you can download using the config send command. The output can be directed to a file or to the NMS window, either in a Telnet session or a serial NMS session. The config send command allows sending the configuration file over the Ethernet management channel and storing it on a PC running a TFTP server.
	Subcommands:
	 send—Upload entire radio configuration file to host (includes all radio-specific data) get—Download radio configuration file from host (DOES NOT download radio-specific data) getall—Download entire radio configuration file from host (including all radio-specific data)
	Radio-specific data includes IP address, network settings, frequencies, target power thresholds, calibration data, and IP routing table.
	Command Example: config send config.txt 192.168.1.14
	This sends the configuration file to a TFTP server running on host 192.168.1.14 and stores it as a file called config.txt.
date	Date
	Usage: date [MM/DD/YYYY]
	This command sets or displays the date and time of the radio's internal real-time clock. The real time clock operates from an internal lithium battery so it is running even if the radio has no DC power connected. The date format may also be set or displayed from this screen for one of three formats: U.S., European, or generic.
	The real time clock is fully compliant with year 2000 standards.



	Subcommands: date format [<1-3>]
	Date Format 1: mm/dd/yyyy (All numbers)
	Date Format 2: dd/mm/yyyy (All numbers)
	Date Format 3: dd-MON-yyyy (English abbreviation of month)
	Example Response: date: 07-JUN-1999 08:11:30
dtren	DTR Handshaking
	Usage: dtren [<on off>]</on off>
	The dtren command sets or displays the status of the DTR (handshaking) input.
	Example Response: dtren: on
ethernet	Ethernet Port's Hardware Address
	Usage: ethernet
	This command displays the fixed hardware address of the radio's Ethernet port. This address is globally unique; it is assigned at the factory and cannot be changed.
events	Events
	Usage: events [subcommand] [<arguments>] Subcommands: pending filter [event#] [count] init desc [<event#>]</event#></arguments>
	This command allows viewing the pending events (pending), sup- pressing the notification of particular events (filter), initializing events processing (init) and display of event descriptions (desc). To turn off log- ging (notification in the event log) for a particular event, the filter count value should be set to zero.
	Events 135-138 are remote alarm in [1-4] , respectively, which reflects the event state of the alarm in [1-4] of the remote-located radio at the other end of the RF link.
	Example Response:
	events {events}: -DEMOD_ACQUISITION (Event #27) events: Event#0 Filter count=1 events {init}: The event log has been re-initialized events {desc}: Event#40 Description- IO2_DIG_REM_LPBACK
evmap	Event Mapping (for Alarm Output and LEDs)



Usage: evmap [subcommand] [event #] [arguments]

This command sets or displays which radio system events cause alarm indications on the front panel LEDs or the rear panel ALARM I/O connector. The user can rename the alarm events, but they cannot be deleted, nor can new ones be created.

The subcommands specify which output will be asserted (led or aout) upon occurrence of an event #. Multiple outputs can be specified with spaces between them. The dump option allows determining the current event mapping for all of the events or, optionally, a specified numeric range of events.

Events 135-138 are remote alarm in [1-4], respectively, which reflects the event state of the alarm in [1-4] of the remote-located radio at the other end of the RF link. Use the event filter counter to enable each particular arrant Ilaa and man to alarma autout contact when

	event. Use evmap and map to alarm output contact when necessary.
	Subcommands:
	<pre>led [ioalarm txalarm rxalarm alarm none]—Maps front panel LED(s) to an event. aout [none 1 2 3 4]—Maps an alarm output(s) to an event. dump [<range>]—Display the LED and alarm output mappings for all events.</range></pre>
	Example Response: evmap: Event #0 LED alarm evmap: Event #0 Alarm Output NONE
	See Figure 8 for reference to the Front Panel LEDs. Refer to <i>Alarm</i> — <i>Rear Panel</i> on Page 131 for the pinouts of the ALARM I/O connector and <i>Disabling the Front Panel Alarm LED for Unused E1 Option Ports</i> on Page 89 for further information.
fec	Forward Error Correction Statistics
	Usage: [fec <clear>]</clear>
	This command displays corrected bytes and uncorrectable FEC block errors.
	Example Response: fec: 1812992 Correctable Bytes fec: 2 Uncorrectable Blocks
freq	Frequency (of TX & RX Channel)
	Usage: freq [<tx rx>] [<freq>] [<freq>]</freq></freq></tx rx>
	This command sets or displays the transmit and receive frequency.
	Example Response: freq {TxFreq}: 942175000 Hz freq {RxFreq}: 944175000 Hz



fset	Frequency Setting		
	Usage: fset [<min freq="">] [<max freq="">]</max></min>		
	This command sets the absolute frequency limits of the transmitter and receiver.		
	Example Response	fset {Tx MinFreq}: 135000000 Hz fset {Tx MaxFreq}: 1535000000 Hz fset {Rx MinFreq}: 135000000 Hz fset {Rx MaxFreq}: 1535000000 Hz	
fstruct	Frame Structure		
FT1	Usage: fstruct [linelist]	[mode <0-7 none>]	
E1 FE1	This command is used to set or display the span(s) frame structure. T [linelist] variable represents a list of line interfaces. This entry can be either a single line number or line name (see linename command), a comma-separated list of line numbers or line names, a range of line numbers (i.e., 1-4), or if linelist is not given <i>all</i> lines.		
	In general this param	peter should be configured to match the frame	

In general, this parameter should be configured to match the frame structure used by the customer premises equipment. The **fstruct** command also controls the generation of performance report messages in ESF modes. In E1 radios, an unframed mode is available by issuing the command **fstruct mode 8**.

In Fractional-E1 mode timeslot 0 is always sent, and for fstruct modes 4 through 7, timeslot 16 must be added to the payload list for proper operation.

Table 18 shows a list of line mode values for T1 interfaces and Table 19 for E1 interfaces.

Value	Mode
0	FT only (default)
1	ESF
2	ESF + PRM
3	SF
4	SF + JYEL
5	ESF + CRC
6	ESF + CRC +PRM

Table 18. T1 Frame's Line Mode Values



		Value	Mode	
	—	0	FAS only (default)	
	_	1	FAS + BSLIP	
		2	FAS + CRC	
		3	FAS + CRC + BSLIP	
	_	4	FAS + CAS	
		5	FAS + CAS + BSLIP	
	_	6	FAS + CRC + CAS	
		7	FAS + CRC + CAS + BSLIP	
	_	8	Raw, unframed, transparent mode.	
g821	G.821 Informatio	on		
	Usage: demod io1	io2 io3	io4 all [clr]	
	This command is	sused	to show or reset the radio's G.82	1 information.
	The LEDR famil display of four ca able seconds, err able seconds.	y of ra ategori ored se	dios support the ITU G.821 recon es of statistical availability inform econds, severely errored seconds,	nmendation for mation: avail- , and unavail-
	Example Respon	ise: [se: [se: [se: [se: [se: [se: [] se: []	Demodulator: ERROR FREE Savail: 1036 Sunavail: 0 ES: 0 SES: 0	
group	Group Number in	n LED	R System	
	Usage: Group [<0-	99>]		
	This command se operating.	This command sets or displays the network group in which the radio is operating.		
	Example Respon	Example Response: group: 1		
	In a typical syste allowing the flow between radios a repeater site, all r group zero) for th numbers differen from a network-r works and contro Across a radio lir ically connected must have the sam	In a typical system, all the radios would operate in the same group, allowing the flow of network-management and orderwire activity between radios and from one radio link to any other in the system. At a repeater site, all radios must be set to the same "group number" (and not group zero) for this flow of information to take place. Setting group numbers differently in repeater systems isolates links from each other from a network-management perspective, allowing segmenting net- works and controlling the flow of network-management information. Across a radio link, groups can differ from each other; only radios phys- ically connected by Ethernet cables to each other or to the same hub must have the same group number to intercommunicate.		

Table 19. E1 Frame's Line Mode Values



	Systems Inc.
	Setting a radio's group to zero prohibits <i>all</i> network management traffic from flowing to and from that radio's Ethernet port.
help or?	Help for Users
	Usage: help
	This command can be used alone, to list all available commands, or with a specific command, to provide syntax assistance. Entering help before or after a command will display the usage and possible subcommands of the command. The character? may also be used to obtain help.
http	HTTP Server in LEDR Radio
	Usage: http
	Displays the status of the radio's internal HTTP server accessible through the radio's ETHERNET Port. The HTTP server supports browser-based management. Use the http command by itself to verify the server is running and http start command to reboot the server.
ісору	Image Copy
	Usage: icopy [<app dsp fpga scripts>]</app dsp fpga scripts>
	This command is used to copy the active software image to the inactive software image.
	Each radio stores two independent firmware files that control the radio's operation. The radio uses one of the files as the active software, which is running. The other software file is inactive and is not running. The ability to have two firmware images allows firmware reprogramming to be done over-the-air and provides the ability to restore operation to the original software if required. The icopy command allows copying all, or a selected subset, of the regions of the active image to the inactive image area. This is typically used to update the inactive image after loading new firmware and rebooting the radio from the new image.
	To view or change the active firmware image see "boot" on Page 54.
idlepat	Idle Pattern
FT1	Usage: idlepat [<linelist>] [slots <slotlist>] <pattern></pattern></slotlist></linelist>
FE1	This command is used to set or display the bit-pattern used in the idle timeslots. Some equipment requires a particular pattern. To set the bits to all ones, use the command idlepat ff . To set the bits to a zero followed

to subrate models.

by seven ones, use the command idlepat 7f. This command does not apply



	Argument Definitions:	
	linelist—Represents a list of line interfaces. It can consist of a single line number or linename, a comma separated list of line num- bers or line names, a range of line numbers (i.e., 1–4) or, if linelist is not given, all lines. See Table 18 on Page 59 for a list of line numbers.	
	slotlist—A list of timeslots consisting of a single slot number, comma separated list of slot numbers, or a range of slot num- bers (i.e., 2-8).	
	pattern—A 2 hex digit value (default value is 17).	
info	Information as Selected by User	
	Usage: info [<owner description contact name location>] [<string>] info clear [<owner description contact name location>]</owner description contact name location></string></owner description contact name location>	
	This command is used to program information into (or clear it from) radio memory that is particular to the radio site or installation. The information is intended for identification and memorandum needs.	
	Five text fields are provided. The owner's name string is limited to 10 characters. The description, contact, location, and name text fields are limited to 254 characters. Any standard, printable ASCII characters are allowed. The description field is programmed at the factory and is not user-definable.	
	To display the owner's name text field enter info owner. To display the contact information enter info contact. To display the name information enter info name. To display the location information enter info location. To display all the parameters enter info.	
	To change the info text, enter text after info owner or other info field name.	
interface	Interface for User Data	
530	Usage: interface [e1 t1 530]	
E1 FE1	This command is used to set or display the payload data interface. If an optional data interface board is installed, the user may select between the T1 or E1 interface modes. The system will recommend a reboot and provide a prompt to do so.	
	Example Response:	
	interface {Line}: e1	



NOTE: 1E1 through 4E1 data rates are not supported when using the EIA-530 interface. The maximum EIA-530 data rate is 768 kbps.

	1		
interleave	Interleave		
	Usage: interleave [1-12]		
	This command is used to set or display the interleave depth. Range: 1–12. Default: 12. (Actual values are 1, 2, 3, 4, 6 and 12.) The interleave setting must match at both ends of a radio link, or the link cannot synchronize regardless of any other radio settings or signal strength. Larger interleave settings cause longer link latency; in latency-sensitive applications, interleave value should be reduced to as small a value as is possible while maintaining good link performance (See the g821 demod command).		
	Example Response:		
	interleave: 1		
	Background:		
	In digital communications, interference often occurs in the form of short noise bursts. These bursts normally corrupt a series of consecutive bits.		
	Interleaving is a digital algorithm that allows Forward Error Correction (FEC) to better handle bursts of noise. Interleaving reorders the data so that the symbols that would normally be neighbors in a given block are spread among multiple blocks. FEC works on a block of data of a specific size and can properly correct errors as long as the number of errors is small enough. With interleaving, the number of errors that occur within a single block is reduced, thereby allowing the FEC to more effectively correct burst errors.		
	The value of the interleaver function should not be changed unless there are latency limitations for the radio link. If low latency is required, then the interleave can be changed, but the ability to correct for the influence of burst-noise on the BER will be reduced.		
ір	Internet Protocol Settings		
	Usage: ip [subcommand] [<argument>]</argument>		
	Subcommands:		
	address [x.x.x.x] netmask [x.x.x.x] gateway [x.x.x.x] IP port [ETH AIR]		



	This command sets or displays the Internet Protocol (IP) settings LEDR radio. The subcommands allow you to set the IP address mask, IP gateway, or IP port. The port setting determines whether munication to and from a particular radio occurs over the radio via a PC (or other networked device, such as a router) directly con to the radio's ETHERNET port. See "Network" on Page 39 for ad- information.		
	Example Response:	IP Address: 10.2.142.143 IP Netmask: 255.255.0.0 IP Gateway: 0.0.0.0 IP Port: ETH	
iverify	Image Integrity Verif	ication	
	Usage: iverify [image <1 2>] [<app dsp fpga scripts>]</app dsp fpga scripts>		
	This command is used ware image files that	d to determine the data integrity of the two firm- reside in the radio. (See also icopy , above.)	
	Example Response:		
	iverify: Image has been verified		
lcd	Liquid Crystal Displa	y Test	
	Usage: Icd [<on off rest< td=""><td>core>]</td></on off rest<>	core>]	
	This command starts When Icd is first entered When the RETURN keepletely blank.	a two-part test of the radio's front panel LCD. ed, the display should appear with all blocks black. ey is pressed, the screen should change to com-	
led	Light Emitting Diode	s (LEDs on Front Panel)	
	Usage: led [<alarm rxal< td=""><td>arm txalarm ioalarm all restore>] [<on off>]</on off></td></alarm rxal<>	arm txalarm ioalarm all restore>] [<on off>]</on off>	
	This command is used given, all front panel Press Control-C to en LED for Unused E1 (d to test the front panel LEDs. If no argument is LEDs (except POWER) should flash in sequence. d the test. (See "Disabling the Front Panel Alarm Option Ports" on Page 89 for further information.)	
	Command Example:		
	led alarm on		
	Returns:		
	led: Alarm LED ON		


line

FT1 E1 FE1

FT1

Attributes of lines (cables) used with the LEDR's T1 or E1 Interface.

This command is used to set or display the internal pulse template selection used by the LEDR interface to compensate for signal distortion created by various lengths and types of interface cables.

The **[linelist]** variable represents a list of line interfaces. It can consist of a single line number or line name, a comma-separated list of line numbers or line names, a range of line numbers (i.e., 1–4), or if linelist is not given all lines will be displayed. See Table 18 on Page 59 for a list of line numbers.

Usage For T1: line [linelist] [cable length<0-4>] [spec]

T1 interfaces require setting of a minimum of two variables: cable length and ITU cable specification. Table 20 show specification options and Table 21 the lists values used for various lengths of standard 100 Ω twisted pair cables.

Table 20. ITU Cable Specifications—Subcommand [spec]

Specification	
g.775 (Default)	
i.431	

Table 21.	T1 Cable Length	Values—Subcommand	[cable length]
-----------	-----------------	-------------------	----------------

Value	Line Length (Meters)	Line Length (Feet)
0	0.3 to 40 (Default)	1 to 133 feet (Default)
1	40 to 81	133 to 266 feet
2	81 to 122	266 to 399 feet
3	122 to 163	399 to 533 feet
4	163 to 200	533 to 655 feet



E1 FE1 Usage For E1: line [linelist] [spec]

The only cable specification needed for E1 is the ITU cable type.

Table 22 lists values used for various specifications for standard 120 Ω ITU-T G.703 cables.

Table 22.	E1 Cable	Specifications-	-Subcommand	[spec]
-----------	----------	-----------------	-------------	--------

Specification	
g.775 (Default)	
i.431	

Command Example:

LEDR> line

Returns:

line {LINE1} {cable}: ITU-T G.703 120 Ω Twisted Pair {spec}: i.431 line {LINE2} {cable}: ITU-T G.703 120 Ω Twisted Pair {spec}: g.775 line {LINE3} {cable}: ITU-T G.703 120 Ω Twisted Pair {spec}: g.775 line {LINE4} {cable}: ITU-T G.703 120 Ω Twisted Pair {spec}: g.775

linecode	Line Code
FT1	Usage: linecode [linelist] [B8ZS AMI HDB3]
E1 FE1	This command sets or displays the radio's linecode (T1: B8ZS or AMI; E1: HDB3 or AMI).
	The [linelist] variable represents a list of line interfaces. It can consist of a single line number or line name, a comma-separated list of line numbers or line names, a range of line numbers (i.e., 1–4), or if linelist is not given all lines will be displayed. See Table 18 on Page 59 for a list of line numbers.
	The most typical Fractional-T1 selection is to choose B8ZS for all ports by entering linecode b8zs and E1 interfaces choose HDB3 for all ports by entering linecode hdb3 .
	Example Response:
	linecode: HDB3
linemap	Line Mapping
	Usage: linemap [maplist]



This command is used to set or display the current span mapping configuration for E1 and T1 configurations. The **maplist** variable consists of from 1 to 4 alpha-numeric characters specifying line interface to span mapping. Valid numbers are 1–4. Valid span characters are a–d.

Example: Entering linemap 1d 2b 3a 4c causes the following:

maps line 1 to span d maps line 2 to span b maps line 3 to span a maps line 4 to span c

Figure 16 shows the example pictorially. There are no restrictions of which lines are mapped to which data channel spans.



Figure 16. Example of Linemapping

NOTE: The cluster of four RJ-45 jacks on the rear of the radio is coded from left to right as 1, 2, 3 and 4 as viewed from the outside of the chassis.

	chassis.
linename	Line Name
FT1	Usage: linename <linelist> <namelist></namelist></linelist>
E1 FE1	This command is used to set or display meaningful names of up to 16 characters to the four possible line interfaces. The [linelist] variable represents a list of line interfaces. It can consist of a single line number or line name, a comma separated list of line numbers or line names, a range of line numbers (i.e., 1–4) or, if linelist is not given, <i>all</i> lines. See Table 18 on Page 59 for a list of line numbers.
	The namelist variable consists of a list of names. It can consist of a single name or a comma/whitespace-separated list of names. Names can be up to 16 characters long.
linerr	Line Errors
	Usage: linerr [linelist] [on off]





[FT1
[E1
	FE1

log

This command measures and displays the line performance between the radio and customer equipment. Entering the command linerr on will initialize the line error measurement feature. The [linelist] variable represents a list of line interfaces. It can consist of a single line number or line name, a comma-separated list of line numbers or line names, a range of line numbers (i.e., 1–4), or if linelist is not given all lines will be displayed. See Table 18 on Page 59 for a list of line numbers.

Log of Events

Usage: log [subcommand] [<argument>]

Subcommands: view [critical|major|minor|inform] clear send [filename] [hostIP]

This command is used to display and manage the event log file. Without a subcommand, the complete log file will be displayed one page at a time. If you are interested in less than the full report, use one of the following subcommands:

view—Sets or displays the types of events to be displayed.

clear—Resets the event log and purges all events from memory.

send—Uploads the event log information to an IP address using TFTP protocol in a way similar to the **config** command. (See config command on Page 56.)

NOTE: When setting up a link for the first time, after powering up the unit, you may want to clear the event log. After logging in as **SUPER**, enter the command **log clear**.

login

Log Into the CONSOLE Port

Usage: login [username]

This command allows access to configuration and diagnostics information as allowed by the radio system administrator. You can shorten the login sequence by following the **login** command with the user/account name (**username**).

Example:

LEDR> login

Returns:

Username>

Type: fieldserv (or appropriate user name)



Returns:

Password>

Type: (password)

NOTE: User names and passwords must not exceed eight characters and are case sensitive. Do not use punctuation marks. See user command on Page 86 for more information on user access levels. **NOTE:** Only one user can be logged in through the CONSOLE Port at a time. Any new login will close the previous user/account. Other users can login simultaneously through the ETHERNET Port or front panel. logout Logout Usage: logout This command is used to log out a user. Subcommands: loopback Loopback Functions The loopback command is used to set or display the loopback mode that can be used for diagnostic purposes. Entering loopback without any parameters displays the current loopback mode. Various data loopback modes can be used for diagnostic purposes. To loop back Line Interface 1 towards itself, use loopback iol 1. To loop back all line interfaces towards themselves and test the T1 option, use loopback local. To loop back all data at the remote site towards the RF path, use loopback remote. Entering loopback without any parameters displays the current loopback mode. Usage 1 for Fractional-T1: loopback [none|rf|local|remote|iol [linelist]|ior [linelist] <timeout>] Usage 1 Subcommands: iol-The iol subcommand, for "I/O local," refers to the *local* line loopback. local—Enables a local digital loopback mode. With this test, incoming bits on the EIA-530 interface are sent back out the radio's DATA connector before the modem module. This can be used to verify proper interconnection between the radio and the connected equipment. None



of the radio's RF circuitry is involved in this test. (This description covers only EIA-530 operation.)

For T1/E1 operation, the **local** subcommand enables a local digital MUX loopback in the radio transceiver's FT1 Interface Board before going out to the main transceiver board.

none—Disables all loopback operation. This is the mode for normal point-to-point operation.

remote—*EIA-530 Operation:* Instructs the radio at the other end of the link to "echo" all of the data it receives. This is an effective way of testing the entire communications system, including the transmission path over the air. (In the event of a communications failure with the remote radio, the message "Remote Error" is displayed, and no loopback mode is selected.

T1/E1 Operation: The **remote** subcommand mimics the **ior** subcommand described below.

rf—Enables an RF loopback mode. This mode allows testing of the local radio transceiver's transmit and receive chain.

NOTE: RF loopback testing is a valuable diagnostic tool, but it should not be considered an exhaustive test of the transceiver. In some cases, interaction between the transmit and receive phase-locked loops (PLLs) can occur, causing erroneous results during testing. Changing the transceiver's RF output setting may resolve these problems. Also, in some configurations, insufficient signal strength for RF loopback testing may exist.

In addition, on all LEDR radios except the LEDR 1400 Series, the transmit and receive frequencies must be within the same subband for RF loopback to function.

Variables:

ior—An abbreviation for "I/O remote", refers to the *remote* line loopback. Remote loopback port selection is relative to the local port. The radio link will translate any line mapping to select the correct physical remote port to loop back, based on the selected local port.

linelist—Represents a list of local line interfaces. It can consist of a single line number or line name, a comma-separated list of line numbers or line names, a range of line numbers (i.e., 1–4), or if linelist is not given *all* lines. See Table 18 on Page 59 for a list of line numbers.

timeout—The timeout variable may be set between 0 minutes (never time out) and 60 minutes.



Usage 2: loopback [inb|outb] [linelist] [on|off] [-u <code>] [-d <code>]

FT1 E1 FE1

Lleane 2	(E1)	subcommands
Usaye z (Subcommanus.

inb—Refers to the *inband* loopback configuration.

outb—Refers to the *outband* Extended Super Frame (ESF) loopback configuration.

linelist—Represents a list of local line interfaces. It can consist of a single line number or line name, a comma-separated list of line numbers or line names, a range of line numbers (i.e., 1–4) or, if linelist is not given, *all* lines. See Table 18 on Page 59 for a list of line numbers.

on|off—To turn the loopback feature on or off.

-u <code>—Allows setting of the inband|outband loopback *upcode*.

The inband code consists of 1-7 bits, binary format.

Example: 00001

-d <code>—The subcommand allows setting of the inband|outband loop-back *downcode*.

The outband code consists of 6 bits within the 16 bit ESF data link codeword.

Example: 000111 within 16 bit codeword: 0<000111>0 1111111

model

Model Number

Usage: model

This command displays the radio model number. This information is programmed at the factory and cannot be changed.



modem

Modem

Usage: modem [matrix id] [+cas]

This command sets or displays the radio modem modulation type and data rate. Table 23 shows the alphanumeric codes that can be entered for fullrate radios and Table 24 for codes for subrate radios. Note that the E1 selections are only valid on fullrate radios.

Table 23. Modem Command Arguments for E1 (Fullrate) Radios¹

	DATA RATES					
Modulation Type	1xE1	2xE1	3xE1	4xE1		
QPSK	A7	—	—	—		
16 QAM	B7	B8	—	—		
32 QAM	C7	C8	C9	C10		

1. The available selections depend on the radio's factory programmed bandwidth. See Table 9 on Page 22 for the allowable combinations of bandwidth, data rates and modulation types.

Table 24. Modem Command Arguments forEIA-530 & FT1 (Subrate) Radios1

		DATA RATES				
Modulation Type	64 kbps	128 kbps	256 kbps	384 kbps	512 kbps	768 kbps
QPSK	A1	A2	A3	—	_	_
16 QAM	B1	B2	B3	B4	B5	B6
32 QAM	—	—	—	—	_	C6

1. The available selections depend on the radio's factory programmed bandwidth. See Table 9 on Page 22 for the allowable combinations of bandwidth, data rates and modulation types.

Command Examples:

To set 32 QAM with 1xE1, enter modem C7 To set 16 QAM/384 kbps, enter modem B4

Special-Order Argument

NOTE: The **cas** command functions only in radios equipped with either the FT1 or FE1 Interface and user firmware of revision 3.0 or higher.



FT1 FE1	cas—Set o Fractional- modem +cas Robbed-Bi command, handling o	cas —Set or display the Channel Associated Signaling (CAS) status for Fractional-T1 or Fractional-E1 operation. The available selections are modem +cas (on) and modem -cas (off). This command provides for FT1 Robbed-Bit Signaling bits to pass over the link. In the FE1 case, this command, in conjunction with the fstruct command, ensures the proper handling of the timeslot 16 signaling bid.						
network	Network	Network						
	Usage: netv	Usage: network						
	This comm Channel fo nostics.	This command displays the radios that can be reached via the Service Channel for Orderwire and Element Management System (EMS) diag- nostics.						
	Example R	lesponse:						
	Network Address 10.2.142.148 10.2.200.196	Netmask 255.255.0.0 255.255.0.0	RF Hops 0 1	Ethernet Hops 0 0	Received on Port LPBK AIR	Owner Tech Serv 1 Tech Serv 2		
passwd	Password							
	Usage: pas	swd						
	This comm logged in. tive.	nand is used to A maximum o	change f 8 char	the passwo acters is all	rd for the us owed, and it	ser currently is case sensi-		
ping	Ping IP Ad	ldress (Send IC	CMP Ec	ho Request))			
	Usage: ping	g [ip address] [re	eps]					
	This comm network to This comm	This command is used to verify the accessibility of any IP address on the network to determine availability and measure network response time. This commands requires proper IP Routing and IP connectivity.						
	ipaddress—	IP address to v	which y	ou will send	the request			
	reps - Num	ber of request	s-to-sen	d (default =	$1, \max = 10$)00)		
	Example:	Example:						
	LEDR> ping	10.2.233.12 5						
	Example R	Response:						
	PING 10.2.233.12: 56 data bytes 64 bytes from 10.2.233.12: seq=1, ttl=255, rtt=49ms 64 bytes from 10.2.233.12: seq=2, ttl=255, rtt=6ms 64 bytes from 10.2.233.12: seq=3, ttl=255, rtt=9ms 64 bytes from 10.2.233.12: seq=4, ttl=255, rtt=33ms 64 bytes from 10.2.233.12: seq=5, ttl=255, rtt=12ms							



pll	Phase Locked Loop		
	Displays several key t imum frequency step, TX & RX frequencies	frequency control parameters, including the Min- the reference frequency, oscillator output, current s, and TX/RX PLL status.	
	Example Response:		
	pll:		
	Min Freq Step = 25000 H Tx Freq = 438075000 Hz, Tx PLL Status: Locked Rx PLL Status: Locked	z, Reference = 400000 Hz, ICPO = 1600 uA Rx Freq = 428075000	
pmmode	Power Measurement	Mode	
	Usage: pmmode <on of< th=""><th>f></th></on of<>	f>	
	This command is used mitter frequency for the quency stability using	to generate an unmodulated carrier on the trans- he purpose of measuring RF output power or fre- g a spectrum analyzer.	
	Example Response:		
	pmmode: off		
	NOTE: Enabling the the local line	e power measurement mode (pmmode on) will take k down (out-of-service).	
rdnt	Redundant (Protected	Operation)	
	The rdnt command is radio and display oper	used to manage protected operation of the LEDR rating status.	
	Usage: rdnt [subcomma	and] [arguments]	
	Subcommands:	active default hitless ip mode nsd status swxcyr	
		temp mode	
	The following subcon read and set.	nmands are divided into two groups: read only and	
	Read Only		

active—Shows whether the currently selected transmitter is active or inactive.



default—Displays whether the radio is the default radio in a protected configuration.

status—Protected status of this radio and the sibling radio.

Read & Set

hitless—Sets or displays the hitless (error-free) switching status of the receivers. It can be enabled or disabled using the **hitless on|off** command. In protected operation, either receiver (regardless of which transmitter is active) can provide data to the user data port(s) in hitless mode. In non-hitless mode, only the receiver in the active radio provides received data. Radios operated in a space-diversity configuration must be configured to use hitless switching.

ip—Used to set or display the IP address to be kept in the memory of this unit of the associated (sibling) radio in a redundant pair of transceivers. In other words, the **rdnt ip** setting of the top radio in a protected pair must be set to the bottom radio's IP address for proper switching and network-management functionality.

NOTE: The associated radio (sibling) IP address should be programmed to the IP address of the other radio connected to the Protected Switch Chassis. The associated radio IP address is used by the redundant radio to share information between the units. This address is necessary for warm-standby switching. The associated radio IP address parameters do not affect IP routing and forwarding, SNMP, or Telnet.

The **rdnt swxcvr** will not operate correctly if this parameter is not set correctly.

mode [#]—Set or display one of three redundant operation modes (0 =Standalone, 1 = 1+1 Hot Standby, 2 = 1+1 Warm Standby).

status—Shows the state of both radios. Two status lines are displayed; This Radio and Other Radio.

swxcvr—Forces a switchover to the inactive radio transceiver. (The newly selected unit becomes the active transceiver.) The **rdnt ip** parameter must be configured correctly on both radios in order for the **swxcvr** command to operate correctly.

NOTE: The rdnt swxcvr command should not be used within 2 minutes of a power-up to ensure reliable communications exist between the two transceivers.

temp—Set or display an over-temperature threshold (final amplifier temperature in degrees Celsius), at which temperature switchover to the other radio occurs.



nsd—Enable or disable network self-discovery between the units in a protected pair

Example Response for rdnt command:

rdnt {status}: This Radio = OK rdnt {status}: Other Radio = OK rdnt {active}: inactive rdnt {mode}: 1+1 Hot Standby rdnt {ip}: 10.2.233.12 rdnt {hitless}: on rdnt {default}: no rdnt {temp}: 50 rdnt {nsd}: on

	rdnt {default}: no rdnt {temp}: 50 rdnt {nsd}: on
reframe	Reframe Criteria for User Interface Ports
FT1	Usage: reframe [linelist] [2of4 2of5 2of6 CFAS CRC]
E1 FE1	This command is used to set or display the reframe criteria. The [linelist] variable represents a list of line interfaces. It can consist of a single line number or linename, a comma separated list of line numbers or line names, a range of line numbers (i.e., 1–4), or if linelist is not given <i>all</i> lines. See Table 18 on Page 59 for a list of line numbers.
	For Fractional-T1:
	20f4 $- 2$ out of 4 Fbit errors (default) 20f5 $- 2$ out of 5 Fbit errors 20f6 $- 2$ out of 6 Fbit errors
	For E1:
	CFAS – Consecutive FAS errors (default) CRC – 915 CRC (rx framer only)
reprogram	Load Radio Firmware Into LEDR Radio
	Usage: reprogram [subcommand] [<argument>]</argument>
	Subcommands:network [filename] [hostIP] status
	This write command loads the radio application software (firmware) into the LEDR chassis from an external resource using Trivial File Transfer Protocol (TFTP). A TFTP server must be running on the net- work and properly configured to serve the necessary file(s). See "OPTION 3: Uploading Firmware from a Remote Server via Ethernet" on Page 97 for further details.
rfocal	Transmitter RF Output Calibration Table
	Usage: rfocal <freq region#=""> <cal-point#></cal-point#></freq>



This command starts the **RFOUT** Calibration Sequence and should only be used when directed by MDS factory personnel.

ffect ent. MDS nand. ure for
f I I I I

Recalibration may be necessary if the radio's transmitting frequency has been significantly changed. For the LEDR 400 and 900 radios, this is generally a change of more than two radio channels. In addition, it is very important to verify the power calibration is *incorrect* on the new frequency by measurement with a calibrated external wattmeter before using this command.

The radio frequencies of the LEDR 1400 radio can be changed without impacting the accuracy of the power metering circuit's calibration.

Example Entry: rfocal

Example Response:

	Region 0 Index 0, Rfout = 18 dbm, Gain = 17 Index 1, Rfout = 20 dbm, Gain = 28 Index 2, Rfout = 22 dbm, Gain = 47 Index 3, Rfout = 25 dbm, Gain = 79 Index 4, Rfout = 27 dbm, Gain = 110 Index 5, Rfout = 30 dbm, Gain = 170 Index 6, Rfout = 32 dbm, Gain = 210
rfout	RF Output Level Measurement
	Usage: rfout
	This command displays the transmitter RF power output in dBm. See "Watts-dBm-Volts Conversion" on Page 132.
rlogin	Remote Login
	Usage: [<tounitid>} [<username>]</username></tounitid>
	The rlogin command is used to login to a remotely located radio via the CONSOLE Port. It can be used to log into any radio that appears in the network command display.



route

Routing Tables for IP

Usage: route [command [destination] [mask netmask] [gateway] [port]]

The **route** command is used to add, delete or modify the IP routing table entries. Other radios in the network are automatically added to the routing table using the radio's "Network Self-Discovery." Routing IP traffic to other devices via the radio's management channel can be performed by adding routes to the radio's routing table.

Once the IP configuration is set using the *ip* command (Page 63), several routing entries will appear in the routing table. The first of these routes is the default route which has a destination address of 0.0.0.0. This route is used when a more appropriate route is not available. Thus it becomes the "catch-all" route. The second route that will appear is the default network route. This route has a destination address calculated by "anding" the IP address and subnet mask together. The Next Hop address of this entry will be the default gateway configured using the *ip* command and the Interface will be the default port. This route is used to tell the radio how to reach its base network.

The third route that is added has a destination address of 127.0.0.1. This is known as the loopback route and is used when the radio sends a packet to its own IP address.

Primary Commands:

print —Show the current IP routing table

add [address] mask [netmask] [gw] [port]-Add/Change a route

gw is a gateway IP address

port is specified as either "ETH" or "AIR"

delete [address] mask [netmask] [gw]-Delete a route

gw is a gateway IP address

stored—Display all user-added stored routes

flush—Deletes all stored routes

destination—Specifies the host to send command

Command Arguments:

mask—Where the mask keyword is present, the next parameter is interpreted as the netmask parameter.

netmask—Specifies a sub-net mask value to be associated with this route entry.

gateway—Specifies gateway IP address



port-Specifies IP port, either "ETH" or "AIR"

Example 1 Entry:

LEDR> route add 10.2.150.1 mask 255.255.255.255 10.2.150.101 air

Example 1 Response:

route: Route added

Example 2 Entry:

LEDR> route stored

Example 2 Response:

DestinationNet MaskNext HopInterface 10.2.150.1255.255.255.25510.2.150.101AIR 10.2.140.0255.255.255.010.2.227.51ETH

Example 3 Entry:

LEDR> route print

Example 3 Response:

DestinationNet MaskNext HopInterface 0.0.0.00.0.0 0.0.0.0ETH 10.2.140.0255.255.255.010.2.227.51ETH 10.2.150.1255.255.255.25510.2.150.101AIR 127.0.0.1255.255.255.25510.2.227.5LPBK

Background:

The LEDR Series of radios can be configured to pass IP management traffic across the radio's raw service channel. A process called "network self-discovery" automatically configures IP routes between all radios in a network (provided that the **group** command has been correctly configured throughout the system. (See "group" on Page 60). Also, see the arp command on Page 51.

IP management traffic routing allows configuring and monitoring devices other than LEDR radios using the same management channel, providing clean integration of SNMP, Telnet, TFTP, and other IP management methods via one channel that doesn't use any of the customer payload bandwidth of the radio network.

Routes must be added to the radios at two points in the system to support routing IP traffic to and from the connected devices: 1. At the gateway end (where the management station is located), and 2. At the destination end. Routes are added to the radios using the same convention as used in the MS Windows, Windows NT, and DOS operating environments. The exceptions here are that a mask and port must be specified, as well as the target and gateway IP addresses. At both ends, the command used is exactly the same (see command Example 1, above). In the command



example given above, the route is being added at the gateway end. The difference is that at the gateway end, the port is **air**, and at the destination end, the port is **eth**. Routes do not need to be added at points between the gateway and destination, because the radio network handles the routing between radios via network self-discovery. However, in each radio, the IP gateway must be specified as the IP address of the radio at the network-management gateway in the system.

NOTE: Gateway Settings in Connected Devices

In the connected IP-manageable device, use the local radio's IP address as the default IP gateway for the device.

NOTE: Routing in Protected Systems

Each route added to a protected radio must be added to both units in the protected pair, as they are stored separately. The radios in a protected pair proxy for one another depending on which radio is active, so the routing functionality is unchanged and either radio in a protected pair can be specified as the gateway for a connected device; but if a protected LEDR radio is removed for servicing, all the routing information must be programmed in the remaining radio for proper IP management functionality.

rssi	Received Signal Strength Indicator			
	Usage: rssi			
	This command displays the received signal strength. The measurements is in dBm. Therefore, an RSSI of -80 dBm is stronger than a -100 dE signal.	This command displays the received signal strength. The measurement is in dBm. Therefore, an RSSI of -80 dBm is stronger than a -100 dBm signal.		
rssical	RSSI Calibration	RSSI Calibration		
	Usage: rssical <freq region#=""> <cal-point#></cal-point#></freq>	Usage: rssical <freq region#=""> <cal-point#></cal-point#></freq>		
	This command starts the RSSI Calibration Sequence. See rfocal com- mand on Page 76 for conditions.			
	CAUTION: This command should never be used unless calibrated test equipment has shown the radio to have inaccurat RSSI calibration. Contact the Technical Services Group at MDS for further instructions before usin this command.	d æ ng		
	Example entry: reside			

Example entry: rssical

Example Response:



	Region 0 Index 0, RSSI = -110 dbm Index 1, RSSI = -90 dbm Index 2, RSSI = -75 dbm Index 3, RSSI = -60 dbm Index 4, RSSI = -45 dbm Index 5, RSSI = -30 dbm	n, Gain = –104 , Gain = –40 , Gain = +1 , Gain = +28 , Gain = +61 , Gain = +97
rxlock	Receiver locked onto	Remote radio
	Usage: rxlock	
	This command display	ys the current modem synchronization status.
	Example Response: rx	lock: Modem is locked
sabytes	SA Bytes in E1 Multi	-framing
E1	Usage: sabytes [linelist] [bytes <bytelist>]</bytelist>
	This command is used The [linelist] variable r a single line number of bers or line names, a r given <i>all</i> lines. See Ta	It to set or display SA bytes in E1 multiframing. epresents a list of line interfaces. It can consist of or line name, a comma-separated list of line num- ange of line numbers (i.e., $1-4$), or if linelist is not able 18 on Page 59 for a list of line numbers.
	The bytelist variable co To keep a bytes prese fying SA[7] only) use Example: sabytes 1 byt	onsists 5 hex bytes (i.e., 3c) representing SA[4-8]. nt value when modifying higher bytes (i.e., modi- a * character in the respective byte position. tes *,*,*,3c changes only SA[7] for line 1 to 3c.
sernum	Serial Number of Rad	lio
	Usage: sernum	
	This command display played with this comm serial number sticker	ys the serial number of the radio. The number dis- nand matches the serial number printed on the on the radio chassis.
snmpcomm	SNMP Community N	ames
	Usage: [<read write trap< td=""><td>>>][<string>]</string></td></read write trap<>	>>][<string>]</string>
	This command is used munity names are pas management station a security to the radio s non-default communi community names in	to set or display SNMP community names. Com- swords that are required to match at the SNMP nd each radio or other SNMP agent. You can add ystem's network management by choosing ty names (listed in the example) and setting the your management software to match.
	Example Response:	snmpcomm {read}: public snmpcomm {write}: private snmpcomm {trap}: public



snr	Signal-to-Noise Ratio of Incoming RF Signal
	Usage: snr
	This command displays the signal-to-noise ratio (SNR) of the received signal in dB. The SNR is an indication of the quality of the received signal. The higher this number, the higher the quality of the received signal. SNR readings are invalid when the receiver is unlocked. See rxlock command for details.
status	Status
	Usage: status
	This command is used to display key performance and configuration
	data.
	Example Response:
	status {Tx Freq}:438075000 status {Rx Freq}:428075000 status {Bandwidth}:100 kHz status {Data Rate}: 256 kbps status {Interleave}: 1 status {Clock Mode}:internal status {Clock Mode}:internal status {RSSI}:-78 dBm status {SNR}:28 dB status {SNR}:28 dB status {Tx RF Out}:30 dBm status {Tx RF Out}:30 dBm status {TxKey}: Keyed status {Temp}:37 Degrees C status {IP Address}: 192.168.11.49 status {IP Netmask}: 255.255.0.0 status {IP Gateway}: 0.0.0
svch	Service Channel Settings
	Usage: svch [subcommand] [<argument>]</argument>
	Subcommands: baud [300 1200 2400 4800 9600 19200 38400] csize [5–8] parity [none even odd] stop [0–2]
	This command sets or displays the Service Channel settings. For further information, see "USING THE SERVICE CHANNEL" on Page 101.
telnetd	Telnet Display or Terminate Session
	Usage: telnetd [kill session]
	This command is used to display or kill (terminate) the current Telnet session(s).
	Example: telnetd



Response:

	Session	Username tns0	Rem. Addr. ENGR	Connected 10.2.129.22	07/01/1999 @ 13:57:17
	Use telnetd ki	Il session to ter	minate the curr	ent session.	
temp	Temperature	of PA Device	:		
	This comma	nd displays the	e radio's power	amplifier (PA)	temperature.
	Example Res	sponse: temp: 3	5 Degrees C (PA	Temperature)	
test	Self-Test of	Radio Hardwa	re		
	Usage: test [<	<0–n> <testname< th=""><th>»>]</th><th></th><th></th></testname<>	»>]		
	This comma separate tests after the com	nd starts a self s that can be ru umand.	test function o n individually l	f the radio. The by specifying th	ere are several le test number
CAUTION POSSIBLE EQUIPMENT	CA	UTION: Do r io is keyed, or	ot perform a tr the radio's reco	ansmitter PLL eive LNA may	test while the be damaged.

NOTE: Performing a receiver or transmitter PLL test during normal link operation will take the link down for the duration of the test and the re-synchronization interval.

The internal self tests are listed in Table 25.

Table 25. Internal self tests

Function Evaluated	Number	Name
Flash Memory	0	flash
DRAM Memory	1	dram
Configuration	2	config
Battery	3	batt
Radio A- to-D Circuits	4	atod
Transmitter Phase Locked Loop	5	txpll
Receiver Phase Locked Loop	6	rxpll
Real-Time Clock	7	rtc
FPGA Logic	8	fpga
DSP	9	dsp
CODEC	10	codec

threshold

DAMAGE

Threshold of Performance Degradation



Usage: threshold [<level>]

This command sets or displays the performance degradation threshold(s) of the LEDR radio, at which time events are logged and SNMP traps are generated. Setting these thresholds to zero or a negative number will disable event logging and trap generation for those parameters.

	Example Response:	threshold {rssi}: 0 threshold {snr}: 0 threshold {coffset}: 0 threshold {temp}: 110 threshold {15mines}: 900 threshold {15minses}: 900 threshold {24hres}: 86400 threshold {24hrse}: 86400
	rssi—dBm level belov	w which an RSSI alarm is generated.
	snr—Value below wh	ich a signal-to-noise level alarm is generated.
	coffset —Maximum to the local LEDR unit' from the other LEDR	blerable RF carrier frequency difference between s transmit frequency and the incoming RF signal c radio.
	temp—Power amplifi generated.	er temperature above which an alarm condition is
	15mines—Number of	errored seconds within the last 15 minutes.
	15minses —Number o utes.	f severely errored seconds within the last 15 min-
	24hres—Number of en	rrored seconds within the last 24 hours.
	24hrses—Number of s	severely errored seconds within the last 24 hours.
time	Time of Internal Clo	ck
	Usage: time [HH:MM[:S	SS]
	This command displa clock. The radio's rea tery so it is running e	al time clock operates from an internal lithium bat- even if the radio has no DC power connected.
	The real time clock is	s fully compliant with Year 2000 standards.
timeslot	Time Slot Assignment	nt
FT1 FE1	Select which timeslo Usage 1, the timeslot timeslots are commit	ts to transmit. This command has two uses; in as can be set or displayed. In Usage 2, all pending ted/made active.



The timeslots may be different at each end of the link. They will be monotonically mapped; that is, Slot 1 is mapped to Slot 13, Slot 2 is mapped to Slot 14, etc. To select timeslots 1 through 12, enter the command **timeslot 1-12**.

Usage 1: timeslot [-d] [slotlist]

Usage 2: timeslot -c

Variables:

- -d Disable timeslot(s)
- -c Commit pending timeslots

Modifications to the timeslot list are kept pending until *all available* slots have been assigned. The user can choose to commit slots when the last available slot is added to the pending list, or by using the **-c** option. (See Usage 2.)

The default action is to enable given timeslots. If no arguments are entered, the currently active timeslots and pending timeslots are displayed.

The **slotlist** variable is a list of timeslots and can be a single slot number, comma separated list of slot numbers, or a range of slot numbers (i.e., 2-8). Timeslots can be entered in any order and are automatically configured. Extra slots will be ignored. *Unassigned timeslots in the pending list are signified by MA (must assign)*.

NOTE: Enough slots for the full data capacity of the modem setting must be specified or the link will not synchronize.

NOTE: FT1 timeslots are 1–24. E1 timeslots are 0–31.

NOTE: In FE1 mode timeslot 0 is always selected. When frame structures are selected that contain CAS (fstruct 4-7) timeslot 16 must be selected.

trapfilter Trap Filtering for SNMP

Usage: trapfilter [<critical|major|minor|inform>]

This command sets or displays which events cause SNMP traps. Filtering traps is done by category. Traps that are filtered are allowed to pass through the network-management system. (See *trapmgr* on Page 85 and *snmpcomm* on Page 81 for additional information.)

trapmgr Trap Manager IP Addresses

Usage: trapmgr [<1-5>] [<IP address>]



	This command sets or the IP addresses of up SNMP manager softw SNMP events (traps) is that set by the ip co	displays the trap manager IP addresses. These are to to five network-management stations on which ware is operating, and to which notifications of are to be sent. The IP mask used for sending traps mmand. (See "ip" on Page 63.)
	Example Response:	trapmgr: 1 = 10.2.129.22 trapmgr: 2 = 0.0.0 trapmgr: 3 = 0.0.0 trapmgr: 4 = 0.0.0 trapmgr: 5 = 10.2.129.1
trend	Trend of RF Perform	ance Indicators
	Usage: trend [<rssi tem< td=""><td>p rfout snr fec ifec time all>] [<display (msec)="" time="">]</display></td></rssi tem<>	p rfout snr fec ifec time all>] [<display (msec)="" time="">]</display>
	This command is use RSSI, radio temperate errors (corrected and pressing Control-C or	d to display continuously updated readings of: ure, RF output, signal-to-noise ratio, and FEC uncorrectable). The display can be stopped by n the terminal.
	If the trend command parameters will be rep play several selected	is used by itself or with all (trend all), all associated ported. More than one argument can be used to dis- items in the desired order.
	NOTE: This comma	and is not available from a Telnet session.
txkey	Radio Transmitter Ke	eying Status
	Usage: txkey [on off]	
	This command sets or the radio transmitter i mitter is not keyed.	displays the radio transmitter status. ON indicates s keyed and transmitting. OFF indicates the trans-
unitid	Unit Identification N	umber for Orderwire and NMS
	Usage: unitid [<id>]</id>	
	This command sets of This number is used f Management System) factory default is the (1-999)	r displays the radio's unit identification number. or Orderwire signaling and by the NMS (Network). (See "USING ORDERWIRE" on Page 99.) The last three numbers of the unit serial number.
uptime	Up Time	
	Usage: uptime	
	This command displa	ys how long the radio has been powered-on.
user	User Account Inform	ation



Usage: user [subcommand] [<argument>] Subcommands: add <user> <pass> <perm> del <user> perm <user> <perm> pass

This command provides administrator access for setting new user accounts and permission levels.

NOTE: The password (**pass**) and user names are case sensitive and may not exceed eight characters. Two quotation mark characters ("") may be used as a "blank" password. If quotation marks are used, the shift key or cap lock keys must be depressed.

User permission (perm) may be set to: read (r), write (w), network (n) or administrator (a). The privileges granted by each level are as follows:

- Read (r) is the lowest level of user access and allows radio information to be viewed only. Changes to radio settings are not allowed.
- Write (w) allows most, but not all radio settings to be changed.
- Network (n) allows everything permitted by lower levels, and also allows changes to the radio's IP configuration.
- Administrator (a) allows everything permitted in lower levels, and also allows changes to be made to user accounts (add, delete, modify). It is normally used by a System Administrator or other person responsible for the radio system.

Example entry: user add fieldserv secret w

The above example shows the command string for adding a new user (fieldserv), with "write" permission and a password of **secret**.

Example Response: user: Command Complete

NOTE: If you are logging in for the *first time* since the radio was shipped from the factory, refer to Page 25 for important login information.

Version of Firmware/Hardware

Usage: ver [frw|hdw|ext]

This command displays radio version information for firmware (frw), hardware (hdw) and Extended Version Information (ext).

Example 1: LEDR> ver frw

ver



	Response 1:	ver: LEDR Part #06-3451A01 ver: 2.4.3 (Version of firmware P/N above)	
	Example 2:	LEDR> ver hdw	
	Response 2:	ver: {Hardware version}: A	
	Example 3:	LEDR> ver ext	
	Response 3: Note: I	ver: Part #06-3451A01 ver: 2.4.3 ver: ver: Image 1 ver: Region Expected Upgrade ver: Firmware 2.4.3 ver: DSP 1.1.0 ver: FPGA Ver1.22 ver: Scripts Ver1.44 ver: Option Ver1.56 ver: ver: Image 2 (Active) ver: Region Expected Upgrade ver: Firmware 2.4.3 ver: DSP 1.1.0 ver: FPGA Ver1.22 ver: Scripts Ver1.44 ver: Option Ver1.56 ver {Active code}: compiled Aug 15 2000 08:47:46 Blank lines following "Ver:" are spaces used as vertical tions between data groups	
volume	Volume of Or	derwire Earpiece	
	Usage: volume [<level (0–255)="">]</level>		
	This command	d sets or displays the orderwire handset volume.	
	Example Resp	oonse: volume: 100	
vox	Voice Operated Transmit		
	Usage: vox threshold <1-100>		
	The vox command sets or displays the level/threshold at which the order- wire microphone will key the transmitter.		
	NOTE: When be he have jack. half-	n the orderwire microphone is spoken into, the audio will eard by all LEDR radios in the network which currently a handset plugged into the front panel ORDERWIRE Only one station can transmit at a time; the circuit is duplex.	

Example Response: vox: 5



Who is currently logged on to the Network Management Ports?

Usage: who

This command displays users currently logged in to the radio operating system.

6.5 Disabling the Front Panel Alarm LED for Unused E1 Option Ports

To disable the ALARM LED on the front panel for a particular E1 port, use the commands found in Table 26 according to the E1 port number. When alarm events are pending, the alarm condition for the unused E1 ports remains until a valid input signal (as defined by G.703) is applied.

You must log into the LEDR radio as a user with "Administrator" privileges to execute these commands. If you are using a terminal program connected to the radio, send one command sequence at a time to the radio with a 5 ms delay between each line.

Disable the LED for IO1	Disable the LED for IO2
Evmap led 74 none	Evmap led 87 none
Evmap led 75 none	Evmap led 88 none
Evmap led 76 none	Evmap led 89 none
Evmap led 77 none	Evmap led 90 none
Evmap led 78 none	Evmap led 91 none
Evmap led 79 none	Evmap led 92 none
Evmap led 80 none	Evmap led 93 none
Evmap led 81 none	Evmap led 94 none
Evmap led 82 none	Evmap led 95 none
Evmap led 83 none	Evmap led 96 none
Evmap led 84 none	Evmap led 97 none
Evmap led 85 none	Evmap led 98 none
Evmap led 86 none	Evmap led 99 none
Disable the LED for IO3	Disable the LED for IO4
Evmap led 100 none	Evmap led 113 none
Evmap led 101 none	Evmap led 114 none
Evmap led 102 none	Evmap led 115 none
Evmap led 103 none	Evmap led 116 none
Evmap led 104 none	Evmap led 117 none
Evmap led 105 none	Evmap led 118 none
Evmap led 106 none	Evmap led 119 none
Evmap led 107 none	Evmap led 120 none
Evmap led 108 none	Evmap led 121 none
Evmap led 109 none	Evmap led 122 none
Evmap led 110 none	Evmap led 123 none
Evmap led 111 none	Evmap led 124 none
Evmap led 112 none	Evmap led 125 none

Table 26. Commands to Disable E1 Port Alarms



To restore the factory default settings to all of the E1 ports, issue the commands shown in Table 27.

Evmap led 74 ioalarm	Evmap led 100 ioalarm
Evmap led 75 ioalarm	Evmap led 101 ioalarm
Evmap led 76 ioalarm	Evmap led 102 ioalarm
Evmap led 77 ioalarm	Evmap led 103 ioalarm
Evmap led 78 ioalarm	Evmap led 104 ioalarm
Evmap led 79 ioalarm	Evmap led 105 ioalarm
Evmap led 80 ioalarm	Evmap led 106 ioalarm
Evmap led 81 ioalarm	Evmap led 107 ioalarm
Evmap led 82 ioalarm	Evmap led 108 ioalarm
Evmap led 83 ioalarm	Evmap led 109 ioalarm
Evmap led 84 ioalarm	Evmap led 110 ioalarm
Evmap led 85 ioalarm	Evmap led 111 ioalarm
Evmap led 86 ioalarm	Evmap led 112 ioalarm
Evmap led 87 ioalarm	Evmap led 113 ioalarm
Evmap led 88 ioalarm	Evmap led 114 ioalarm
Evmap led 89 ioalarm	Evmap led 115 ioalarm
Evmap led 90 ioalarm	Evmap led 116 ioalarm
Evmap led 91 ioalarm	Evmap led 117 ioalarm
Evmap led 92 ioalarm	Evmap led 118 ioalarm
Evmap led 93 ioalarm	Evmap led 119 ioalarm
Evmap led 94 ioalarm	Evmap led 120 ioalarm
Evmap led 95 ioalarm	Evmap led 121 ioalarm
Evmap led 96 ioalarm	Evmap led 122 ioalarm
Evmap led 97 ioalarm	Evmap led 123 ioalarm
Evmap led 98 ioalarm	Evmap led 124 ioalarm
Evmap led 99 ioalarm	Evmap led 125 ioalarm

Table 27. Restore Factory Defaults to Alarm Ports

7.0 STANDARDIZING RADIO CONFIGURATIONS

7.1 Introduction

Setting up and configuring a network of point-to-point systems can be a frustrating task. To make the task easier and more predictable, the parameters of one LEDR radio can be used as a template for other radios in your system. You need only address the parameters that are site or unit-specific, such as an IP addresses.

The **config** command allows the user to upload/download the radio's configuration data from/to a PC. There are two classifications of configuration data—radio-specific data and standard data.



Radio-Specific data is:

- Frequencies
- Target Power
- Thresholds
- Calibration Data
- IP Address
- IP Routing Table
- Network Settings

Standard radio data are the configuration parameters that are common in *all* LEDR radios.

Both types of data can be uploaded and downloaded between the radio and a PC. It is up to the user to decide whether to download *both* types or just the standard (core) data. Once the data is on a PC, the file can be edited off-line, for example, the configuration data, if desired. The customized configuration file can then be downloaded to other LEDR radios in your system from your PC.

7.2 Setup by TFTP

To use this function the user will need:

- A PC with a TFTP server running.
- The IP address of the PC running the TFTP server.

If you do not know your computer's address on a Windows PC, you can use the **RUN** function from the **Start** menu and enter **winipcfg** to determine your local PC's IP address. The IP address of the radio can be found by the use of the radio's **ip** command.

Downloading Procedure

To download the configuration data from the LEDR chassis to a file (filename.txt) on the user's PC, enter the following command:

LEDR> config send [filename.txt] [1.2.3.4 <IP Address>]

The file, **filename.txt**, will be written to in the default path set in the TFTP server. The numeric string, "**1.2.3.4**", is the IP address of the PC destined to receive the file.

Uploading Procedure

To upload into a LEDR radio only the *standard* configuration data from a file on the PC (filename.txt) to the radio enter the following command:

LEDR> config get [filename.txt] [1.2.3.4 <IP Address>]



To download *both* the standard and radio-specific configuration data from a file on the PC (filename.txt) to the radio enter the following command:

LEDR> config getall [filename.txt] [1.2.3.4 <IP Address>]

Ideally, the process of updating a system would go like this:

1. Upload the current configuration data from each radio to a specific file on your PC.

At radio 1 CONSOLE Port enter: config send radio_1.txt 1.2.3.4 At radio 2 CONSOLE Port enter: config send radio_2.txt 1.2.3.4 (etc...)

- 2. Upgrade the software on each radio.
- 3. Boot from the new software.
- 4. Download the saved configuration data from Step 1 back into each radio using the **getall** subcommand so that you will get both the standard and radio-specific parameters.

At radio 1 CONSOLE Port enter: config getall radio_1.txt 1.2.3.4

At radio 2 CONSOLE Port enter: config getall radio_2.txt 1.2.3.4 (etc.)

7.3 Setup Through the DB-9 CONSOLE Port

You have the option of sending the configuration data to the CONSOLE Port instead of sending it to a file on a PC. Then the terminal program can be set to log the data as it is created by the radio. The advantage of this option is that you do not need to use the TFTP server, routing, etc. on the PC.

During the upload, the LEDR software will prompt you to begin/end recording at the terminal program. You will also be prompted on how to end a download.

When the **config get** downloading option is chosen (standard data only), the software will filter out all the radio-specific parameters as they come through.

To upload the data to the CONSOLE Port:

LEDR> config send console

To download only the standard data via the CONSOLE Port:

LEDR> config get console

To download standard and radio-specific data: LEDR> config getall console



8.0 UPGRADING LEDR FIRMWARE

8.1 Introduction

The LEDR radio's firmware can be upgraded with new software releases that may be issued from time-to-time by Microwave Data Systems. To support firmware upgrades while the radio is in use, the LEDR radio contains two complete copies of its firmware. Once the inactive version is replaced, the radio can be rebooted using the code in the new firmware. However, if an error occurs during the download, the radio can easily recover because it always has a complete copy of firmware available.

Reprogramming can be done through three common options:

- 1. Locally through the front panel CONSOLE Port \Box .
- 2. Locally using TFTP and Telnet through the ETHERNET Port [...].
- 3. Remotely over a network connection using TFTP and Telnet to the ETHERNET Port .

The procedures that follow use one or both of two utilities found in MDS' *LEDR Utilities* package. These utilities will facilitate local and remote transferring of firmware files to and from the LEDR radio. These applications are available from Microwave Data Systems on floppy disk (P/N 03-3631A01) or on MDS' Internet sites FTP section of the primary site of **www.microwavedata.com**.

The following sections will explain how to program new firmware into the radio using each of the three connection options. They assume the LEDR Utilities are installed on each computer system named in the procedure.

NOTE: The ETHERNET, SERVICE CHANNEL and CONSOLE Ports share a common data channel when loading firmware over-the-air. Transferring the radio firmware image file (≈ 1 MB), may take up to 30 minutes if there is other activity on any of the other ports.

Regardless of your connection to the LEDR radio, loading data/firmware into the radio's SRAM is much slower than loading software onto a PC hard drive or RAM.



8.2 OPTION 1: Uploading Firmware via the CONSOLE Port

This method of upgrading the firmware is well suited to field service personnel that carry a laptop PC to field installation. Any computer running the Windows operating system is suitable. Figure 17 shows the basic arrangement.





Setup

Connect a PC to the radio's front panel CONSOLE Port \square using a 9-pin RS-232 cable. (See Figure 33 on Page 129 for cable wiring details.) The CONSOLE Port supports RS-232 at 9600 bps to 38.4 kbps.

Download Procedure

- 1. Start the MDS MDS Flash Utility application.
- 2. From the View>Options menu, select the appropriate COM Port and baud rate. Ensure that autobaud is enabled (Look in the lower right-hand corner of the *Flash Utility* window).
- 3. From the View menu, select console. This will bring up a NMS window to the LEDR radio. At the LEDR> prompt, enter a login name and password and then close the session.
- 4. Using the File|Open dialog, select the directory where the new firmware is located. In the file window, highlight the correct (.mpk) file and then press the green start arrow.



Verification and Reboot

1. To verify the correct operation of the new firmware, open the NMS again by pressing Alt + L. Enter **boot** to determine which image is currently active. This command will respond as follows:

boot: Image 1 is Active or, boot: Image 2 is Active

2. The new firmware is downloaded into the *inactive* image. Therefore, if the radio responded **Image 1 is Active**, enter "image verify" command, **iverify 2**, otherwise, enter **iverify 1**. The radio will respond indicating whether or not the image has been verified as being a valid file, it will not determine if the contents are complementary to the other firmware image. If the image does not verify, try downloading the firmware again into the radio.

NOTE: The following paragraph describes rebooting the radio. This action will disrupt the communications link.

- Once the image has been verified, the radio must be rebooted using the new firmware. This is done by entering the command **boot 1** or **boot 2**, where the 1 or 2 corresponds with the image number used with the iverify command above.
- 4. Once the radio has rebooted and Flash Utility screen displays the LEDR> prompt, the firmware can be downloaded or copied into the other image. Often, copying the firmware from one image to the other can be faster than performing a second download. To copy the firmware over to the other image, simply enter icopy. The radio will prompt you for confirmation (y/n) and then begin copying.

8.3 OPTION 2: Uploading Firmware Locally by Telnet via Ethernet

This method can be used in the field or in a workshop by using a Windows computer equipped with an Ethernet interface. Figure 17 shows the basic arrangement.

NOTE: You must know the IP address of the LEDR Radio and the PC that you are going to connect together. (Both units must have the same Subnet, Netmask and Gateway addresses, or at least have routes to one another.) This is essential for a direct Ethernet connection.

If you do not know your Windows computer's IP address, you can use the **RUN** function from the **Start** menu and enter **winipcfg** to determine your local PC's IP address. The IP address of the radio can be found by the use of the radio's **ip** command.





Figure 18. Direct connection through the LEDR ETHERNET Port

Setup

- 1. Connect the PC's Ethernet interface to the radio's ETHERNET Port using a Category 5 Ethernet cross-over cable.
- 2. Copy the file LEDR firmware image file (ledr.mpk) into a known directory on your PC. For example, c:\windows\LEDR\Firmware V2.5\. This directory path will be used later by the TFTP server.

Download Procedure

- 1. Launch the MDS *TFTP Server* on a PC connected to the LEDR radio's ETHERNET Port through a cross-connect cable.
- 2. Point the *TFTP server* to the directory from which you desire to upload the new firmware. In the SNMP TFTP server, you should execute the **set root** command and point to the known directory where **ledr.mpk** has been copied.
- 3. Launch your Telnet application and login to the radio which you desire to load (reprogram) the firmware image file.
- 4. Determine the active (firmware) image from which you are currently executing by typing **boot**. The new firmware will downloaded into the *inactive* image.
- 5. Execute the command reprogram network ledr.mpk [IP address]. In the command, in place of [IP address], you should actually type the IP address of the TFTP server. For example, reprogram network ledr.mpk 192.168.1.2



- 6. If desired, the status of the transfer during reprogramming may be displayed by typing **reprogram status**.
- 7. The *TFTP Server* and radio will notify you when the programming is complete.

Verification and Reboot

1. To verify the integrity of the new firmware enter **boot** to determine which image is currently active. This command will respond as follows:

boot: Image 1 is Active or, boot: Image 2 is Active

If the radio responded to the **boot** command with **Image 1 is Active**, enter the "image verify" command, **iverify 2**, otherwise, enter **iverify 1**. The radio will respond indicating whether or not the image has been verified as being a valid file, it will not determine if the contents are complementary to the other firmware image. If the image does not verify, try downloading the firmware again into the radio.

NOTE: The following paragraph describes rebooting the radio. This action will disrupt the communications link.

- Once the image has been verified, the radio must be rebooted using the new firmware. This is done by entering the command **boot 1** or **boot 2**, where the 1 or 2 corresponds with the image number used with the iverify command above.
- 3. Once the radio has rebooted and Flash Utility screen displays the LEDR> prompt, the firmware can be downloaded or copied into the other image. Often, copying the firmware from one image to the other can be faster than performing a second download. To copy the firmware over to the other image, simply enter icopy. The radio will prompt you for confirmation (y/n) and then begin copying.

8.4 OPTION 3: Uploading Firmware from a Remote Server via Ethernet

Setup

Connect the LEDR radio's ETHERNET connector to network which has a PC connected with the desired LEDR firmware on its hard drive. The "network" can be a local area network, a wide-area network or any IP network that can connect the two units.



The computer hosting the firmware image, must be running a TFTP server software. If not, install, launch and configure the MDS *TFTP Server* software found on the *LEDR Utilities* disk. The setup configuration is shown in Figure 19.



Figure 19. Uploading firmware from a remote server via Ethernet

Download Procedure

- 1. Start a terminal program, such as HyperTerminal, on the local PC.
- 2. Log into the LEDR radio using the login command.
- 3. Use the ip command to ensure that the radio has a valid IP address.
- 4. Use the ping command from the local PC to ensure that the PC and the radio have valid routes to pass information between them.
- 5. At the radio's LEDR> prompt, start the download by entering reprogram network [filename] [source PC's IP Address]. The download can be monitored from the radio by entering reprogram status. When the download is complete the radio will sound two short beeps and the response from reprogram status will indicate that the download has finished.



SNMP Option The TFTP download process can also be initiated using an SNMP manager. The Firmware|FwProgTable object provides a means for specifying the TFTP server IP address and the filename for the firmware.

Verification and Reboot

When the download is complete, verify the firmware image and reboot the radio as described under Verification and Reboot in Paragraph See "Verification and Reboot" on Page 95 for the procedure.

9.0 USING ORDERWIRE

9.1 Introduction

A handset may be plugged into the front panel of the LEDR radio to allow voice communications between radio sites (see Figure 20). This can be especially useful during setup and service of the radio equipment. All radios on the network can hear what is said by any individual speaking into a handset. No other radio may transmit on the orderwire until the current speaker is finished. Depending on the number of hops, the link data rates, and Interleave setting, there may be a noticeable latency from one end of the network to the other.

The front panel alert function (See "Unit ID" on Page 34) and alert command (Page 51) can be used to signal all units in the network or a specific radio.

Normal payload data is *not* affected by Orderwire use. The Orderwire uses voice-compression technology that introduces a slight, but notice-able, delay in Orderwire audio.

The orderwire will not interrupt the normal data flow through the LEDR data communication channel, however, it will reduce the throughput efficiency of any data communications on the Service Channel during periods of voice transmission.

A handset is available from MDS (P/N 12-1307A01), which has a push-to-talk button and provides basic communication services but does not contain a built-in DTMF (tone) keypad. (The Orderwire supports the transmission of DTMF-type signaling by detecting tones at the source, and regenerating them at the receiving end, however, there are no DTMF supported radio functions in the LEDR radios.)

9.2 Setup

Program the vox and volume setting for each radio. The volume setting is user preference. The vox setting requires some forethought. The higher the vox setting, the louder the user must speak to get the voice decoder to recognize the speech. This will, however, prevent noise from entering



the "line." A low **vox** level will recognize speech better but may transmit more noise with the speech. The user should experiment with the **vox** setting to determine the best level for the speaker and the noise environment.

9.3 Operation

- 1. Plug the handset into the front panel jack labeled & . (Figure 32 on Page 129 provides pinout details for this connector.)
- 2. Press () or () at the menu's top level until Orderwire appears on the LCD display. Press () to move to the lower levels of the menu.
- 3. To call a specific radio station, enter the Unit ID number for the station to be called. (At this point, an alert signal ("ring") will be sent to earpiece of the handset connected to the "called" station.
- 4. Press the PTT on handset to speak to the other station(s) listening to their handsets connected to LEDR equipment on the network.

Release the handset PTT to listen. VOX (voice-activated transmit) operation is also supported. (See "vox" on Page 88.)

- 5. Alternatively, a DTMF-style handset can be used to "dial" the required radio station.
- 6. Remember, regardless of the number of users, only one may speak at a time.
- **NOTE:** The LEDR radio has a built-in DTMF decoder in the orderwire circuitry. If a standard DTMF telephone test set is plugged into the orderwire, the user can dial in the three digit unit address on the handset to "ring" the earpiece of the handset of the associated LEDR unit. The LEDR chassis will not provide power to ring a standard bell or electronic ringer.




Figure 20. Orderwire Connection

9.4 Related NMS Commands

The orderwire can be configured by the NMS commands or through the front panel. The earpiece volume is more easily set by the front panel controls as the level is dependent on personal preference.

vox – Voice level (relative) at which speech will be detected by the software (See "vox" on Page 88)

volume – Sets/displays the handset volume (See "volume" on Page 88)

alert – Sends an orderwire alert to a specific radio or to all the radios on the network (See "alert" on Page 51)

10.0 USING THE SERVICE CHANNEL

10.1 Concept

The Service Channel sends and receives ASCII-based information at 9600 bps in a half-duplex broadcast mode throughout the network. This means that any data coming through the Service Channel Port of a radio will be broadcast to the Service Channel of each radio in the network. There can be only one radio transmitting Service Channel data over the network at a time and the data will always be sent to every radio on the network. *No other radio will be allowed to transmit until the current sender is finished*.



If a radio does receive data in the Service Channel Port while another radio is the active-sender, the data coming in the port will be queued and sent when the active sender is finished. Depending on the number of hops, link data rate, and Interleave setting, there may be a noticeable latency from one end of the network to the other.

10.2 Setup

The user can configure all the Service Channel parameters for a specific radio. The port may be enabled or disabled. In the disabled state (**svch port off**), any data that comes in the Service Channel port will be discarded and any Service Channel data that comes into the radio from another radio in the network will be passed along to the rest of the network but not sent out the Service Channel Port. When the Service Channel Port (**svch port on**) is enabled, it will behave based on the other settings.

The most important setting is the **echo** parameter. Echo is used with a terminal emulator on a PC and the program does not display on the screen character keyed in by the user.

When you set up a system, you must be careful to avoid an infinite loop. If echo is enabled, then every character that enters the Service Channel port will be echoed back out the port. When echo is disabled then data that comes in the Service Channel port is not sent back out the port. Trouble may arise if the device that is connected to the Service Channel also echoes the data it sends. In that case, the device will send characters into the Service Channel Port, the radio will echo the characters back to the device, the device will consider the echoed data to be input which it will in turn echo back to the radio, etcetera, until an overflow condition occurs.

You must also set the communication parameters (baud rate, stop bits, char length, and parity) via the **svch** subcommands so that the settings match those at the device connected to the Service Channel Port.

Lastly, the user can re-initialize the Service Channel port via the **svch reset** command. This may be helpful in the case where an infinite loop overflow condition has locked the port.

10.3 Usage

The Service Channel supports ASCII data transfer over the network in broadcast fashion. As a result, devices connected to the Service Channel Ports of different radios will appear to have a transparent half-duplex connection between them.



10.4 NMS Commands

This command is used to set/display Service Channel parameters.

Usage: svch [subcommand] [<argument>]

Subcommands: baud char echo off off on parity reset stop

on—Enable the Service Channel

off—Disable the Service Channel

reset-Re-initialize the Service Channel

 $\texttt{echo} \underline{-\!on/off}$

baud—300, 600, 1200, 2400, 4800 and 9600

char— 5, 6, 7, 8 (ASCII character length in bits)

parity-none, even, odd

stop—1, 2 (Stop bits)

11.0 PROTECTED CONFIGURATION

11.1 Introduction

The LEDR radio can be supplied in a protected (also called redundant or "1+1") configuration (Figure 21). The protected version is designed to perform automatic switchover to a second radio in the event of a failure in the primary unit.

Protected operation is important for many mission-critical or revenue producing links. By configuring two identical LEDR radios in parallel and including a third switch box containing the RF switching circuits and the customer interfaces, it is possible to protect against failure in any of the LEDR radio sub-systems. Failures can be either malfunction or external environmental effects, such as multipath fading or nearby lightning strikes.

A Protected station consists of two standard LEDR Series radios and a Protected Switch Chassis (center unit in Figure 21). Ordinarily, the three chassis are mounted together in a "stacked" arrangement, one above the other, as shown in the figure.



The top unit is referred to as the system's "Unit A", and the lower one as "Unit B". Each unit is considered to be the "sibling" of the other. The sibling of Unit A is Unit B, and the sibling of Unit B is Unit A. This distinction is used in the rdnt command found on Page 74 under the subheading "*Read & Write Commands*."



Figure 21. LEDR Radio Protected Version

The front panel of the Protected Switch Chassis (PSC) front panel has only two LEDs and an RJ-45 jack for an orderwire handset. The LEDs indicate by light and an arrow outline which LEDR chassis is active. It is assumed the two LEDR chassis will be mounted above and below the PSC as shown in Figure 21.

11.2 Protected Operation

During normal operation, one radio path is selected and the RF and interface switches are set to service that path. (The illuminated POWER LED indicator on the front panel of the Protected Switch Chassis (PSC) points to the currently active unit.) A switch in the transmitter circuitry allows one transmitter to be connected to the common ANTENNA port on the Protected Switch Chassis. On the receive path, a splitter in the Protected Switch Chassis allows both radio receivers to receive the incoming RF signal for processing.

The Protected Switch Chassis is a gateway for data coming and going between each of the LEDR radio units and the common data circuits connected to the PSC. The PSC monitors various RF and data signal paths for predefined fault-determining parameters. If signal conditions are not normal, the PSC's microprocessor controller will issue an alarm and move the standby LEDR radio to the active mode.



Fault-determining parameters can be programmed from the Network Management System (NMS) software. Examples of these parameters are:

- Low transmitter power
- High transmitter temperature
- Synthesizers is out-of-lock
- Problem with the option board or framers
- CPU failure wherein the CPU watchdog causes a reset
- Fan fault

Transmitter Failure

Any failure on the "active" transmitter path will create a fault condition which will place the currently the active transmitter on standby and switch the "standby" transmitter to "active." The newly active transmit path will remain in use until a manual changeover returns the configuration to the original transmitter path. This allows the link to remain fully operational until the user has replaced the faulty transmitter circuitry.

Receiver Failure

Both receivers are fed via an RF splitter from the antenna port. Each RF path is buffered and monitored for receive signal integrity for uncorrectable bit-errors. If the "active" receive circuitry fails, uncorrectable bit-errors will be detected. The modem receive switch will first determine that the "standby" receive path is operational (no uncorrectable bit errors) and will switch accordingly.

11.3 Configuration Options

The protected LEDR radio is available with a number of configuration options, each designed to optimize particular system solutions:

1+1 Operation—Warm or Hot Standby

In a warm standby link, the standby transmitter is powered down. In a hot standby link, the standby transmitter is powered up and transmitted in a dummy load. The warm standby option offers the advantages of significantly reduced power consumption, since only one transmitter path is powered. However, upon transmitter failure, the switchover takes longer due to the transmitter having to be powered. Thus the hot standby mode offers the advantages of faster switchover time and increased overall system availability.



Symmetrical or Asymmetrical Receiver Splitters

The default protected radio is configured with a 3 dB splitter on the receive path, meaning that each radio's receiver signal level is equal, but typically 4dB worse than an unprotected radio (3 dB due to splitter, plus dB cabling and additional connectors). As an option, an asymmetrical splitter (1 dB / 10 dB) is offered. Using this option, the active path is 2 dB stronger than with a symmetrical splitter (1 dB compared to 3 dB splitter loss), allowing for a better fade margin and increased system availability during normal operation.

However, upon receiver change over, the receive signal strength will be significantly reduced due to the 10 dB of splitter loss rather than the equal splitter's 3 dB loss, making the link more sensitive to fading in this temporary switched state. Providing the failed standby receiver is replaced within a short period of time, many users find that the asymmetric splitter's increased normal performance offsets any deterioration in the temporary switched state.

11.4 PSC Rear Panel Connectors

The following are descriptions of the rear panel connections of the Protected Switch Chassis. The PSC's rear chassis is shown in Figure 22.

Figure 21 presents an inter-unit cabling diagram for protected configurations.



Figure 22. Protected Switch Chassis—Rear Panel

RxA

The RXA (Receive—Radio A) connector is a N-type coaxial connector. It connects to the RX port on the rear panel of Radio A via a short coaxial cable.

RxB

Same as RXA, but for Radio B.

Antenna

The ANTENNA connector is a N-type coaxial connector. It serves as the connection point for the station antenna.



TxA

The TXA (transmit, radio A) connector is a N-type coaxial connector. It connects to the TX port on the rear panel of Radio A via a short coaxial cable.

ТхВ

Same as TXA, but for Radio B.

Protected (Data)

This pair of connectors accepts G.703 signals from each of the LEDR radios. The top connector is for Radio A, and the bottom connector is for Radio B. For pinout information, see Figure 36 on Page 130.

E1

This is a block of four RJ-45 modular connectors for connection to a multiplexer or other customer-supplied E1 equipment. For detailed pin information, Figure 34 on Page 130.

These connectors are not operational on "S" Series (Subrate) radios.

Ethernet

The ETHERNET connector provides access to the embedded SNMP agent and other elements of the TCP/IP network management system. The connector is a standard 10 Base-T connection with an RJ-45 modular connector. For detailed pin information, see Figure 34 on Page 130.

530 (A&B)

This pair of DB-25 connectors accepts EIA-530 data signals from each of the LEDR radios. The top connector is for Radio A, and the bottom connector is for Radio B. For pinout information, see Figure 36 on Page 130.

EIA-530-A

This DB-25 connector provides a connection point for customer-supplied EIA-530 data equipment. Note: This port is not operational in fullrate models.

Service Channel

In a protected configuration, this DB-9 connector becomes the Service Channel connection for *both* LEDR radios. (In the protected radio configuration, the Service Channel connectors on the radios are non-functional.) For detailed pin information, see "Service Channel—Rear Panel" on Page 131.



11.5 Inter-Unit Cabling for Protected Stations

The required cabling between the two radios and the Protected Switch Chassis is dependent on the data interface, unit type (subrate versus full-rate), and transmit and receive antenna configuration.

The cabling for a pair of standard radios with internal duplexers is shown in Figure 23.



Figure 23. Inter-unit Cabling—Protected Version with Internal Duplexers

11.6 Configuration Commands for a Protected System

NOTE: In a protected link configuration, ensure that the E1/T1 interface settings are identical for both radios at a each end of the link.

Once the inner-chassis cabling is in place and the units are powered up, several parameters are required to place the LEDR radio into proper operation as a member of a protected system.

The tasks involved are reviewing and setting up of the following parameters:



- Radio Operation
 - General
 - Redundant Specific
- Data Interface
 - Subrate—Fractional-T1
 - Fullrate—E1/T1

Redundant Specific Parameters

There are several parameters that must be set to enable proper operation of a protected station. These are all covered under the **rdnt** command found on Page 74.

Sample Redundant Configuration Session

The following is a example of a session used to configure a LEDR radio to serve in a protected system. This sequence will need to be repeated for each radio in the protected pair.

1. Configure the protected mode to hot-standby:

```
LEDR> rdnt mode 1
rdnt {mode}: 1+1 Hot Standby
LEDR>
```

2. Configure the IP address of each radio:

LEDR> ip address 192.168.1.1 ip {netmask}: (255.255.0.0) ip {gateway}: (0.0.0.0) ip {port}: (ETH) ip {address}: 192.168.1.1 ip {netmask}: 255.255.0.0 ip {gateway}: 0.0.0.0 ip {gateway}: 0.0.0.0 ip {port}: ETH ip: A reboot is strongly recommended. Do you wish to reboot? (y/n) >y LEDR>

3. Configure the sibling IP address of each radio:

LEDR> rdnt ip 192.168.1.2 redundant {ip}: 192.168.1.2 LEDR>

4. Configure the hitless switching. (Note that the default is on.):

LEDR> rdnt hitless on rdnt {hitless}: on LEDR>

5. Configure the temperature (°C) threshold:

LEDR> rdnt temp 100 rdnt {temp}: 100 LEDR>



Transmit Clock Selection (Subrate Models Only)

The transmit clock selection must be addressed for every radio in a subrate radio system installation. The single most important consideration is that there be only *one* master clock in a subrate radio network. The master clock can originate from the radio or from the Customer Premises Equipment (CPE).

The radio is capable of several different clocking modes. Refer to Figure 24 on Page 111 for typical system clocking methods.

Refer to the Clock Mode screen description on Page 35 for setting the radio transmit clocking from the front panel. Refer to the **clkmode** description on Page 56 for setting the radio transmit clocking mode from the CONSOLE Port.

NOTE: When customer premises equipment (CPE) is operated in looped clock mode, it is recommended that the radio *not* be set to line clock mode. To do so may cause the transmitting radio's PLL to be pulled out-of-lock, especially when operating at 4E1 data rates.





Figure 24. Typical Repeater Clocking Arrangement (no multiplexer at repeater site)



12.0 SPACE DIVERSITY OPERATION

12.1 Introduction

Space diversity operation is an effective mechanism of increasing a radio link's resilience to transmission impairments such as multipath fading or frequency selective fading. In difficult transmission environments such as over highly reflective and moving water paths, or in arid environments where atmospheric ducting occurs, space diversity is the most effective way of maintaining a continuous radio link.

In a space diversity link, two radio receivers are operated in parallel, from two separate antennas mounted several wavelengths apart vertically on the antenna tower. The separation of antennas is such that when one antenna experiences fading due to multi-path interference, the other antenna, being several wavelengths away, is not likely to experience the same fade. Thus, one receive path may experience uncorrectable errors, while the other path will be error free. Similar to the protected operation, the receive modem switch will determine which buffered data path is operating with the highest integrity, and select that path without inducing any additional bit errors into the link.

Space diversity is especially effective in changeable multi-path environments such as over tidal water paths. Since water is highly reflective, there will be continual "constructive" and "destructive" interference at each single antenna over the course of the day as the water rises and falls and the reflected water path interferes with the line-of-sight path. By correct vertical positioning of the antennas, these effects can be negated, allowing one antenna to see a good signal while the other is experiencing fading, and the modem switching accordingly to allow the link to operate error- free.

The space diversity LEDR radio is available only in a hot standby configuration.

12.2 User Interface & Control

Protected operation is configured using the Redundant screen (Page 41) on either radio front panel, or with the **rdnt** command from a NMS terminal (see Page 74).

12.3 Transmit Clock Selection

There is no difference between a space diversity system and redundant radio arrangements with respect to transmit clock selection. Fullrate radios require no user intervention for clocking. Users of subrate systems should set the radio clocks as described for subrate systems. See "Transmit Clock Selection" on Page 112 for further information.



12.4 Inter-Unit Cabling for Space Diversity Stations

The RF cabling for space diversity stations depends on the location of the duplexers. The block diagram in Figure 25 shows the RF connections in a typical system with two external duplexers.



Figure 25. Block Diagram of a Space Diversity Station with External Duplexers

The inter-unit cabling for a space diversity system with external duplexers is shown in Figure 26.



Figure 26. Inter-unit Cabling—Space Diversity with External Duplexers



The inter-unit cabling for a space diversity system with internal duplexers is shown in Figure 27.



Figure 27. Inter-unit Cabling—Space Diversity with Internal Duplexers



13.0 SPARE PARTS, UNITS AND ACCESSORIES

13.1 Spares

Spare assemblies and units used for repair of LEDR radios are listed in Table 28. Field servicing, or replacement of PC boards and assemblies, should only be performed by qualified service personnel.

When ordering parts from the factory, always give the *complete* model number of the radio as found on the serial number label on the chassis. Contact information can be found on Page 140 of this guide.

Item	Model	Part Number
Transceiver's SRAM Power Back-up Battery	All Models	27-3109A01
Protected Switch Chassis (Complete unit)	LEDR 400F	03-3873A01
	LEDR 900F	03-3873A02
	LEDR 1400F	03-3873A03
Duplexer (If equipped)	All Models	Frequency dependent; Contact factory.
FT1 Data Interface PCB	LEDR 900S	03-3846A01
E1/FE1 Data Interface PCB	LEDR 400F LEDR 400S LEDR 900F LEDR 900S LEDR 1400F LEDR 1400S	03-3846A02
Subrate Data Interface PCB	LEDR PSC	03-2824A01
Fullrate Data Interface PCB	LEDR PSC	03-3539A01

Table 28. Field Replaceable Units for LEDR Radios



13.2 Accessories

Table 28 lists accessories available from the factory as a convenience to our customers. Factory contact information can be found on Page 140 of this guide.

Item	Description	Part Number
V.35 Interface Cable	6 ft (1.8 m) cable adapter used to convert subrate LEDR radio EIA-530 data interface to V.35 male data interface.	03-2174A01
G.703 Balun	Miniature G.703 balun used to convert a fullrate LEDR radio's 120 Ω balanced data interface to two 75 Ω BNC coaxial data interfaces.	01-3494A01
	One balun required per E1 port.	
EIA-530 Null-MODEM Crossover Cable	6 ft (1.8 m) cable adapter to connect subrate interfaces in a repeater configuration.	97-2841L06
SNMPc™ Network Management Manager	SNMP Management Software to access the LEDR embedded SNMP agent, allowing management of the LEDR radio network and any interconnected SNMP enabled peripherals.	03-3530A01
	For Windows 95 O/S	
SNMPc™ Network Management Manager	SNMP Management Software to access the LEDR embedded SNMP agent, allowing management of the LEDR radio network and any interconnected SNMP enabled peripherals.	03-3530A02
	For Windows 98 or NT O/S.	
Orderwire Handset	Voice handset with 4-wire cord (RJ-11 modular plug).	12-1307A03
Orderwire Handset Kit	Voice handset with 4-wire cord (RJ-11 modular plug), hanger and mounting bracket.	02-1207A01
AC Power Adapter	External AC power supply provides 24 Vdc to LEDR radio.	03-3862A01
	Input: 110 Vac to 240 Vac, 50 to 60 Hz	

Table 29. Accessory Items for LEDR Radios



14.0 FRACTIONAL-T1 INTERFACE CARD 03-3846A01

FRACTIONAL-E1 INTERFACE CARD 03-3846A02

14.1 Introduction

The Fractional-T1 (FT1) and Fractional-E1 (FE1) Interface cards are optional assemblies which provide additional connectivity within a LEDR network for all subrate (S) models. The installation of the FT1/FE1 Interface card inside the radio allows the standard EIA-530 customer data interface to be bypassed and the radio data lines to be connected *directly* to a G.703 T1 or E1 interface.

With the optional FT1/FE1 Interface, users are able to place a LEDR link from a network service access point to a remote site, where an installation supports multiple communications devices. Direct interface to customer equipment, such as channel banks, is possible without the use of expensive protocol converters.

14.2 Fractional-T1/E1 Performance

The FT1 and FE1 Interface allows the LEDR radio to be connected directly with a G.703 T1 or E1 interface. The line rate of the interface operates at the T1 rate of 1.544 Mbps, or E1 rate of 2.048 Mbps. Twelve user selectable DS0 timeslots are transmitted over the air in either case. The FT1 interface is G.703 at 100 Ω line impedance. The FE1 interface is G.703 at 120 Ω line impedance. Physical connection is via an RJ-45 jack on the rear panel.

14.3 Configurable Parameters

The following performance specifications of the T1 fractional interface are adjustable by the user. All of these parameters are manageable locally, or over the air via SNMP network management. (Refer to the SNMP Handbook, P/N 05-3532A01 for more information.)

Timeslots and Framing

Twelve DS0 timeslots are permitted. In FT1, the timeslot selection is arbitrary. In FE1, timeslot 0 is always sent and the remaining timeslots are arbitrary with the exception of timeslot 16. (Timeslot 16 must be sent when any CAS frame structures are selected.) The selection of timeslots can be different at each end of the link, provided their *number* is equal. The timeslots may not be reordered.



Alarm signals RAI and AIS are generated as appropriate. The user may optionally have these signals forwarded over the RF link.

The frame formats available for **Fractional-T1** operation are as follows:

- FT only
- ESF without CRC checking and generation
- SF (D4)
- SF with JYEL indication
- ESF with CRC checking and generation

The frame formats available for **Fractional-E1** operation are as follows:

- FAS only
- FAS with BSLIP
- FAS with CRC
- FAS with CRC and BSLIP
- FAS and CAS
- FAS with CAS and BSLIP
- FAS with CAS and CRC
- FAS with CAS
- CRC and BSLIP.

The re-framing criteria may be adjusted to the following settings: 2 out of 4 Fbit errors, 2 out of 5 Fbit errors, 2 out of 6 Fbit errors. For FE1, the reframing criteria is selectable between consecutive FAS errors or CRC errors.

Line Codes

The following standard T1 line codes are supported: B8ZS, AMI, and per-channel B7ZS.

The following standard E1 line codes are supported: HDB3 and AMI.

Diagnostics

The T1 line at each end of the link may be tested using a variety of bit patterns. In normal operation, statistics are stored for any errors occurring at the line interface, such as framing errors, bipolar violations, and CRC errors.

Data may be looped back at the local port, through the T1 option only, and at the remote unit. Further, the unit will respond to in-band (SF) and data link (ESF) loopback codes at the local port.

When in ESF framing mode, the option can automatically generate performance report messages.



The following alarms may be monitored & logged. They may also be associated with a user-selectable indication (alarm contact or front panel LED): Remote Loopback, Lost Frame, Lost Signal, Lost Analog Signal, AIS, RAI (RYEL), MultiFrame RAI, Severely Errored Frame, Frame Re-Align, MultiFrame AIS, Far End Block Error, Line Code Error, CRC Errors and Frame Bit Error.

Clocking

The clock source is configurable for network, loopback, and internal timing, with secondary selections available should the primary source become faulty. Refer to the discussion of the **clkmode** command (Page 54) for more information

14.4 Field Installation of the FT1 Interface Board

An "S" Series LEDR radio can be fitted with a Fractional-T1 (FT1) or Fractional-E1 (FE1)Interface Board (Figure 28). The addition of an FT1/FE1 board enables the radio to operate with a G.703 interface at speeds up to 768 kbps.

To add the FT1/FE1 Interface Board to an existing LEDR radio transceiver, follow these steps:

- 1. Remove the top cover of the radio (4 Phillips screws).
- 2. Identify the installation area for the Interface Board (See Figure 29). Remove the three Phillips screws on the main PC board which correspond to the mounting holes on the Interface Board.
- 3. Install the threaded standoff spacers (furnished with the option board) onto the main PC board in the holes formerly occupied by the screws. (Note: Washers must *not* be used between the standoff spacers and either of the PC boards.)
- 4. Locate connectors J912 and J913 (See Figure 29). These connectors mate with the plugs on the bottom of the Interface board.
- 5. Carefully set the optional board into place, making sure to align the mounting holes with the threaded standoffs on the main PCB. (The Interface Board's rear panel connector should align with the rectangular cutout at the radio's rear panel, and the rear edge of the option board should be parallel to the main PC board.)
- 6. Look under the right edge of the Interface board to ensure that J912 is aligned with the mating connector on the option board. With the board properly aligned, push down firmly in the area directly above J913 and then over J912 at the edge. A distinct "locking" action will be felt as the connectors engage.



7. Install the Phillips mounting screws with lockwashers on the top of the FT1 board.

For protected versions only: Install the plastic clip, if supplied, at the right rear corner of the Interface board. It slips over the edge of the main PC board and the option board. *Gently* tighten the hex screw to secure the clamp.)

The Interface board must be properly seated onto the LEDR radio's motherboard before powering up the radio chassis. Failure to properly install the board could result in permanent damage to the motherboard and the optional PCB.

8. Re-install the radio's top cover. This completes the Interface Board installation.



Figure 28. FT1/FE1 Interface Board—Optional Assembly (Part No. 03-3846Axx)







Figure 29. View of Radio PC Board Showing Installation Details for FT1/FE1 Interface Board



15.0 INCREASE BANDWIDTH BY CHANGING TRANSMITTER AND RECEIVER FILTERS

15.1 Introduction

It is possible for qualified service personnel to upgrade LEDR Series radios in the field to increase the radios RF bandwidth. Listed in Table 30 are five upgrade kits. Each kit consists of three RF filters; one is used in the transmitter section and two are used in the receiver section. In addition, there is a unique software key that will allow the data circuitry to handle the higher data bandwidth. This key is based on the radio's serial number and can only be used with that radio.

Each kit consists of a set of 3 filters (transmitter 1; receiver 2), software activation key and instructions for converting radio's occupied bandwidth. The radio serial number must be provided to the factory for issue of authorization key.

For Subrate Radios	For Fullrate Radio
25 kHz to 50 kHz	500 kHz to 1.0 MHz
25 kHz to 100 kHz	500 kHz to 2.0 MHz
25 kHz to 200 kHz	1.0 MHz to 2.0 MHz
50 kHz to 100 kHz	
50 kHz to 200 kHz	
100 kHz to 200 kHz	

Table 30. Hardware Upgrade Kits for Increased RF Bandwidth

To realize the full benefit of the increased RF bandwidth, it may be necessary to upgrade the radio's data interface. Table 1 on Page 1 provides a simplified listing of radio bandwidth and compatible data interfaces.

15.2 Filter Removal and Replacement

These instructions describe the removal and replacement of filter modules inside a LEDR Transceiver, as well as the software commands necessary to authorize the new bandwidth.

CAUTION: This upgrade involves the removal of small, delicate parts. It must be performed by experienced personnel only, using proper tools and equipment to preserve the factory warranty. Precautions must be taken to prevent damage to components due to static discharge and other risks.

1. Remove the radio from service and disconnect all cabling from the rear panel.



- 2. Remove the top cover of the radio (four Phillips head screws).
- 3. Remove the Transmitter and Receiver section's RF shields (Figure 30). It will be necessary to unplug the ribbon cables that cross over the shields—record their locations as you remove them.
- 4. Locate and remove Filter FL700 from the transmitter section. In its place, install the replacement filter furnished with the upgrade kit. Ensure that the new filter is installed in the same orientation as the original unit.



Figure 30. Location of Bandwidth Filters FL600, FL601 and FL700

- 5. Locate and remove Filters FL600 and FL601 from the Receiver module. In their place, install the replacement filters furnished with the upgrade kit. Ensure that the new filters are installed in the same orientation as the original units.
- 6. This completes the required hardware changes. Fasten the top cover and re-connect all cables to the rear panel.
- 7. Power up the radio and proceed to "Software Commands" below.



15.3 Software Commands

To activate the new filter bandwidth, it is necessary to enter an authorization key provided by Microwave Data Systems. This key is based upon the radio serial number and will authorize the new bandwidth of the radio. Contact the factory if you do not already have an authorization number.

- 1. Initiate a NMS terminal session with the LEDR radio. (Refer to Page 25 for login details.)
- 2. At the LEDR> prompt, type: auth add <authorization number>, where <authorization number> is the number provided to you by the factory. Press ENTER.
- 3. This completes the required software changes. If desired, the **auth show** command may be entered to display all of the current options for the LEDR radio.
- 4. Check for alarms on the front panel LED display. If no alarms are present, the basic functionality of the radio can be confirmed. If an alarm is present, double check all cable connections and radio settings.

16.0 BENCH TESTING OF RADIOS

In some cases, it may be necessary to test the operation of the equipment in a bench setting. Figure 31 shows a simple arrangement for bench testing using RF attenuators between the two units under test.

For weak signal tests (weaker than -80 dBm), additional physical separation between Radio 1 and Radio 2 may be required to prevent unintentional coupling between the radios.

On protected radio configurations, a weak received signal will cause the radio transceivers to switch.



Figure 31. Back-to-Back Link Test



You can perform an over-the-air BER test on the bench or in the field. In this case, attach a separate piece of BER test equipment and feed it into one or more of the T1/E1 ports. At the other end of the link, you use another BER test box, or attach a loopback plug to the CPE data I/O port. This tests the quality of the radio link itself with regard to the user payload data. Such a bench, or over-the-air, test does not use the LEDR **bert** command.

- **NOTE:** It is important to avoid over-driving the receiver as it can be damaged by strong signals. Signals stronger than -20 dBm should be avoided to protect the receiver.
- **NOTE:** User BERT test equipment connected to a LEDR T1 data interface my yield different BERT results than the radio's **ber** command. This is likely when less than the channel's capacity is utilized by the timeslot command configuration.

17.0 TECHNICAL REFERENCE

17.1 Specifications— Models: LEDR 400S, LEDR 900S & LEDR 1400S

General

Frequency Ranges:	330–512 MHz (LE 800–960 MHz (LE 1350–1535 MHz (EDR 400S) EDR 900S) (LEDR 1400S)
RF Occupied Bandwidth:	25, 50, 100 and 2	00 kHz
User Data Rates:	64, 128, 256, 384	, 512 & 768 kbps
	With optional FT1 Interface Board: n x 64 kbps (Where n = 12)	
Permitted Data Throughput:	<u>Channel Size</u> 25 kHz 50 kHz 100 kHz 200 kHz	Data Rate 64 kbps 64 kbps to 128 kbps 64 kbps to 256 kbps 64 kbps to 768 kbps
Modulation Type:	32 QAM, 16 QAM	I, QPSK
Forward Error Correction (FEC):	Reed-Solomon	
Acquisition Time— Typical:	From power up, 1	0 seconds
Voltage Range:	24 Vdc or 48 Vdc	(±20%)
Power Consumption:	Less than 60 watt	s (non-protected configuration)
Temperature Range:	– 5° to 50° C	
Humidity:	≤ 90% non-conde	nsing @ 40° C
Size:	1 RU; 19 Inch rac 45 mm (1.75 in) h 426 mm (16.75 in 305 mm (12 in) de	k mount compatible igh, 1RU) wide (excluding rack brackets) eep



Transmitter

Transmit Power:	+30 dBm (1 watt) at antenna port	
Output Control Range:	0 dB to -10 dB		
Frequency Stability:	1.5 ppm		
Spurious Outputs:	< -60 dBc 400S < -60 dBc 900S < -60 dBm 1400S		
Receiver			
Sensitivity (for 10 ⁻⁶ BER):	<u>Bandwidth</u> 25 kHz 50 kHz 100 kHz 200 kHz	<u>Data Rate</u> 64 kbps 128 kbps 256 kbps 768 kbps	<u>Sensitivity</u> –101 dBm –98 dBm –95 dBm –92 dBm
Residual BER:	< 1 x 10 ⁻¹⁰		
Dynamic Range:	> 65 dB		
Interfaces			
Data:	EIA-530, G.703 100 Ω, ba with optional FT1	lanced (RJ-45) Interface Board	
Orderwire:	Voice handset interface, DTMF capable		
Service Channel:	RS-232 @ 9600 bps		
Ethernet:	10 Base-T		
Console Port:	RS-232, 9600 bps to 38.4 kbps		
Alarms:	4 programmable outputs; 4 inputs		
Antenna:	50 Ω Impedance		
Network Management Syste	m		
Accessibility:	Via built-in HTTP	server or comm	and line interfac
SNMP Management (Optional):	Using MIB II and	custom enterpris	e MIB
Diagnostic Functions			
Via Front Panel LEDs:	Power, Active, G & I/O Alarm	eneral Alarm, Rx	Alarm, Tx Alarr
Via Front Panel LCD Display :	Measurements of RSSI, RF Power, Signal-to-Noise ratio, BER		
Data Loopback:	Local and Remo	te	
Agency Approvals			
EMC:	ETS 300 385		
Transmission:	FCC Part 101, RS-119		

LEDR 400S

LEDR 900S



LEDR 1400S

Transmission: Environmental: EMC: Safety: ETS 300 630, MPT 1717 ETS 300 019, Class 3.2 ETS 300 385 CE Mark

17.2 Specifications— Models: LEDR 400F, 900F, 1400F

General

Frequency Ranges:	330–512 MHz (LEDR 400F) 800–960 MHz (LEDR 900F) 1350–1535 MHz (LEDR 1400F)			
RF Occupied Bandwidth:	500 kHz, 1 MHz & 2 MHz			
User Data Rates:	1 x E1 (2.048 Mbp 2 x E1 (4.096 Mbp 4 x E1 (8.192 Mbp	us) us) us)		
Permitted Data Throughput:	<u>Channel Size</u> 500 kHz 1 MHz 2 MHz	Data Rate 1 x E1 (2.048 Mb 2 x E1 (4.096 Mb 4 x E1 (8.192 Mb	ps) ps) ps)	
Modulation Type:	32 QAM, 16 QAM,	, QPSK		
Forward Error Correction (FEC):	Reed-Solomon			
Acquisition Time (Typical):	From power up, 10) seconds		
Voltage Range:	24 Vdc or 48 Vdc	(±20%)		
Power Consumption:	Less than 60 watts	s (non-protected c	onfiguration)	
Temperature Range:	–5° to 50° C			
Humidity:	\leq 90% non-condensing @ 40° C			
Size:	1RU, 19 Inch rack mount compatible 45 mm (1.75 in) high, 1RU 426 mm (16.75 in) wide (excluding rack brackets) 305 mm (12 in) deep			
Transmitter				
Transmit Power:	+30 dBm (1 watt) a	at antenna port		
Output Control Range:	0 dB to -10 dB			
Frequency Stability:	1.5 ppm			
Spurious Outputs:	< –60 dBc (400F) < –60 dBm (1400F)			
Receiver				
Sensitivity (for 10 ⁻⁶ BER):	<u>Bandwidth</u> 500 kHz 1 MHz 2 MHz	<u>Data Rate</u> 1 x E1 2 x E1 4 x E1	<u>Sensitivity</u> –90 dBm –87 dBm –84 dBm	
Residual BER:	< 10 ⁻¹⁰			
Dynamic Range:	> 65 dB			



Interfaces

Data:	G.703 120 Ω , balanced (4 x RJ-45)
Orderwire:	Voice handset interface, DTMF capable
Service Channel:	RS-232 @ 9600 bps
Ethernet:	10 Base-T
Console Port:	RS-232, 9600 bps to 38.4 kbps
Alarms:	4 programmable outputs, 4 inputs
Antenna:	50Ω Impedance

Network Management System

Accessibility:	Via built-in HTTP server or command line interface
SNMP Management (Optional):	Using MIB II and custom enterprise MIB

Diagnostic Functions

Via Front Panel LEDs:	Power, Active, General Alarm, Rx Alarm, Tx Alarm, I/O Alarm
Via Front Panel LCD Display :	Measurements of RSSI, RF Power, Signal-to-Noise ratio, BER
Data Loopback:	Local and Remote

Agency Approvals

LEDR 1400F

Transmission:	ETS 300 630, MPT 1717
Environmental:	ETS 300 019, Class 3.2
EMC:	ETS 300 385
Safety:	CE Mark

17.3 Specifications— Protected Switch Chassis

Transmitter Coupling Loss:	2 dB (Typical)
Receive Coupling Losses:	4 dB with Symmetrical Splitter (Typical) 2 dB/10 dB with Asymmetrical Splitter (Typical)
Power Consumption:	Less than 135 watts (Two LEDR radios and Protected Switch Chassis)

17.4 Optional Equipment (Consult factory for details)

- Space Diversity
- Hot-standby Protected
- Warm-standby Protected
- Bandwidth Upgrade Kits



17.5 Accessories

- 120/240 Vac 50/60 Hz Power Supply (24 Vdc Output)
- Orderwire Handset
- Other items listed in Table 29 on Page 116

NOTE: The factory reserves the right to make changes to this specification without advance notice or obligation to any person.

17.6 I/O Connector Pinout Information

Orderwire—Front Panel



Figure 32. Orderwire RJ-11 Connector

CONSOLE Port—Front Panel



Figure 33. CONSOLE Port DB-9 Female Pinout



Ethernet—Rear Panel



Figure 34. Ethernet Connector

EIA-530-A Data—Rear Panel

Source	Signal Designation	Pin No.	Pin No.	Signal Designation	Source
Source DCE DTE Return DTE Return DTE DEE DCE Return	Test Mode gnal Element Timing (A) Common Remote Loopback Local Loopback gnal Element Timing (A) Receiver Data (B)	25 24 23 22 21 19 9 9 9 9 9 0 0 0 0 0 0 0 0 0 0 0 0 0	- 13 - 12 - 11 - 10 - 9 - 8 - 7 - 6 - 5 - 4 - 3	Clear to Send (B) — Transmit Signal Element Timing (B) — Received Line Signal Detector (B) — Receiver Signal Detector (A) — Signal Ground — DCE Ready (A) — Request to Send (A) — Received Data (A) —	Source — Return — Return — Return — DCE _ Common — DCE — DCE — DTE — DTE
Return	Transmitted Data (B)		- 2 - 1	Transmitted Data (A) Shield	DTE _ Common

Figure 35. EIA-530 Connector Pinout (DB-25)

G.703 Data Connectors (4)—Rear Panel

	Pin	Signal	Direction
	1	Differential digital output signal, ring	Output
RJ-45	2	Differential digital output signal, tip	Output
12345678	3	Ground (Early models: No Connection)	—
╏┎┛┼┼┼┼┼┼┶┓╏	4	Differential digital input signal, ring	Input
	5	Differential digital input signal, tip	Input
	6	Early models: No Connection Late models: Ground	_
	7	No Connection	_
	8	No Connection	_

Figure 36. G.703 Data Connector Pinout (RJ-45)



Service Channel—Rear Panel





Alarm—Rear Panel



Figure 38. Alarm Connector DB-9 Female Pinout (See See "Alarm I/O" on Page 20 for parameters.)



17.7 Watts-dBm-Volts Conversion

Table 31 is provided as a convenience for determining the equivalent voltage or wattage of an RF power expressed in dBm.

dBm	v	Ро	dBm	v	Ро	dBm	m٧	Ро	dBm	μV	Ро
+53	100.0	200W	0	.225	1.0mW	-49	0.80		-98	2.9	
+50	70.7	100W	-1	.200	.80mW	-50	0.71	.01µW	-99	2.51	
+49	64.0	80W	-2	.180	.64mW	-51	0.64		-100	2.25	.1pW
+48	58.0	64W	-3	.160	.50mW	-52	0.57		-101	2.0	•
+47	50.0	50W	-4	.141	.40mW	-53	0.50		-102	1.8	
+46	44.5	40W	-5	.125	.32mW	-54	0.45		-103	1.6	
+45	40.0	32W	-6	.115	.25mW	-55	0.40		-104	1.41	
+44	32.5	25W	-7	.100	.20mW	-56	0.351		-105	1.27	
+43	32.0	20W	-8	.090	.16mW	-57	0.32		-106	1.18	
+42	28.0	16W	-9	.080	.125mW	-58	0.286				
+41	26.2	12.5W	-10	.071	.10mW	-59	0.251		dBm	nV	Po
+40	22.5	10W	-11	.064		-60	0.225	.001µW	107	1000	
+39	20.0	8W	-12	058		-61	0 200		107	000	
+38	18.0	6.4W	-13	050		-62	0 180		100	900	
+37	16.0	5W	-14	045		-63	0.160		-109	710	01-11/
+36	14 1	4W	-15	040		-64	0 141		-110	640	.01010
+35	12.5	3.2W	-16	0355			0.111		-111	640 590	
+34	11.5	2.5W		.0000		dBm	υV	Po	-112	580	
T33	10.0	2\\/	dBm	mV	Po		μν	10	-113	500	
+33	Q ()	1.6\//			10	-65	128		-114	450	
+32	8.0	1.25\//	-17	31.5		-66	115		-115	400	
120	7 10	1.2300	-18	28.5		-67	100		-116	355	
+30	6.40	1.000 800m\\/	-19	25.1		-68	90		-117	325	
+29	6.40 5.90	600mW	-20	22.5	.01mW	-69	80		-118	285	
+28	5.80	640mW	-21	20.0		-70	71	.1nW	-119	251	
+27	5.00	500mW	-22	17.9		-71	65		-120	225	.001pW
+26	4.45	400mvv	-23	15.9		-72	58		-121	200	
+25	4.00	320mVV	-24	14.1		-73	50		-122	180	
+24	3.55	250mW	-25	12.8		-74	45		-123	160	
+23	3.20	200mW	-26	11.5		-75	40		-124	141	
+22	2.80	160mW	-27	10.0		-76	35		-125	128	
+21	2.52	125mW	-28	8.9		-77	32		-126	117	
+20	2.25	100mW	-29	8.0		-78	29		-127	100	
+19	2.00	80mW	-30	7.1	.001mW	-79	25		-128	90	
+18	1.80	64mW	-31	6.25		-80	22.5	.01nW	-129	80	.1 <i>f</i> W
+17	1.60	50mW	-32	5.8		-81	20.0		-130	71	
+16	1.41	40mW	-33	5.0		-82	18.0		-131	61	
+15	1.25	32mW	-34	4.5		-83	16.0		-132	58	
+14	1.15	25mW	-35	4.0		-84	11 1		-133	50	
+13	1.00	20mW	-36	3.5		-85	12.9		-134	45	
+12	.90	16mW	-37	3.2		-86	11.5		-135	40	
+11	.80	12.5mW	-38	2.85		-87	10.0		-136	35	
+10	.71	10mW	-30	2.05		-07	0.0		127	22	
+9	.64	8mW	40	2.5	1\//	-00	9.0		120	20	
+8	58	6.4mW	-40	2.25	.14	-09	0.0	001-10/	120	29	
+7	500	5mW	-41	2.0		-90	7.1	.00100	-139	25	04.614/
+7 +6	.300	4mW	-42	1.8		-91	6.1		-140	23	.015 VV
+0 +5	.445	3.2m\//	-43	1.6		-92	5.75				
+0	.400	0.2111VV	-44	1.4		-93	5.0				
+4	.300	2.0mW	-45	1.25		-94	4.5				
+3	.320	∠.000V	-46	1.18		-95	4.0				
+2	.280		-47	1.00		-96	3.51				
+1	.252	1.25mW	-48	0.90		-97	3.2				

Table 31. dBm-Volts-Watts Conversion Chart

18.0 RADIO EVENT CODES

Table 32 lists the event codes that may be encountered during operation of the radio. These codes may be read from a terminal using the **events pending** command. (See Page 57 for a full description of the **events** command.)



NOTE: The event codes listed here are available on radios equipped with the optional FT1 Interface Board. Standard "S" Series radios will display fewer codes.

ID	EVENT NAME	DESCRIPTION	DEFAULT LED	SNMP TRAP LEVEL
0	EXT_ALARM_IN1	External Alarm Input #1	ALARM	CRITICAL
1	EXT_ALARM_IN2	External Alarm Input #2	ALARM	CRITICAL
2	EXT_ALARM_IN3	External Alarm Input #3	ALARM	CRITICAL
3	EXT_ALARM_IN4	External Alarm Input #4	ALARM	CRITICAL
4	MODULATOR_EV	Communication failure with modulator	ALARM	CRITICAL
5	DEMODULATOR_EV	Communication failure with demodulator	ALARM	CRITICAL
6	MOD_SELFTEST	Modulator selftest failed	NONE	CRITICAL
7	DEMOD_SELFTEST	Demodulator selftest failed	NONE	INFORM
8	PERM_REGN_CHECKSUM	Permanent region checksum failed	NONE	INFORM
9	APP1_REGN_CHECKSUM	Application #1 checksum failed	NONE	INFORM
10	APP2_REGN_CHECKSUM	Application #2 checksum failed	NONE	INFORM
11	BOOT_REGN_CHECKSUM	Boot loader checksum failed	NONE	INFORM
12	CONF1_REGN_CHECKSUM	Configuration Data region #1 checksum failed	NONE	INFORM
13	CONF2_REGN_CHECKSUM	Configuration Data region #2 checksum failed	NONE	INFORM
14	RTC_TEST	Real-time clock error	NONE	INFORM
15	BBRAM_TEST	NV-RAM test failed	NONE	INFORM
16	BATTERY_LOW	NV-RAM battery is low	ALARM	MAJOR
17	TX_SYNTH_LOCK	Transmit Synthesizer out-of-lock	TXALARM	CRITICAL
18	RX_SYNTH_LOCK	Receive Synthesizer out-of-lock	RXALARM	CRITICAL
19	DIG_POWER_REF	Digital Power Reference is out of specified range	ALARM	CRITICAL
20	TEMPERATURE	Temperature sensor reads over 80 degrees Celsius	ALARM	CRITICAL
21	TX_POWER_LOOP	Transmit Power Loop is out-of-lock	TXALARM	MAJOR
22	DEMOD_SNR_LOW	Demodulator Signal-to-Noise ratio is unacceptably low	NONE	MINOR

Table 32. Event Codes



Table 32. Event Codes (Continued)

ID	EVENT NAME	DESCRIPTION	DEFAULT LED	SNMP TRAP LEVEL
23	DEMOD_AGC_RSSI	Demodulator Automatic Gain Controlled RSSI too low	NONE	MINOR
24	DEMOD_FEC_RECOVER	FEC circuitry has detected and corrected one or more errors	NONE	MINOR
25	DEMOD_FEC_UNRECOVER	FEC circuitry has detected one or more uncorrectable errors	NONE	MINOR
26	DEMOD_MULTIPATH	Excessive multipath distortion detected	NONE	MINOR
27	DEMOD_ACQUISITION	Demodulator lost sync. lock on received signal	RXALARM	CRITICAL
28	TX_TO_REMOTE_RX	Problem with link between the local transmitter & remote Rx	ALARM	CRITICAL
29	REDUNDANT_ALARM	Problem with redundant unit	ALARM	CRITICAL
30	WDOG_TIME_OUT	Processor watchdog has expired and reset the processor	ALARM	CRITICAL
31	RX_OFF	Radio is not receiving due to a weak signal or equipment failure	RXALARM	CRITICAL
32	SOFTWARE_TX_OFF	Software command has unkeyed the radio	TXALARM	CRITICAL
33	RTC_NOT_SET	The real time clock is not programmed	NONE	MINOR
34	IO1_DIG_LOC_IOOPBACK	The radio's 530 or TELCO I/O port is in Digital local loopback mode	NONE	INFORM
35	IO2_DIG_LOC_IOOPBACK	The radio's 2nd TELCO I/O port is in Digital local loopback mode	NONE	INFORM
36	IO3_DIG_LOC_IOOPBACK	The radio's 3rd TELCO I/O port is in Digital local loopback mode	NONE	INFORM
37	IO4_DIG_LOC_IOOPBACK	The radio's 4th TELCO I/O port is in Digital local loopback mode	NONE	INFORM
38	RF_LOCAL_LOOPBACK	The radio is in Local RF loopback test mode	NONE	INFORM
39	IO1_DIG_REM_LOOPBACK	The radio's 530 or TELCO I/O port is in Digital Remote loopback mode	NONE	INFORM
40	IO2_DIG_REM_LOOPBACK	The radio's 2nd TELCO I/O port is in Digital Remote loopback mode	NONE	INFORM



Table 32.	Event Codes	(Continued)
		(Commucu)

ID	EVENT NAME	DESCRIPTION	DEFAULT LED	SNMP TRAP LEVEL
41	IO3_DIG_REM_LOOPBACK	The radio's 3rd TELCO I/O port is in Digital Remote loopback mode	NONE	INFORM
42	IO4_DIG_REM_LOOPBACK	The radio's 4th TELCO I/O port is in Digital Remote loopback mode	NONE	INFORM
43	RAW_SERVICE_CHANNEL	The Raw Service Channel data frame is exhibiting error	ALARM	MAJOR
44	ATOD_REFERENCE	A fault is detected with the Analog to Digital converter	ALARM	CRITICAL
45	NEW_CONFIG_REV	A new revision of configuration data structure has been detected	NONE	INFORM
46	FPGA_LOAD	FPGA is not loaded correctly	NONE	INFORM
47	DATE_TIME_CHANGE	The date or time is been modified	NONE	INFORM
48	HARDWARE_TX_OFF	The transmitter key hardware is in an unkeyed state	TXALARM	CRITICAL
49	INACTIVE_ON	Current radio transceiver is in standby mode when in protected radio chassis	ALARM	MAJOR
50	NO_OPTION_UNIT	No Option Card is detected	NONE	INFORM
51	VOCODER_INIT_ERR	The voice processor initialization failed	ALARM	MAJOR
52	VOCODER_ERROR	The voice processor is reporting a problem	ALARM	MAJOR
53	POWER_ON_RESET	This indicates PowerOn Reset Cycle	NONE	INFORM
54	EXT_HARD_RESET	This indicates last Power-Up Cycle was due to External Hard Reset	NONE	INFORM
55	EXT_SOFT_RESET	This indicates last Power-Up Cycle was due to External Soft Reset	NONE	INFORM
56	INACT_CONFIG_SYNC	Protected 1+1 mode Active to Inactive Configuration data sync. error	ALARM	CRITICAL
57	NEW FIRMWARE LOADED	New firmware has been downloaded from flash memory.	NONE	INFORM
58	CONFIG_CHANGED	The radio transceiver configuration has been modified	NONE	INFORM



ID	EVENT NAME	DESCRIPTION	DEFAULT LED	SNMP TRAP LEVEL
59	SELFTEST_COMPLETE	A self test has completed execution	NONE	INFORM
60	PERFORM_DEGRADED	A performance degradation threshold has been exceeded	ALARM	INFORM
61	DUPLICATE_UNIT_ID	Another unit with the same unit ID has been detected	ALARM	INFORM
62	LINK_UNAVAILABLE	The G821 status indicates that the link is unavailable	NONE	INFORM
63	EVENT_LOG_CLEARED	The event log has been cleared	NONE	INFORM
64	FAN1_TROUBLE	There is a problem with the fan	ALARM	INFORM
65	Reserved for future use	_	—	_
66	USER_REBOOT	The user has rebooted the radio	NONE	INFORM
67	MODEM_LOCAL_LOOPBACK	Modulator data path is locally looped back to Demodulator	NONE	INFORM
68	MODEM_REMOTE_LOOPBA CK	Demodulator data path is looped back to modulator for remote radio loopback application	NONE	INFORM
69	OPT_MUX_LOOBACK	Option card multiplexed data path from Line(s) is looped back	NONE	INFORM
70	IO1_REM_LOOPBACK_SERV	Radio is server for remote radio loopback mode with its payload data at Line IO #1 looped back to the commanding local radio	NONE	INFORM
71	IO2_REM_LOOPBACK_SERV	Radio is server for remote radio loopback mode with its payload data at Line IO #2 looped back to the commanding local radio	NONE	INFORM
72	IO3_REM_LOOPBACK_SERV	Radio is server for remote radio loopback mode with its payload data at Line IO #3 looped back to the commanding local radio	NONE	INFORM
73	IO4_REM_LOOPBACK_SERV	Radio is server for remote radio loopback mode with its payload data at Line IO #4 looped back to the commanding local radio	NONE	INFORM
74	IO1_RECVR_LOF	Line IO #1 receiver Loss-of-framing alarm.	I/O ALARM	CRITICAL


ID	EVENT NAME	DESCRIPTION	DEFAULT LED	SNMP TRAP LEVEL
75	IO1_RECVR_LOS	Line IO #1 receiver Loss-of-signal alarm	I/O ALARM	CRITICAL
76	IO1_RECVR_ALOS	Line IO #1 receiver Loss-of-analog-signal alarm	I/O ALARM	CRITICAL
77	IO1_RECVR_AIS	Line IO #1 receiver detected AIS alarm	I/O ALARM	CRITICAL
78	IO1_RECVR_RAI	Line IO #1 receiver detected RAI (yellow) alarm	I/O ALARM	CRITICAL
79	IO1_RECVR_MRAI	Line IO #1 receiver detected multi-framed RAI (yellow) alarm	I/O ALARM	CRITICAL
80	IO1_RECVR_SEF	Line IO #1 receiver detected Severely Errored Frames	I/O ALARM	CRITICAL
81	IO1_RECVR_COFA	Line IO #1 receiver detected Change-of-Frame- Alignment alarm	I/O ALARM	CRITICAL
82	IO1_RECVR_MAIS	Line IO #1 receiver detected multi-framed AIS alarm	I/O ALARM	CRITICAL
83	IO1_RECVR_FEBE	Line IO #1 receiver detected E1 Far-End-Block-Errors alarm	I/O ALARM	INFORM
84	IO1_RECVR_LCV	Line IO #1 receiver detected Line-Code- Violation alarm	I/O ALARM	INFORM
85	IO1_RECVR_CRC	Line IO #1 receiver detected CRC alarm	I/O ALARM	INFORM
86	IO1_RECVR_FBIT	Line IO #1 receiver detected Frame Bit Error	I/O ALARM	INFORM
87	IO2_RECVR_LOF	Line IO #2 receiver Loss-of-framing alarm	I/O ALARM	CRITICAL
88	IO2_RECVR_LOS	Line IO #2 receiver Loss-of-signal alarm	I/O ALARM	CRITICAL
89	IO2_RECVR_ALOS	Line IO #2 receiver Loss-of-analog-signal alarm	I/O ALARM	CRITICAL
90	I02_RECVR_AIS	Line IO #2 receiver detected AIS alarm	I/O ALARM	CRITICAL
91	IO2_RECVR_RAI	Line IO #2 receiver detected RAI (yellow) alarm	I/O ALARM	CRITICAL
92	IO2_RECVR_MRAI	Line IO #2 receiver detected multi-framed RAI (yellow) alarm	I/O ALARM	CRITICAL



ID	EVENT NAME	DESCRIPTION	DEFAULT LED	SNMP TRAP LEVEL
93	IO2_RECVR_SEF	Line IO #2 receiver detected Severely Errored Frames	I/O ALARM	CRITICAL
94	IO2RECVR_COFA	Line IO #2 receiver detected Change-of-Frame- Alignment alarm	I/O ALARM	CRITICAL
95	IO2_RECVR_MAIS	Line IO #2 receiver detected multi-framed AIS alarm	I/O ALARM	CRITICAL
96	IO2_RECVR_FEBE	Line IO #2 receiver detected E1 Far-End-Block-Errors alarm	I/O ALARM	INFORM
97	IO2_RECVR_LCV	Line IO #2 receiver detected Line-Code-Violation alarm	I/O ALARM	INFORM
98	IO2_RECVR_CRC	Line IO #2 receiver detected CRC alarm	I/O ALARM	INFORM
99	IO2_RECVR_FBIT	Line IO #2 receiver detected Frame Bit Error	I/O ALARM	CRITICAL
100	IO3_RECVR_LOF	Line IO #3 receiver Loss-of-framing alarm	I/O ALARM	CRITICAL
101	IO3_RECVR_LOS	Line IO #3 receiver Loss-of-signal alarm	I/O ALARM	CRITICAL
102	IO3_RECVR_ALOS	Line IO #3 receiver Loss-of-analog-signal alarm	I/O ALARM	CRITICAL
103	IO3_RECVR_AIS	Line IO #3 receiver detected AIS alarm	I/O ALARM	CRITICAL
104	IO3_RECVR_RAI	Line IO #3 receiver detected RAI (yellow) alarm	I/O ALARM	CRITICAL
105	IO3_RECVR_MRAI	Line IO #3 receiver detected multi-framed RAI (yellow) alarm	I/O ALARM	CRITICAL
106	IO3_RECVR_SEF	Line IO #3 receiver detected Severely Errored Frames	I/O ALARM	CRITICAL
107	IO3_RECVR_COFA	Line IO #3 receiver detected Change-of-Frame- Alignment alarm	I/O ALARM	CRITICAL
108	IO3_RECVR_MAIS	Line IO #3 receiver detected multi-framed AIS alarm	I/O ALARM	CRITICAL
109	IO3_RECVR_FEBE	Line IO #3 receiver detected E1 Far-End-Block-Errors alarm	I/O ALARM	INFORM



ID	EVENT NAME	DESCRIPTION	DEFAULT LED	SNMP TRAP LEVEL
110	IO3_RECVR_LCV	Line IO #3 receiver detected Line-Code- Violation alarm	I/O ALARM	INFORM
111	IO3_RECVR_CRC	Line IO #3 receiver detected CRC alarm	I/O ALARM	INFORM
112	IO3_RECVR_FBIT	Line IO #3 receiver detected Frame Bit Error	I/O ALARM	INFORM
113	IO4_RECVR_LOF	Line IO #4 receiver Loss-of-framing alarm	I/O ALARM	CRITICAL
114	IO4_RE CVR_LOS	Line IO #4 receiver Loss-of-signal alarm	I/O ALARM	CRITICAL
115	IO4_RECVR_ALOS	Line IO #4 receiver Loss-of-analog-signal alarm	I/O ALARM	CRITICAL
116	IO4_RECVR_AIS	Line IO #4 receiver detected AIS alarm	I/O ALARM	CRITICAL
117	IO4_RECVR_RAI	Line IO #4 receiver detected RAI (yellow) alarm	I/O ALARM	CRITICAL
118	IO4_RECVR_MRAI	Line IO #4 receiver detected multi-framed RAI (yellow) alarm	I/O ALARM	CRITICAL
119	IO4_RECVR_SEF	Line IO #4 receiver detected Severely Errored Frames	I/O ALARM	CRITICAL
120	IO4_RECVR_COFA	Line IO #4 receiver detected Change-of-Frame- Alignment alarm	I/O ALARM	CRITICAL
121	IO4_RECVR_MAIS	Line IO #4 receiver detected multi-framed AIS alarm	I/O ALARM	CRITICAL
122	IO4_RECVR_FEBE	Line IO #4 receiver detected E1 Far-End-Block-Errors alarm	I/O ALARM	INFORM
123	IO4_RECVR_LCV	Line IO #4 receiver detected Line-Code-Violation alarm	I/O ALARM	INFORM
124	IO4_RECVR_CRC	Line IO #4 receiver detected CRC alarm	I/O ALARM	INFORM



ID	EVENT NAME	DESCRIPTION	DEFAULT LED	SNMP TRAP LEVEL
125	IO4_RECVR_FBIT	Line IO #4 receiver detected Frame Bit Error	I/O ALARM	INFORM
126	DIG_REM_LOOPBACK	For EIA-530, local radio is in remote loopback mode	NONE	INFORM
127	SERV_REM_LOOPBACK	For EIA-530, local radio (as remote server) is serving remote loopback mode	NONE	INFORM
128	BAD_CLKMODE	Line framers detected bad clock mode configuration	NONE	INFORM

19.0 IN CASE OF DIFFICULTY

MDS products are designed for long life and trouble-free operation. However, this equipment, as with all electronic equipment, may have an occasional component failure. The following information will assist you in the event that servicing becomes necessary.

19.1 FACTORY TECHNICAL ASSISTANCE

Assistance for MDS products is available from our Technical Services group during business hours (8:00 A.M.–5:30 P.M. Eastern Time). When calling, please give the complete model number of the radio, along with a description of the trouble symptom(s) that you are experiencing. In many cases, problems can be resolved over the telephone, without the need for returning the unit to the factory.

Please use the following telephone numbers for product assistance:

716-241-5510 (Phone) 716-242-8369 (FAX)

19.2 FACTORY REPAIRS

Component level repair of radio equipment is *not* recommended in the field. Many components are installed using surface mount technology, which requires specialized training and equipment for proper servicing. For this reason, the equipment should be returned to the factory for any PC board repairs. The factory is best equipped to diagnose, repair and align your radio to its proper operating specifications.



If return of the equipment is necessary, you will be issued a Returned Material Authorization (RMA) number. The RMA number will help expedite the repair so that the equipment can be repaired and returned to you as quickly as possible. Please be sure to include the RMA number on the outside of the shipping box, and on any correspondence relating to the repair. *No equipment will be accepted for repair without an RMA number*.

A statement should accompany the radio describing, in detail, the trouble symptom(s), and a description of any associated equipment normally connected to the radio. It is also important to include the name and telephone number of a person in your organization who can be contacted if additional information is required.

The radio must be properly packed for return to the factory. The original shipping container and packaging materials should be used whenever possible. All factory returns should be addressed to:

Microwave Data Systems Inc. Customer Service Department (RMA No. XXXX) 175 Science Parkway Rochester, NY 14620 USA

When repairs have been completed, the equipment will be returned to you by the same shipping method used to send it to the factory. Please specify if you wish to make different shipping arrangements.







GLOSSARY

AMI—Alternate Mark Inversion. A bipolar format where consecutive marks (ones) have the polarity inverted. Spaces (ones) are represented by zero volts. This technique prevents long sequences of positive or negative voltages.

Analog—Signals with a continuously varying amplitude, such as the human voice.

BERT—Bit-error rate test. The results of a BERT are normally expressed as a ratio (power of 10) of the number of bits received in error compared to the total number received.

BER—Bit-error rate. See also *BERT*.

Bit—Binary digit. The smallest unit of digital data, often represented by a one or a zero. Eight bits usually comprise a byte.

bps—Bits-per-second. A measure of the information transfer rate of digital data across a communication channel.

Byte—A digital "word" usually made up of eight bits.

dBi—Decibels of gain relative to an isotropic radiator. (A hypothetical antenna which radiates equally in all directions.) Used to express antenna gain.

dBm—Decibels relative to one milliwatt. An absolute unit used to measure signal power, as in transmitter power output, or received signal strength.

DTR—Data Terminal Ready. A control signal sent from the radio indicating that it is ready to transmit data.

CPE—Customer premise (provided) equipment.

DCE— Data (circuit terminating) Communications Equipment. In data communications terminology, this is the "modem" side of a computer-to-modem connection. The transceiver is a DCE device which is designed to connect to a DTE device.

Decibel (dB)—A measure of the ratio between two signal levels. Frequently used to express the gain or loss of a system.

DSP—Digital Signal Processing. A processing technique that uses software algorithms to filter, shape, or otherwise modify the characteristics of a given signal. In the LEDR radio, DSP is used primarily in modulation and demodulation functions.

E1—An international telephony standard that operates at 2.048 megabits-per-second (Mbps). This transmission speed is commonly used throughout the world except for North America (which uses T1 1.544 Mbps). Framed E1 consists of 30 digitized telephone channels and two 64 Kbps control channels.

EIRP—Effective Isotropic Radiated Power. Commonly used to express the power radiated from a gain antenna. It is equal to the power transmitted (minus feedline loss) plus the antenna gain.

Fade Margin—The maximum tolerable reduction in received signal strength which still provides an acceptable signal quality. This compensates for reduced signal strength due to multipath, slight antenna movement or changing atmospheric losses. Expressed in decibels.

FEC—Forward Error Correction. Extra data is added to the transmitted signal to allow for detection and correction of some transmission errors.



Frame—A segment of data that adheres to a specific data protocol and contains definite start and end points. It provides a method of synchronizing transmissions.

Fresnel Zone—A point of maximum width or girth of the transmitted radio signal. Obstructions in this region (the "first Fresnel zone") can have a detrimental effect on reception quality. As a general rule, 60 percent of the first Fresnel zone should be free of obstructions in a well designed system. (Additional considerations are also required when planning a microwave path.

G.703—The ITU standard defining the characteristics of digital interfaces (pulse shape, voltage levels, etc.). This applies to high-speed, three-level data being sent over coaxial or twisted pair lines.

G.821—The ITU standard by which data transmission quality is measured. The analysis considers available vs. unavailable time.

Half-Power Beamwidth—The customary way of measuring the width of a directional antenna's radiation pattern. This beamwidth is measured in degrees between the half-power points (the point at which the power is reduced 3 dB with respect to the main beam).

HDB3—High density bipolar order of 3. A line interface standard for E1 transmission that employs coding to eliminate data streams with four or more consecutive zeros.

Hitless Switching Operation—Refers to the practice of switching between receive signal paths without introducing bit errors or timing slips. This feature is required for space or frequency diversity applications.

Hot Standby—Refers to a state of the inactive (standby) transceiver in a Protected or Redundant configuration. In a Hot Standby configuration, the standby transceiver is actively transmitting.

ITU—International Telecommunications Union.

kbps—Kilobits-per-second.

Linecode—Refers to the data coding format used by the radio for the line interface. (It does not pertain to the radio's modulation coding.) The available linecode selections are HDB3 and AMI.

Mbps—Megabits-per-second.

MIB—Management Information Base. The MIB stores SNMP messages that are directed to the management console. This can include Server events, statistical data and system queries.

Multipath Fading—Signals arriving at the receiver out of phase which have a tendency to cancel each other. It is caused by reflections of the transmitted wave and results in distortion at the receiver or weak received signal strength.

Multiplexer—A signal processing unit that combines multiple streams of data into one for transmission across a single data channel.

NMS—Network Management System. A software application used to configure, diagnose and monitor a communication network. The LEDR radio's SNMP program is an example of an NMS.

Protected Radio—A radio configuration where there are redundant modules that automatically become active in the event of a failure.

Protected Operation—Refers to the practice of providing redundant transmit and receive signal paths through the radio (antenna to customer payload interface) so that no single point of failure in a single radio will interrupt the link. This feature is also referred to as 1+1 Operation and is usually provided by operating the system using Hot Standby.

PSC—Protected Switch Chassis. Chassis holding data and RF control/switch circuitry in a redundant/protected configuration.



QAM—Quadrature Amplitude Modulation. Uses phase shifts and amplitude changes to send high-speed data in a comparatively narrow RF channel. See also *QPSK*.

QPSK—Quadrature Phase Shift Keying. Uses four levels of phase shift to send high-speed data with a higher system gain than QAM modulation. See also *QAM*.

Redundant Switching—Refers to the practice of switching between transmit signal paths when a fault condition occurs on the currently active radio.

RSSI—Received signal strength indication. Expressed in dBm.

SNMP—Simple Network Management Protocol. A common network management system (NMS) protocol used to monitor and control a communications network

SNR—Signal-to-noise ratio. Expressed in decibels (dB).

SWR—Standing Wave Ratio. A parameter related to the ratio between forward transmitter power and the reflected power from the antenna system. As a general guideline, reflected power should not exceed 10% of the forward power (2:1 SWR).

TFTP—Trivial File Transfer Protocol. A standard network protocol used to send and receive files between two devices.

Warm Standby—Refers to a state of the inactive (standby) transceiver in a Protected or Redundant configuration. In a Warm Standby configuration, the standby transceiver is not transmitting and must be keyed after switching.





QUICK START GUIDE

Continued from inside of the front cover.

7. Set TCP/IP settings to enable SNMP and/or Telnet Network Management (If required)

- The unit IP address are factory configured with a unique address based on the last three digits of the unit serial number.
- Use IP command to change the IP address, set netmask, gateway and IP Port as necessary. In a protected radio, change the **RDNT** settings to match the user-assigned IP addresses.

8. Assign user configurable fields (As required)

Many items are user configurable, to ease customer use. These include, but are not limited to the following. See the **NMS** command description in the manual for more detail:

- Set user information fields using INFO command (Page 62).
- Set alarms and alarm mappings using the ALARM (Page 49) and EVMAP (Page 57) commands.
- Set alarm thresholds using the THRESHOLD command (Page 83).
- Set the SNMP community using the SNMPCOMM command (Page 81).

9. Perform bench tests to verify the performance of the radio

The data performance and NMS should be verified. Use the LOOPBACK commands (Page 69) to verify data throughput. (See "BENCH TESTING OF RADIOS" on Page 124.)

10.Install the link

Peak the antennas for maximum RSSI using the continuously updated **RSSI** command (Page 80) through the front panel screen or the **TREND** command (Page 86) via the NMS.

11. Verify proper operation by observing the LED display

- Refer to "Front Panel" on Page 13 for a description of the status LEDs.
- Aim directional antenna for maximum receive signal strength using the RSSI Screen.

12. Configure the SNMP Manager software

• Refer to the SNMP Handbook (Part No. 05-3532A01). (This manual is published by MDS in paper form, or may be downloaded from our web site at **www.microwavedata.com**.

End of Quick Start Guide



Microwave Data Systems Inc.

175 Science Parkway, Rochester, New York 14620 General Business: +1 (716) 242-9600 FAX: +1 (716) 242-9620 www.MicrowaveData.com