



TimeSource 3500

GPS Primary Reference Source



097-72050-01
Issue 6: March 2003

FCC Regulatory Notice

Warning: This equipment generates, uses, and can radiate radio frequency energy, and if not used in accordance with the instruction manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart B of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

Symmetricon, Inc.
2300 Orchard Parkway
San Jose, CA 95131-1017

<http://www.symmetricon.com>

Copyright © 2003 Symmetricon, Inc.
All rights reserved. Printed in U.S.A.

Symmetricon is a registered trademark of Symmetricon, Inc. BesTime, DCD, and TimeSource are trademarks of Symmetricon, Inc. All other product names, service marks, trademarks, and registered trademarks used in this document are the property of their respective owners.

Acronyms and Abbreviations

AIS	alarm indication signal
ANSI	American National Standards Institute
DS1	digital signal, level 1 (1.544 Mb/s)
ESD	electrostatic discharge
ESF	extended superframe
GPS	Global Positioning System
LOS	loss of signal
MDEV	mean time deviation
pps	pulse per second
PRS	primary reference source
RO	remote oscillator
RU	rack unit (1.75 in.)
SSM	synchronization status messaging
T1	digital transmission (1.544 Mb/s)
TDEV	time deviation
TOD	time of day
UTC	Universal Coordinated Time

What's New in This Manual

This issue of the TimeSource 3500 user manual has the following changes from the previous issue:

- Added "Antenna Installation and Lightning Protection", "Startup", and "Bridging/Holdover Behavior" sections to Chapter 1.
- Removed TimeScan Craft connection key (020-46700-001) from system equipment lists in Chapter 2.
- Added wall antenna lightning suppressor kit (093-72050-94) to Wall Antenna kit listing in Chapter 2.
- Added information on installing wall antenna lightning suppressor kit to Procedure E, Wall Antenna Installation, in Chapter 3.
- Added section on TimeWizard software installation application to Chapter 3.
- Added Procedure I, TimeWizard Installation and Operation, to Chapter 3.

Description

Chapter 1

Overview	18
Global Positioning System	19
Physical Description	20
Roof Antenna	22
Mechanical Window Antenna	23
Self-Adhesive Window Antenna	24
Wall Antenna	25
Functional Description	26
Overview	26
Antenna	28
Antenna Installation and Lightning Protection	28
IF Interface	30
GPS Receiver	30
Local Oscillator	30
Clock Extractors	30
Power Supply	31
NTP TimeServer	31
Network Time Protocol Password Activation	31
BesTime Ensemble Timing Generator	31
Eight Mixed E1/T1 Outputs	32
Eight Mixed T1/CCK Outputs	32

T1 Outputs	32
Additional T1 Outputs (990-72050-02 Systems Only)	33
TOD Output	33
IRIG-B TOD Outputs (990-72050-05 Systems Only)	33
1 PPS Output	33
10 MHz Output	34
Composite Clock Outputs (990-72050-03 Systems Only)	34
Alarm Interface	34
Communication Ports	34
Ethernet	34
Passthrough	35
Alarm Programmability	36
Startup	37
Bridging/Holdover Behavior	38

Engineering & Ordering Chapter 2

Antenna Guidelines	42
Roof Antenna Location and Cabling Guidelines	44
Roof Antenna Earth Ground Location Guidelines	49
Roof Antenna Cable Choices	50

Window and Wall Antenna Location Guidelines	52
Window and Wall Antenna Cable Choices	54
IRIG-B TOD (990-72050-05 System Only)	56
RJ-422-to-RS-232 TOD Converter	57
Shelf Considerations	58
Systems	59
Standard System (Two T1 Outputs)	60
With Eight Additional T1 Outputs	61
With Eight Additional Mixed E1/T1 Outputs	62
With Eight Additional Mixed T1/CCK Outputs	63
With Eight Composite Clock Outputs	64
With Two IRIG-B TOD Outputs . .	65
Antennas	66
Roof Antenna	67
Mechanical Window Antenna . .	68
Self-Adhesive Window Antenna . .	69
Wall Antenna	70
User-Supplied Tools and Materials . .	71

For Roof Antenna Installation	72
For Mechanical Window Antenna Installation	73
For Self-Adhesive Window Antenna Installation	74
For Wall Antenna Installation	75
For Shelf Installation	76
Outputs, Power, and Miscellaneous	77

Installation

Chapter 3

Unpacking	80
Antenna	81
Roof Antenna	81
Mechanical Window Antenna	87
Self-Adhesive Window Antenna	91
Wall Antenna	94
Shelf	98
Rack Mounting	98
Power and Signal Cabling	99
Frame Ground	101
Power	103
Alarms Output	104
GPS Antenna	104
Additional T1 Outputs (990-72050-02 System Only)	105
Mixed E1/T1 Outputs	105

Mixed T1/CCK Outputs	106
Composite Clock Outputs (990-72050-03 System Only)	106
IRIG-B TOD Outputs (990-72050-05 System Only)	106
1 PPS Output	108
10 MHz Output	108
Ethernet	109
Time of Day Output	110
T1 Reference Inputs	114
T1 Synchronization Outputs	115
Communication Port 1	116
Communication Port 2	117
Craft Port	118
Power-Up	119
TimeWizard	132
Factory-Set Values	135

TL1 Reference

Chapter 4

Conventions	140
Command Format	142
Response Format	143
Parameters	144
Autonomous Messages	149
Report Alarm	150
Report Event	151
Tasks/Commands	152

Commands	154
Activate User	155
Cancel User	156
Copy Memory	157
Delete Equipment	160
Delete User Security	161
Edit Communication	162
Edit Date	166
Edit Equipment	169
Enter Equipment	179
Enter User Security	181
Initialize Log	182
Initialize Register	183
Initialize System	184
Operate Alarm Cutoff All	185
Retrieve Alarm All	186
Retrieve Alarm Equipment	187
Retrieve Communication	189
Retrieve Condition All	192
Retrieve Condition Equipment	193
Retrieve Equipment	195
Retrieve GPS Status	205

Retrieve Inventory	207
Retrieve Log	210
Retrieve Performance Monitoring .	211
Retrieve User Security	227
Set Source Identifier	228

Troubleshooting

Chapter 5

Troubleshooting with Front Panel Items	230
Troubleshooting with Error Messages .	233
Card Replacement	240
Repair and Return	242
Technical Assistance	244
Sales	245
Manual Updates	246

Specifications

Chapter 6

Antennas	248
Roof Antenna	248
Mechanical Window Antenna	248
Wall Antenna	249
Self-Adhesive Window Antenna	249
Communication Ports	250
Port 1	250
Port 2	251
Craft Port	252
Ethernet Port	253
Time of Day Outputs	254

Network Time Protocol (NTP), Type 4, Format 2 Driver Format	254
Cisco Systems	255
IRIG-B TOD Outputs (990-72050-05 System Only)	256
T1 Inputs	257
1 PPS Output	258
T1 Outputs	259
Standard	259
Additional T1 Outputs (990-72050-02 System Only)	260
Mixed E1/T1 Outputs	262
E1/T1 Common	262
E1 Outputs	262
T1 Outputs	263
Mixed T1/CCK Outputs (990-72050-07 System Only)	264
T1/CCK Common	264
T1 Outputs	264
CCK Outputs	265
Composite Clock Outputs (990-72050-03 System Only)	266
10 MHz Output	267
Office Alarms	268
Rear Panel Contacts	268
Front Panel Lamps	268
Front Panel Control	268
Simple Network Time Protocol	269

Power	270
Shelf Mechanical	270
Shelf Environmental	271

Index

Figures

1. Shelf	21
2. Roof Antenna	22
3. Mechanical Window Antenna	23
4. Self-Adhesive Window Antenna	24
5. Wall Antenna	25
6. Block Diagram	27
7. Zone of Protection	29
8. TimeSource 3500 Passthrough Function	36
9. Antenna Field of View	45
10. Antenna Location Examples	46
11. Sample Rooftop Antenna Mount	48
12. Antenna Mask Angle	53
13. Rack Mounting Options	58
14. Roof Antenna-to-Shelf Cabling	82
15. Mechanical Window Antenna-to-Shelf Cabling	88

16. Attaching the Mechanical Window Antenna	90
17. Mechanical Window Antenna Pivot Screws	90
18. Self-Adhesive Window Antenna-to-Shelf Cabling	91
19. Attaching the Self-Adhesive Window Antenna to a Window	93
20. Attaching the IF Converter	93
21. Wall Antenna-to-Shelf Cabling	94
22. Hole Spacing	97
23. Wall Antenna Mounting	97
24. Rack Mounting Options	98
25. Rear Panel Connectors	100
26. Front Panel Connector	100
27. Battery Connections	101
28. Alarm Connections	104
29. OPTIONS I/O Wire-Wrap Pin Connections	105
30. IRIG-B TOD BNC Output Connections	107
31. RS-422-to-RS-232 TOD Converter Mounting Plate	112
32. RS-422-to-RS-232 TOD Converter Connections	112

33. T1 Input Connections	114
34. T1 Output Connections	115
35. Command Format	142
36. Completed Response Format . . .	143
37. Deny Response Format	143
38. Controls and Indicators	230
39. Front of Shelf	241
40. NTP Type 4 Data Format	254
41. Cisco Systems Data Format . . .	255

Tables

A. Timing Source Characteristics . . .	28
B. Ethernet 10base-T RJ-45 Connector Pinouts	109
C. TOD Connector Pinouts	110
D. Converter DB-25 Connector Pinouts	113
E. COM1 Pinouts	116
F. COM2 Connector Pinouts	117
G. Craft Pinouts	118
H. Parameter Factory Settings	135
I. Parameter Definitions	144
J. Commands for Tasks	152
K. Front Panel Items	231
L. Message Troubleshooting	233

Procedures

A. Site Survey 43

B. Roof Antenna Mounting and Cable
Connection 83

C. Mechanical Window Antenna
Mounting and Cable Connection . 89

D. Self-Adhesive Window Antenna
Mounting and Cable Connection . 92

E. Wall Antenna Installation 95

F. IRIG-B TOD Output Installation . . . 107

G. RS-422-to-RS-232 TOD
Converter Installation 111

H. Power-Up 119

I. TimeWizard Installation and
Operation 132

J. Card Replacement 240

K. Equipment Return 243

Description

This chapter provides an overview of the global positioning system, and a physical and functional description.

Overview

1

The TimeSource 3500 is a Primary Reference Source (PRS) that receives and processes signals from GPS satellites, and outputs Stratum 1 synchronization signals traceable to UTC. TimeSource 3500 applications include synchronization for central offices, wireless base stations, transmission nodes, and other cases where a primary reference source can improve the performance of a telecommunications network infrastructure.

The TimeSource 3500 is also ideal for installation in environments where receiving GPS signals is difficult. Examples of environments hostile to GPS signals include urban canyons which have a very limited view of the sky because of blockage from nearby buildings, and high interference zones where GPS signals are jammed by competing over-the-air signals.

The TimeSource 3500 creates timing outputs by ensembling signals from several sources. The sources include GPS signals, an onboard rubidium local oscillator, and optional T1 signals. Timing outputs created from the ensemble are composed of the most stable and least noisy parts of each input. The performance of the T1 sources can be monitored and classified using standard measures. Synchronization outputs are delivered in a framed, all-ones, T1 format, a 10 MHz signal, a 1 pps signal, a composite clock format (optional), and a choice of time of day (TOD) formats.

The TimeSource 3500 minimizes timing impairments, such as jitter and wander, that are created by network and transmission systems. The synchronization timing is traceable to the GPS, which provides the highest level of synchronization for telephony networks. The TimeSource 3500 with its GPS input is a stand-alone office PRS. With the optional inputs ensembled, holdover is extended if GPS signals are disrupted.

Global Positioning System

The United States Government developed the GPS navigation system. It is a satellite-based, radio navigation aid designed to provide global, all-weather, precise navigation and timing capability to users 24 hours a day.

The satellites, circling the earth at approximately 12,550 statute miles, are arranged in 6 orbits with 4 operational satellites in each orbit. Each satellite has an orbital period of approximately 12 hours. This configuration assures that a minimum of 4 satellites, and as many as 12, are in view anywhere in the world at all times.

The TimeSource 3500 tracks all satellites within its field of view. The performance of each tracked satellite is observed and compared to the others, and available for use in the timing solution. A satellite with unacceptable performance data is dropped from the timing solution.

GPS antennas must have line-of-sight access to the transmitting satellites. Any structure that interferes with, or blocks, the view of the satellites disrupts the reception of the signals, and can adversely impact the timing performance of a receiver.

The TimeSource 3500 bridges frequent GPS outage periods with BesTime algorithms, its ultra-stable Rubidium local oscillator and advanced holdover technology. The technology anticipates the outages and uses BesTime-generated predictor values to optimize the performance of timing without direct satellite input.

Physical Description


The TimeSource 3500 consists of a shelf, a plug-in card, an antenna, cables, hardware, and software. Optional system configurations include eight additional T1 outputs, eight additional composite clock outputs, two IRIG-B TOD timing outputs, or eight mixed E1/T1 outputs.

The shelf (Figure 1) occupies two rack mounting units (RU), and can be mounted in a 19 inch rack or a 23 inch rack. One RU (1.75 in.) of air space above the TimeSource 3500 is required for proper ventilation. Other than a communications connector on the front panel, all connectors are at the rear of the shelf.

Four types of antennas are available:

- roof antenna for installation outdoors, usually on a roof
- mechanical antenna for installation indoors, mounted on a window sill or wall for reception through a window
- self-adhesive antenna for installation indoors, adhered directly to a window
- wall antenna for installation outdoors, through a hole in the wall


Figure 1. Shelf



Roof Antenna

The roof antenna (Figure 2) is encased in weather-resistant plastic housing for outdoor installation, usually on a roof. A single coaxial cable carries signals and power between the antenna and the shelf.

Figure 2. Roof Antenna




Mechanical Window Antenna

1

The mechanical window antenna (Figure 3) may be attached to a window sill or wall, in any position that allows the antenna to be moved flush against the window. The antenna can be swung away from the window for window maintenance, and returned to its original position.

A single length of coaxial cable carries signals and power between the antenna assembly and the shelf.

Figure 3. Mechanical Window Antenna



Self-Adhesive Window Antenna

The self-adhesive window antenna assembly (Figure 4) consists of the antenna and two pieces of self-stick hook-and-loop fabric fasteners (Velcro brand or equivalent). The hook-and-loop fabric attaches directly to a window. Coaxial cables carry signals and power between the antenna and the IF converter, and between the IF converter and the shelf.

Figure 4. Self-Adhesive Window Antenna




Wall Antenna

The wall antenna (Figure 5) is mounted on the outside of a building wall. The antenna attaches magnetically to the mounting bracket. The cable from the antenna is routed through a hole drilled in the wall. Coaxial cables carry signals and power between the antenna and the IF converter, and between the IF converter and the shelf.

1

Figure 5. Wall Antenna



Functional Description

Overview

Figure 6 shows the main functions of the TimeSource 3500. The center of the TimeSource 3500 is the BesTime Ensemble Timing Generator, which uses the BesTime algorithm to analyze the phase and frequency relationships, individually and collectively, of the timing sources. Each type of timing source has a particular characteristic that gives it an advantage over other sources, as listed in Table A.

The BesTime algorithm uses the best characteristic of each source to produce an output signal with greater overall accuracy and stability than any single source. The contribution of a source is based on its deviation from the weighted average of all the sources. The more accurate a source, the more weight it has in the final output. Every source is under constant evaluation and its contribution subject to periodic adjustment. The output is essentially the best performance of the best source.

Figure 6. Block Diagram




Table A. Timing Source Characteristics

Source	Characteristic
Local Oscillator	Short term stability
T1 Line	Intermediate term stability
GPS Signal	Long term stability

Antenna

The antenna types include a roof antenna, mechanical window antenna, self-adhesive window antenna, or wall antenna. All antennas include a GPS receiver, amplifier, and intermediate-frequency (IF) downconverter.

The GPS Receiver extracts a clock signal from the GPS satellite signals. The receiver can process the signals from all satellites in view, while simultaneously using the Earth location of the receiver and other factors to determine an accurate clock signal.

An amplifier provides signal gain.


The downconverter converts the L1-band GPS signal to IF for long-distance transport on the coaxial antenna cable. The antenna cable provides current from the shelf to the antenna, and transports GPS satellite IF signals from the antenna to the shelf.

Antenna Installation and Lightning Protection

The TimeSource 3500 standard wall antenna kits do not include lightning protectors. When the antenna is installed on the side of the building, the antenna is in the zone of protection and is protected from lightning strikes as described in the Standard for the Installation of Lightning Protection Systems (NFPA 780), 2000 edition.

The zone of protection shall include the space not intruded by a rolling sphere having a radius of 150 ft (45.72 meters). Where the sphere is tangent to earth and resting against a strike termination device, all space in the vertical plane between the two points of contact and under the sphere shall be considered to be in the zone of protection. A zone of protection shall also be formed where such a sphere is resting on two or more strike termination devices and shall include the space between those devices (see Figure 7). All possible placements of the sphere shall be considered when determining the zone of protection using the rolling sphere model.

Figure 7. Zone of Protection



For structure heights exceeding 150 ft (45.72 m) above earth or above a lower strike termination device, the zone of protection shall be considered to be the space in the vertical plane between the points of contact and under the sphere where the sphere is resting against a vertical surface of the structure and the lower strike termination device or earth. The zone of protection shall be limited to the space above the horizontal plane of the lowest

terminal unless it can be extended by further analysis, such as in rolling the sphere to be tangent to earth.

If the wall antenna is installed outside the zone of protection, Symmetricom offers a lightning protector kit for these installations. Refer to Chapter 2, Engineering & Ordering, for more information on this kit.

IF Interface

An IF interface accepts the signals from the antenna/IF converter, and provides the clock information to the BesTime Ensemble Timing Generator.

GPS Receiver

The GPS Receiver continuously tracks up to eight satellites, using both carrier and code lock. The recovered pseudo-range measurement data is processed to determine precise time and frequency state estimates for the local oscillator. The receiver software is optimized to track and update state estimates, when as few as one satellite is in view.

Local Oscillator

A rubidium oscillator, based on a digitally controlled servo-loop, provides an ultra-stable local oscillator signal, which is sent to the BesTime Ensemble Timing Generator.

Clock Extractors

A clock extractor circuit extracts a timing signal from each external reference source. (External sources, other than the GPS antenna, are optional.) The extracted timing signal is sent to the BesTime Ensemble Timing Generator.

Power Supply

A power converter filters and converts –48 volts dc power supplied to the shelf into the voltages required by the circuitry.

NTP TimeServer

The TimeServer is a Simple Network Time Protocol (SNTP) device. The SNTP TimeServer function is provided via the TimeSource Ethernet interface and associated IP address. User software requests UTC time of day via NTP protocol. The TimeSource SNTP server responds with current UTC time. The TimeServer is compatible with the SNTP RFC-1769 format.

To enable the SNTP feature, a password must be entered using the ED-EQPT TL1 command. If a user makes a fourth attempt of an incorrect password entry, the TimeServer will lock out the user for 1 hour.

Network Time Protocol Password Activation

Use of the Network Time Protocol (NTP) feature requires activation with a password. Activation is accomplished through receipt of a Network Time Protocol Activation Certificate from Symmetricom. This certificate contains the unit purchase order number, unit model number, unit activation date, unit serial number, and unit activation key. The unit activation key is the password that enables the NTP feature. To activate the NTP feature, enter the TL1 command printed on the activation certificate. Once activated, this feature will be permanently enabled. To order the NTP feature, contact the local Symmetricom sales representative.

BesTime Ensemble Timing Generator

Clock signals from the GPS antenna (via the IF interface), local oscillator, and optional T1 span lines are used as sources by the

BesTime algorithms in the BesTime Ensemble Timing Generator. The signals are analyzed for MDEV, TDEV, and other phase and frequency characteristics.

The BesTime Ensemble Timing Generator uses mathematical models to analyze each clock. The ensemble algorithms use the comparisons and analyses to generate a highly stable timing signal, which uses the best qualities of all inputs.

Eight Mixed E1/T1 Outputs

This feature enables a user to mix any combination of E1 and T1 outputs. A user can also use any combination of framing. For E1, CCS, CAS, CCS with CRC4, and CAS with CRC4 can be used per G.703 table 6. For T1, D4 or ESF can be used per ANSI T1.101. In addition, there is support for analog (2.048 MHz) per G.703 table 10 and support for synchronization status messaging (SSM) per TR-33 for E1 and T1.

Eight Mixed T1/CCK Outputs

This feature enables a user to mix any combination of T1 and CCK outputs. For T1, D4 or ESF framing can be used per ANSI T1.101. Support for SSM is per TR-33 for T1.

T1 Outputs

The BesTime Ensemble Timing Generator provides the timing for the T1 timing signal available at the T1 OUT A and B connectors in a framed, all-ones format, which can be set to ESF or D4 framing.

Additional T1 Outputs (990-72050-02 Systems Only)

This option provides eight additional T1 outputs. The outputs are available at the OPTIONS I/O wire-wrap pins on the rear panel. These outputs function the same as the standard T1 outputs.

TOD Output

The BesTime Ensemble Timing Generator provides the timing for the TOD timing signal available at the RJ-45 connector, which provides time code to devices compatible with NTP Type 4 or Cisco ASCII format.

IRIG-B TOD Outputs (990-72050-05 Systems Only)

This option provides two additional TOD outputs in IRIG-B format. The outputs are available at a BNC output module on the OPTIONS I/O wire-wrap pins on the rear panel.

The BesTime Ensemble Timing Generator provides the timing for the TOD timing signal, which provides timing code to devices compatible with IRIG-B.

1 PPS Output

The BesTime Ensemble Timing Generator provides the timing for the 1 pulse-per-second timing signal available at the 1 PPS connector, which can be used for application-specific requirements. This signal is not squelched during an alarm.

10 MHz Output

The BesTime Ensemble Timing Generator provides timing for the 10 MHz timing signal available at the 10 MHz connector, which can be used for local cellular frequency or testing purposes. This signal is not squelched during an alarm.

Composite Clock Outputs (990-72050-03 Systems Only)

This option provides eight composite clock signals. The outputs are available at the OPTIONS I/O wire-wrap pins on the rear panel.

Alarm Interface

The microprocessor delivers alarms to normally open dry-contact type connections. Alarms are also indicated by the front-panel status lamps.

Communication Ports

Three serial communication ports carry TL1 commands, responses, and autonomous messages between the TimeSource 3500 and an external terminal.

Ethernet

TimeSource 3500 has six Ethernet ports to carry TL1 commands, responses, and autonomous messages between the TimeSource 3500 and an external terminal, or an Element Manager, or both. The user can configure the IP address, subnet mask, and gateway address for the Ethernet ports.

Four ports (5001, 5002, 5003, and 5004) are configured to act as though a serial-port communication terminal were connected to them. These ports communicate TL1 commands, responses and autonomous messages.

Two additional ports communicate with Element Managers, which may have NMS, OSMF, or similar software. An Element Manager establishes a connection with one port (5551) for TL1 commands and responses. Another port (5550) establishes a connection to an Element Manager, sends autonomous messages, and closes the connection when finished.

Passthrough

The Passthrough feature of the TimeSource 3500 allows the unit to front a DCD product to provide one management interface for a user site. Passthrough allows a user to do the following:


- Provide a no download exclusion for the Passthrough port
- COM1 or COM2 is connected to the DCD product
- The user port can be any unused port, including the Ethernet port
- Messages can pass from a user to the DCD product and from the DCD product to a user through the TimeSource 3500
- The TID (SID for DCD) is used to identify commands that go to the DCD product. The TimeSource 3500 passes any TID not its own through to the DCD product. In the reverse direction, all commands received from the DCD product are passed through to the user.

Note: The TID of the TL1 command must be the SID of MIS.

- DCD is fully managed except for firmware download.

Figure 8 shows a TimeSource 3500 Passthrough setup.

Figure 8. TimeSource 3500 Passthrough Function



Alarm Programmability

The new release of TimeSource (1.05.03) allows the user to provision the alarm escalation parameters that were hardcoded in the previous releases of TS3000.hex. The defaults for this release remain the same as were previously hardcoded. This feature can be used to set the programmability for such alarms as GPS, HOLDOVER, SPAN-X, and RO-X.

The TS3500 alarms can be programmed for GPS and HOLDOVER types of events. The SPAN-X alarms can be programmed for AIS, ERROR, and LOS types of events. The RO-X alarms can be programmed for ERROR and LOS types of events.

The user can set the parameters for SEVERITY1 and SERAFF1 which initially come into effect when the condition is detected. The user can also set the parameters for SEVERITY2 and SERAFF2 which come into effect after TIME (another user programmable parameter).

Startup

When the TimeSource starts up, the CRIT lamp lights. The CRIT lamp remains on for approximately 50 seconds to 60 seconds and then shuts off.

During startup, the TimeSource performs several self-tests to verify the integrity of the hardware and software. Neither communication nor outputs are possible at this time, and the CRIT lamp is switched on. Once the self-tests are done, a connection to the system can be made and the events viewed.

Two events are initially provided. These events are:

- "Power Up Restart"
- "Settling Period"

In the "Power Up Restart" event, which lasts for approximately 2 minutes, the system does additional checks and starts all the various tasks within the system.

The "Settling Period" event is an informational message that lasts until the TimeSource's BesTime engine reaches the highest possible stable point. The time taken to reach this point depends on satellite availability, type of oscillator, ambient temperature, etc. and may take up to 20 hours to clear. Since "Settling Period" is independent of the quality of the output and is the normal behavior of the system, it is generated as an event rather than an alarm. If "Settling Period" is not cleared after 24 hours, another "Settling Period" event is generated as a marker. This is still Non-Service-Affecting.

As soon as the "Power Up Restart" message is cleared, the "BT3 Warmup" event is generated. This is also an informational message that lasts till the time it takes the system to acquire the satellites, warm up the oscillator, and start giving out valid outputs. It may take up to 2 hours for the message to clear, but typically takes approximately 40 minutes. During the "BT3 Warmup" time, the outputs will generally be squelched. If the

outputs are enabled using the TL1 command (ED-EQPT::TS3500:ctag:::ALMCOND=INH;) they may not be within the PRS mask. In case the system is not able to acquire sufficient number of satellites and/or discipline the oscillator within 2 hours, the event escalates into a Non Service Affecting Minor alarm.

Once the warm up is complete, the system generates valid outputs and the event is cleared.

Bridging/Holdover Behavior

In the TimeSource 3500, alarms are designed with a built-in hysteresis. This means that an alarm is not announced as soon as some error condition is detected. There is a pre-integration time during which the error must persist in order for the alarm to be announced. On the flip side, the error must be clear for a certain time for an alarm condition to be cleared. This ensures that intermittent conditions are not flagged unnecessarily.

During the normal working of the TimeSource 3500, it is a very common occurrence that the GPS satellites may not be visible during certain parts of the day, depending on the installation of the antenna. This is particularly true with wall and, especially, window antenna installations. The TimeSource 3500 has been designed to work around this situation.

The TimeSource 3500 enters "Bridging" mode when all satellite locks are lost. There is no TL1 annunciation that the system has entered "Bridging" mode. This is "Non Service Affecting" and the outputs are not affected. The system runs off its internal oscillator and the outputs are kept within the GR-2830 PRC mask by the BesTime engine.

When "Bridging" mode persists for more than 30 minutes, the system enters "Holdover" mode and a "Holdover" event is generated. This may or may not affect the outputs depending on the alarm integration parameters that can be set by the user.

The system allows the user to set various parameters for GPS error, Holdover error, and SPAN error conditions. These parameters are:

- Initial Severity
- Initial Service Affecting state
- Integration Time
- Final Severity
- Final Service Affecting state

The system also allows the user to set a parameter to define how outputs should behave in an alarm condition. Outputs can be set to AIS, Squelch, or SSM on an alarm. Outputs can also be set to ignore alarm conditions.

When the "Holdover" event is announced, it is announced with the Initial Severity and Initial Service Affecting state. If the "Holdover" event persists for the length of the Integration Time, the alarm is escalated to the Final Severity and Final Service Affecting state.

The "Holdover" event/alarm is cleared when the satellites are visible again.

This page intentionally left blank.

Chapter 2

Engineering & Ordering

This chapter provides information to assist in planning the installation and ordering a system appropriate for a specific site.

Antenna Guidelines

Perform a site survey as described in Procedure A before ordering the system. Use the guidelines and considerations in the Roof Antenna Location and Cabling Guidelines section and the Shelf Considerations section.

2

Procedure A. Site Survey

Step	Action
1	Determine the shelf location.
2	Determine the best location for mounting the antenna (less than 1,000 ft of cable from the shelf). Use the guidelines and considerations in the Roof Antenna Location and Cabling Guidelines section.
3	If a roof-mounted antenna is installed, determine the location of the grounding point for the lightning suppressor, then determine the location of the lightning suppressor. The cable length between the lightning suppressor and the grounding point must be less than 15 ft. If the grounding point is inside the building, the cable length between the grounding point and the cable entry must be less than 50 ft. Valid lightning suppressor grounding points are: • Valid ring ground system (usually for roof-mounted lightning suppressors) • Structural steel of building (for interior-mounted or exterior-mounted lightning suppressors, attach with a cad weld) • Central Office ground plate (usually for interior-mounted lightning suppressors)
4	If a roof-mounted antenna is installed, two lengths of cable are required. Plan the cable route and measure the length of cable required between the antenna and the lightning suppressor, and between the lightning suppressor and the shelf.
5	If a window or wall-mounted antenna is installed, plan the cable route and measure the length of cable required between the antenna and the shelf.
6	Determine the two separate -48 V power sources for the shelf. If only one -48 V power source is available, it must be cabled to both TimeSource 3500 power inputs.

End of Procedure

2

Roof Antenna Location and Cabling Guidelines


DANGER: Do not select an antenna location that could be an electrical or physical hazard to work persons or equipment. Avoid proximity to all high-voltage sources. Mount in an easily maintainable location.

The ideal roof antenna location provides a clear, unobstructed view of the sky from the zenith to the horizon line, and 360 degrees around the horizon.

A compromise often must be made between location and satellite field of view. With a smaller the field of view, the TimeSource 3500 can use fewer satellites in the solution for GPS derived time. The TimeSource 3500 will operate with an average of one satellite in view for 40 percent of the time in a day.

Signals closer to the horizon are often subject to multipath effects, which degrade the timing solution. The TimeSource 3500 can be set to ignore, or mask, all signals from the horizon up to a chosen angle of elevation (mask angle). (See Figure 8.)


Figure 9. Antenna Field of View



Due to the geometry of the GPS satellite orbits, more satellites are visible in the direction of the equator than the poles. If possible, place the antenna so that the antenna has a clear view toward the equator (toward the south in the northern hemisphere, or toward the north in the southern hemisphere). Up to 60 degrees of arc, centered at the pole, may be blocked with little effect in the temperate latitudes. This note is less applicable in latitudes nearer the equator.

The total of obstructions above the mask angle should not obscure more than 25 percent of the total field of view (90 degrees of azimuth) (Figure 9).

Figure 10. Antenna Location Examples



Notes:

1. Place the antenna high enough on the tower that obstructions are below the mask angle; mount the antenna more than 3 feet away from the tower, and far below the interference of the antennas at the top of the tower. Tower mounting is the least desirable location because of the potential for severe multipath, and difficulty in troubleshooting and maintenance.
2. Place the antenna high enough that the roof structure and tree are below the mask angle, and the water tower does not block more than 12.5 percent of the sky.

No single obstruction should block a large portion (45 degrees of azimuth) of the view.

The most important obstructions are within 1/4 mile (400 yards) of the antenna. Obstructions may include, but are not limited to, towers, buildings, other construction, trees, and high-voltage power lines.

Attempt to avoid locating the antenna within 30 degrees azimuth of the transmission direction of any transmitting antenna in the area, even if the transmitting antenna operates at a different

frequency. A transmitting antenna may cause the GPS antenna to become overloaded and reduce its reception capabilities.

The minimum horizontal distance from other receiving antennas is 3 feet.

To reduce multipath signal distortions, the minimum horizontal distance from vertical reflective structures (e.g., heating ducts, equipment housings, etc.) is twice the height of the structure, and no less than 10 feet (Figure 10).

Do not locate the antenna underneath high power lines. If this cannot be avoided, ensure the antenna is placed at least twice as far from the power line as the power line is high (to avoid danger to personnel and multipath effects).

Cables must be run as straight as possible. All cables should be routed in accordance with local company practices.


Note: Keep all impedances as low as possible, otherwise the grounding scheme may be defeated.

Observe the following guidelines during the placement and installation of the cables:

- Route cables as straight as possible (bends in the cable increase impedance at lightning frequencies), in accordance with local company practices.
- Any opening where conduit enters the building must be waterproofed per local company practices.
- Treat all exposed connections with an electrically conductive anti-corrosion compound (Kopr-Shield or equivalent).

Warning: Avoid small-radius turns and unnecessary turns.

Figure 11. Sample Rooftop Antenna Mount



Note: This is an example only. Not all parts are available from Symmetricom.

Roof Antenna Earth Ground Location Guidelines

The roof ring ground system, a Central Office grounding plate, and building structural steel are examples of valid earth ground points. If the mounting plate cannot be bolted to a valid earth ground, or if the mounting plate is to be installed in a nonmetallic junction box, bolt the mounting plate to a point within 15 feet of the valid earth ground.

2

Roof Antenna Cable Choices

The antenna assembly uses the same coaxial cable for power and antenna signals. The length of cable is determined by circumstances of the installation and site.

Symmetricon offers RG-59/U plenum-rated coaxial cable (20 AWG [0.812 mm], 75 ohm coaxial) with male TNC connectors attached, in the following lengths:

- 10 feet (060-72010-01)
- 20 feet (060-72010-02)
- 50 feet (060-72010-05)
- 100 feet (060-72010-10)
- 200 feet (060-72010-20)
- 300 feet (060-72010-30)
- 500 feet (060-72010-50)
- 600 feet (060-72010-60)
- 800 feet (060-72010-80)
- 1000 feet (060-72010-99)

Two cables are required: one to connect the antenna to the lightning suppressor, and another to connect the lightning suppressor to the TimeSource 3500 Shelf.

Optionally, one length of coaxial cable may be ordered, which must be cut and prepared with end-connectors at the point where the suppressor is located.

The following items, which must be ordered separately, are available for this type of installation:

- TNC connector kit (093-72010-98) includes:
 - TNC connectors for RG-59/U cables (8)
 - Rubber boots (8)
 - TNC adapter connectors (2)
- TNC crimp tool (154-00023-01)

Window and Wall Antenna Location Guidelines


When selecting a window or wall in which to install the antenna, select the window or wall which has the maximum unobstructed view of the sky. Do not select a window or wall which has the view of the sky obstructed by trees, buildings, or towers. The smaller the field of view, the fewer the number of satellites that can be used in the timing solution for GPS derived time. The consequence of this is that the timing generator may experience holdover more often and may eventually go into alarm.

Due to the geometry of the GPS satellite orbits, more satellites are visible in the direction of the equator than the poles. If possible, select a window or wall which has a clear view toward the equator (toward the south in the northern hemisphere, or toward the north in the southern hemisphere). This guideline is less applicable in latitudes nearer the equator and more important nearer the poles.

Certain parts of the sky are blocked from view. These obstructions usually exist from the horizon line and up, for example, a building or mountain. The processor inside the GPS receiver possesses every piece of the sky, whether it is blocked or not. If unproductive parts of the sky are masked from the processor's view, the processing time is reduced, and the timing solution can be achieved more quickly.

Note: A band of the sky from the horizon up to a point where a view of the sky begins is called a mask angle. The mask angle typically should not exceed 10 degrees (if the mask angle is set too high, too little of the sky is available to the receiver). Determine the mask angle for the selected antenna location (Figure 11) and make a note of it. The mask angle, in degrees, will be entered during the initial setup.

Figure 12. Antenna Mask Angle



*An angle of 10° masks objects up to about 3.5 ft above the horizon at 20 ft from the antenna.

Window and Wall Antenna Cable Choices

A window or wall antenna includes an attached coaxial cable terminating in a male SMA connector.

A separate cable is required to connect the IF converter to the TimeSource 3500 shelf. Two types of plenum-rated cable are available.

The cables with longer length capabilities (060-72010-xx) are RG-59/U (20 AWG [0.812 mm], 75 ohm coaxial) with male TNC connectors attached to each end. Assembled cables are available in the following lengths:

- 10 feet (060-72010-01)
- 20 feet (060-72010-02)
- 50 feet (060-72010-05)
- 100 feet (060-72010-10)
- 200 feet (060-72010-20)
- 300 feet (060-72010-30)
- 500 feet (060-72010-50)
- 600 feet (060-72010-60)
- 800 feet (060-72010-80)
- 1000 feet (060-72010-99)

The more flexible cables (060-72050-xx) are Mini RG-59/U (20 AWG [0.812 mm], 75 ohm coaxial) with male TNC connectors attached to each end. Assembled cables are available in the following lengths:

- 50 feet (060-72050-05)
- 100 feet (060-72050-10)
- 200 feet (060-72050-20)
- 500 ft (060-72050-50)

IRIG-B TOD (990-72050-05 System Only)

If using the IRIG-B TOD outputs (990-72050-05 TimeSource 3500 System), right-angle BNC connectors are provided to prevent small radius turns in the IRIG-B TOD cables. The right-angle BNC connectors may be attached to the IRIG-B BNC adapter (also provided) BNC connectors, to direct the cables from the shelf as desired.

For each IRIG-B TOD output, a user-supplied cable with BNC connectors on each end is installed between the adapter and the network elements requiring IRIG-B TOD timing.

RJ-422-to-RS-232 TOD Converter

If using time-of-day (TOD), and the device receiving the time code accepts an RS-232 signal instead of an RS-422 signal (for example, a Cisco router), an RJ-422-to-RJ-232 TOD Converter Kit is required (ordered separately, part number 093-72000-98).

The RJ-422-to-RJ-232 TOD Converter Kit consists of a mounting plate with a female RJ-45 connector, a female DB-25 connector, a TOD converter, and two screws.

Install the converter anywhere (for example, on unused space on a rack) within 1,000 cable feet of the TimeSource 3500 shelf, and within 50 cable feet of the device receiving the time code.

The user must supply two cables. One cable is a Category 5 four-pair RS-422 cable, 1,000 feet maximum, with RJ-45 connectors on each end. Route this cable between the TimeSource 3500 Shelf and the converter.


The other cable is an RS-232 data communications cable, 50 feet maximum, with a 25-pin male D-type connector and another connector determined by the device receiving the time code. Route this cable between the converter and the device receiving the time code.

Shelf Considerations

The TimeSource 3500 Shelf can be mounted in a 19 inch rack or a 23 inch rack. The shelf is shipped with supplied mounting ears positioned for flush mounting on a 23 inch rack. Attach the mounting ears, as shown in Figure 12, for flush mounting or 5 inch offset mounting. Attach the long side of the mounting ear to the shelf for a 23 inch rack, and attach the short side of the mounting ear to the shelf for a 19 inch rack. Mount the shelf in the rack according to standard company practices. Leave one RU (1.75 inches) of air space above the TimeSource 3500 Shelf for proper ventilation. Mount the shelf in the rack according to standard company practices.

Note: Two screws can be used in each mounting ear if the holes in the rack are spaced 1.75 inches apart.

Figure 13. Rack Mounting Options



Systems

The TimeSource 3500 Systems available are listed below. The antenna must be ordered separately.

Standard System (Two T1 Outputs)

This system (990-72050-01) includes:

- TimeSource 3000 Shelf (090-72000-01)
- TimeSource 3500 card (090-72050-01)
- Hardware kit (093-72050-87)
- System software compact disc (CD) (992-72050-xx) Version 1.05.04 or higher
- TimeScan Craft (keyless version) software CD (992-46750-xx) Version 7.2.0 or higher

With Eight Additional T1 Outputs

This system (990-72050-02) includes:

- TimeSource 3000 Shelf (090-72000-01)
- TimeSource 3500 card with additional T1 outputs (090-72050-02)
- Hardware kit (093-72050-87)
- System software CD (992-72050-xx)
Version 1.05.04 or higher
- TimeScan Craft (keyless version) software CD (992-46750-xx)
Version 7.2.0 or higher

2

With Eight Additional Mixed E1/T1 Outputs

This system (990-72050-06) includes:

- TimeSource 3000 Shelf (090-72000-01)
- TimeSource 3500 card with mixed E1/T1 outputs (090-72050-06)
- Hardware kit (093-72050-87)
- System software CD (992-72050-xx)
Version 1.05.04 or higher
- TimeScan Craft (keyless version) software CD (992-46750-xx)
Version 7.2.0 or higher

With Eight Additional Mixed T1 /CCK Outputs

This system (990-72050-07) includes:

- TimeSource 3000 Shelf (090-72000-01)
- TimeSource 3500 card with mixed T1 /CCK outputs (090-72050-07)
- Hardware kit (093-72050-87)
- System software CD (992-72050-xx)
Version 1.06.02 or higher
- TimeScan Craft (keyless version) software CD (992-46750-xx)
Version 7.2.0 or higher

With Eight Composite Clock Outputs

This system (990-72050-03) includes:

- TimeSource 3000 Shelf (090-72000-01)
- TimeSource 3500 card with composite clock outputs (090-72050-03)
- Hardware kit (093-72050-87)
- System software CD (992-72050-xx)
Version 1.05.04 or higher
- TimeScan Craft (keyless version) software CD (992-46750-xx)
Version 7.2.0 or higher

With Two IRIG-B TOD Outputs

This system (990-72050-05) includes:

- TimeSource 3000 Shelf (090-72000-01)
- TimeSource 3500 card with IRIG-B TOD outputs (090-72050-05)
- IRIG-B BNC adapter board (090-72100-06)
- Two right-angle BNC connectors (121-00530-01)
- Hardware kit (093-72050-87)
- System software CD (992-72050-xx)
Version 1.05.04 or higher
- TimeScan Craft (keyless version) software CD (992-46750-xx)
Version 7.2.0 or higher

Antennas

The antennas available are listed below. A TimeSource 3500 System must be ordered separately.

2

Roof Antenna

This antenna kit (990-72050-96) includes:

- IF antenna assembly (090-72010-97)
- Rooftop antenna installation kit (093-72050-96) includes:
 - Antenna cable bracket kit (093-00001-01)
 - Mounting bracket for surge suppressor (070-00300-02)
 - Surge suppressor (143-00018-01)
 - Miscellaneous installation parts

Mechanical Window Antenna

This antenna kit (990-72050-97) comes as a fully assembled antenna with the following major components:

- Antenna, with cable and SMA connector attached (090-72050-90)
- IF converter (090-72050-97)
- Mechanical chassis (074-72050-97)

Self-Adhesive Window Antenna

This antenna kit (990-72050-98) includes:

- Antenna (090-72010-87)
- IF converter (090-72050-97)
- Self-adhesive window antenna installation kit (093-72050-98) includes:
 - RG316 cable, 10 feet (060-00062-01)
 - Cable tie mounts (128-00302-02) and cable ties (128-00500-05)

Wall Antenna

This antenna kit (990-72050-99) includes:

- IF converter (090-72050-97)
- Wall antenna kit (093-72050-99) includes:
 - Antenna, with 19 feet of cable and SMA connector attached (112-00013-01)
 - Antenna mounting bracket (070-00413-01)
 - Cable tie mounts (128-00302-02) and cable ties (128-00500-05)
- Wall antenna lightning suppressor kit (093-72050-94) (optional) includes:
 - Mounting bracket (070-00300-02)
 - Surge protector (143-00018-01)
 - RG59 cable, 2 feet (060-72010-92)

User-Supplied Tools and Materials

Ensure that the user-supplied tools and materials listed below are on hand for installation, as applicable.

For Roof Antenna Installation

2

- 1 inch diameter galvanized metal pipe, used as a mast to mount the antenna. Mast should be long enough to position the antenna above any metal object on the roof.
- Screws to attach the lightning suppressor mounting plate.
- Plumb line or bubble level.
- Nonmetallic junction box for lightning suppressor (optional if lightning suppressor mounted indoors).
- 1 inch diameter PVC pipe as conduit for outdoor cables.
- PVC fittings appropriate to the installation and cable route.
- Appropriate tools and materials for cutting, shaping, and connecting PVC pipe.
- 6 AWG ground wire.
- Spade lugs for 6 AWG ground wire.
- Crimp tool for 6 AWG spade lugs.
- Hardware to attach the ground wire to a valid earth ground.
- Fire-stopping material to seal conduit hole in roof or wall.
- Electrically conductive antioxidant compound (Kopr-Shield or equivalent) to coat exposed connections to prevent oxidation.
- Tool to cut cable, if installation requires custom lengths of cable.

For Mechanical Window Antenna Installation

- Drill with bit of appropriate size and type to make pilot holes for the mounting screws
- 2 screws of appropriate size and type to attach the foot of the mechanical chassis to a window sill or wall near a window.
- Screwdriver
- Cable ties or other method of securing cable
- GPS handheld receiver, personal computer with GPS location software, or other method of determining latitude, longitude, and altitude

2

For Self-Adhesive Window Antenna Installation

- Drill with bit of appropriate size and type to make pilot holes for the mounting screws
- 4 screws of appropriate size and type to attach the IF converter to a wall or other mounting surface.
- Screwdriver
- GPS handheld receiver, personal computer with GPS location software, or other method of determining latitude, longitude, and altitude

For Wall Antenna Installation

- Ladder, or safe method of reaching the antenna location on the exterior wall
- Drill with bits of appropriate size and type to make pilot holes for the antenna mounting bracket screws, and to make a hole through the wall for the antenna cable
- 2 screws of appropriate size and type to attach the antenna mounting bracket to an exterior wall.
- Screwdriver
- Electrically conductive antioxidant compound (Kopr-Shield or equivalent) to coat exposed connections to prevent oxidation
- Fire stopping material to seal the hole in the wall
- GPS handheld receiver, personal computer with GPS location software, or other method of determining latitude, longitude, and altitude

For Shelf Installation

- A Phillips-head screwdriver for installing the TimeSource 3500 Shelf in a rack
- Four screws to mount the shelf in a rack

Outputs, Power, and Miscellaneous

- RG-58 coaxial cable for 1 PPS, 10 MHZ outputs
- Ethernet 10BaseT cable for Ethernet port
- Category 5 four-pair RS-422 cable, with RJ-45 connector for the TOD output, RS-422-to-RS-232 TOD converter
- RS-232 cable with DB-25 connector for the RS-422-to-RS-232 TOD converter
- RS-232 cable with DB-9 connector for COM2 port
- 6 AWG ground wire
- 16 AWG green insulated ground wire
- 16 AWG red insulated wire
- 16 AWG black insulated wire
- T1 cables

This page intentionally left blank.

Installation

This chapter is the sequential order of procedures for installation and power-up.

Chapter 3

Unpacking

Use the procedures in the order they appear in this chapter to install the TimeSource 3500. If any difficulties are encountered during the installation process, contact Symmetricom's Customer Technical Assistance Center (CTAC). Refer to the Technical Assistance section of the Troubleshooting chapter for telephone numbers.

CTAC includes Product Technical Support for technical information, and Customer Service for information about an order, RMAs, and other information.

Warning: When handling electronic equipment, use local office procedures regarding electrostatic discharge (ESD), including:

- **Use grounded wrist straps connected to equipment frame ground when handling cards.**
- **Store cards only in antistatic packaging provided by the factory.**

Note: Save packing material. All equipment returned *must be packed in the original packing material*. Contact Customer Service if additional packaging is needed.

Unpack equipment carefully; check for completeness against the purchase order. Notify Symmetricom if items are missing.

Inspect equipment for shipping damage, including bent or loose hardware, and broken connectors.

If equipment was damaged in transit, contact Customer Service to request an RMA, and notify the carrier.

Antenna

Roof Antenna

Installation procedures are to follow local company procedures and the Installation Job Specification.

Prior to installing the antenna, the site, antenna location, lightning suppressor location, lightning suppressor grounding point, cable route, and all other details should have been planned.


To install the antenna, refer to Figure 14 and perform Procedure B. Ensure all user-supplied materials are available.

Warning: Ensure that the lightning suppressor is placed away from electrical devices or cabling that may induce arcing.



Notes:

1. Recommended grounding points:
 - a. Valid roof ring ground system.
 - b. Cad weld to building structural steel.
 - c. Central office ground plate within 50 feet of antenna cable entrance into building.
2. Order two cables or a single cable run can be made from the antenna to the TimeSource Shelf. The cable can then be cut at the lightning suppressor location, and TNC connectors attached to the cut ends of the cable. The “xx” in the part number indicates the cable length.


Figure 14. Roof Antenna-to-Shelf Cabling



Procedure B. Roof Antenna Mounting and Cable Connection

Step	Procedure
1	Attach the antenna mounting bracket to a pipe (1 in. diameter) or a wood post. • If mounting the bracket to a pipe, slide the two V-bolts over the pipe, and through the mounting bracket slots; then place the provided four washers and four nuts over the V-bolts, against the mounting bracket. Leave the V-bolts loose enough to allow for final adjustments.  This diagram illustrates the assembly for mounting the bracket to a pipe. A vertical rectangular 'Pipe' is shown. A 'Mounting Bracket' is positioned over the top of the pipe. Two 'V-Bolts (2)' are shown passing through the bracket's slots and around the pipe. On the left side of the bracket, four 'Washers (4)' and four 'Nuts (4)' are shown being placed over the V-bolts to secure the bracket against the pipe. • If mounting the bracket to a wood post, use the provided two self-tapping screws in two diagonally positioned mounting bracket slots, and attach to the post.  This diagram illustrates the assembly for mounting the bracket to a wood post. A vertical rectangular 'Post' is shown. A 'Mounting Bracket' is positioned over the top of the post. Two 'Screws (2)' are shown being driven through the bracket into the post at diagonal positions to secure it.

Procedure B. Roof Antenna Mounting and Cable Connection (cont'd)

Step	Procedure
2	Slide the antenna bolts through the holes in the mounting bracket, then attach the antenna to the bracket, using the provided three nuts and three lockwashers. 
3	Using a plumb line or bubble level, ensure the antenna is within 5° of vertical (perpendicular to the horizon), and tighten the mounting bracket bolts.
4	Bolt the lightning suppressor mounting plate to a flange that is attached to a valid earth ground. The roof ring ground system, a Central Office grounding plate, and building structural steel are examples of valid earth ground points. If the mounting plate cannot be bolted to a valid earth ground, bolt the mounting plate to a point within 15 ft of the chosen valid earth ground. If the mounting plate is to be installed in a nonmetallic junction box, perform the installation, and bolt the assembly near the chosen valid earth ground.

Procedure B. Roof Antenna Mounting and Cable Connection (cont'd)

Step	Procedure
5	Slide the longer bolt of the lightning suppressor through the D-hole, and attach with a nut and a washer (provided). KEPS nut (2) 6 AWG (4.115 mm) ground wire Lightningsuppressor Cable connector (2) Nut Washer D-hole Mounting plate Hole for mounting bolt (2) Threaded posts (3) (use any 2)
6	Install 1 in. nonmetallic conduit from the antenna to the lightning suppressor, and from the lightning suppressor to the cable entrance into the building.
7	Install a user-supplied bracket, preferably non-metallic, to support the vertical section of conduit to the antenna.
8	Connect a cable to the antenna, route the cable through the conduit, and connect the cable to the lightning suppressor.
9	Connect a cable to the lightning suppressor, route the cable through the conduit into the building, and route the cable through the building to the TimeSource 3500 Shelf location.

Procedure B. Roof Antenna Mounting and Cable Connection (cont'd)

Step	Procedure
10	If the lightning suppressor was not mounted directly to a valid earth ground, crimp a length of 6 AWG (4.115 mm) ground cable to the two-hole terminal, slide the terminal over two of the three threaded posts on the lightning suppressor mounting plate, and attach the terminal to the mounting plate with two KEPS nuts. Use the two posts that allow the least bending of the 6 AWG (4.115 mm) ground cable.
11	Attach the other end of the cable to a valid earth ground.
12	Install fire-stopping material in all holes opened in the roof and/or walls during this procedure.
13	Check all connections for tightness to prevent arcing and intermittent operation.
14	Coat all exposed connectors with an electrically conductive antioxidant compound (e.g., Kopr-Shield spray).
End of Procedure	

Mechanical Window Antenna


Installation procedures are to follow local company procedures and the Installation Job Specification.

Prior to installing the antenna, the site, antenna location, cable route, and all other details should have been planned.

For best results, choose a window facing the equator (facing south in the northern hemisphere, facing north in the southern hemisphere), and with the fewest obstructions of the sky.

To install the antenna, refer to Figure 15 and perform Procedure C.

Figure 15. Mechanical Window Antenna-to-Shelf Cabling



Procedure C. Mechanical Window Antenna Mounting and Cable Connection

Step	Procedure
Prerequisite: Observe all guidelines, considerations, Dangers, Warnings, Cautions, and Notes in the Engineering and Ordering chapter.	
Symmetricom Parts: • Mechanical Window Antenna (990-72050-97) • A length of RG-59/U plenum-rated coaxial cable (060-72010-xx), or • A length of Mini RG-59/U plenum-rated coaxial cable (060-72050-xx)	
User-Supplied Materials: • Drill with bit of appropriate size and type to make pilot holes for the mounting screws • Two screws of appropriate size and type to attach the foot of the mechanical chassis to a window sill or wall near a window • Screwdriver • Cable ties or other method of securing cable • GPS handheld receiver, personal computer with GPS location software, or other method of determining latitude, longitude, and altitude	
1	At the window chosen in Chapter 2, Engineering and Ordering, attach the base of the mechanical window antenna to the chosen location (sill, wall, etc.) using user-supplied screws (Figure 16).
2	Use the pivots on the mechanical window antenna to place the antenna section flat against the window.
3	Tighten the pivot screws to secure the antenna (Figure 17).
4	Connect the antenna cable to the IF downconverter on the mechanical window antenna assembly and route the cable to the TimeSource 3500 Shelf location.
5	Secure the cable using local company procedures.
6	Check all connections for tightness to prevent intermittent operation.
End of Procedure	

Figure 16. Attaching the Mechanical Window Antenna





Figure 17. Mechanical Window Antenna Pivot Screws



Self-Adhesive Window Antenna


Prior to installing the antenna, the site, antenna location, cable route, and all other details should have been planned.

Installation procedures are to follow local company procedures and the Installation Job Specification.

For best results, choose a window facing the equator (facing south in the northern hemisphere, facing north in the southern hemisphere), and with the fewest obstructions of the sky.

To install the antenna, refer to Figure 18 and perform Procedure D.

Figure 18. Self-Adhesive Window Antenna-to-Shelf Cabling



Procedure D. Self-Adhesive Window Antenna Mounting and Cable Connection

Step	Procedure
Prerequisite: Observe all guidelines, considerations, Dangers, Warnings, Cautions, and Notes in the Engineering and Ordering chapter. Symmetricom Parts: • Self-Adhesive Window Antenna kit (990-72050-98) • A length of RG-59/U plenum-rated coaxial cable (060-72010-xx), or • A length of Mini RG-59/U plenum-rated coaxial cable (060-72050-xx) User-Supplied Materials: • Drill with bit of appropriate size and type to make pilot holes for the mounting screws • Four screws of appropriate size and type to attach the IF converter to a wall or other mounting surface • Screwdriver • GPS handheld receiver, personal computer with GPS location software, or other method of determining latitude, longitude, and altitude	
1	Peel off the backing of one of the self-adhesive hook-and-loop strips and stick the strip to the antenna (Figure 19).
2	Attach the hook-and-loop side of the other strip to the hook-and-loop side of the strip on the antenna.
3	Peel off the backing and stick the antenna to the position on the window selected in Chapter 2, Engineering & Ordering.
4	Use user-supplied screws to mount the IF downconverter to a suitable wall or other structure (Figure 20). Be sure the distance along the cable route between the IF downconverter and the antenna is no more than 10 ft.
5	Route and connect the antenna cable to the antenna side of the IF downconverter.
6	Connect a cable to the TimeSource 3500 shelf side of the IF downconverter and route the cable to the shelf location.
7	Secure the cable using local company procedures.

Procedure D. Self-Adhesive Window Antenna Mounting and Cable Connection (cont'd)

Step	Procedure
8	Check all connections for tightness to prevent intermittent operation.
End of Procedure	

Figure 19. Attaching the Self-Adhesive Window Antenna to a Window





Figure 20. Attaching the IF Converter



Wall Antenna


Prior to installing the antenna, the site, antenna location, cable route, and all other details should have been planned.

Installation procedures are to follow local company procedures and the Installation Job Specification.

For best results, choose a wall facing the equator (facing south in the northern hemisphere, facing north in the southern hemisphere), and with the fewest obstructions of the sky.

To mount the antenna through the wall, refer to Figure 21 and follow Procedure E.

Figure 21. Wall Antenna-to-Shelf Cabling



Procedure E. Wall Antenna Installation

Step	Action
Prerequisite: Observe all guidelines, considerations, Dangers, Warnings, Cautions, and Notes in the Engineering and Ordering chapter. Symmetricom Parts: • Wall Antenna (990-72050-95 or 990-72050-99) • Wall Antenna Lightning Suppressor Kit (093-72050-94) (optional) • A length of RG-59/U plenum-rated coaxial cable (060-72010-xx), or • A length of Mini RG-59/U plenum-rated coaxial cable (060-72050-xx) User-Supplied Materials: • Ladder, or safe method of reaching the antenna location on the exterior wall • Drill with bits of appropriate size and type to make pilot holes for the antenna mounting bracket screws, and to make a hole through the wall for the antenna cable • Two screws of appropriate size and type to attach the antenna mounting bracket to an exterior wall • Screwdriver • Electrically conductive antioxidant compound (Kopr-Shield or equivalent) to coat exposed connections to prevent oxidation • Fire-stopping material to seal the hole in the wall • GPS handheld receiver, personal computer with GPS location software, or other method of determining latitude, longitude, and altitude	
1	Attach the IF downconverter (Figure 20) inside the building to a suitable wall or other structure. Be sure the distance along the cable route between the IF converter and the antenna is no more than 19 ft. Include allowances for the drip loop and local company procedures for cable routing.
2	Use Figure 22 to determine the spacing of the 2 holes for mounting the bracket, and the distance to the hole for passing the cable into the building.
3	Drill a 25/64-inch (0.390625-inch) hole in the wall for the antenna cable. The diameter of the hole should be larger than the outer diameter of the SMA connector on the antenna cable, which will pass through the hole from the antenna to the inside of the building.
4	Drill two pilot holes for the user-supplied screws or bolts that attach the mounting bracket to the outside wall.

Procedure E. Wall Antenna Installation (cont'd)

Step	Action
5	Using two screws or bolts, mount the antenna bracket assembly to the outside wall.
6	Place the magnetic side of the antenna on the outside of the mounting bracket.
7	Push the SMA connector of the antenna cable through the hole drilled in the wall in Step 3. Be sure the antenna cable forms a drip loop between the antenna and the cable entry into the building (Figure 23).
8	Route the antenna cable to the antenna side of the IF converter and connect the cable.
9	Connect a cable to the TimeSource 3500 shelf side of the IF downconverter and route the cable to the shelf location.
10	Secure the cable using local company procedures.
11	Install fire-stopping material in all holes opened in the roof and/or walls during this procedure.
12	Check all connections for tightness to prevent intermittent operation.
13	If the optional Wall Antenna Lighting Suppressor Kit is not installed, then skip Steps 14 through 20.
14	Mount the lightning protector mounting bracket to the inside wall.
15	Mount and secure the lightning protector in the lightning protector mounting bracket.
16	If the lightning suppressor was not mounted directly to a valid earth ground, crimp a length of 6 AWG (4.115 mm) ground cable to the two-hole terminal, slide the terminal over two of the three threaded posts on the lightning suppressor mounting plate, and attach the terminal to the mounting plate with two KEPS nuts. Use the two posts that allow the least bending of the 6 AWG (4.115 mm) ground cable.
17	Attach the other end of the cable to a valid earth ground.
18	Route the wall antenna cable to the antenna side of the IF converter and connect the cable.

Procedure E. Wall Antenna Installation (cont'd)

Step	Action
19	Connect the IF converter to the lightning protector using the two-foot RG-59 cable.
20	Connect an RG-59 cable from the lightning protector to the TimeSource 3500 shelf.
21	Coat all exposed connectors with an electrically conductive antioxidant compound (e.g., Kopr-Shield spray).
End of Procedure	

Figure 22. Hole Spacing





Figure 23. Wall Antenna Mounting



3


Shelf

Rack Mounting

The shelf is shipped with the ears positioned for flush mounting in a 23 inch rack (Figure 24B). The ears can be positioned in the front of the shelf for flush mounting (Figure 24A, and Figure 24B), or in the middle of the shelf for 5 inch offset mounting (Figure 24C and Figure 24D). Leave 1 RU (1.75 inches) of air space above the TimeSource 3500 Shelf for proper ventilation. Mount the shelf in the rack according to standard company practices.

Note: Two screws may be used in both mounting ears if the holes in the rack are spaced 1.75 inches apart.

Figure 24. Rack Mounting Options



Power and Signal Cabling


Warning: The circuitry on the plug-in circuit board is subject to electrostatic discharge (ESD) damage. Be sure to wear an ESD wrist strap when making connections to the rear panel. Failure to observe this warning may result in equipment damage.

Warning: The faceplate on the card contains a plastic overlay bonded to the metal plate with an adhesive. The overlay is an integral part of the ESD protection. Do not pierce, peel, or otherwise violate the integrity of the overlay. Failure to observe this warning may result in equipment damage.

The Craft connection is made at the shelf front panel. All other connections are made at the shelf rear panel.


Figure 25 shows the rear panel connectors. Figure 26 shows the front panel connector. All connectors can be located using these illustrations.

Figure 25. Rear Panel Connectors



3


Figure 26. Front Panel Connector




Frame Ground

Frame ground connections are made on power terminal blocks TB1 and TB2. Refer to Figure 25 for the location of the terminals on the rear of the shelf, and refer to Figure 27 for the terminal connections.

Figure 27. Battery Connections



A. TB1 Connections
(Office Battery A)



B. TB2 Connections
(Office Battery B)

Remove the protective covers from the terminal blocks.

Ensure the frame ground wires are long enough to reach from the shelf rear panel to the frame ground connection. Use one 16 AWG (1.47 mm) green insulated wire to connect the ⊕ terminal of power terminal block TB1 to the frame ground, and use another 16 AWG (1.47 mm) green insulated wire to connect the ⊕ terminal of TB2 to frame ground.

Make the ground connection, following one of the methods described below, depending on whether a ground rod is installed:

With ground rod

Solder the frame ground connection to the 6 AWG (4.115 mm) frame ground rod run vertically on each side of the rack. Two methods are acceptable:

- Crimp an appropriate-size spade lug (user-supplied) to the 16 AWG (1.47 mm) wire, bend the lug around the 6 AWG (4.115 mm) rod, and solder.
- Strip enough insulation from the 16 AWG (1.47 mm) wire to permit three complete turns around the 6 AWG (4.115 mm) rod, and solder.

Note: When soldering, use a 25 watt soldering iron to ensure the 6 AWG (4.115 mm) rod is heated sufficiently to prevent a cold solder connection.

If the power is not to be connected immediately, replace the protective covers on the terminal blocks.

Without ground rod

Crimp the supplied spade lug to the 16 AWG (1.47 mm) wire, and screw the lug to a screw hole on the rack. Remove the paint and sand the area around the screw hole to ensure proper conductivity. Coat the connection with an electrically conductive antioxidant compound, for example, Kopr-Shield spray.

Crimp the supplied spade lug to the other end of the 16 AWG (1.47 mm) wire, and connect it to the ⊕ terminals on TB1 and TB2 (Figure 27).

If the power is not to be connected immediately, replace the protective covers on the terminal blocks.

Power

Warning: This equipment is intended for installation in a restricted access location. Power source protective fusing must be provided as part of the installation.

Caution: Do not apply power to the TimeSource 3500 before instructed in this procedure. Before connecting the power cables to the TimeSource 3500, ensure the fuses are removed from the fuse panel that supplies power to the power cables.

Note: Input power is reverse polarity protected; there are no user replaceable fuses in the TimeSource 3500.

Power connections are made on power terminal blocks TB1 and TB2. Refer to Figure 25 for the location of the terminals on the rear of the shelf, and refer to Figure 27 for the terminal connections.

Remove the protective covers from the terminal blocks, if covered.

Ensure the power wires are long enough to reach from the shelf rear panel to the office battery source connection.

Use two 18 AWG (1.024 mm) stranded wires for the power connection, one with red insulation (–48V), and the other with black insulation (RTN). Crimp a supplied spade lug to each wire.

Connect the power wires with red insulation to the –48V wire receptacles on TB1 and TB2. Connect the power wires with black insulation to the RTN wire receptacles on TB1 and TB2.

Replace the protective covers on the terminal blocks.


Note: Two separate office battery supplies (–48V A and –48V B) are recommended. If separate office battery supplies are not available, connect a single office battery to both inputs (TB1 and TB2) to avoid a standing battery-failure alarm.

Alarms Output

Connect the TimeSource 3500 alarms to the office alarm panel at the critical (CR), major (MJ), and minor (MN) wire-wrap pins. See Figure 25 for the location of the alarm pins, and Figure 28 for the connections.

Connect at the upper group of pins (AUD) for audible alarms and at the lower group of pins (VIS) for visible alarms. Connect the alarm circuit between the NO and C pins for normally open contacts, or between the NC and C pins for normally closed contacts.

Figure 28. Alarm Connections



GPS Antenna


Use the supplied 90 degree adapter to connect the coaxial cable from the lightning suppressor or IF downconverter to the TNC connector labeled GPS ANT. Refer to Figure 25 for the connector location.

Additional T1 Outputs (990-72050-02 System Only)

Connect up to eight optional T1 outputs at the OPTIONS I/O wire-wrap pins. See Figure 25 for the connector location, and Figure 29 for the connections.

Note: The shield pin is capacitively coupled to ground, therefore, the shield must be connected at the source end. The shield may also be connected at the TimeSource 3500 end for additional longitudinal noise protection.

Figure 29. OPTIONS I/O Wire-Wrap Pin Connections



Mixed E1/T1 Outputs

Connect up to eight optional mixed E1/T1 outputs at the OPTIONS I/O wire-wrap pins. Refer to Figure 25 for the connector location and Figure 29 for the connections.

Mixed T1/CCK Outputs

Connect up to eight optional mixed T1/CCK outputs at the OPTIONS I/O wire-wrap pins. Refer to Figure 25 for the connector location and Figure 29 for the connections.

Composite Clock Outputs (990-72050-03 System Only)


Connect up to eight optional composite clock outputs at the OPTIONS I/O wire-wrap pins. Refer to Figure 25 for the connector location and Figure 29 for the connections.

IRIG-B TOD Outputs (990-72050-05 System Only)

Connect one or two optional IRIG-B TOD outputs at the OPTIONS I/O wire-wrap pins. See Figure 25 for the connector locations, and Figure 30 for the connections.

Follow Procedure F to install the IRIG-B BNC adapter, and make the IRIG-B TOD connections.

Figure 30. IRIG-B TOD BNC Output Connections



3

Procedure F. IRIG-B TOD Output Installation

Step	Procedure
1	Position the IRIG-B adapter onto the rear of the shelf so that the OPTIONS I/O wire-wrap pins project through holes in the adapter card.
2	Secure the adapter onto the shelf, using the four screws integral to the adapter (see Figure 30).
3	To prevent small radius turns in the IRIG-B TOD output cables, secure the provided right-angle BNC connectors to the adapter BNC connectors, to direct the cables from the shelf as desired.
4	Connect the IRIG-B TOD outputs from the BNC connectors on the IRIG-B adapter to network elements requiring IRIG-B TOD timing.

End of Procedure

1 PPS Output

Connect a user-supplied RG-58 coaxial cable from the connector labeled TTL PPS to the equipment that will use the 1 pulse-per-second TTL output signal. See Figure 25 for the connector location.

10 MHz Output

Connect a user-supplied RG-58 coaxial cable from the connector labeled 10 MHz to the equipment that will use the 10 MHz output signal. See Figure 25 for the connector location.

Ethernet

Connect a user-supplied Ethernet cable from the network to the 10base-T Ethernet connector labeled ETHER. See Figure 25 for the connector location, and Table B for the connector pinouts.

Table B. Ethernet 10base-T RJ-45 Connector Pinouts

Pin	Signal	Abbreviation	Direction
1	Transmit data +	TXD +	From TimeSource 3500
2	Transmit data –	TXD –	From TimeSource 3500
3	Receive data +	RXD +	To TimeSource 3500
4	—	—	—
5	—	—	—
6	Receive data –	RXD –	To TimeSource 3500
7	—	—	—
8	—	—	—

Time of Day Output

Connect a time of day (TOD) output at the female RJ-45 connector labeled TOD. See Figure 25 for the connector location, and Table C for the connector pinouts.

Table C. TOD Connector Pinouts

Pin	Signal	Abbreviation	Direction
1	1 pps A	TOD PPS +	From TimeSource 3500
2	1 pps B	TOD PPS –	From TimeSource 3500
3	12 V power source	TOD P12V	—
4	Receive data B	TOD RXD –	To TimeSource 3500
5	Receive data A	TOD RXD +	To TimeSource 3500
6	Circuit ground	TOD GND	—
7	Transmit data A	TOD TXD +	From TimeSource 3500
8	Transmit data B	TOD TXD –	From TimeSource 3500

Note: Pins not listed are reserved for future use.

If the device receiving the time code (for example, Cisco router) accepts an RS-232 cable instead of an RS-422 cable, follow Procedure G to install the RS-422-to-RS-232 TOD converter.

Note: Before performing Procedure G, ensure that the appropriate Cisco router or NTP Type 4 compatible device is installed, and power applied, per manufacturer's instructions.

Procedure G. RS-422-to-RS-232 TOD Converter Installation

Step	Procedure
1	Secure the provided mounting plate to the RS-422-to-RS-232 TOD converter, using the two provided screws. The plate may be attached to the top or front of the converter, depending on the desired surface (for example, a rack or cabinet) to which the converter will be mounted (see Figure 31). <i>Notes:</i> 1. Due to distance constraints, the converter must be placed no more than 1000 ft from the TimeSource 3500 Shelf, and no more than 50 ft from the device receiving the time code. 2. The converter dimensions are 3 in. by 2.5 in by 1 in. 3. The mounting plate dimensions are 3 in by 2 in.
2	Secure the converter to the desired surface, using the slots in the plate and user-supplied bolts.
3	Install a user-supplied Category 5 four-pair RS-422 cable, with RJ-45 connectors on each end, between the TimeSource 3500 Shelf and the converter (see Figure 32).
4	Install a user-supplied RS-232 cable, with DB-25 connectors on each end, between the converter and the device receiving the time code (see Figure 32). See Table D for the DB-25 connector pinouts.

End of Procedure

Figure 31. RS-422-to-RS-232 TOD Converter Mounting Plate




Figure 32. RS-422-to-RS-232 TOD Converter Connections




Table D. Converter DB-25 Connector Pinouts

Pin	Signal
1	Frame ground
3	Data output (RS-232)
5	1 pps (RS-232)
7	Signal ground

Note: Pins not listed are reserved for future use.


T1 Reference Inputs

Warning: Because the T1 input circuits do not provide lightning protection, do not connect the T1 input line directly to an outside facility. Failure to observe this warning may result in equipment damage.

T1 reference sources, traceable to an independent Stratum 1 source, can be connected to further increase holdover stability, or to be monitored by the TimeSource 3500. In either case, connect the cables to the wire-wrap pins labeled SPAN IN A and SPAN IN B. Connect the tip wire to the pin labeled T, the ring wire to the pin labeled R, and the shield (if connected at the TimeSource 3500) to the pin labeled S. See Figure 25 for the location of the connectors and pins, and Figure 33 for the wire-wrap connections.

Note: The shield pin is capacitively coupled to ground, therefore, the shield must be connected at the source end. The shield may also be connected at the TimeSource 3500 end for additional longitudinal noise protection.

Figure 33. T1 Input Connections




T1 Synchronization Outputs

Warning: Because the T1 output circuits do not provide lightning protection, do not connect the T1 output line directly to an outside facility. Failure to observe this warning may result in equipment damage.

Connect the T1 synchronization outputs at the wire-wrap pins labeled T1 OUT A and T1 OUT B. Connect the tip wire to the pins labeled T, the ring wire to the pins labeled R, and the shield to the pins labeled S. See Figure 25 for the location of the pins, and Figure 34 for the connections.

Note: The shield pin is provided to ground the cable shield at the shelf, if required. Normally, the shield is grounded at the source. Grounding the shield at both ends is not recommended unless one end is capacitively coupled to ground.

Figure 34. T1 Output Connections



Communication Port 1

To provide an RS-232 link for TL1 command access to the TimeSource 3500, connect to port 1 at the female 25-pin D connector labeled COM1. See Figure 25 for the location of the connector. See Table E for the connector pinouts.

Note: The COM1 connector transmits data on pin 2, and receives data on pin 3. Be sure the other equipment receives data from the transmitting pin, and transmits data to the receiving pin.

Table E. COM1 Pinouts

Pin	Signal	Abbreviation	Direction
2	Transmit data	TXD	From TimeSource 3500
3	Receive data	RXD	To TimeSource 3500
4	Request to send	RTS	From TimeSource 3500
5	Clear to send	CTS	To TimeSource 3500
7	Signal ground	GND	—
20	Data terminal ready	DTR	From TimeSource 3500

Note: Pins not listed are reserved for future use.

Communication Port 2

To provide an RS-232 link for TL1 command access to the TimeSource 3500, connect to port 2 at the female RJ-45 connector labeled COM2. See Figure 25 for the location of the connector, and Table F for the connector pinouts.

Note: The COM2 connector transmits data on pin 2, and receives data on pin 3. Be sure the other equipment receives data from the transmitting pin, and transmits data to the receiving pin.

Table F. COM2 Connector Pinouts

Pin	Signal	Abbreviation	Direction
2	Transmit data	TXD	From TimeSource 3500
3	Receive data	RXD	To TimeSource 3500
5	Signal ground	GND	—
6	Data terminal ready	DTR	From TimeSource 3500
7	Clear to send	CTS	To TimeSource 3500
8	Request to send	RTS	From TimeSource 3500

Note: Pins not listed are reserved for future use.

Craft Port

To provide an RS-232 link for TL1 command access to the TimeSource 3500, connect to the craft port at the female RJ-45 connector labeled Craft on the front panel. A Craft-port-to-PC cable is supplied with the TimeSource 3500 for making this connection. See Figure 26 for the location of the connector, and Table G for the connector pinouts.

Note: The Craft connector transmits data on pin 2, and receives data on pin 3. Be sure the other equipment receives data from the transmitting pin, and transmits data to the receiving pin.

Table G. Craft Pinouts

Pin	Signal	Abbreviation	Direction
2	Transmit data	TXD	From TimeSource 3500
3	Receive data	RXD	To TimeSource 3500
5	Signal ground	GND	—
6	Data terminal ready	DTR	From TimeSource 3500

Note: Pins not listed are reserved for future use.

Power-Up

To power the TimeSource 3500, follow the steps in Procedure H. Before starting this procedure, be sure the antenna, shelf, and all connections appropriate for this installation have been installed, and that the host computer is set to communicate with the TimeSource 3500.

Note: If using the TimeScan Craft software program for the power-up procedure, see the TimeScan Craft manual for the appropriate TimeScan commands to use in place of the TL1 commands in Procedure H.

Procedure H. Power-Up

3

Step	Procedure
Test Equipment: • Grounding wrist strap • Digital multimeter (Fluke 77 or equivalent) • Laptop computer with communications software (e.g., Windows Hyperterminal, ProComm Plus, CrossTalk)	
1	On the computer connected to the TimeSource 3500, start a VT100 terminal mode session via communication software that supports the Y-modem protocol (such as Hyperterminal, or a commercial package such as PROCOMM PLUS or CrossTalk).
2	On the computer connected to the TimeSource 3500, set the communication software to communicate with the port that is connected to the TimeSource 3500.
3	On the computer connected to the TimeSource 3500, set the RS-232 communication parameters to 8 data bits, no parity bit, 1 stop bit, and 9600 baud.

Procedure H. Power-Up (cont'd)

Step	Procedure																		
4	On the computer connected to the TimeSource 3500, connect the computer communication port to the COM1, COM2, or Craft port on the TimeSource 3500. A craft port-to-PC communication cable is provided in the hardware kit for this purpose.																		
5	Ensure that the TimeSource 3500 plug-in card is not installed in the shelf.																		
6	Ensure that all fuses that supply power to the TimeSource 3500 Shelf are removed from the fuse panel.																		
7	At the shelf end of the battery leads, use the multimeter to measure the voltage between the following: <table><tr><td><u>Test Point</u></td><td><u>Test Point</u></td><td><u>Result</u></td></tr><tr><td>-48V A lead</td><td>-48V B lead</td><td>0 V</td></tr><tr><td>-48V A lead</td><td>TB1: RTN A</td><td>0 V</td></tr><tr><td>-48V A lead</td><td>TB1: </td><td>0 V</td></tr><tr><td>-48V B lead</td><td>TB2: RTN B</td><td>0 V</td></tr><tr><td>-48V B lead</td><td>TB2: </td><td>0 V</td></tr></table>	<u>Test Point</u>	<u>Test Point</u>	<u>Result</u>	-48V A lead	-48V B lead	0 V	-48V A lead	TB1: RTN A	0 V	-48V A lead	TB1: 	0 V	-48V B lead	TB2: RTN B	0 V	-48V B lead	TB2: 	0 V
<u>Test Point</u>	<u>Test Point</u>	<u>Result</u>																	
-48V A lead	-48V B lead	0 V																	
-48V A lead	TB1: RTN A	0 V																	
-48V A lead	TB1: 	0 V																	
-48V B lead	TB2: RTN B	0 V																	
-48V B lead	TB2: 	0 V																	
8	Attach a grounding wrist strap to the wrist, and plug the other end into the ground jack at the upper-right corner of the front of the plug-in card.																		
9	Pull out the latching levers at each end of the front panel so that the levers are pointing directly out from the front panel.																		
10	Push the card into the shelf until the latching levers begin to move in.																		
11	Push the latching levers flat against the front panel to complete the card insertion.																		
12	Tighten the knurled screw above each latching lever to secure the card in the shelf.																		
13	Unplug and remove the grounding wrist strap.																		

Procedure H. Power-Up (cont'd)

Step	Procedure
14	Install the battery source fuse(s) in the rack fuse bay that supplies power to the TimeSource 3500. The TimeSource 3500 enters its warm-up mode after approximately 60 s when power is applied. During the warm-up period, the following conditions exist: • Status GPS lamp is green • Status SYS lamp is off • T1 outputs are squelched, sending AIS (factory setting), or sending an SSM message, as specified in the ED-EQPT command • Composite clock outputs (if equipped) are squelched • Additional eight T1 outputs (if equipped) are squelched, sending AIS (factory setting), or sending an SSM message, as specified in the ED-EQPT command • Two IRIG-B outputs (if equipped) are squelched • 10 MHz and 1 pps outputs are on (unreliable while Status SYS lamp is off) • TOD output is not enabled (factory setting) <i>Notes:</i> 1. The CRIT lamp and other alarm indication lamps may light. The host computer may display transient and standing alarm condition messages. Ignore alarms while the Status SYS lamp is off during warm-up, unless alarms apply to inputs and outputs that were previously entered. 2. TLI commands may be entered during warm-up. Inputs and outputs can be enabled, and system parameters can be set or changed.
15	<i>Note:</i> If using the TimeScan Craft software program for the power-up procedure, see the TimeScan Craft manual for the appropriate TimeScan commands to use in place of the TLI commands in this Procedure. Use the Activate User command to log onto the system. <pre>ACT-USER::TELECOM:<ctag>::TS3000!!;</pre>

Procedure H. Power-Up (cont'd)

Step	Procedure
16	Skip this step if the current unit is equipped with a roof antenna. Use the Edit Equipment command to change the antenna locating mode to manual and to enter the latitude, longitude, and altitude. In manual mode, the survey process used to determine the antenna's exact position starts with this information. <i>Caution:</i> Enter data carefully. When entering degrees, an error of a single degree will cause the system location accuracy to be off by as much as 60 mi. <pre>ED-EQPT::GPS:<ctag>::ANTMODE=MANUAL,MANLAT=a-b-c-d, MANLONG=e-f-g-h,MANELEVALT=i;</pre> a= north (a = N) or south (a = S) of the equator b= degrees of latitude (b = 0 to 60) c= minutes of the degree (c = 0 to 60) d= decimal fraction of the minute (d = 000 to 999) e= east (e = E) or west (e = W) of the Greenwich Meridian f= degrees of longitude (f = 0 to 180) g= minutes of the degree (g = 0 to 60) h= decimal fraction of the minute (h = 000 to 999) i= elevation, or altitude, of the antenna in meters Example command to set the latitude, longitude, and altitude of the antenna: <pre>ED-EQPT::GPS:<ctag>::ANTMODE=MANUAL,MANLAT=N-37-19-016, MANLONG=W-121-59-246,MANELEVALT=12;</pre> <i>Notes:</i> 1. The TimeSource 3500 can find its position on the earth without latitude, longitude, and altitude entered, but the process may take several hours, and may not result in the position accuracy (within 1/8 mi) required for the system to perform to specification. It is recommended that the information be obtained and manually entered by the user.

Procedure H. Power-Up (cont'd)

Step	Procedure
16 (cont'd)	<i>Notes:(cont'd)</i> 2. Latitude, longitude, and altitude data can be obtained through the use of a GPS hand-held receiver (user supplied). Location mapping software is also available for personal computers, which can be used to obtain latitude and longitude. When the entered figures are within 1/8 mi of the actual coordinates, the TimeSource 3500 typically delivers UTC traceable timing within 1 h of applying power. Warm-up times vary greatly depending on the window location and antenna placement. 3. Obtain latitude, longitude, and altitude outdoors when using a GPS hand-held receiver, to ensure an accurate reading. Do not use the GPS hand-held receiver inside the building near the window or wall where the antenna will be installed. GPS hand-held receivers do not provide an accurate location reading when used indoors.
17	If UTC time is desired, skip to Step18. Use the Edit Date command to set the local date and time. ED-DAT:::<ctag>::yyyy-mm-dd,hh-mm-ss:MODE=LOCAL; yyyy= year (yyyy = 1998 to 2096) mm= month (mm = 01 to 12) dd= day (dd = 01 to 31) hh= hours (hh = 00 to 23) mm= minutes (mm = 00 to 59) ss= seconds (ss = 00 to 59) Example command to set local time: ED-DAT:::123::2000-06-15,14-25-00:MODE=LOCAL;

Procedure H. Power-Up (cont'd)

Step	Procedure
18	If UTC time is not desired, skip to Step 19. Use the Edit Date command to set the system for UTC time. ED-DAT:::<ctag>::yyyy-mm-dd:MODE=UTC; yyyy= year (yyyy = 1998 to 2096) mm= month (mm = 01 to 12) dd= day (dd = 01 to 31) Example command to set UTC time: ED-DAT:::123::2000-06-15:MODE=UTC;
19	Use the Retrieve Equipment command to identify whether and how the inputs have been provisioned. RTRV-EQPT::ALL:<ctag>; <i>Notes:</i> 1. Observe those results with an <aid> of SPAN-a. If MONITOR=ALW appears for an input, that input has previously been entered. If ENSEMBLER=ALW appears for an input, that input has been set to be ensembled. 2. Note the results of the Retrieve Equipment command to set the remaining parameters in this procedure. 3. Factory default settings are found at the end of this Power Up procedure section.
20	If the results of Step 19 indicate the span inputs (if used) are set as desired, skip to Step 21. Use the Enter Equipment command to monitor each available span input, and to specify whether those inputs are to be ensembled. ENT-EQPT::SPAN-a:<ctag>:::ENSEMBLER=b; a= span input (a = A or B) b= whether this input is ensembled (b = ALW ensembles the input; b = INH inhibits the input from being ensembled)

Procedure H. Power-Up (cont'd)

Step	Procedure
21	Use the Edit Equipment command to set the output signal framing format for the two standard T1 outputs, and set the mode for each T1 output during an alarm. ED-EQPT::T1-a:<ctag>::FRAMING=b,ALMOUT=c; a= T1 output (a = A or B) b= framing format (b = ESF or D4) c= T1 output during alarm (c = AIS, SQUELCH, or SSM) (for SSM, framing format must be ESF)
22	If not using a 990-72050-02 system, skip this step. Use the Edit Equipment command to set the output signal framing format for each additional T1 output, and set the mode for each T1 output during an alarm. ED-EQPT::OPT-a:<ctag>::FRAMING=b,ALMOUT=c; a= T1 output module port (a = 1 to 8) b= framing format (b = ESF or D4) c= T1 output during alarm (c = AIS, SQUELCH, or SSM) (for SSM, framing format must be ESF)
23	If not using performance monitoring, skip to Step 24. Use the Initialize Register command to reset the performance monitoring data to zero for all input spans. INIT-REG-EQPT::ALL:<ctag>::ALL;

Procedure H. Power-Up (cont'd)

Step	Procedure
24	If not using Ethernet, go to Step 28. Use the Edit Equipment command while connected to COM1, COM2, or the CRAFT port to set the IP address, subnetwork mask, and gateway address for the current TimeSource 3500 unit, as required for proper operation in the managed element network. (These parameters affect all Ethernet ports. The Ethernet port should be closed and all users logged off before issuing this command.) ED-EQPT: : TS3500: <ctag>: : : IPNE=a, IPSUBNET=a, IPGATE=a; IPNE=a= This unit's IP address in the form a.a.a.a (each a is an independent value of 0 to 255) IPSUBNET=a= Subnet mask in the form a.a.a.a (each a is an independent value of 0 to 255) IPGATE=a= Gateway IP address in the form a.a.a.a (each a is an independent value of 0 to 255)

Procedure H. Power-Up (cont'd)

Step	Procedure
25	Ports 5001, 5002, 5003 and 5004 on the TimeSource 3500 are used as though they were serial TL1 communication ports. The following values are set at the factory and appear at reset: MONMSG=INH (monitors only the current port for messages) KEEPALIVE=0 (does not send a COMPLD message to keep connection open) ENDOFTEXT=0 (does not include an end-of-text code with a TL1 message) ECHO=ALW (echoes characters back to the sending terminal) COMPRI=ALW1 (normal communication, including autonomous messages) AUTOLOGOFF=20 (does not log off the user during inactivity) SWCONTROL=INH (uses no flow control) If these values require change, use the Edit Communications command to set communications parameters for TL1 communications. <pre>ED-COM::COM-a:<ctag>:::[MONMSG=b[.]] [KEEPALIVE=c[.]] [ENDOFTEXT=d[.]] [ECHO=b[.]] [COMPRI=e[.]] [AUTOLOGOFF=c[.]] [SWCONTROL=b];</pre> COM-a= User IP port (a = 5001, 5002, 5003 or 5004) MONMSG=b= Monitors messages on all ports (b = ALW), or current port (b = INH) KEEPALIVE=c= Inactive minutes until the unit sends a COMPLD message to keep the connection from being closed (c = 0 to 255) ENDOFTEXT=d= Hex code added to responses before semicolon (d = 0 (disabled) to 9F) ECHO=b= Echoes characters received so they appear on the user's screen as typed (b = ALW), or inhibits echo (b = INH) COMPRI=e= Sets the communication port capabilities as follows: ALW0= normal communication, no autonomous messages ALW1= normal communication, autonomous messages ALW2= autonomous messages received, logged on or not INH= closes connection and keeps port from use (command must go to another port) (if the port is in use, this command also logs off the user) AUTOLOGOFF=c= Inactive minutes until the unit logs off the user, keeping the connection open (c = 0 to 255) SWCONTROL=b= uses software (XON/XOFF) flow control (b = ALW), or no flow control (b = INH)

Procedure H. Power-Up (cont'd)

Step	Procedure
26	If not using an Element Manager, skip to Step 28. If not using a separate port to send autonomous messages to an Element Manager, skip to Step 27. Use the Edit Equipment command to set the IP address and port address of the Element Manager. Port 5550 connects to this address when the TimeSource 3500 develops a TL1 autonomous message, sends any messages, and closes the connection. An alternate Element Manager may be set up in case port 5550 cannot make a connection to the primary Element Manager. ED-EQPT: :TS3500:<ctag>:::IPEM1=a,IPEM1PORT=b[,IPEM2=a] [,IPEM2PORT=b][,IPINACT=c]; IPEM1=a= Primary Element Manager's IP address in the form a.a.a.a (each a is an independent value of 0 to 255) IPEM1PORT=b=Primary Element Manager's Ethernet port address (b = 0 to 65535) IPEM2=a= Alternate Element Manager's IP address in the form a.a.a.a (each a is an independent value of 0 to 255) IPEM2PORT=b=Alternate Element Manager's Ethernet port address (b = 0 to 65535) IPINACT=c= Disconnects from the Element Manager if an autonomous message is not developed during this number of 100-ms units of inactivity (0 to 10,000, where 0 deactivates the timer)

Procedure H. Power-Up (cont'd)

3

Step	Procedure
27	Use the Edit Communications command to set the communications parameters of port 5551. An Element Manager connects to port 5551 for TL1 command and response messages. The following values for port 5551 are set at the factory and appear at reset: MONMSG=INH (monitors only the current port for messages) KEEPALIVE=0 (does not send a COMPLD message to keep connection open) ENDOFTEXT=0 (does not include an end-of-text code with a TL1 message) ECHO=INH (does not echo characters received) COMPRI=ALW1 (normal communication, including autonomous messages) AUTOLOGOFF=20 (does not log off the user during inactivity) SWCONTROL=INH (uses no flow control) If these values require change, use the Edit Communications command to set communications parameters for TL1 communications. <pre>ED-COM::COM-5551:<tag>:::[MONMSG=b[.]] [KEEPALIVE=c[.]] [ENDOFTEXT=d[.]] [ECHO=b[.]] [COMPRI=e[.]] [AUTOLOGOFF=c[.]] [SWCONTROL=b];</pre> MONMSG=b= Monitors messages on all ports (b = ALW), or current port (b = INH) KEEPALIVE=c= Inactive minutes until the unit sends a COMPLD message to keep the connection from being closed (c = 0 to 255) ENDOFTEXT=d= Hex code added to responses before semicolon (d = 0 (disabled) to 9F) ECHO=b= Echoes characters received so they appear on the user's screen as typed (b = ALW), or inhibits echo (b = INH) COMPRI=e= Sets the communication port capabilities as follows: ALW0 = normal communication, no autonomous messages ALW1 = normal communication, autonomous messages ALW2 = autonomous messages received, logged on or not INH = closes connection and keeps port from use (command must go to another port) (if the port is in use, this command also logs off the user) AUTOLOGOFF=c= Inactive minutes until the unit logs off the user, keeping the connection open (c = 0 to 255) SWCONTROL=b= uses software (XON/XOFF) flow control (b = ALW), or no flow control (b = INH)

Procedure H. Power-Up (cont'd)

Step	Procedure
28	If the results of Step 19 indicate the antenna cable delay and elevation mask are set as desired, skip to Step 29. Use the Edit Equipment command to set the length of cable between the antenna and the TimeSource 3500 Shelf. This number should have been recorded during installation. Use the same command to set the antenna elevation mask angle. ED-EQPT::GPS:<ctag>::ANTCBLDLY=a,ANTELEVMAK=b; a= antenna cable delay in meters (a = 0 to 330) b= antenna elevation mask angle in degrees (b = 0 to 45) (see note below) <i>Note:</i> The antenna elevation mask is that portion of the sky from which the TimeSource 3500 masks out satellite signals, measured as an angle of elevation from the horizon. Reflections or other anomalies may disturb signals received from an area of the sky that has obstructions, usually the area near the ground. Masking that part of the sky may allow the receiver to acquire GPS signals more quickly and accurately. Factory setting is 10.
29	If not using the TOD output, skip to Step 30. Use the Edit Equipment command to set the TOD output. ED-EQPT::TS3500:<ctag>::TOD=b; b= TOD format (b = Cisco or NTP4)
30	Use the Edit Equipment command to allow or inhibit alarm conditioning on the outputs. Inhibiting the alarm conditioning forces the TimeSource 3500 to continue to output valid timing signals while in major alarm. This may be useful when testing, troubleshooting, or in installations where a TimeSource 3500 that is in major alarm may produce better timing signals than other sources (for example, offices without additional holdover clocks in a distribution shelf). ED-EQPT::TS3500:<ctag>::ALMCOND=b; b= alarm conditioning of the outputs (b = ALW or INH)

Procedure H. Power-Up (cont'd)

Step	Procedure
31	Use the Copy Memory command to copy the database from volatile to nonvolatile memory within the TimeSource 3500. CPY-MEM:[tid]:TS3500:<ctag>::WKG, .AUX:DATA; <i>Note:</i> Although the database is automatically copied to nonvolatile memory once per hour, it is recommended that the Copy Memory command be executed each time the database is changed.
32	When the GPS signals have been acquired and the outputs are stable enough to output a signal, the TimeSource enters a settling period. During the settling period, the following conditions exist: • Status GPS lamp is green • Status SYS lamp is green • Any Span lamp is green when its input is connected, entered, contains valid framing, and is usable for ensembling • All outputs are functioning according to specifications or in a slightly degraded mode • A TL1 autonomous "settling period" event message exists. <i>Notes:</i> 1. In roof antenna installations, the nominal time to reach normal operation (output a PRS signal) is 20 min. If normal operation has not been reached after 40 min, refer to the Troubleshooting chapter. 2. The settling period is the condition where this clock is beyond the warm-up state but not yet in steady state operation. Steady state operation is indicated by the clearing of the "settling period" event. 3. In window or wall antenna installations, the nominal time to reach normal operation (output a PRS signal) is variable, depending on the view of the sky and the satellite positions at the time of power-up, and may take up to several hours. If normal operation is not reached, refer to the Troubleshooting chapter. 4. The TimeSource 3500 develops and sends timing within the PRS specification during normal operation and during any event (other than settling period) or minor alarm, but not during a major or critical alarm.

End of Procedure

TimeWizard

The TimeWizard Software Installation application was created to facilitate installing software upgrades for the TimeSource 3500. Procedure I shows how to install the TimeWizard application and how to use TimeWizard to download software upgrades.

Procedure I. TimeWizard Installation and Operation

Step	Procedure
Use this procedure to install the software in the TimeSource 3500 using the TimeWizard application.	
Requirements:	
1. A PC running Windows 95/98/NT 4.0/2000/XP.	
2. The TimeSource 3500 CD labeled 092-72050-06 Rev. A Version 1.06.02.	
Hardware Installation	
1	Connect the TimeSource 3500 to the PC with a serial cable.
2	Ensure that the TimeSource 3500 port on which the serial cable is connected is set to either 9600 baud or 115K baud, and echo is set to ALW (factory default).
Software Installation	
3	Insert the TimeSource 3500 CD labeled 092-72050-06 Rev. A Version 1.06.02 into the PC's CD-ROM drive.
4	The CD should autorun to install TimeWizard. If it does not, proceed to step 5.
5	Click on setup.exe to install TimeWizard. This application will install the new release of TS3000.hex and GPS.hex.
6	Select OK when prompted.
7	Choose the installation directory (or defer to the default) and start the installation. The setup will copy all necessary files to the selected directory, including the TS3000.hex and GPS.hex files.

Procedure I. TimeWizard Installation and Operation (cont'd)

Step	Procedure
Download Procedure	
8	Run TimeWizard from the Start Menu.
9	Enter the login name and password. To perform downloads at 115K baud, check the high speed box. Unchecking the box will perform downloads at 9600 baud. Click Next to go on to the next screen.
10	Check the box when TimeWizard displays the prompt to download GPS.hex. Doing so will download the GPS.hex file. Downloading may be skipped in case the displayed GPS.hex version is 1.02.04. To skip this download, uncheck the box. The download will take approximately 3 minutes to complete at 115K baud. Wait for the screen to refresh (until the hourglass icon changes to the arrow cursor). Verify that the GPS version displayed is 1.02.04. <i>Note:</i> If the download fails for any reason, a screen appears with instructions to contact Symmetricom. If this happens, exit the application, check the cable connections, and restart TimeWizard.
11	Check the box when TimeWizard displays the prompt to download TS3000.hex. Doing so will download the TS3000.hex file. Downloading may be skipped in case the displayed TS3000.hex version is 1.06.02. To skip this download, uncheck the box. The download will take approximately 3 minutes to complete at 115K baud. Wait for the screen to refresh (until the hourglass icon changes to the arrow cursor). Verify that the TS3000 version displayed is 1.06.02. <i>Note:</i> If the download fails for any reason, a screen appears with instructions to contact Symmetricom. If this happens, exit the application, check the cable connections, and restart TimeWizard.
12	After clicking Next , an alarm parameters screen is displayed. The Holdover and GPS alarm escalation parameters can be modified here. Once the parameters have been changed, they can be saved for future use by clicking the Save button. An existing parameter file can also be loaded by clicking the Load button.
13	After clicking Next , the alarm parameters will be sent to the TimeSource 3500 and the status is displayed on the screen.

Procedure I. TimeWizard Installation and Operation (cont'd)

Step	Procedure
14	In the Exit Application screen, a prompt is displayed to save a log of the entire TimeWizard session. Check the box if saving the log is desired. Click the button with the file name to change the log file name. Click Exit to exit the application.
<i>End of Procedure</i>	

Factory-Set Values

The parameter values initially set at the factory are shown in Table H.

Table H. Parameter Factory Settings

<aid>	Parameter Setting
TS3500	TOD=NONE ALMCOND=ALW IPNE=0.0.0.0 IPSUBNET=255.255.255.255 IPGATE=0.0.0.0 IPEM1=0.0.0.0 IPEM1PORT=0 IPEM2=0.0.0.0 IPEM2PORT=0 IPINACT=0 DCDPASSTHRU=INH DCDUSERPORT=2
TS3500 HOLDOVER ALARM	TIME=72-0 SEV1=EV SEV2=MJ SAFF1=NSA SAFF2=SA
TS3500 GPS ALARM	TIME=10-0 SEV1=EV SEV2=MN SAFF1=NSA SAFF2=NSA
GPS	ANTCBLDLY=0 ANTELEV MASK=10 ANTMODE=AUTO MANLAT=N-0-0-0 MANLONG=W-0-0-0 MANELEV=0

Table H. Parameter Factory Settings (cont'd)

<aid>	Parameter Setting
SPAN-A, SPAN-B	ENSEMBLER=INH MONITOR=INH SSM=INH
SPAN-A, SPAN-B LOS ALARM	TIME=24-0 SEV1=EV SEV2=MN SAFF1=NSA SAFF2=NSA
SPAN-A, SPAN-B AIS ALARM	TIME=24-0 SEV1=EV SEV2=MN SAFF1=NSA SAFF2=NSA
SPAN-A, SPAN-B ERROR ALARM	TIME=24-0 SEV1=EV SEV2=MN SAFF1=NSA SAFF2=NSA
T1-A, T1-B	FRAMING=ESF ALMOUT=AIS
COM-1, COM-2, COM-3	BAUD=9600 MONMSG=INH KEEPAIVE=0 ENDOFTEXT=00 ECHO=ALW COMPRI=ALW1 AUTOLOGOFF=20 HWCONTROL=INH SWCONTROL=INH PARITY=NONE STOP=1

Table H. Parameter Factory Settings (cont'd)

<aid>	Parameter Setting
COM-5001, COM-5002, COM-5003, COM-5004	MONMSG=INH KEEPALIVE=0 ENDOF TEXT=00 ECHO=ALW COMPRI=ALW1 AUTOLOGOFF=20 SWCONTROL=INH
COM-5551	MONMSG=INH KEEPALIVE=0 ENDOFTEXT=00 ECHO=INH COMPRI=ALW1 AUTOLOGOFF=20 SWCONTROL=INH
OPT-1, OPT-2, OPT-3, OPT-4, OPT-5, OPT-6, OPT-7, OPT-8 (990-72050-02, 990-72050-06, and 990-72050-07 systems only)	FRAMING=ESF ALMOUT=AIS

TL1 Reference

*This chapter provides
information for using the
TL1 language.*

Chapter 4

Conventions

Uppercase letters in a command designate parameter values which must be entered as shown. Lowercase letters in a command are the parameter name, and the specific values that must be entered for the parameter. The Parameters section of this chapter describes the parameters and the values where a value is the same for all parameters. Parameter values for a particular command are listed with the command. The system accepts either uppercase, lowercase, or a mixture of both, but upper and lower case cannot be mixed within a parameter block.

The following symbols are used in the input and response messages:

- [] encloses an optional parameter
- { } encloses a group of parameters, at least one of which must be entered
- | separates alternatives in a group of parameters, at least one of which must be entered

^	indicates a space (used in the description of the response format, but not used in the command responses)
–	separates command code fields
:	separates parameter blocks
,	separates parameters within a block
;	terminates a command, and causes execution
" "	encloses text to be parsed by a machine
/* */	encloses comments for humans
< >	encloses a TL1 named variable
\ " \"	encloses a description of a condition
...	indicates the previous line in a response may be repeated as required

Command Format


A command consists of a command code of up to three fields separated by hyphens, followed by parameter blocks separated by colons. Figure 35 shows the command format. Parameter blocks consist of one or more parameters separated by commas.

Parameter blocks may be null (contain no parameters), or contain one or more parameters. Two colons occur next to each other if a parameter block is null.

Multiple parameters in a parameter block are separated by commas. Two commas occur next to each other if a parameter is null.

Entering a semicolon at the end of the command indicates that the command statement is completed to the interpreter, and executes the command.

Figure 35. Command Format



Response Format

When a command is received and processed, a response is returned. All responses include a source identifier (<sid>), the date, the time, an M to indicate that it is a response to a command, and the correlation tag (<ctag>) that was entered with the command.

Figure 36 shows the completed response format. COMPLD indicates that the command was completed without error.

Figure 37 shows the denied response format. DENY indicates that the command was denied due to an error. The <errcde> parameter indicates the corresponding error type, or cause of the error.

Figure 36. Completed Response Format

```
^^^<sid>^<date>^<time>
M^^<ctag>^COMPLD
^^^/*LINK:<link>,CMD:<command>*/
;
```

Note: If the command was a query, additional information would be displayed before the semicolon.

Figure 37. Deny Response Format

```
^^^<sid>^<date>^<time>
M^^<ctag>^DENY
^^^<errcde>
^^^/* <error message> */
^^^/*LINK:<link>,CMD:<command>*/
;
```

Parameters

The parameters that may be used in commands, responses, and messages are defined in Table I. When a parameter uses the same values in every instance, those values are listed with the parameter in the table. When the context requires different values for a parameter, the value is listed with the parameter in the applicable commands, responses, and messages.

Table I. Parameter Definitions

Parameter	Definition
<aid>	Access identifier for the object of the command or message. It may have more than one part.
<almcde>	Alarm code. Identifies the severity of the alarm based on its priority of action. If multiple alarms are reported, almcde is the highest severity of those reported.
<atag>	Automatic message tag. It is incremented by one for each autonomous message. The <atag> value is a whole number from 001 through 999, which is reset to 001 at reset or when it rolls over.
<command>	Echo of the entered command.
<conddescr>	Text description of the condition. The <conddescr> value is limited to 64 characters starting and ending with a back slash and a double quotation mark (\"). Refer to the Troubleshooting chapter of this manual for the list of values.
<condeff>	Effect on the condition of the equipment.
<condtype>	Type of alarm condition.
<ctag>	Correlation tag used to correlate input and response messages. The ctag contains 1 to 6 characters. It must be included in a command, and the same ctag is returned in the response.

Table I. Parameter Definitions (cont'd)

Parameter	Definition
<date>	Date in the 8-digit form: yyyy-mm-dd (command) or yyyy:mm:dd (response or message), where yyyy is the year, mm is the month (01 to 12), and dd is the day of the month (01 to 31). For example, May 3, 2000 is 2000-05-03.
<errcde>	Four-character mnemonic error code, which is one of the following: EFON = equipment feature option not provided ENEQ = not equipped ICNV = command not valid IDNV = invalid data in command IDRG = invalid data range in command IIAC = invalid aid in command IICT = invalid correlation tag IIDT = invalid data parameter in command IISP = invalid syntax or punctuation IITA = invalid tid PIUI = invalid or duplicate uid or pid (privileged users only) RALB = All units of requested type are busy RCBY = circuit is busy SCSN = invalid command sequence SDBE = internal database error SNIS = not in service SNVS = not in a valid state SRCN = requested condition currently exists SRQN = request invalid SWFA = working unit failed
<error message>	Error code text message.
<link>	Communication link identifier.

Table I. Parameter Definitions (cont'd)

Parameter	Definition
<modifier>	Equipment initiating the alarm or event message, which is one of the following: TS3500 = system software GPS = GPS receiver software SPAN-x = T1 span input
<mondat>	Date of the performance monitoring data.
<montm>	Time of the performance monitoring data.
<montype>	Data type of the performance monitoring data.
<monval>	Value of the performance monitoring data.
<ntfcncde>	Notification code showing the alarm severity, which is one of the following: CR = critical MJ = major MN = minor
<ocrdat>	Occurrence date in the 8-digit form: yyyy-mm-dd (command) or yyyy:mm:dd (response or message), where yyyy is the year, mm is the month (01 to 12), and dd is the day of the month (01 to 31). For example, May 3, 2000 is 2000-05-03.
<ocrtm>	Occurrence time in the 6-digit form: hh-mm-ss (command) or hh:mm:ss (response or message), where hh is hours (00 to 23), mm is minutes (00 to 59), and ss is seconds (00 to 59). For example, 2:34 pm is 14:34:00.
<pid>	Private identifier, factory-set to "TS3000!!". It is the initial password for the TELECOM <uid>. Passwords are encrypted when stored in the TimeSource 3500, and are never transmitted from the shelf. The pid contains a case-insensitive string of 8 to 10 ASCII characters, and must include at least one letter, one numeral, and one special character from the following: ! " \$ % & ' () * + - . / < > ? @

Table I. Parameter Definitions (cont'd)

Parameter	Definition
<sid>	Source identifier of the equipment sending the message. The <sid> may contain a maximum of 20 characters (limited to letters, digits, and hyphens), and may begin with a letter. The <sid> is recommended to be the equipment's CLI code.
<spec_block>	Replaced by a number of parameters within the command. Parameters are in the format <name>=<value>, may be entered in any order, and must be separated by a comma.
<srveff>	Identifies whether the alarm condition is service affecting: SA = service affecting NSA = not service affecting
<tid>	Target identifier of the equipment to which the command is directed. The tid must be a valid TL1 identifier of a maximum of 20 characters (limited to letters, digits, and hyphens) beginning with a letter. The <tid> is recommended to be the target's CLI code, and can also be used as the <sid>. The <tid> can be null if the OS directly interfaces to the target. The <tid> can be omitted only if connection is made directly to a single TimeSource 3500 Shelf.
<time>	Current time in the six-digit form: hh-mm-ss (command) or hh:mm:ss (response or message), where hh is hours (00 to 23), mm is minutes (00 to 59), and ss is seconds (00 to 59). For example, 5:11:49 a.m. is 05:11:49.
<uap>	User access level, used by a system administrator to assign a given level of access to system users. User access level ranges from 1 to 5, with 1 being the lowest access level, and 5 being the highest access level.
<uid>	User identifier, factory-set to TELECOM. The <uid> contains alphanumeric, case-insensitive strings of 6 to 10 characters provisioned as valid login IDs.
<uout>	User inactivity password which indicates the number of days a system user has not logged on to the system. The user inactivity timeout range is 0 to 180 days, with 0 indicating no timeout.

Parameter	Definition
<utc>	Universal Coordinated Time (UTC) in the 6-digit form: hh-mm-ss, where hh is hours (00 to 23), mm is minutes (00 to 59), and ss is seconds (00 to 59). For example, 2:34 pm is 14-34-00.
<vldty>	Validity of the performance monitoring data.

Autonomous Messages

Autonomous messages are sent out when an alarm or event occurs. Two types of autonomous messages are used:

- Report Alarm: reports alarms
- Report Event: reports events that are not alarms, or that have not yet become alarms

Autonomous messages are listed on the following pages. After the message name, a definition of the message is given.

Report Alarm

This autonomous message appears when an alarm is raised, and appears again when the alarm is cleared.

Message:

```
^^^<sid> <date> <time>
M^^<almcde> <atag> REPT ALM <modifier>
^^^"<aid>:<ntfcncde>,<condtype>,<srveff>,<ocrdat>,<ocrtm>,,,:\"<conddescr>\
                                     "[:<dgntype>]"
```

Note: Refer to Table I for parameter definitions.

Report Event

This autonomous message appears when an event is raised, and again when the event is cleared; also appears when a transient event occurs. An event is a state of the TimeSource 3500 that does not cause an alarm.

Message:

```
^^^<sid> <date> <time>
M^^<atag> REPT EVT <modifier>
^^^"<aid>:<condtype>,<condeff>,<ocrdat>,<ocrtm>
      ,,,,:\"<conddescr>\":<dgntype>]"
```

Note: Refer to Table I for parameter definitions.

Tasks/Commands

To perform each task, use the command listed beside that task in Table J.

Table J. Commands for Tasks

Task	Command	Page
Log user onto system	Activate User	155
Log user off of system	Cancel User	156
Copy software program or database	Copy Memory	157
Delete equipment from the database	Delete Equipment	160
Delete a user from system	Delete User Security	161
Change communication port parameters	Edit Communication	162
Change the system date and time	Edit Date	166
Change equipment parameters	Edit Equipment	169
Enter equipment into the database and allow the equipment to be used for monitoring	Enter Equipment	179
Enter a new user and configure the new user's user name, password, and access level	Enter User Security	181
Reset the alarm log	Initialize Log	182
Reset to zero all performance monitoring parameters associated with a given aid	Initialize Register	183

Table J. Commands for Tasks (cont'd)

Task	Command	Page
Reset the system processor or GPS receiver processor	Initialize System	184
Deactivate the audible office alarm	Operate Alarm Cutoff All	185
Display current system alarms	Retrieve Alarm All	186
Display current alarms for specific equipment	Retrieve Alarm Equipment	187
Display current communication port parameter settings	Retrieve Communication	189
Display current system alarms and events	Retrieve Condition All	192
Display current alarms and events for specific equipment	Retrieve Condition Equipment	193
Display parameter settings of equipment	Retrieve Equipment	195
Display GPS status information	Retrieve GPS Status	205
Display information about equipment	Retrieve Inventory	207
Display alarm log data	Retrieve Log	210
Display performance monitoring data	Retrieve Performance Monitoring	211
Display security parameters for a single user or for all users	Retrieve User Security	227
Set the name of the equipment	Set Source Identifier	228

Commands

The commands used with the TimeSource 3500 are listed on the following pages. After the command name, a definition of the command is given. The definition is followed by the actual command, followed by the variables that can be used with the command.

The response format shows how the response will appear, with additional definitions of the response parameters where required.

Activate User

This command logs the user onto the system, and begins a session. The factory-set user name is “TELECOM”, and the factory-set password is “TS3000!!”. The user name and password are not case sensitive (either uppercase or lowercase can be used). The command format is:

ACT-USER:[<tid>]:<uid>:<ctag>::<pid>;

Parameter	Parameter Description
<uid>	Assigned user name
<pid>	Assigned password

Command Example:

ACT-USER::TELECOM:<ctag>::TS3000!!;

Response Format:

```
<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;
```

Cancel User

This command logs the current user off the system, and logs other users off the system as well, provided the current user has access rights of 5. The user name is not case sensitive, but must otherwise be entered exactly as assigned.

To cancel another user, type the command with the UID as the user name to be logged out.

The command format is:

CANC-USER:[<tid>]:<uid>:<ctag>;

Parameter	Parameter Description
<uid>	Assigned user name

Command Example:

CANC-USER::TELECOM:<ctag>;

Response Format:

<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;

Copy Memory

This command copies a software program from an external computer to the TimeSource 3500, or copies the system database to nonvolatile memory.

Notes:

1. The Software Release Document (included with this software release) contains detailed instructions for copying programs from an external computer to nonvolatile memory.
2. Clear any existing alarms before using this command.
3. The database is automatically copied to nonvolatile memory once per hour. However, if power to the TimeSource 3500 is interrupted before the automatic copying occurs, changes made since the last automatic copy will be lost. To avoid the possibility of losing database changes, the Copy Memory command may be used to copy database changes to nonvolatile memory after any changes are made.

To copy a program from an external computer to nonvolatile memory within the TimeSource 3500, the command format is:

```
CPY-MEM:[<tid>]:<aid>:<ctag>::AUX,,WKG:PGM;
```

Copy Memory (cont'd)

Aid	Item Addressed
TS3000	System software
GPS	GPS receiver software
DEV1	TimeSource 3500 (standard) (990-72050-01 systems) or TimeSource 3500 with two T1 outputs and eight composite clock outputs (990-72050-03 systems)
DEV3	TimeSource 3500 with two TOD IRIG-B outputs (990-72050-05 systems)
DEV5	TimeSource 3500 with eight additional T1 outputs (990-72050-02 systems)
DEV9	TimeSource 3500 with eight mixed E1/T1 outputs (990-72050-06 systems)
DEV11	TimeSource 3500 with eight mixed T1/CCK outputs (990-72050-07)

Command Example:

CPY-MEM::TS3000:<ctag>::AUX,,WKG:PGM;

Response Format:

```
^^^<sid> <date> <time>
M^^<atag> REPT EVT <modifier>
^^^"<aid>:<condtype>,<condeff>,<ocrdat>,<ocrtm>
    ,,,:\ "<conddescr>\"[:<dgntype>]"
```

Copy Memory (cont'd)

Note: Refer to Table I for parameter definitions.

To copy a database from volatile to nonvolatile memory within the TimeSource 3500, the command format is:

CPY-MEM:[<tid>]:<aid>:<ctag>::WKG,,AUX:DATA;

Aid	Item Addressed
TS3500	System Database

Command Example:

CPY-MEM::TS3500:<ctag>::WKG,,AUX:DATA;

Response Format:

<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;

Delete Equipment

This command deletes the specified equipment from the database, removes the input from the ensembling algorithm, and stops the monitoring for that input. Alarms are not reported for deleted equipment. The command format is:

DLT-EQPT:[<tid>]:<aid>:<ctag>::<spec_block>

Aid	Value	Item Addressed
SPAN-a	a = A	T1 span A input
	a = B	T1 span B input

Command Example:

DLT-EQPT::SPAN-A:<ctag>;

Response Format:

```
<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;
```


Delete User Security

This command allows a system administrator to delete a user. The command format is:

DLT-USER-SECU:[<tid>]:<uid>:<ctag>;

Parameter	Parameter Description
<uid>	Assigned user name

Command Example:

DLT-USER-SECU::TELECOM:<ctag>;

Response Format:

<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;

Edit Communication

This command changes communication port parameters. The command format is:

ED-COM:[<tid>]:<aid>:<ctag>:::<spec_block>;

Aid	Value	Item Addressed
COM-a	a = 1	Serial communication port 1 (COM1)
	a = 2	Serial communication port 2 (COM2)
	a = 3	Serial communication port 3 (Craft)
	a = 5001	Ethernet user interface port 5001 (Note 1)
	a = 5002	Ethernet user interface port 5002 (Note 1)
	a = 5003	Ethernet user interface port 5003 (Note 1)
	a = 5004	Ethernet user interface port 5004 (Note 1)
	a = 5551	Ethernet element manager interface port 5551 (Note 2)

Notes:

1. Ethernet ports 5001, 5002, 5003, and 5004 are set up to act as serial communication ports, so that a terminal program on a computer connected to these ports can communicate effectively.
2. Ethernet port 5551 is set up to allow an element manager to connect with it for TL1 commands and responses. TL1 autonomous messages are sent through port 5550, which connects to an element manager to send one or a group of autonomous messages, then disconnects. Port 5550 is not to be reconfigured.

Edit Communication (cont'd)

The parameters which can be entered in the <spec_block> are listed below. For any specific <aid> entered in a command, only certain parameters are valid. For each valid parameter, choose the appropriate value from the Value column. When entering multiple parameters, separate the parameters with commas.

Aid	Parameter	Value	Description
COM-a	MONMSG=b	b = ALW	View messages from all ports
		b = INH	View messages from this port only
	KEEPALIVE=b	b = 1 to 255	Inactive minutes until the unit sends a COMPLD message to keep the connection from being closed
		b = 0	No COMPLD message is output
	ENDOFTEXT=b	b = 1 to 9F	Hex code at end of all responses
		b = 0	No hex code at end of responses
	ECHO=b	b = ALW	Echoes characters received so they appear on the user's screen as typed
		b = INH	Local echo is disabled
	COMPRI=b	b = ALW0	TL1 commands and responses, no autonomous messages sent
		b = ALW1	TL1 commands and responses, autonomous messages
		b = ALW2	TL1 commands and responses, autonomous messages whether logged on or not
		b = INH	Closes connection, logs off any user (if logged on), and keeps port from use. Releases a telnet session from an Ethernet port (a port cannot close itself)

Edit Communication (cont'd)

Aid	Parameter	Value	Description
COM-a (cont'd)	AUTOLOGOFF=b	b = 1 to 255	Inactive minutes until the unit logs off the user, keeping the connection open
		b = 0	Autologoff is disabled
	HWCONTROL=b (See Note 2)	b = ALW	Serial port CTS/RTS flow control is enabled
		b = INH	Serial port CTS/RTS flow control is not enabled
	SWCONTROL=b (See Note 2)	b = ALW	XON/XOFF flow control is enabled
		b = INH	XON/XOFF flow control is not enabled
	BAUD=b (See Note 1)	b = 115	Serial port baud rate is 115 kbaud
		b = 57.6	Serial port baud rate is 57.6 kbaud
		b = 38.4	Serial port baud rate is 38.4 kbaud
		b = 19.2	Serial port baud rate is 19.2 kbaud
		b = 9600	Serial port baud rate is 9600 baud
		b = 4800	Serial port baud rate is 4800 baud
		b = 2400	Serial port baud rate is 2400 baud
		b = 1200	Serial port baud rate is 1200 baud
	PARITY=b (See Note 1)	b = EVEN	Even parity is enabled on serial port
		b = ODD	Odd parity is enabled on serial port
		b = NONE	No parity is enabled on serial port
	STOP=b (See Note 1)	b = 1	1 stop bit on serial port
		b = 2	2 stop bits on serial port

Edit Communication (cont'd)

Notes:

1. Baud rate, parity, and stop bits can only be configured on serial communication ports (1, 2, and 3).
2. Flow control is not implemented on communication port 3 (Craft port).
3. XON/XOFF flow control is simulated for Ethernet ports.

Command Example:

```
ED-COM::COM-1:<ctag>::BAUD=9600,MONMSG=ALW,  
KEEPALIVE=30,ENDOFTEXT=0,ECHO=ALW,  
COMPRI=ALW1,AUTOLOGOFF=30,HWCONTROL=ALW,  
SWCONTROL=ALW,PARITY=NONE,STOP=1;
```

Response Format:

```
<sid> <date> <time>  
M <ctag> COMPLD  
/*LINK:<link>,CMD:<command>*/  
;
```

Edit Date

This command changes the system date and time. The command format is:

ED-DAT:[<tid>]::<ctag>::<date>,<time>]
:[MODE=a];

Parameter	Value	Parameter Description
date in the format a-b-c	a = <year>	4-digit year
	b = 01 to 12	Month
	c = 01 to 31	Day
time in the format a-b-c (Note 1)	a = 00 to 23	Hour of the day
	b = 00 to 59	Minutes
	c = 00 to 59	Seconds
MODE=a	a = UTC (Note 2)	Uses Universal Coordinated Time from GPS (cannot set time by TL1 command)
	a = LOCAL	Uses local time for hours, UTC for minutes and seconds

Notes:

1. The <time> value can only be entered when MODE=LOCAL, or in the same command as MODE=LOCAL, otherwise the command is denied. A successful command with <time> changes the display of time to conform to the nearest 30 minutes, relative to UTC.

Edit Date (cont'd)

For example, when the UTC time is 01:12:10, setting the local time to 18:50:30 will actually set the clock to 18:42:10, because 18:42:10 is the closest 30 minute jump, relative to UTC, from 18:50:30. This is done to accommodate 30-minute time zones and still keep the local time accurate to UTC.

2. If a command includes MODE=UTC, and the GPS signal is not present, the command is denied.

The date/time behavior is as follows:

- During warm-up:
 - The date/time displayed starts from 1970 and increments from there. If the ED-DAT command is used to set the time in local mode, the time is changed as specified in the command.
- After warm-up:
 - If the ED-DAT command has not been used to set the local mode time, then UTC date and time are displayed.
 - If the ED-DAT command has been used to set the local mode time, then it is changed in the manner described as follows.
 - The date given in the ED-DAT command is retained. The local hours, minutes, and seconds are set to the nearest 30-minute divisible difference from UTC. A few examples will help to clarify.
 - > Example 1. UTC time = 01:00:00. Local time = 18:01:10 will set the local time to 18:00:00.
 - > Example 2. UTC time = 01:00:00. Local time = 18:25:30 will set the local time to 18:30:00.

Edit Date (cont'd)

- > Example 3. UTC time = 01:12:10. Local time = 18:50:30 will set the local time to 18:42:10.
- During Holdover Event
 - The date/time continues to increment normally.
- During Holdover Alarm
 - The date/time continues to increment normally.

Example to set date without changing time or mode:

```
ED-DAT::tag>::2000-08-13;
```

Example to change to local time:

```
ED-DAT::tag>::2000-08-13,07-00-00:MODE=LOCAL;
```

Example to change from local to UTC time:

```
ED-DAT::tag>::2000-08-13:MODE=UTC;
```

Response Format:

```
<sid> <date> <time>  
M <c>tag> COMPLD  
/*LINK:<link>,CMD:<command>*/  
;
```


Edit Equipment

This command changes equipment parameters. Additionally, this command can cause an input to be ensembled. The command format is:

ED-EQPT:[<tid>]:<aid>:<ctag>:::<spec_block>;

Aid	Value	Item Addressed
TS3500	—	System-wide configuration
GPS	—	GPS configuration
SPAN-a	a = A	T1 span A input
	a = B	T1 span B input
T1-a	a = A	T1 A output
	a = B	T1 B output
OPT-a	a = 1 to 8	T1 output module port number (990-72050-02, 990-72050-06, and 990-72050-07 systems only)

Edit Equipment (cont'd)

The parameters which can be entered in the <spec_block> are listed below. For any specific <aid> entered in a command, only certain parameters are valid. For each valid parameter, choose the appropriate value from the Value column. When entering multiple parameters, separate the parameters with commas.

Aid	Parameter	Value	Description
TS3500	TOD=a	a = CISCO	Serial message sent in Cisco format
		a = NTP4	Serial message sent in NTP Type 4 format
		a = NONE	No serial message sent
	ALMCOND =a	a = ALW	Alarm conditioning for T1, TOD, and IRIG-B outputs is enabled
		a = INH	Alarm conditioning for T1, TOD, and IRIG-B outputs is disabled
	IPNE=a.b.c.d (See Note 1)	a = 0 to 255	IP address of this TimeSource 3500 (command must be sent from COM1, COM2, or Craft port to set this parameter)
		b = 0 to 255	
		c = 0 to 255	
		d = 0 to 255	
	IPSUBNET=a.b.c.d (See Note 1)	a = 0 to 255	Subnet mask for this TimeSource 3500 (command must be sent from COM1, COM2, or Craft port to set this parameter)
		b = 0 to 255	
		c = 0 to 255	
		d = 0 to 255	

Edit Equipment (cont'd)

Aid	Parameter	Value	Description
TS3500 (cont'd)	ALARM=x	x = HOLDOVER	HOLDOVER alarm
		x = GPS	GPS alarm
SPAN A & B	ALARM=x	x = LOS	LOS alarm
		x = AIS	AIS alarm
		x = ERROR	ERROR alarm
TS3500, SPAN A & B	TIME=x	x = HH-MM	Hour (00-999) and minute (00-59) time to escalate alarm
		x = 0	No alarm escalation
	SEVERITY1=x (See Note 7)	x = CR	Severity of initial alarm prior to escalation
		x = MJ	
		x = MN	
		x = EV	
		x = NA	
	SEVERITY2=x (See Note 7)	x = CR	Severity of escalated alarm
		x = MJ	
		x = MN	
		x = EV	
		x = NA	
	SERAFF1=x (See Note 7)	x = SA	Service affecting state of initial alarm prior to escalation
		x = NSA	
	SERAFF2=x (See Note 7)	x = SA	Service affecting state of escalated alarm
		x = NSA	

Edit Equipment (cont'd)

Aid	Parameter	Value	Description
TS3500 (cont'd)	IPGATE=a.b.c.d (See Note 1)	a = 0 to 255	Default gateway IP address for this TimeSource 3500 (command must be sent from COM1, COM2, or Craft port to set this parameter)
		b = 0 to 255	
		c = 0 to 255	
		d = 0 to 255	
	IPEM1=a.b.c.d (See Notes 1, 2, 3)	a = 0 to 255	IP address of primary element manager (port 5550 connects to this element manager to send autonomous messages, disconnects when transmit is complete)
		b = 0 to 255	
		c = 0 to 255	
		d = 0 to 255	
	IPEM1PORT=a (See Notes 1, 2, 3)	a = 0 to 65535	Port address of primary element manager (port for IPEM1 address)
	IPEM2=a.b.c.d (See Notes 1, 2, 3)	a = 0 to 255	IP address of alternate element manager (if used) (port 5550 connects to this element manager if connection cannot be made to the primary element manager)
		b = 0 to 255	
		c = 0 to 255	
		d = 0 to 255	
	IPEM2PORT=a (See Notes 1, 2, 3)	a = 0 to 65535	Port address of alternate element manager (port for IPEM2 address)
	IPINACT=a (See Note 1)	a = 0 to 10000	Port 5550 closes the connection to the Element Manager if no autonomous messages are sent during this number of 100-ms units (0 to 10,000, where 0 deactivates the timer, for example, 100 = 10 s)

Edit Equipment (cont'd)

Aid	Parameter	Value	Description
GPS	ANTCBLDLY=a (See Note 4)	a = 0 to 300	Antenna cable length (meters)
	ANTELEV MASK=a (See Note 4)	a = 0 to 45	Antenna elevation mask angle (degrees)
	ANTMODE=a	a = AUTO	Automatic survey-in mode (use only with roof antenna configuration)
		a = MANUAL	Manual survey-in mode (do not use with roof antenna configuration)
	MANLAT=a-b-c-d	a = N	North latitude
		a = S	South latitude
		b = 0 to 180	Degrees of latitude
		c = 1 to 59	Minutes of latitude
		d = 1 to 999	Decimal minutes of latitude
	MANLONG=a-b-c-d	a = E	East longitude
		a = W	West longitude
		b = 1 to 180	Degrees of longitude
		c = 1 to 59	Minutes of longitude
		d = 1 to 999	Decimal minutes of longitude
	MANELEV ALT=a	a = -1000 to 8000	Antenna elevation (meters)
TS3500	NTPPWD=x (See Note 5)	x = 6 ASCII characters	NTP Password (contact factory)

Edit Equipment (cont'd)

Aid	Parameter	Value	Description
SPAN-a (See Note 7)	ENSEMBLER=b	b = ALW	Span is ensembled
		b = INH	Span is not ensembled
	SSM=b (See Note 6)	b = ALW	SSM qualifies span input
		b = INH	SSM does not qualify span input
T1-a	ALMOUT=b	b = AIS	Output is AIS during holdover alarm
		b = SQUELCH	Output is off during holdover alarm
		b = SSM	Outputs are at 'STU' quality level during holdover alarm (SSM requires ESF output framing)
	FRAMING=b	b = ESF	Output framing is ESF
		b = D4	Output framing is D4
OPT-a (Additional T1 ports on 990-72050- 02 systems only)	ALMOUT=b	b = AIS	Output is AIS during holdover alarm
		b = SQUELCH	No output during holdover alarm
		b = SSM	Outputs are at 'STU' quality level during holdover alarm (SSM requires ESF output framing)
	FRAMING=b	b = ESF	Output framing is ESF
		b = D4	Output framing is D4

Edit Equipment (cont'd)

Aid	Parameter	Value	Parameter Description
OPT-a (990-72050-06 systems only)	ALMOUT=b	b = AIS	Output is AIS during alarm
		b = SQUELCH	Output is squelched during alarm
		b = SSM	Outputs are at 'STU' quality level for ESF framing and at 'SSUT' quality level for CAS4 and CCS4 framing during holdover alarm (SSM requires CAS4, CCS4, or ESF output framing)
	FRAMING =b	b = CAS	Output framing is CAS
		b = CAS4	Output framing is CAS4
		b = CCS	Output framing is CCS
		b = CCS4	Output framing is CCS4
		b = D4	Output framing is D4
		b = ESF	Output framing is ESF
		b = NONE	Output framing is NONE (analog) (If ALMOUT is SQUELCH, the signal turns off during holdover alarm. Any other ALMOUT option does not affect output during alarm)

Edit Equipment (cont'd)

Aid	Parameter	Value	Parameter Description
OPT-a (990- 72050-07 systems only)	ALMOUT=b	b = AIS	Output is AIS during alarm
		b = SQUELCH	Output is squelched during alarm
		b = SSM	Outputs are at 'STU' quality level during holdover alarm (SSM requires ESF output framing)
	FRAMING =b	b = D4	Output framing is D4
		b = ESF	Output framing is ESF
		b = CCK	Output is Composite Clock. (ALMOUT is SQUELCH by default and need not be programmed. ALMOUT cannot be set to AIS or SSM. The signal turns off during holdover alarm.)

Edit Equipment (cont'd)

Aid	Parameter	Value	Description
TS3500	DCDPASSTHRU	INH	DCD port communication is inhibited
		ALW1	COM1 is the DCD interface port
		ALW2	COM2 is the DCD interface port
	DCDUSERPORT=x (See Note 8)	x = 1	COM1
		x = 2	COM2
		x = 3 or 5001, 5002, 5003, 5004	COM3 or IP port 5001 to 5004

Notes:

1. This parameter affects all Ethernet ports. Close the Ethernet ports and log off all users before issuing a command with this parameter.
2. Port 5550 makes a connection to this element manager to send TL1 autonomous messages, and closes the connection when the transmission is complete.
3. Port 5551 accepts a connection from this element manager for TL1 commands and responses.
4. When the TimeSource 3500 uses a roof antenna, only the parameters ANTCBLDLY and ANTELEV MASK, and the mode ANTMODE=AUTO, are allowed.

Edit Equipment (cont'd)

Notes:

5. If the dbinit jumper is changed, the NTP password has to be re-entered.
6. A span must have been put into service using the ENT-EQPT command before setting the ENSEMBLER and SSM parameters.
7. When setting alarm integration time (SEVERITY or SERAFF), the type of alarm (HOLDOVER, GPS, LOS, AIS, or ERROR) has to be specified. For example, ED-EQPT::TS3500:CTAG::
ALARM=HOLDOVER, TIME=72-00, SEVERITY1=EV,
SERAFF1=NSA, SEVERITY2=MJ, SERAFF2=SA; will generate a holdover event as soon as the condition is detected with an NSA flag. Once this condition has existed for 72 hours, TS3500 will generate a major alarm with an SA flag. These parameters can then be verified using the RTRV-EQPT command.
8. All commands on DCDUSERPORT having TID which equals SID of the DCD are forwarded to the DCD. Similarly, the responses from the DCD are sent to the provisioned DCDUSERPORT.

Response Format:

```
<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;
```

Enter Equipment

This command puts optional inputs in service, and causes the selected input to be monitored. Additionally, this command can cause an input to be ensembled. All in-service inputs are monitored. The Delete Equipment command must be used to take an input out of service. The command format is:

ENT-EQPT:[<tid>]:<aid>:<ctag>:::<spec_block>;

Aid	Value	Item Addressed
SPAN-a	a = A	T1 span A input
	a = B	T1 span B input

Enter Equipment (cont'd)

The parameters which can be entered in the <spec_block> are listed below. For any specific <aid> entered in a command, only certain parameters are valid. For each valid parameter, choose the appropriate value from the Value column. When entering multiple parameters, separate the parameters with commas.

Aid	Parameter	Value	Description
SPAN-a	ENSEMBLER=b	b = ALW	Span is monitored and ensembled
		b = INH	Span is monitored, but not ensembled

Example to set an input to be monitored, but not ensembled:

ENT-EQPT:[<tid>]:SPAN-A:<ctag>;

Example to set an input to be monitored and ensembled:

ENT-EQPT:[<tid>]:SPAN-A:<ctag>::ENSEMBLER=ALW;

Response Format:

<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;

Enter User Security

This command allows a system administrator to enter a new user, and the new user's user name, password, and access level. The command format is:

ENT-USER-SECU:[<tid>]:<uid>:<ctag>::<pid>,,<uap>;

Parameter	Parameter Description
<uid>	User name – must start with an alpha character and have a maximum of 10 characters.
<pid>	Password – has to be a minimum of 8 characters and a maximum of 10 characters. It must contain at least one digit and one of the following characters: ! \$ % ' () * + . / < > ? @ Password cannot be the same as User ID even if extra characters are appended to password at the end.
<uap>	Access level (1 to 5). Levels 1 to 4 do not allow the user to enter or delete users. Level 5 allows the user to enter or delete users.

Command Example:

ENT-USER-SECU::TELECOM:<ctag>::TS3000!!,,1;

Response Format:

<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;

Intialize Log

This command clears the alarm log. The command format is:

```
INIT-LOG:[<tid>]::<ctag>::almlog;
```

Response Format:

```
<sid> <date> <time>  
M <ctag> COMPLD  
/*LINK:<link>,CMD:<command>*/  
;
```

Initialize Register

This command resets to zero all the performance monitoring associated with the entered aid. The command can be used to reset either span independently or both spans at the same time. The command format is:

INIT-REG-EQPT:[<tid>]:<aid>:<ctag>::ALL;

Aid	Value	Item Addressed
SPAN-a	a = A	TI span A input
	a = B	TI span B input
ALL	—	TI span A and span B inputs

Response Format:

<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;

Initialize System

This command resets the specified processor.

Caution: Using this command with an <aid> of TS3500 will cause a loss of outputs until GPS satellites are reacquired if ALMOUT is SQUELCH, or unstable outputs if ALMOUT is not SQUELCH.

The command format is:

INIT-SYS:[<tid>]:<aid>:<ctag>::1;

Aid	Item Addressed
TS3500	System software
GPS	GPS receiver software

Response Format:

<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;

Operate Alarm Cutoff All

This command deactivates (silences) the audible office alarm. The command format is:

```
OPR-ACO-ALL:[<tid>]:ALL:<ctag>;
```

Response Format:

```
<sid> <date> <time>  
M <ctag> COMPLD  
/*LINK:<link>,CMD:<command>*/  
;
```

Retrieve Alarm All

This command displays all current system alarms. The command format is:

```
RTRV-ALM-ALL:[<tid>]:ALL:<ctag>;
```

If there are no alarms:

```
<sid> <date> <time>  
M <ctag> COMPLD  
/*LINK:<link>,CMD:<command>*/  
;
```

If there is at least one alarm:

```
<sid> <date> <time>  
M <ctag> COMPLD  
  "<aid>:<ntfcncde>,<condtype>,<srveff>,  
<ocrdat>,<ocrtm>,,:\"<conddescr>\"...  
  /*LINK:<link>,CMD:<command>*/  
;
```

Note: Refer to the Troubleshooting chapter for a list of all <conddescr> messages, and the recommended action.

Retrieve Alarm Equipment

This command displays current alarms for the specified equipment. The command format is:

RTRV-ALM-EQPT:[<tid>]:<aid>:<ctag>;

Aid	Value	Item Addressed
TS3500	—	System (all TS3500 alarms)
SPAN-a	a = A	T1 span A input
	a = B	T1 span B input
GPS	—	GPS receiver

Retrieve Alarm Equipment (cont'd)

If there are no alarms:

```
<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;
```

If there is at least one alarm:

```
<sid> <date> <time>
M <ctag> COMPLD
"<aid>:<ntfcncde>,<condtype>,<srveff>,
  <ocrdat>,<ocrtm>,,:\ "<conddescr>\""...
/*LINK:<link>,CMD:<command>*/
;
```

Note: Refer to the Troubleshooting chapter for a list of all <conddescr> messages, and the recommended action.

Retrieve Communication

This command displays communication port parameter settings.
The command format is:

RTRV-COM:[<tid>]:<aid>:<ctag>;

Aid	Value	Item Addressed
COM-a	a = 1	Serial communication port 1
	a = 2	Serial communication port 2
	a = 3	Serial communication port 3
	a = 5001	Ethernet user interface port 5001
	a = 5002	Ethernet user interface port 5002
	a = 5003	Ethernet user interface port 5003
	a = 5004	Ethernet user interface port 5004
	a = 5551	Ethernet element manager interface port 5551
ALL	—	All communication ports

Response Format:

```
<sid> <date> <time>
M <ctag> COMPLD
  "<aid>:::<spec_block>"...
/*LINK:<link>,CMD:<command>*/
;
```

Retrieve Communication (cont'd)

The parameters which may be displayed in the <spec_block> are listed below.

Parameter	Value	Description
MONMSG=a	a = ALW	View messages from all ports
	a = INH	View messages from this port only
KEEPALIVE=a	a = 1 to 255	Inactive minutes until the unit sends a COMPLD message to keep the connection from being closed
	a = 0	No COMPLD message is output
ENDOFTEXT=a	a = 1 to 9F	Hex code at end of all responses
	a = 00	No hex code at end of responses
ECHO=a	a = ALW	Echoes characters received so they appear on the user's screen as typed
	a = INH	Local echo is disabled
COMPRI=a	a = ALW0	TL1 commands and responses, no autonomous messages sent
	a = ALW1	TL1 commands and responses, sends autonomous messages
	a = ALW2	TL1 commands and responses, sends autonomous messages whether or not logged on
	a = INH	Closes connection, logs off a user (if logged on), and keeps port from use (a port cannot close itself)

Retrieve Communication (cont'd)

Parameter	Value	Parameter Description
AUTOLOGOFF=a	a = 1 to 255	Inactive minutes until the unit logs off the user, keeping the connection open
	a = 0	Autologoff is disabled
SWCONTROL=a	a = ALW	XON/XOFF flow control is enabled
	a = INH	XON/XOFF flow control is not enabled
HWCONTROL=a	a = ALW	Serial port CTS/RTS flow control is enabled
	a = INH	Serial port CTS/RTS flow control is not enabled
BAUD=a	a = 115	Serial port baud rate is 115 kbaud
	a = 57.6	Serial port baud rate is 57.6 kbaud
	a = 38.4	Serial port baud rate is 38.4 kbaud
	a = 19.2	Serial port baud rate is 19.2 kbaud
	a = 9600	Serial port baud rate is 9600 baud
	a = 4800	Serial port baud rate is 4800 baud
	a = 2400	Serial port baud rate is 2400 baud
PARITY=a	a = EVEN	Even parity bit is enabled
	a = ODD	Odd parity bit is enabled
	a = NONE	Parity bit is disabled
STOP=a	a = 1	1 stop bit
	a = 2	2 stop bits

Retrieve Condition All

This command displays all current system alarms and events. The command format is:

```
RTRV-COND-ALL:[<tid>]:ALL:<ctag>;
```

If there are no alarms or events:

```
<sid> <date> <time>  
M <ctag> COMPLD  
/*LINK:<link>,CMD:<command>*/  
;
```

If there is at least one alarm or event:

```
<sid> <date> <time>  
M <ctag> COMPLD  
"<aid>:<ntfcncde>,<condtype>,<srveff>,  
  <ocrdat>,<ocrtm>,,,\"<conddescr>\""...  
/*LINK:<link>,CMD:<command>*/  
;
```

Note: Refer to the Troubleshooting chapter for a list of all <conddescr> messages, and the recommended action.

Retrieve Condition Equipment

This command displays current alarms and events for the specified equipment. The command format is:

RTRV-COND-EQPT:[<tid>]:<aid>:<ctag>;

Aid	Value	Item Addressed
TS3500	—	System
SPAN-a	a = A	T1 span A input
	a = B	T1 span B input
GPS	—	GPS receiver

Command Example:

RTRV-COND-EQPT::TS3500:<ctag>;

Retrieve Condition Equipment (cont'd)

If there are no alarms:

```
<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;
```

If there is at least one alarm:

```
<sid> <date> <time>
M <ctag> COMPLD
"<aid>:<ntfcncde>,<condtype>,<srveff>,<ocrdat>,<ocrtm>,...\"<conddescr>\"...
/*LINK:<link>,CMD:<command>*/
;
```

Note: Refer to the Troubleshooting chapter for a list of all <conddescr> messages, and the recommended action.

Retrieve Equipment

This command displays parameter settings for the specified equipment. The command format is:

RTRV-EQPT:[<tid>]:<aid>:<ctag>;

Aid	Value	Item Addressed
ALL	—	All aids for this command
TS3500	—	System
GPS	—	GPS receiver
SPAN-a	a = A	Span A input
	a = B	Span B input
T1-a	a = A	T1 A output
	a = B	T1 B output
OPT-a	a = 1 to 8	T1 1 through 8 outputs option (990-72050-02 systems only) T1 or E1 outputs option (990-72050-06 systems only) T1 or CCK outputs option (990-72050-07 systems only)

Command Example:
RTRV-EQPT::ALL:G;

Retrieve Equipment (cont'd)

Response Format:

```
<sid> <date> <time>
M <ctag> COMPLD
  "<aid>:::<spec_block>"...
/*LINK:<link>,CMD:<command>*/
;
```

The parameters which may be displayed in the <spec_block> are listed below.

Aid	Parameter	Value	Parameter Description
TS3500	TOD=a	a = CISCO	Serial message sent is Cisco format
		a = NTP4	Serial message sent is NTP Type 4 format
		a = NONE	No serial message is sent
	ALMCOND=a	a = ALW	Alarm conditioning for outputs is enabled
		a = INH	Alarm conditioning for outputs is disabled
	IPNE=a.b.c.d	a = 0 to 255	This unit's IP address
		b = 0 to 255	
		c = 0 to 255	
		d = 0 to 255	
	IPSUBNET=a.b.c.d	a = 0 to 255	Subnetwork mask
		b = 0 to 255	
		c = 0 to 255	
		d = 0 to 255	

Retrieve Equipment (cont'd)

Aid	Parameter	Value	Parameter Description
TS3500 (cont'd)	IPGATE=a.b.c.d	a = 0 to 255	Default gateway IP address
		b = 0 to 255	
		c = 0 to 255	
		d = 0 to 255	
	IPEM1=a.b.c.d	a = 0 to 255	Primary element manager IP address
		b = 0 to 255	
		c = 0 to 255	
		d = 0 to 255	
	IPEM1PORT=a	a = 0 to 65535	Primary element manager output port address
	IPEM2=a.b.c.d	a = 0 to 255	Alternate element manager IP address
		b = 0 to 255	
		c = 0 to 255	
		d = 0 to 255	
	IPEM2PORT=a	a = 0 to 65535	Alternate element manager port number
	IPINACT=a	a = 0 to 10000	Port 5550 closes the connection to the Element Manager if no autonomous messages are sent during this number of 100-ms units (0 to 10,000, where 0 deactivates the timer, for example, 100 = 10 s)
	IPNTP=a	a = ALW	NTP feature activated

Retrieve Equipment (cont'd)

Aid	Parameter	Value	Parameter Description
TS3500 (cont'd)	DCDPASSTHRU	INH	DCD port communication is inhibited
		ALW1	COM1 is the DCD interface port
		ALW2	COM2 is the DCD interface port
	DCDUSERPORT=a (See Note 1)	a = 1	COM1
		a = 2	COM2
		a = 3 or 5001, 5002, 5003, 5004	COM3 or IP port 5001 to 5004
GPS	ANTCBLDLY=a	a = 0 to 330	Antenna cable length (meters)
	ANTELEV MASK=a	a = 0 to 45	Antenna elevation mask angle (degrees)
	ANTMODE=a	a = AUTO	Automatic survey-in mode
		a = MANUAL	Manual survey-in mode (do not use for roof antenna)
	MANLAT=a-b-c-d	a = N	North latitude
		a = S	South latitude
		b = 1 to 180	Degrees of latitude
		c = 1 to 60	Minutes of latitude
		d = 1 to 1000	Decimal minutes of latitude

Retrieve Equipment (cont'd)

Aid	Parameter	Value	Parameter Description
GPS (cont'd)	MANLONG= a-b-c-d	a = E	East longitude
		a = W	West longitude
		b = 1 to 180	Degrees of longitude
		c = 1 to 60	Minutes of longitude
		d = 1 to 1000	Decimal minutes of longitude
	MANELEV=a	a = -1000 to 8000	Antenna elevation (meters)
SPAN-a	ENSEMBLER=b	b = ALW	T1 span is ensembled
		b = INH	T1 span is not ensembled
	MONITOR=b	b = ALW	T1 span is monitored
		b = INH	T1 span is not monitored
	SSM=b	b = ALW	SSM message is used to qualify input
		b = INH	SSM message is not used to qualify input
T1-a	FRAMING=b	b = ESF	Output framing is ESF
		b = D4	Output framing is D4
	ALMOUT=b	b = AIS	Output is AIS during alarm
		b = SQUELCH	Output is squelched during alarm
		b = SSM	Outputs are at 'STU' quality level during holdover alarm (SSM requires ESF output framing)

Retrieve Equipment (cont'd)

Aid	Parameter	Value	Parameter Description
TS3500	ALARM=x	x = HOLDOVER	HOLDOVER alarm
		x = GPS	GPS alarm
SPAN A & B	ALARM=x	x = LOS	LOS alarm
		x = AIS	AIS alarm
		x = ERROR	ERROR alarm
RO A & B	ALARM=x	x = LOS	LOS alarm
		x = ERROR	ERROR alarm
TS3500, SPAN A & B, RO A & B	TIME=x	x = HH-MM	Hour (00-999) and minute (00-59) time to escalate alarm
		x = 0	No alarm escalation
	SEV1=x (See Note 2)	x = CR	Severity of initial alarm prior to escalation
		x = MJ	
		x = MN	
		x = EV	
		x = NA	
	SEV2=x (See Note 2)	x = CR	Severity of escalated alarm
		x = MJ	
		x = MN	
		x = EV	
		x = NA	

Retrieve Equipment (cont'd)

Aid	Parameter	Value	Parameter Description
TS3500, SPAN A & B, RO A & B (cont'd)	SAFF1=x (See Note 2)	x = SA	Service affecting state of initial alarm prior to escalation
		x = NSA	
	SAFF2=x (See Note 2)	x = SA	Service affecting state of escalated alarm
		x = NSA	
OPT-a (990- 72050- 02 systems only)	ALMOUT=b	b = AIS	Output is AIS during alarm
		b = SQUELCH	Output is squelched during alarm
		b = SSM	Outputs are at 'STU' quality level during holdover alarm (SSM requires ESF output framing)
	FRAMING=b	b = ESF	Output framing is ESF
		b = D4	Output framing is D4

Retrieve Equipment (cont'd)

Aid	Parameter	Value	Parameter Description
OPT-a (990- 72050-06 systems only)	ALMOUT=b	b = AIS	Output is AIS during alarm
		b = SQUELCH	Output is squelched during alarm
		b = SSM	Outputs are at 'STU' quality level for ESF framing and at 'SSUT' quality level for CAS4 and CCS4 framing during holdover alarm (SSM requires CAS4, CCS4, or ESF output framing)
	FRAMING =b	b = CAS	Output framing is CAS
		b = CAS4	Output framing is CAS4
		b = CCS	Output framing is CCS
		b = CCS4	Output framing is CCS4
		b = D4	Output framing is D4
		b = ESF	Output framing is ESF
		b = NONE	Output framing is NONE (analog) (If ALMOUT is SQUELCH, the signal turns off during holdover alarm. Any other ALMOUT option does not affect output during alarm)

Retrieve Equipment (cont'd)

Aid	Parameter	Value	Parameter Description
OPT-a (990- 72050-07 systems only)	ALMOUT=b	b = AIS	Output is AIS during alarm
		b = SQUELCH	Output is squelched during alarm
		b = SSM	Outputs are at 'STU' quality level during holdover alarm (SSM requires ESF output framing)
	FRAMING =b	b = D4	Output framing is D4
		b = ESF	Output framing is ESF
		b = CCK	Output is Composite Clock. (ALMOUT is SQUELCH by default and need not be programmed. ALMOUT cannot be set to AIS or SSM. The signal turns off during holdover alarm.)

Retrieve Equipment (cont'd)

Notes:

1. All commands on DCDUSERPORT TID which equal SID of the DCD are forwarded to the DCD. Similarly, the responses from the DCD are sent to the provisioned DCDUSERPORT.
2. When setting alarm integration time (SEVERITY or SERAFF), the type of alarm (HOLDOVER, GPS, LOS, AIS, or ERROR) has to be specified. For example, ED-EQPT::TS3000:CTAG::
ALARM=HOLDOVER, TIME=72-00, SEVERITY1=EV,
SERAFF1=NSA, SEVERITY2=MJ, SERAFF2=SA; will generate a holdover event as soon as the condition is detected with an NSA flag. Once this condition has existed for 72 hours, TS3000 will generate a major alarm with an SA flag. These parameters can then be verified using the RTRV-EQPT command.

Retrieve GPS Status

This command displays the position of the GPS receiver, UTC time, and status information for each of the GPS satellites in view. The command format is:

RTRV-GPS-STAT:[<tid>]:GPS:<ctag>;

Response Format:

```
<sid> <date> <time>
M <ctag> COMPLD
  "<aId>:LAT=a, LONG=a, ALT=a, UTC=a
  ANTMODE=a, MERIT=a, SUCCESS=a%
  SAT-a, USE=a, CNO=a, ELEV=a, AZ=a,
  LOCK=a..."
/*LINK:<link>, CMD:<command>*/
;
```

Retrieve GPS Status (cont'd)

Parameter	Value	Description
LAT=a	a = dd.mm.fffN	Current latitude north in degrees, minutes, and decimal-fractions of a minute
	a = dd.mm.fffS	Current latitude south in degrees, minutes, and decimal-fractions of a minute
LONG=a	a = ddd.mm.fffE	Current longitude east in degrees, minutes, and decimal-fractions of a minute
	a = ddd.mm.fffW	Current longitude west in degrees, minutes, and decimal-fractions of a minute
ALT=a	a = mm.mmm	Altitude in meters to the thousandth of a meter, referenced to mean sea level
UTC=a	a = hh-mm-ss	Universal Coordinated Time (UTC), where hh is hours (00 to 23), mm is minutes (00 to 59), and ss is seconds (00 to 59)
ANTMODE=a	a = AUTO	Automatic survey-in mode
	a = MANUAL	Manual survey-in mode
MERIT=a	a = bbb	Timing error estimate in ns
SUCCESS=a	a = bb	Percentage of time satellites are visible
SAT=a	a = 1 to 25	Satellite identification number
USE=a	a = Y	Satellite in use
	a = N	Satellite not in use
CNO=a	a = nn	Satellite carrier-to-noise ratio
ELEV=a	a = dd	Satellite elevation in degrees
AZ=a	a = ddd	Satellite azimuth in degrees
LOCK=a	a = 1 to 2500	Seconds since the receiver locked to the satellite carrier

Retrieve Inventory

This command displays information about the specified equipment. The command format is:

RTRV-INVENTORY:[<tid>]:TS3500:<ctag>;

Response Format:

```
<sid> <date> <time>
M <ctag> COMPLD
  "TS3500::::CARD=TS3500,
  MACID=a,
  TYPE=a,
  PART=a,
  SERIAL=a,
  SOFTVER_TS3000=a,
  SOFTVER_GPS=a,
  SOFTVER_DEV=a"
/*LINK: x, CMD:<command>*/
;
```

Retrieve Inventory (cont'd)

Parameter	Value	Description
CARD=TS3500	—	System
MACID=a.b.c.d.e	a = 00 to FF in hexadecimal format	MAC address
	b = 00 to FF in hexadecimal format	
	c = 00 to FF in hexadecimal format	
	d = 00 to FF in hexadecimal format	
	e = 00 to FF in hexadecimal format	
TYPE=a	a = NO OPTION BOARD	TimeSource 3500 (standard) (990-72050-01 systems)
	a = T1 OPTION BOARD	TimeSource 3500 with eight additional T1 outputs (990-72050-02 systems)
	a = CCK OPTION BOARD	TimeSource 3500 with eight composite clock outputs (990-72050-03 systems)
	a = IRIG OPTION BOARD	TimeSource 3500 with two TOD IRIG-B outputs (990-72050-05 systems)
	a = MIXED E1/T1 OPTION BOARD	TimeSource 3500 with eight mixed E1/T1 outputs (990-72050-06 systems)
	a = MIXED T1/CCK OPTION BOARD	TimeSource 3500 with eight mixed T1/CCK outputs (990-72050-07 systems)
PART=a	—	a = Part number
SERIAL=a	—	a = Serial number

Retrieve Inventory (cont'd)

Parameter	Value	Description
SOFTVER_ TS3000=a	a = bb.cc.dd	System software version
SOFTVER_GPS=a	a = bb.cc.dd	GPS receiver software version
SOFTVER_ DEV=a	a = bb.cc.dd or bb.cc.dd-ee.ff.gg	Device software version

Retrieve Log

This command retrieves the alarm log. The command format is:

RTRV-LOG:[<tid>]::<ctag>::almlog;

Response Format:

```
<sid> <date> <time>
M <ctag> COMPLD
  "<logtype>"
  "<aid>:<ntfcncde>,<condtype>,<srverff>,<ocrdat>,<ocrtm>,,[,<conddescr>,<dgntype>]"*/
/*LINK:<link>,CMD:<command>*/
;
```

Parameter	Parameter Description
<ntfcncde>	Severity of alarm: critical, major, or minor
<condtype>	Single type of alarm condition being reported on this particular line, i.e., LOS, FAIL, TBD for each alarm
<srverff>	Alarm is service affecting (SA) or non-service affecting (NSA)
<ocrdat>	Occurrence date in MOY-DOM format, where MOY=1 to 12 and DOM=1 to 31
<ocrtm>	Occurrence Time of Day in HOD-MOH-SOM format, where HOD=0 to 23, MOH=0 to 59, SOM=0 to 59
<conddescr>	Text string of no more than 64 characters enclosed within a pair of escape quotes (\)
<dgntype>	TL1 identifier up to 16 characters in length

Retrieve Performance Monitoring

This command retrieves the performance monitoring data from the TimeSource 3500. This data includes MTIE, TDEV, PHASE1S, and PHASE1M. For current 24 hour data, MTIE, TDEV, and PHASE1S data are grouped every 15 minutes. In addition, there are 7 daily summaries of MTIE, TDEV, and PHASE1M. Each value type can be retrieved for both span inputs A and B.

MTIE data includes the following time intervals in seconds: 1, 4, 10, 40, 100, 300, 900, 1800, 3600, 7200, 14400, 28800, and 86400.

TDEV data includes the following time intervals in seconds: 1, 2, 4, 8, 16, 32, 64, 128, 256, 512, and 1024.

PHASE1S data includes 900 seconds of phase values.

PHASE1M data includes 60 minutes of phase values.

The command format is:

```
RTRV-PM-EQPT:[<tid>]:SPAN-a:<ctag>::<montype>
      , , , , [<mondatt>][<montm>];
```

Retrieve Performance Monitoring (cont'd)

Parameter	Value	Description
SPAN-a	a = A	E1 span A input
	a = B	E1 span B input
<montype>	MTIE	MTIE data reported
	TDEV	TDEV data reported
	PHASE1S	1-second phase data reported
	PHASE1M	1-minute phase data reported
<mondat>=x	x = 1 to 12	Monitor date, month of the year
	x = 1 to 31	Monitor date, day of the month
<montm>=x	x = 0 to 23	Monitor time, hour past midnight
	x = 0 to 59	Monitor time, minutes past the hour

MTIE Response Format:

```
<sid> <date> <time>
M <ctag>COMPLD
  "SPAN-a:MTIE-a,<monval>,<vldty>
    ,,,,,<mondat>,<montm>"
    .
    .
    .
  "SPAN-a:MTIE-a,<monval>,<vldty>
    ,,,,,<mondat>,<montm>"
  /*LINK:<link>,CMD:<command>*/
;
```

Retrieve Performance Monitoring (cont'd)

Note: MTIE Data types:

- One 15 minute bin from the last 24 hours of data. To select a 15 minute bin, enter mondat and montm. Any mondat/montm combination outside of the past 24 hour window is denied. Any time increment may be entered. The system rounds the value to the nearest bin. Entered minutes of 1 to 15 correspond to the first 15 minute bin, 16 to 30 correspond to the second 15 minute bin, etc.
- One day summary from the last 7 days of daily summaries. To select one daily summary, enter mondat, but do not enter montm. Any mondat not in the previous 7 day window is denied.

Retrieve Performance Monitoring (cont'd)

Parameter	Value	Description
SPAN-a	a = A	E1 span A input
	a = B	E1 span B input
MTIE-a	a = 1S, 2S, 4S, 10S, 40S, 100S, 300S, 900S, 1800S, 3600S, 7200S, 14400S, 28800S, or 86400S	MTIE monitored type, where a is time intervals in seconds
<monval>	One 15 min bin from the last 24 h of data	Monitored value
<vldty>	COMPL	Data is valid
	NA	Data is not valid
MONDAT=a-b	a = 1 to 12	Monitor date, month of the year
	b = 1 to 31	Monitor date, day of the month
MONTM=a-b	a = 0 to 23	Monitor time, hour of the day
	b = 0 to 59	Monitor time, minute of the hour

Retrieve Performance Monitoring (cont'd)

MTIE Response Example:

```
TS3500-2009 2000-05-25 11:01:58
M G COMPLD
"SPAN-A:MTIE-1S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
"SPAN-A:MTIE-4S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
"SPAN-A:MTIE-10S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
"SPAN-A:MTIE-40S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
"SPAN-A:MTIE-100S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
"SPAN-A:MTIE-300S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
"SPAN-A:MTIE-900S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
"SPAN-A:MTIE-1800S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
"SPAN-A:MTIE-3600S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
"SPAN-A:MTIE-7200S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
"SPAN-A:MTIE-14400S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
"SPAN-A:MTIE-28800S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
"SPAN-A:MTIE-86400S,1,COMPL
    , , , , ,2000-05-25,11-00-00"
/*LINK:5002,CMD:RTRV-PM-EQPT::
    SPAN-A:G::MTIE*/
;
```

Retrieve Performance Monitoring (cont'd)

TDEV Response Format:

```
<sid> <date> <time>
M <ctag>COMPLD
  "SPAN-a:TDEV-a,<monval>,<vldty>
    ,,,,,<mondatt>,<montm>"
    .
    .
    .
  "SPAN-a:TDEV-a,<monval>,<vldty>
    ,,,,,<mondatt>,<montm>"
/*LINK:<link>,<CMD>:<command>*/
;
```

Note: TDEV Data types:

- One 15 minute bin from the last 24 hours of data. To select a 15 minute bin, enter mondatt and montm. Any mondatt/montm combination outside of the past 24 hour window is denied. Any time increment may be entered. The system rounds the value to the nearest bin. Entered minutes of 1 to 15 correspond to the first 15 minute bin, 16 to 30 correspond to the second 15 minute bin, etc.
- One day summary from the last 7 days of daily summaries. To select one daily summary, enter mondatt, but do not enter montm. Any mondatt not in the previous 7 day window is denied.

Retrieve Performance Monitoring (cont'd)

Parameter	Value	Item Addressed
SPAN=a	a = A	E1 span A input
	a = B	E1 span B input
TDEV=a	a = 1S, 2S, 4S, 8S, 16S, 32S, 64S, 128S, 256S, 512S, or 1024S	TDEV monitored type, where a is time intervals in seconds
<monval>	One 15 min bin from the last 24 h of data	Monitored value
<vldty>	COMPL	Data is valid
	NA	Data is not valid
MONDAT=a-b	a = 1 to 12	Monitor date, month of the year
	b = 1 to 31	Monitor date, day of the month
MONTM=a-b	a = 0 to 23	Monitor time, hour of the day
	b = 0 to 59	Monitor time, minute of the hour

Retrieve Performance Monitoring (cont'd)

TDEV Response Example:

TS3500-2009 2000-05-25 11:01:58

M G COMPLD

"SPAN-A:TDEV-1S,0,COMPL
,,,,,2000-05-25,11-00-00"

"SPAN-A:TDEV-2S,0,COMPL
,,,,,2000-05-25,11-00-00"

"SPAN-A:TDEV-4S,0,COMPL
,,,,,2000-05-25,11-00-00"

"SPAN-A:TDEV-8S,0,COMPL
,,,,,2000-05-25,11-00-00"

"SPAN-A:TDEV-16S,0,COMPL
,,,,,2000-05-25,11-00-00"

"SPAN-A:TDEV-32S,0,COMPL
,,,,,2000-05-25,11-00-00"

"SPAN-A:TDEV-64S,0,COMPL
,,,,,2000-05-25,11-00-00"

"SPAN-A:TDEV-128S,0,COMPL
,,,,,2000-05-25,11-00-00"

"SPAN-A:TDEV-256S,0,COMPL
,,,,,2000-05-25,11-00-00"

"SPAN-A:TDEV-512S,0,COMPL
,,,,,2000-05-25,11-00-00"

"SPAN-A:TDEV-1024S,0,COMPL
,,,,,2000-05-25,11-00-00"

/*LINK:5002,CMD:RTRV-PM-EQPT::
SPAN-A:G::TDEV*/

;

PHASE 1 S Response Format:

4

Retrieve Performance Monitoring (cont'd)

Note: PHASE1S Data types:

- One 15 minute bin from the last 24 hours of data as 900 seconds of data. To select a 15 minute bin, enter mondat and montm. Any mondat/montm combination outside of the past 24 hour window is denied. Any time increment may be entered. The system rounds the value to the nearest bin.
- Entered minutes of 1 to 15 correspond to the first 15 minute bin, 16 to 30 correspond to the second 15 minute bin, etc.
- The first monitor value is the first second of the 900 second window.
- The 900 seconds of data is broken into 9 groups of 100 seconds. For each group of 100 seconds, the first value is the absolute 1 second phase for that group. The absolute 1 second phase value is followed by 99 seconds of delta phase values.

Retrieve Performance Monitoring (cont'd)

Parameter	Value	Item Addressed
SPAN-a	a = A	E1 span A input
	a = B	E1 span B input
PHASE1S	—	Phase 1S monitored type, which shows 900 s of phase values
<monval>	First s of the 100 s data group. There are 9 groups of 100 s.	Absolute monitored phase value
<D>	The difference (D) from the proceeding number	99 s of delta phase values which follow the absolute 1 s phase value
<vldty>	COMPL	Data is valid
	NA	Data is not valid
MONDAT=a-b	a = 1 to 12	Monitor date, month of the year
	b = 1 to 31	Monitor date, day of the month
MONTM=a-b	a = 0 to 23	Monitor time, hour of the day
	b = 0 to 59	Monitor time, minute of the hour

PHASE1 S Response Example (cont'd):

[illegible]

"SPAN-A:PHASE1S,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,
0,
.0,
0,
.0,0,0,0,0,0,0,0,0,0,0,0,0,NA,...2000-10-13.12-55-00"

"SPAN-A:PHASE1S,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,
0,
.0,
0,
.0,0,0,0,0,0,0,0,0,0,0,0,0,NA...2000-10-13.12-56-40"

"SPAN-A:PHASE1S,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,
0,
.0,
0,
.0,0,0,0,0,0,0,0,0,0,0,0,NA,...2000-10-13,12-58-20"

```
/* LINK: 5001, CMD: RTRV-PM-EQPT::SPAN-A:C::
PHASE1S..... */
```

•

Retrieve Performance Monitoring (cont'd)

PHASE1M Response Format:

```
<sid> <date> <time>
M <ctag>COMPLD
  "SPAN-a:PHASE1M,<monval>,<monval>,
    <monval>,<monval>,<monval>,<monval>,
      . . .
      <monval>,<monval>,<monval>,<monval>,
      <vldty>,,,<mondatt>,<montm>"
/*LINK:<link>,CMD:<command>*/
;
```


Retrieve Performance Monitoring (cont'd)

Note: PHASE 1M Data types:

- The TimeSource 3500 collects a full 7 days of 1 minute phase data.
- The 1 minute phase data is displayed in 1 hour groups. Each request for 1 minute phase is synchronized to the hour.
- Any mondat/montm combination outside of the past 7 day window is denied. Any time increment may be entered. The system rounds the value to the nearest hour, i.e., the minute and second field of the montm is ignored.
- The first value (monval) is the oldest value in the range selected. For example, if montm = 8:45:32, the first monval will exceed time 8:00:00 followed by the value at 8:01:00, etc.

PHASE1M Response Example:

•

Retrieve User Security

This command allows a system administrator to retrieve security parameters for a single user or for all users. The command format is:

RTRV-USER-SECU:[<tid>]:<uid>:<ctag>;

Parameter	Value	Item Addressed
<uid>	(user name)	Single user
	ALL	All users

Response Format:

```
<sid> <date> <time>
M <ctag> COMPLD
  "<aid>:,<uap>;,UOUT=<uout>"...
  /*LINK:<link>,CMD:<command>*/
;
```

Parameter	Parameter Description
<uap>	Access level (1 to 5)
<uout>	(Displayed, but not implemented) Password for this account expires in this number (0 to 180) of days of inactivity; 0 indicates no expiration

Set Source Identifier

This command sets the name of the equipment sending the message. The command format is:

SET-SID:[<tid>]::<ctag>::<sid>;

Parameter	Parameter Description
<sid>	Source identifier – can be up to 20 uppercase or lowercase ASCII characters

Response Format:

```
<sid> <date> <time>
M <ctag> COMPLD
/*LINK:<link>,CMD:<command>*/
;
```

Troubleshooting

This chapter provides troubleshooting information using front-panel lamps and error messages. It also describes how to replace a card, return equipment, get technical and/or sales assistance, and obtain manual updates.

Chapter 5

Troubleshooting with Front Panel Items

All front panel items are shown in Figure 38. The items are described in Table K. Use Table K to troubleshoot the system based on the front-panel lamps.

Figure 38. Controls and Indicators




Table K. Front Panel Items

Name	State	Description	Action
Status GPS	Off	System is not powered.	If in warm-up, none required. If there is no power, apply power.
	Green	GPS is successfully tracking satellites, or is in warm-up.	None required.
	Yellow	A GPS event has occurred.	None required.
	Red	A GPS event, which has existed per the user alarm setting, has escalated to a minor alarm.	Refer to Table L to determine which type and combination of antenna alarms exist, and the recommended action.
Status SYS	Off	System is in warm-up mode or is not powered.	If in warm-up, none required. If there is no power, apply power.
	Green	The output signal is PRS.	None required.
	Red	The system has been in holdover per the user alarm setting, or there is a hardware fault.	Refer to Table L to determine which type and combination of alarms exist, and the recommended action.
Alarms CRIT	Off	There is no critical alarm.	None required.
	Red	A critical alarm has occurred because of a hardware failure.	Replace the plug-in card, using Procedure J.
Alarms MAJ	Off	There is no major alarm.	None required.
	Red	The system has been in holdover per the user alarm setting.	Refer to Table L to determine which type and combination of antenna alarms exist, and the recommended action.

Table K. Front Panel Items (cont'd)

Name	State	Description	Action
Alarms MIN	Off	There is no minor alarm.	None required.
	Yellow	A minor alarm has occurred because Battery A or B has failed.	Troubleshoot and repair the specified -48 V battery input.
		A minor alarm has occurred because a software download is required.	Refer to Table L to determine which software needs to be downloaded and the recommended action.
		A minor alarm has occurred because an event (GPS error, temperature error, or span input problem) has escalated to a minor alarm.	Refer to Table L to determine which event occurred and the recommended action.
		A minor alarm has occurred because the antenna failed.	Refer to Table L to determine whether the minor alarm is due to antenna failure and the recommended action.
ACO (Lamp)	Off	The alarm cutoff function has not been activated.	None required. Press the ACO pushbutton to silence all audible alarms.
	Green	The alarm cutoff function has been activated.	None required.
ACO (Pushbutton)	—	Silences all audible alarms when pressed.	None required.

Troubleshooting with Error Messages

Use the information in Table L to troubleshoot the system based on the condition description (conddescr) parameter in a message.

Note: If only the character “C” is displayed on the terminal every few seconds, the TimeSource 3500 system has restarted with corrupt software. Download and install the system software again, using the procedure in the Software Release Document that came with the software.

Table L. Message Troubleshooting

Message	Meaning	Action
CRITICAL ALARMS		
HARDWARE FAULT	A failure has been detected on the shelf hardware.	Replace the plug-in card.
MAJOR ALARMS		
HOLDOVER	All inputs (GPS signal and span inputs) are lost or unacceptable, and the system is now using the internal oscillator.	Troubleshoot the GPS and SPAN x error messages.
MINOR ALARMS		
BATTERY x FAIL	The specified -48 V battery input has failed.	Troubleshoot, and repair, the specified -48 V battery input.
BT3 WARMUP	The system is in a power-up state when it should not be.	Perform the same action as shown in GPS ERROR message.

Table L. Message Troubleshooting (cont'd)

Message	Meaning	Action
DEVICE DOWNLOAD REQUIRED	The hardware device software is corrupt or missing.	Download and install the appropriate hardware device (DEV) software, using the procedure in the Software Release Document that came with the software.
GPS ERROR	The GPS receiver is reporting an error.	If the installation includes a roof antenna, or if the message is accompanied by the HIGH CURRENT FAULT or LOW CURRENT FAULT message, follow the recommended action for the HIGH CURRENT FAULT or LOW CURRENT FAULT message. If the installation includes a window or wall antenna: 1. Note the satellite tracking success rate reported by the RTRV-GPS-STAT command. 2. If the success rate is better than 40%, follow the recommended action for the HIGH CURRENT FAULT or LOW CURRENT FAULT message. 3. If the success rate is less than 40%, check that the latitude, longitude, and altitude data (position data) are correct. 4. If the position data are correct and the error repeats, move the antenna to a location with an improved view of the sky. 5. If the error repeats, follow the recommended action for the HIGH CURRENT FAULT or LOW CURRENT FAULT message.
GPS DOWNLOAD REQUIRED	The GPS software is corrupt or missing.	Download, and install, the GPS receiver (GPS) software, using the procedure in the Software Release Document that came with the software.

Table L. Message Troubleshooting (cont'd)

Message	Meaning	Action
HIGH CURRENT FAULT	Current to antenna is outside specification.	If not accompanied by the GPS ERROR alarm, none required.
LOW CURRENT FAULT		If accompanied by the GPS ERROR alarm: 1. Check the cable connections between the TimeSource 3500 Shelf and the antenna. 2. If the error repeats, remove the antenna cable from the rear of the shelf, and measure the dc voltage from the connector center pin to the connector housing on the shelf TNC antenna connector. 3. If the voltage is not 24 V dc ± 2 V dc, replace the TimeSource 3500 card, using Procedure J. 4. If the voltage is 24 V dc ± 2 V dc, measure the current between the antenna connector center pin and the connector housing on the shelf TNC antenna connector. 5. If the current is less than 110 mA or more than 150 mA, replace the TimeSource 3500 card, using Procedure J. If not (nominal current is 125 mA), re-connect the antenna cable to the rear of the shelf. 6. Remove the antenna cable from the antenna, and measure dc voltage and current from the connector center pin to the connector housing on the cable connector. 7. If the readings are 24 V dc and 125 mA, replace the antenna. If not, verify the cable path. Replace cables, lightning suppressor, or IF converter as necessary. 8. If the error repeats, replace the antenna.

Table L. Message Troubleshooting (cont'd)

Message	Meaning	Action
SPAN x AIS	An AIS has been received on the specified input span.	Troubleshoot the specified input span signal (check the source).
SPAN x ERROR	An error has been detected on the specified input span.	Troubleshoot the specified input span signal (include checks for signal frequency and jitter).
SPAN x LOSS OF SIGNAL	The signal on the specified input span has been lost.	Troubleshoot the specified input span signal (check the cable, connections, source).
TEMPERATURE ERROR	A temperature error has been detected on the internal oscillator.	If this occurs momentarily during power-up, none required. If this does not occur during power-up: 1. Check that the ambient air temperature is within the TimeSource 3500 environmental specifications. If not, correct the ambient temperature with heating or air conditioning. 2. If the ambient air temperature is within the TimeSource 3500 environmental specifications, replace the plug-in card.
TS3500 DOWNLOAD REQUIRED	The system software is corrupt or missing.	Download and install the system (TimeSource 3500) software again, using the procedure in the Software Release Document that came with the software.
EVENTS		
BT3 WARMUP	The system is in a power-up state.	Wait for the system to power up (20 min to several hours, depending on antenna placement and view of the sky).

Table L. Message Troubleshooting (cont'd)

Message	Meaning	Action
COM-x USER TIMEOUT LOGOFF	The user was auto logged off.	If COM-x is the port this message was received on, retry logging in. If not, none required.
DISCONNECTED USER LOGOFF	A user was logged off by the system administrator.	None required.
HOLDOVER	All inputs (GPS signal, span inputs) are lost or unacceptable. The system is using the internal oscillator.	None required.
CRITICAL ACO EVENT	The ACO pushbutton has been pressed to deactivate a critical audible alarm.	None required.
DOWNLOAD FAILED	The software download has failed.	Retry the software download.
DOWNLOAD IN PROGRESS	Software is being downloaded.	Wait until the download has been completed.
DOWNLOAD SUCCESSFUL	The software has been downloaded successfully.	None required.
GPS ERROR	The GPS receiver is reporting an error.	None required.
MAJOR ACO EVENT	The ACO pushbutton has been pressed to deactivate a major audible alarm.	None required.
MINOR ACO EVENT	The ACO pushbutton has been pressed to deactivate a minor audible alarm.	None required.
POWER UP RESTART	The system processor has just started up.	None required.

Table L. Message Troubleshooting (cont'd)

Message	Meaning	Action
SETTLING PERIOD	The system is between the power-up state and steady-state operation, and signals may be degraded.	None required.
SOFTWARE DOWNLOADING ON LINK	Software is being downloaded at specified communication port.	None required.
SPAN x AIS	An AIS has been received on the specified input span.	Troubleshoot the specified input span (check the source).
SPAN x ERROR	An error has been detected on the specified input span.	Troubleshoot the specified input span (check the source).
SPAN x LOSS OF SIGNAL	The signal on the specified span input has been lost.	Troubleshoot the specified input span (check the source).
SPAN x SSM QUALITY DUS	Do not use for synchronization.	Troubleshoot the specified input span (check the source).
SPAN x SSM QUALITY ST2	The signal on the specified span input has degraded to an SSM quality level of ST2.	Troubleshoot the specified input span (check the source).
SPAN x SSM QUALITY ST3E	The signal on the specified span input has degraded to an SSM quality level of ST3E.	Troubleshoot the specified input span (check the source).
SPAN x SSM QUALITY ST3	The signal on the specified span input has degraded to an SSM quality level of ST3.	Troubleshoot the specified input span (check the source).
SPAN x SSM QUALITY ST4	The signal on the specified span input has degraded to an SSM quality level of ST4.	Troubleshoot the specified input span (check the source).

Table L. Message Troubleshooting (cont'd)

Message	Meaning	Action
SPAN x SSM QUALITY STU	Do not use for synchronization. The level of synchronization traceability is unknown.	Troubleshoot the specified input span (check the source).
TEMPERATURE ERROR	A temperature error has been detected on the internal oscillator.	Wait until this escalates to a minor alarm, or check that the ambient air temperature is within the TimeSource 3500 environmental specifications. If not, correct the ambient temperature with heating or air conditioning.

Card Replacement


To replace the plug-in card, follow the steps in Procedure J, and refer to Figure 39.

Procedure J. Card Replacement

Step	Procedure
1	Put on an ESD wrist strap.
2	Plug the ESD wrist strap into the ESD jack on of the front panel of the shelf.
On the Faulty Card	
3	Loosen the two retaining screws that secure the plug-in card in the shelf.
4	Pull out on the two latching levers to disconnect the card from the shelf connectors.
5	Pull the card completely out of the shelf.
On the Replacement Card	
6	Pull out the latching levers at each end of the front panel of the card so that the levers are pointing directly out from the front panel of the card.
7	Insert the new card into the tracks at each side of the shelf, and slide the card into the shelf until the latching levers begin to move in.
8	Push the latching levers flat against the front panel of the card to complete the card insertion.
9	Tighten the knurled screw above each latching lever to secure the card in the shelf.
10	Unplug and remove the grounding wrist strap.
11	Reconfigure the system per application requirements.

End of Procedure

Figure 39. Front of Shelf



Repair and Return

When returning defective equipment for factory repair, obtain the following information prior to calling Symmetricom:

- A complete description of the trouble (alarms, equipment behavior, etc.), part number, serial number, issue/revision level, and warranty expiration date.
- If the warranty has expired, a purchase order with “bill to” information.
- A customer field technical contact including address, phone number and FAX number.
- Return shipping information.

To return defective or damaged equipment, use Procedure K.

Procedure K. Equipment Return

Step	Procedure
1	Call your local Symmetricom distributor or Symmetricom's Inside Sales (refer to the Sales subsection), and obtain a Return Material Authorization (RMA) number and shipping address. <i>Note:</i> Retain the RMA number for future reference. The RMA number is used by Symmetricom for internal tracking of the unit. Reference the RMA number in all communications with Symmetricom regarding the unit.
2	Pack the defective equipment, including a list containing all the information obtained above, in the original packing material. If the original packing material is not available, inform Symmetricom, and the appropriate shipping material will be provided. <i>Note:</i> Equipment must be returned in the original packaging, or approved replacement packaging for the warranty to be honored.
3	Mark the RMA number and the equipment serial number on the outside of the shipping carton.
4	Ship the equipment prepaid and insured to one of the addresses below, as directed by the Customer Assistance Center: Symmetricom Attn: Customer Service 2300 Orchard Parkway San Jose, CA 95131 or Symmetricom Attn: Repair and Return P.O. Box 1046 Aguada West Industrial Aguada, Puerto Rico 00602 <i>Note:</i> Repaired equipment is typically shipped within 30 days of receipt by Symmetricom, or per contract terms. Shipping costs to Symmetricom are paid by the customer; shipping costs back to the customer are paid by Symmetricom.

End of Procedure

Technical Assistance

For technical assistance, contact the following:

Symmetricom, Inc.
2300 Orchard Parkway
San Jose, CA 95131-1017

U.S.A. Call Center:
1-888-367-7966 (from inside U.S.A. only – toll-free)
1-408-428-7907
Fax: 1-408-428-7998

Europe, Middle East, and Africa (EMEA) Call Center:
+44 (0) 1189 699 799
Fax: +44 (0) 1189 277 520

E-mail: ctac@symmetricom.com

Internet: <http://www.symmetricom.com>

Sales

For sales assistance, contact the following:

Symmetricom, Inc.
2300 Orchard Parkway
San Jose, CA 95131-1017

U.S.A. Call Center:
1-888-367-7966 (from inside U.S.A. only – toll-free)
1-408-428-7907

Europe, Middle East, and Africa (EMEA) Call Center:
+44 (0) 1189 699 799

Fax: 408-428-7998

E-mail: info@symmetricom.com

Internet: <http://www.symmetricom.com>

Manual Updates

From time to time, this manual may be updated. The updated version of the manual will be available for downloading in electronic form via the Internet. After downloading, the manual can be viewed on a computer or printed out.

Manual updates are available at:

<http://www.symmetricom.com/support/login/login.php>

Note: When going to the preceding Web address, it is necessary to register if you are a new user. If you are a currently registered user, enter your user name and password, and log in.

Specifications

This chapter provides equipment specifications.

Antennas

Roof Antenna

Type:	Active volute antenna, right-hand circular polarized, with proprietary IF interface
Cable Length:	Maximum 1,000 feet from antenna to shelf
Dimensions:	
Height:	11 in.
Diameter:	4.3 in.
Weight:	9 oz
Operating Temperature:	-30 °C to +80 °C
Storage Temperature:	-40 °C to +80 °C
Operating Humidity:	0% to 100% relative humidity

Mechanical Window Antenna

Type:	Patch antenna
Cable Length:	Maximum 1000 ft from antenna to shelf
Dimensions: (antenna, including mechanical mounting device)	
Height:	16 in.
Width:	2.2 in.
Depth:	1.3 in.
Weight:	18 oz

Antennas (cont'd)

Wall Antenna

Type:	Patch antenna
Cable Length:	Maximum 1000 ft from antenna to shelf
Dimensions: (not including mounting and peripheral equipment)	
Height:	0.5 in. (12.5 mm)
Width:	1.5 in. (37 mm)
Depth:	1.8 in. (46 mm)
Weight:	1.1 oz (35 g)

Self-Adhesive Window Antenna

Type:	Patch antenna
Cable Length:	Maximum 1000 ft from antenna to shelf
Dimensions:	
Length:	4 in.
Width:	3 in.
Height:	1.5 in.
Weight:	5.3 oz

Communication Ports

Port 1

Connector Type:	25-pin, female D connector
Connector Label:	COM1
Connector Location:	Rear panel
Electrical Interface:	RS-232 (DTE equivalent)
Pin that transmits data:	2
Pin that receives data:	3
Baud Rate:	1200 b/s 2400 b/s 4800 b/s 9600 b/s (factory default) 19.2 kb/s 38.4 kb/s 57.6 kb/s 115 kb/s
Data Bits:	8
Parity Bit:	None Even Odd
Stop Bits:	1 2
Flow Control:	None Software (XON/XOFF) Hardware (CTS/RTS)

Communication Ports (cont'd)

Port 2

Connector Type:	RJ-45
Connector Label:	COM2
Connector Location:	Rear panel
Electrical Interface:	RS-232 (DCE equivalent)
Pin that transmits data:	3
Pin that receives data:	2
Baud Rate:	1200 b/s 2400 b/s 4800 b/s 9600 b/s (factory default) 19.2 kb/s 38.4 kb/s 57.6 kb/s 115 kb/s
Data Bits:	8
Parity Bit:	None Even Odd
Stop Bits:	1 2
Flow Control:	None Software (XON/XOFF) Hardware (CTS/RTS)

Communication Ports (cont'd)

Craft Port

Connector Type:	RJ-45
Connector Label:	Craft
Connector Location:	Front panel
Electrical Interface:	RS-232 (DTE equivalent)
Pin that transmits data:	2
Pin that receives data:	3
Baud Rate:	1200 b/s 2400 b/s 4800 b/s 9600 b/s (factory default) 19.2 kb/s 38.4 kb/s 57.6 kb/s 115 kb/s
Data Bits:	8
Parity Bit:	None Even Odd
Stop Bits:	1 2
Flow Control:	None

Ethernet Port


Connector Type:	RJ-45 (10Base-T)
Connector Label:	Ethernet
Connector Location:	Rear panel
Electrical Interface:	10Base-T Ethernet
Data Rate:	10Mb/s
Protocol:	TCP/IP (interface)
Setup Language:	TL1 (application layer)

Time of Day Outputs

Network Time Protocol (NTP), Type 4, Format 2 Driver Format

Connector Type:	RJ-45
Connector Label:	TOD
Connector Location:	Rear panel
Electrical Interface:	RS-485
Baud Rate:	9600 b/s
Data Bits:	8
Parity Bit:	None
Stop Bit:	1
Data Format:	See Figure 40


Figure 40. NTP Type 4 Data Format



- 1 Alarm field: blank space = receiver has satellite availability; ? = no satellite available
- 2 Year (2000 in this example)
- 3 Day of year (the 225th day of the year in this example)
- 4 Hours:minutes:seconds:milliseconds
- 5 Leap second: blank space = no leap second; L = upcoming leap second
- 6 Daylight savings time indicator: S = standard time; D = daylight savings time

Connector Type:	RJ-45
Connector Label:	TOD
Connector Location:	Rear panel
Electrical Interface:	RS-485
Baud Rate:	9600 b/s
Bit Configuration:	8 data bits, No parity, 1 stop bit
Data Format:	See Figure 41

Example:



- 1 Satellite availability: * = valid, ! = not valid
- 2 Revision
- 3 Modified Julian date (number of days past midnight, Nov 17, 1858)
- 4 Year/month/day
- 5 Hours:minutes:seconds
- 6 Indicator of time zone offset (+, -, or 0)
- 7 Time zone offset
- 8 Leap second indicator
- 9 Latitude
- 10 Longitude
- 11 Altitude above mean sea level in meters
- 12 Alarm severity: EV = event, MN = minor, MJ = major, CL = critical
- 13 Alarm source
- 14 Alarm cause: holdover, BT3 warm-up, or hardware fault

Time of Day Outputs (cont'd)

IRIG-B TOD Outputs (990-72050-05 System Only)

Connector Type:	BNC
Connector Labels:	OUT1 OUT2
Connector Location:	OPTION I/O wire-wrap pins on rear panel and output module
Impedance:	600 Ω
Number of Outputs:	2
Type of Output:	Amplitude modulated
Amplitude:	6 V peak-to-peak maximum terminated with 600 Ω
Time Format:	
Binary Coded Decimal (BCD):	Seconds: 0 – 59 Minutes: 0 – 59 Hours: 0 – 23 Days: 0 – 364 Years: 0 – 99
Non BCD:	Seconds of day: 0 – 86399

T1 Inputs

6

Connector Type:	Wire-wrap pins
Connector Label (2 sets):	T R S
Connector Location:	Rear panel
Impedance:	120 Ω $\pm$ 5% balanced
Bit Rate:	1.544 Mb/s
Format:	DS1
Line Code:	Alternate mark inversion (AMI) with or without B8ZS
SSM State:	Enable Disable
Amplitude:	0 to -26 dB DSX
Framing:	ESF D4

1 PPS Output

Connector Type:	BNC
Connector Label:	TTL PPS
Connector Location:	Rear panel
Impedance:	50 Ω
Frequency:	1 pps
Amplitude:	Transistor-transistor logic (TTL) levels
Time Accuracy:	100 ns with respect to Universal Coordinated Time (UTC) when locked to GPS signal
GPS Holdover Time Error:	3 μ s for 72 h (0 °C to +50 °C $\pm$ 5 °C) after one week of steady-state operation
Format:	Logic low with logic high pulse of 1 μ s
Rise Time:	Less than 20 ns

T1 Outputs

Standard

Connector Type:	Wire-wrap pins
Connector Label:	T1 OUT A (T, R, S) T1 OUT B (T, R, S)
Connector Location:	Rear panel
Impedance:	120 Ω
Bit Rate:	1.544 Mb/s
Frequency Accuracy:	1×10^{-12}
GPS Holdover Stability:	1×10^{-11} for 72 h (0 °C to +50 °C $\pm$ 5 °C) after one week of steady-state operation 1×10^{-10} for 30 days after one week of steady-state operation
Format:	DS1, framed all 1s
Line Code:	Alternate mark inversion (AMI)
Amplitude:	2.4 V to 3.6 V terminated with 100 Ω
Framing:	ESF D4
Output During Alarms:	AIS Squelch SSM Forced

T1 Outputs (cont'd)

Additional T1 Outputs (990-72050-02 System Only)

Connector Type:	Wire-wrap pins
Connector Label:	1 (T, R, S) 2 (T, R, S) 3 (T, R, S) 4 (T, R, S) 5 (T, R, S) 6 (T, R, S) 7 (T, R, S) 8 (T, R, S)
Connector Location:	OPTION I/O wire-wrap pins on rear panel
Impedance:	120 Ω
Bit Rate:	1.544 Mb/s
Frequency Accuracy:	1×10^{-12}
GPS Holdover Stability:	1×10^{-11} for 72 h (0 °C to +50 °C $\pm$ 5 °C) after one week of steady-state operation 1×10^{-10} for 30 days after one week of steady-state operation
Format:	DS1, framed all 1s
Line Code:	Alternate mark inversion (AMI)
Amplitude:	2.4 V to 3.6 V terminated with 120 Ω

T1 Outputs (cont'd)

Additional T1 Outputs (cont'd) (990-72050-02 System Only)

Framing:	ESF D4
Output During Alarms:	AIS Squelch SSM Forced

Mixed E1/T1 Outputs

Note: For E1/T1 commonality, refer to the E1/T1 Common specifications. For E1, refer to the E1 Outputs specifications. For T1, refer to the T1 Outputs specifications.

E1/T1 Common

Connector Type:	Wire-wrap
Connector Label:	T, R, S
Connector Location:	OPTION I/O wire-wrap pins on rear panel
Frequency Accuracy:	1×10^{-12}
Output During Alarms:	AIS, Squelch, SSM, Forced

E1 Outputs

Impedance:	120 Ω balanced or 75 Ω unbalanced
Bit Rate:	2.048 Mb/s
Format:	Framed all 1s
Line Code:	HDB3
Amplitude:	3.0 V nominal terminated with 120 Ω balanced
Framing:	CAS, CAS4, CCS, CCS4

Mixed E1/T1 Outputs (Optional) (cont'd)

E1 Outputs (cont'd)

GPS Holdover Stability:	1×10^{-11} for 72 h (0 °C to +50 °C $\pm$ 5 °C) after one week of steady-state operation
	1×10^{-10} for 30 days after one week of steady-state operation

T1 Outputs

Impedance:	100 Ω
Bit Rate:	1.544 Mb/s
Format:	DS1, framed all 1s
Line Code:	Alternate mark inversion (AMI)
Amplitude:	2.4 V to 3.6 V terminated with 100 Ω
Framing:	ESF, D4
GPS Holdover Stability: (after one week of steady-state operation)	1×10^{-10} per day
	3.2×10^{-11} per day with span input meeting ANSI T1.101 network specification 99% probability (rubidium)
	1×10^{-11} per day over a 10 °C range between 0 °C and +50 °C with an ST2E remote oscillator input (quartz)

Mixed T1/CCK Outputs (990-72050-07 System Only)

Note: For T1/CCK commonality, refer to the T1/CCK Common specifications. For T1, refer to the T1 Outputs specifications. For CCK, refer to the CCK Outputs specifications.

T1/CCK Common

Connector Type:	Wire-wrap
Connector Label:	T, R, S
Connector Location:	OPTION I/O wire-wrap pins on rear panel

T1 Outputs

Impedance:	100 Ω
Bit Rate:	1.544 Mb/s
Format:	DS1, framed all 1s
Line Code:	Alternate mark inversion (AMI)
Amplitude:	2.4 V to 3.6 V terminated with 100 Ω
Framing:	ESF, D4
GPS Holdover Stability: (after one week of steady-state operation)	1×10^{-10} per day 3.2×10^{-11} per day with span input meeting ANSI T1.101 network specification 99% probability (rubidium) 1×10^{-11} per day over a 10 °C range between 0 °C and +50 °C with an ST2E remote oscillator input (quartz)

Mixed T1/CCK Outputs (990-72050-07 System Only) (cont'd)

6

CCK Outputs

Impedance:	135 Ω balanced
Bit Rate:	64 kb/s
Waveform:	2.7 V to 5.5 peak, 3 V nominal; bipolar RTZ; all ones with BPV every eight pulse
Wave Shape:	Rectangular, rise time <500 ns, pulse width 9.8 μ s $\pm$ 5%, pulse interval 15.6 μ s $\pm$ 5%
Duty Cycle:	62.5%

Composite Clock Outputs (990-72050-03 System Only)

Connector Type:	Wire-wrap pins
Connector Label:	1 (T, R, S) 2 (T, R, S) 3 (T, R, S) 4 (T, R, S) 5 (T, R, S) 6 (T, R, S) 7 (T, R, S) 8 (T, R, S)
Connector Location:	OPTION I/O wire-wrap pins on rear panel
Impedance:	135 Ω balanced
Bit Rate:	64 kb/s
Waveform:	2.7 V to 3.5 peak, 3 V nominal; bipolar RTZ; all ones with BPV every eight pulse
Wave Shape:	Rectangular, rise time <500 ns, pulse width 9.8 μ s $\pm$ 5%, pulse interval 15.6 μ s $\pm$ 5%
Duty Cycle:	62.5%

10 MHz Output

Connector Type:	BNC
Connector Label:	10 MHz
Connector Location:	Rear panel
Impedance:	50 Ω
Frequency:	10 MHz
Stability:	5×10^{-12} Root Allen Variance (RAV) at 10 s
Phase Noise:	-110 dBc @ 10 Hz -135 dBc @ 100 Hz -140 dBc @ 1 kHz -145 dBc @ 10 kHz
Harmonic Distortion:	-40 dBc
Spurious Distortion:	-70 dBc
Format:	Sine wave
Amplitude:	1 V peak-to-peak minimum, 50 Ω termination 3.7 V peak-to-peak typical, 50 Ω termination

Office Alarms

Rear Panel Contacts

Connection:	Wire-wrap pins
Type:	Dry contact
Contact Rating:	1 A @ 30 V dc 0.5 A @ 60 V dc 0.5 A @ 125 V ac
Severity:	Critical Major Minor
State:	Normally open and normally closed
Style:	Audible and visible

Front Panel Lamps

Label:	Alarms (CRIT, MAJ, MIN, ACO) Status (GPS, SYS)
Type:	Light emitting diode

Front Panel Control

Label:	ACO
Type:	Push-button switch
Function:	Alarm cutoff (deactivates audible office alarms)

Simple Network Time Protocol

Protocol Type:	SNTP (Simple Network Time Protocol) compliant with RFC-1769 for unicast applications
SNTP Accuracy:	SNTP timestamp derived from UTC time via integrated GPS receiver within –300 microseconds
SNTP Alarm Indications:	1. SNTP packet will indicate Stratum 2 in NTP packet header if GPS is out of lock. 2. The “ref id” field changes from GPS to at Stratum 1 to the IP address at Stratum 2 to signify that the reference is the TimeSource clock itself. 3. SNTP packet will indicate “clock not synchronized” in LI field as a “3” value after user defined alarm integration time.
Password Activated:	Contact factory

Power

Connector Type:	Terminal block
Connector Labels:	TB1 TB2
Voltage:	–40 V dc to –72 V dc (A & B feed)
Current:	750 mA maximum
Steady-State Power	30 W maximum
Recommended Fuse for Battery Feed:	3 A

Shelf Mechanical

Rack Mounting:	NEBS 19 in. rack NEBS 23 in. rack
Mounting Positions:	Flush 5 in. offset
Width:	19 in.
Height:	3.5 in. maximum (2 rack mounting units)
Depth:	12 in. maximum
Weight:	13 lb.

Shelf Environmental

Operating Temperature:	0 °C to +50 °C
Operating Humidity:	Up to 95% non condensing
Electromagnetic:	FCC Part 15, Sub-Part B, Class A
Safety	UL compliant NEBS compliant

This page intentionally left blank.

Index



Symbols

"Bridging" mode 38
"BT3 Warmup" event 37
"Holdover" event 38, 39
"Holdover" event/alarm 39
"Holdover" mode 38
"Power Up Restart" event 37
"Settling Period" event 37

Numerics

1 PPS Output specifications 258
10 MHz Output specifications 267

A

Activate User 152, 155
Alarm All, Retrieve 153, 186
Alarm Cutoff All, Operate 153, 185
Alarm Equipment, Retrieve 153, 187, 188
Algorithm, BesTime 26
Antenna types 20
Antenna, mechanical 20
Antenna, mechanical window 23, 28
Antenna, roof 20, 22, 28, 122
Antenna, self-adhesive window 20, 24, 28
Antenna, wall 20, 25, 28
Antennas, GPS 19
Application, TimeWizard 132
Application, TimeWizard Software Installation 132
Applications, TimeSource 3500 18

B

BesTime algorithm 26
BesTime Ensemble Timing Generator 26, 32, 33

C

Cancel User 152, 156
CCK Outputs 265
Cisco Systems specifications 255
Communication port 1 specifications 250
Communication port 2 specifications 251

.
Communication, Edit 152, 162, 163, 164, 165
Communication, Retrieve 190
Communication, Retrieve 153, 189, 191
Communications, Edit 127, 129
Composite Clock Outputs specifications 266
Condition All, Retrieve 153, 192
Condition Equipment, Retrieve 153, 193, 194
Copy Memory 131, 152, 157, 158, 159
Craft port specifications 252
CRIT lamp 37

D

Date, Edit 123, 124, 152, 166, 167
Delete Equipment 152, 160
Delete User Security 152, 161
Device, strike termination 29
Device, strike termination, lower 29
Devices, strike termination 29

E

E1/T1 Outputs, Mixed 32, 62, 105, 262
Edit Communication 152, 162, 163, 164, 165
Edit Communications 127, 129
Edit Date 123, 124, 152, 166, 167
Edit Equipment 122, 125, 126, 128, 130, 152, 169, 170, 173, 174
Element Manager 35, 128
Enter Equipment 124, 152, 179, 180
Enter User Security 152, 181
Equipment, Delete 152, 160
Equipment, Edit 122, 125, 126, 128, 130, 152, 169, 170, 173, 174
Equipment, Enter 124, 152, 179, 180
Equipment, Retrieve 124, 153, 195, 196, 197, 198, 199
Error message troubleshooting 233
Ethernet port specifications 253
Event, "BT3 Warmup" 37
Event, "Holdover" 38, 39
Event, "Power Up Restart" 37
Event, "Settling Period" 37
Event/alarm, "Holdover" 39

F

Feature, Network Time Protocol (NTP) 31
Feature, NTP 31
Feature, Passthrough 35
Frame ground with ground rod 102
Frame ground without ground rod 102
Front panel items troubleshooting 230, 231

G

Generator, BesTime Ensemble Timing 26, 32, 33
GPS antennas 19
GPS navigation system 19
GPS signals 18
GPS Status, Retrieve 153, 205, 206
Ground rod, frame ground with 102
Ground rod, frame ground without 102

I

Initialize Log 152
Initialize Register 125, 152, 183
Initialize System 153, 184
Installation, mechanical window antenna 73, 89
Installation, roof antenna 72
Installation, self-adhesive window antenna 74, 92
Installation, TimeSource 3500 shelf 76
Installation, wall antenna 75
Intialize Log 182
Inventory, Retrieve 153, 207, 208
IRIG-B TOD Outputs specifications 256

K

Kit, lightning protector 30
Kit, mechanical window antenna 68
Kit, roof antenna 67
Kit, self-adhesive window antenna 69
Kit, wall antenna 70

L

Lamp, CRIT 37
Lightning protector kit 30

Location, roof antenna 44
Location, window or wall antenna 52
Log, Initialize 152, 182
Log, Retrieve 153
Lower strike termination device 29

M

Manager, Element 35, 128
Mechanical antenna 20
Mechanical window antenna 23, 28
Mechanical window antenna installation 73, 89
Mechanical window antenna installation procedures 87
Mechanical window antenna kit 68
Mechanical window antenna specifications 248
Memory, Copy 131, 152, 157, 158, 159
Mixed E1/T1 Outputs 32, 62, 105, 262
Mixed E1/T1 Outputs specifications 262
Mixed T1/CCK Outputs 32, 63, 106, 264
Mode, "Bridging" 38
Mode, "Holdover" 38

N

Navigation system, GPS 19
Network Time Protocol (NTP) feature 31
Network Time Protocol specifications 254
NTP feature 31

O

Office Alarms specifications 268
Operate Alarm Cutoff All 153, 185
Outputs, CCK 265
Outputs, Mixed E1/T1 32, 105, 262
Outputs, Mixed E1/T1 Outputs 62
Outputs, Mixed T1/CCK 32, 63, 106, 264
Outputs, synchronization 18
Outputs, T1 264

P

Passthrough feature 35
Performance Monitoring, Retrieve 153, 211-226

Power specifications 270
Procedure 95
Procedure, RS-422-to-RS-232 converter installation 111
Procedures, mechanical window antenna installation 87
Procedures, roof antenna installation 81, 83
Procedures, self-adhesive window antenna installation 91
Procedures, wall antenna installation 94
Protection, zone of 28, 29, 30
Protocol, Simple Network Time 269

R

Register, Initialize 125, 152, 183
Retrieve Alarm All 153, 186
Retrieve Alarm Equipment 153, 187, 188
Retrieve Communication 153, 189, 190, 191
Retrieve Condition All 153, 192
Retrieve Condition Equipment 153, 193, 194
Retrieve Equipment 124, 153, 195, 196, 197, 198, 199
Retrieve GPS Status 153, 205, 206
Retrieve Inventory 153, 207, 208
Retrieve Log 153
Retrieve Performance Monitoring 153, 211, 212-226
Retrieve User Security 153, 227
RJ-422-to-RJ-232 TOD Converter Kit 57
Roof antenna 20, 22, 28, 122
Roof antenna installation 72
Roof antenna installation procedures 81, 83
Roof antenna kit 67
Roof antenna location 44
Roof antenna specifications 248
RS-422-to-RS-232 converter installation procedure 111

S

Self-adhesive window antenna 20, 24, 28
Self-adhesive window antenna installation 74, 92
Self-adhesive window antenna installation procedures 91
Self-adhesive window antenna kit 69
Self-adhesive window antenna specifications 249
Set Source Identifier 153, 228
Shelf Environmental specifications 271

Shelf Mechanical specifications 270
Shelf, TimeSource 3500 20, 58
Signals, GPS 18
Simple Network Time Protocol 269
Simple Network Time Protocol specifications, Specifications, Simple Network Time Protocol 269
Site survey 42
Source Identifier, Set 153, 228
Specifications, 1 PPS Output 258
Specifications, 10 MHz Output 267
Specifications, Cisco Systems 255
Specifications, communication port 1 250
Specifications, communication port 2 251
Specifications, Composite Clock Outputs 266
Specifications, Craft port 252
Specifications, Ethernet port 253
Specifications, IRIG-B TOD Outputs 256
Specifications, mechanical window antenna 248
Specifications, Mixed E1/T1 Outputs 262
Specifications, Network Time Protocol 254
Specifications, Office Alarms 268
Specifications, power 270
Specifications, roof antenna 248
Specifications, self-adhesive window antenna 249
Specifications, Shelf Environmental 271
Specifications, Shelf Mechanical 270
Specifications, T1 Inputs 257
Specifications, T1 Outputs 259
Specifications, wall antenna 249
Standard for the Installation of Lightning Protection Systems (NFPA 780) 28
Strike termination device 29
Strike termination devices 29
Survey, site 42
Synchronization outputs 18
System, Initialize 153, 184

T

T1 Inputs specifications 257
T1 Outputs 264
T1 Outputs specifications 259

TimeServer 31
TimeSource 3500 applications 18
TimeSource 3500 shelf 20, 58
TimeSource 3500 shelf installation 76
TimeWizard application 132
TimeWizard Software Installation application 132
TOD Converter Kit, RJ-422-to-RJ-232 57
Troubleshooting, error message 233
Troubleshooting, front panel items 230, 231
Types, antenna 20

U

User Security, Delete 152, 161
User Security, Enter 152, 181
User Security, Retrieve 153, 227
User, Activate 152, 155
User, Cancel 152, 156

W

Wall antenna 20, 25, 28
Wall antenna installation 75
wall antenna installation 95
Wall antenna installation procedure 95
Wall antenna installation procedures 94
Wall antenna kit 70
Wall antenna specifications 249
Window or wall antenna location 52

Z

Zone of protection 28, 29, 30