

6520A RF Distribution



*Excerpted from
Document #
14508-201 Rev A*

Operating Manual

6520A Telecom Distribution



datum

Timing, Test & Measurement



Copyright Notice

COPYRIGHT 2001 DATUM - TT&M ALL RIGHTS RESERVED

This manual is provided to assist the user in the operation and maintenance of the supplied equipment or software. It is recognized that multiple copies may be required to support even a single unit, and for this reason, permission is hereby granted to reproduce the supplied User's Guide for the purpose stated above, provided that this notice is included as part of the copy. Additional copies are also available from Datum - TT&M for a nominal fee.

In no case, however, does the supply of this manual or the granting of rights to reproduce the manual, grant any rights to use information contained within to reproduce the supplied equipment or software, either in whole or in part.

The equipment or software described in this manual have been developed solely at the expense of Datum - TT&M and are proprietary. No unlimited rights in technical data are granted. Limited rights as per DFARS 252.227-7013 shall be effective for 10 years from the copyright date.



6520A RF Distribution

CHAPTER ONE

Introduction/Product Overview	3
-------------------------------	---

CHAPTER TWO

Installation	7
--------------	---

CHAPTER THREE

Operation	11
-----------	----

CHAPTER FOUR

Specifications	12
----------------	----



Chapter One

.....

INTRODUCTION/PRODUCT OVERVIEW

This Operating Manual contains procedures and descriptive information for proper installation and operation of the Datum 6520A Telecom Distribution module.

The Datum 6520A Telecom Distribution module takes a single telecom clock signal (either T1 or E1) from a frequency source, like a cesium frequency standard, and provides additional buffered outputs, twelve per module. This manual contains the information needed to install, configure and use the Datum 6520A.

OPERATING MANUAL SUMMARY

This Operating Manual is divided into the following chapters:

A. CHAPTER ONE – INTRODUCTION/PRODUCT OVERVIEW

This chapter includes a general description of the Datum 6520A and provides some basic product information.

B. CHAPTER TWO – INSTALLATION

Provides initial inspection and installation information.

C. CHAPTER THREE - OPERATION

Provides information on the use of the switches and the indicators.

D. CHAPTER FOUR – SPECIFICATIONS

Provides detailed specifications for the Datum 6520A.

PURPOSE OF EQUIPMENT

The Datum 6520A Telecom Distribution uses Datum's high performance distribution technology created for its line of cesium standards. The 1U (1.75" high) chassis houses a set of very low noise and high isolation RF amplifiers. Up to four Datum 6520A Telecom Distribution chassis may be daisy chained to provide up to 48 independently buffered outputs of the common input. The level of the input signal and all ten output signals are monitored, providing a visual indicator of signal presence as well as a summary fault (form-C relay) for each module.

A complete list of performance characteristics is provided in Chapter Four.



INSTRUMENT IDENTIFICATION

The model number 6520A may be followed by a slash (/) and a three-digit number to indicate an option that is supplied within the instrument.

PREPARATION FOR SHIPMENT

To turn off the Datum 6520A prior to shipment, remove the AC power from the plug on the rear panel. Package the instrument in its original packing if possible. If the original packing materials are not available, pack in a reinforced cardboard carton using foam to take up any space inside the carton. Do not use foam popcorn or crushed paper for packing.

If the instrument is being returned to Datum, contact the Service Department at 1-800-938-9888 to advise of the product return.

TYPOGRAPHICAL AND OTHER CONVENTIONS

This Operating Manual uses the following conventions:

Acronyms and Abbreviations – Terms are spelled out the first time they appear in this Operating Manual. Thereafter, only the acronym or abbreviation is used. In addition, the glossary defines the acronyms and abbreviations.

Revision Control – The title page lists the printing date and part number of this Operating Manual. Table 1-1 describes the typographical conventions that this Operating Manual uses to distinguish between the different types of information according to how they are used.

TABLE 1-1. TYPOGRAPHICAL CONVENTIONS

WHEN TEXT APPEARS THIS WAY...	IT MEANS...
<i>Datum 6520A Operating Manual</i>	The title of a document or the name of a product
Critical Port-1 J1	An operating mode, alarm state, status, or chassis label.
Press the Enter key. Press the Print Scm key.	A named keyboard key. The key name is shown as it appears on the keyboard. An explanation of the key's acronym or function immediately follows the first reference to the key, if required.
<i>A re-timing</i> application ...	A term or a word being emphasized.
Datum does not recommend ...	A word or term given special emphasis so that you do not miss the idea being presented.



WARNINGS, CAUTIONS, RECOMMENDATIONS, AND NOTES

Warnings, Cautions, Recommendations, and Notes attract attention to essential or critical information in this Operating Manual. The types of information included in each are explained as follows:



WARNING ...

All warnings have this symbol. Do not disregard warnings. They are installation, operation, or maintenance procedures, practices, or statements that if not strictly observed, may result in personal injury or loss of life.



ELECTRICAL SHOCK HAZARD ...

All electrical shock hazard warnings have this symbol. To avoid serious personal injury or death, do not disregard electrical shock hazard warnings. They are installation, operation, or maintenance procedures, practices, or statements that if not strictly observed, may result in personal injury or loss of life.



CAUTION ...

All cautions have this symbol. Do not disregard cautions. They are installation, operation, or maintenance procedures, practices, conditions, or statements that if not strictly observed, may result in damage to or destruction of equipment or may cause a long-term health hazard.



CAUTION ...

All Electrostatic Discharge (ESD) cautions have this symbol. They are installation, operation, or maintenance procedures, practices, conditions, or statements that if not strictly observed, may result in electrostatic discharge damage to, or destruction of, static sensitive components of the equipment.



RECOMMENDATION ...

All recommendations have this symbol. Recommendations indicate manufacturer-tested methods or known functionality. They contain installation, operation, or maintenance procedures, practices, conditions, or statements that provide you with important information for optimum performance results.



NOTE ...

All notes have this symbol. Notes contain installation, operation, or maintenance procedures, practices, conditions, or statements that alert you to important information which may make your task easier or increase your understanding.



WHERE TO FIND ANSWERS TO PRODUCT AND DOCUMENT QUESTIONS

If you believe that this product is not performing as expected, or if you have comments about this Operating Manual, please contact your Datum representative or sales office

We appreciate your suggestions on ways to improve this Operating Manual. Please mark or write your suggestions on a copy of the page and mail or fax it to ...

Datum – Timing, Test & Measurement
34 Tozer Road
Beverly, MA 01915-5510
US Toll Free: 1-800-544-0233
Phone: +1-978-927-8220
Fax: +1-978-927-4099
E-mail: ttmsales@datum.com

Thank you for providing the information.



NOTE ...

Datum offers a number of applicable training courses designed to enhance product usability. Contact your Datum representative or sales office for a complete list of courses and outlines.



Chapter Two

INSTALLATION


MOUNTING

The Datum 6520A is designed to be mounted in a standard 19-inch equipment rack and take up 1 U of vertical space (1.75"). The chassis depth is 10 inches.

POWER CONNECTION/FUSES/VOLTAGE SELECTION

The Datum 6520A is powered from an AC source by a detachable power supply cord. The power cord is the disconnect device. Refer to Chapter Four for power supply requirements. The AC fuses are located inside the AC connector/filter. The hot and neutral lines are fused separately. To change fuses, refer to Figure 2-1. Open the cover on the AC connector/filter by applying a screwdriver to the cover slot. Once the cover is open, each fuse holder may be removed for inspection or replacement. Replace only with a 0.2A, 250V fuse as specified in Chapter Four.

FIGURE 2-1. AC INPUT FILTER/FUSES/VOLTAGE SELECTOR





The Datum 6520A may be powered from 120 or 240 VAC. To change the AC input between 120 and 240 VAC, refer to Figure 2-1. Open the cover on the AC input connector by applying a screwdriver to the cover slot. Once the cover is open, a selector switch may be rolled left or right to line up "120" or "240" with the small window in the connector cover. Replace the AC input connector cover by snapping in place.




CAUTION ...

Do not use the voltages labeled "100" or "230", as they are not connected.

DC POWER CONNECTION

The Datum 6520A (DC version) is powered from a DC source. The connections are made at TB1 as shown in Figure 2-2. The voltage input may be 20 V to 75 V.

FIGURE 2-2. DC POWER CONNECTION




SIGNAL CONNECTIONS

Connect the signal to be distributed to one of the two D connectors labeled INPUT. Set the impedance switch to 50Ω (down) if only one 6520A module is to be used. If multiple 6520A modules are used to obtain more than twelve outputs, see Figure 2-4.

Output cables may be connected in any order to the D connectors labeled 1 to 12. Refer to Figure 2-3.

FIGURE 2-3. SIGNAL CONNECTIONS





With the 6520A powered, the green power indicator on the front panel will illuminate. The red indicator next to the input signal is off to show that there is a good input signal.


CONNECTOR PIN ASSIGNMENTS

The input connectors and all output connectors all have same pins used for signal: Pins 2 and 6. The signal inputs and outputs are balanced, so there is no assignment of polarity.

DAISY-CHAINING MORE THAN ONE MODULE

If more than twelve outputs are required, up to four Datum 6520A modules can be driven by a common input signal to produce up to 48 outputs. Figure 2-4 illustrates this connection.

FIGURE 2-4. DAISY-CHAINING MULTIPLE MODULES



The example in Figure 2-4 shows three units. The original signal from the source is connected to the top IN connector on the right side of the first module. The lower IN connector on the first module is connected to the top IN connector on the second module. The second module is connected to the third module in the same fashion. The impedance switch for the first and second chassis is set to HI Z, while the impedance switch on the third (or last) chassis in the daisy chain is set to 50Ω.



ALARM CONNECTIONS

The Datum 6520A provides for an alarm to signal the failure of any signal output. One set of form-C relay contacts is provided on the 9-pin D connector labeled ALARMS. For normal operation, pins 1 to 2 are open and pins 1 to 3 are closed. The sense is reversed for a fault condition. Refer to Figure 2-5.

FIGURE 2-5. ALARM CONTACTS



Relay shown in non-faulted condition

If the input signal or input buffer fails or falls below the factory-set low-level threshold, the red fault indicator next to the input connector will turn on. Likewise, if any output buffer fails or falls below the low-level threshold, a red fault indicator next to that output will turn on. The ALARM form-C relay is normally energized, indicating no signal failure. If either the input or any output signal fails, the relay is deenergized (short between pins 1 and 2), indicating a fault condition. This is a failsafe design that will indicate a fault in the event of a power loss.

Chapter Three

OPERATION

The Datum 6520A Telecom Distribution module controls and indicators are described in this chapter.

FIGURE 3-1. 6520A TELECOM DISTRIBUTION FRONT PANEL



FIGURE 3-2. 6520A TELECOM DISTRIBUTION REAR PANEL



HI Z/50Ω – This slide switch on the rear panel selects either the HI Z input impedance (unterminated) or the 50Ω input impedance. When installing two or more (four maximum) units, set the switch to HI Z position on the module connected to the source of the signal, and on all subsequent modules except the last module, set this switch to the 50Ω position, so as to provide proper termination for the signal.

POWER – LED on the front panel to indicate that power is applied. There is no power switch on the 6520A. When power is connected, power is ON.

ALARM – LED on the front panel to indicate that an ALARM condition exists. An alarm condition exists when the input signal or any output signal fails or falls below the factory preset amplitude.

INPUT FAULT – LED on the rear panel, just to the right of the lower INPUT connector. If the input signal fails or falls below the factory preset amplitude, this LED will light and stay on until the cause of the fault is remedied.

OUTPUT FAULT – There are twelve LED indicators, located adjacent to the output connectors. By observing Figure 3-2 it can be seen that there are two LED indicators just to the right of each even numbered output connector. The upper LED relates to the odd numbered output connector above, and the lower LED relates to the even numbered output connector. If any output signal fails or falls below the factory preset amplitude, the LED associated with the failed output will light and stay on until the cause of the fault is remedied.



Chapter Four

.....

SPECIFICATIONS



NOTE ...

All performance is at an ambient temperature of 25°C unless otherwise specified.

RF INPUT

Frequency	T1 (1.544 MHz) or E1 (2.048 MHz) per G706/10 or G706/13
Input Impedance	110 Ω (T1) or 120 Ω (E1)

RF OUTPUTS (12)

Frequency	T1 (1.544 MHz) or E1 (2.048 MHz)
Level	per G706/10 or G706/13
Isolation	> 60 dB
Connector	DB9

ADDITIVE SSB PHASE NOISE (1 HZ BW)

Offset from Carrier	
1 Hz	-120 dB
10 Hz	-135 dB
100 Hz	-145 dB
1,000 Hz	-155 dB
10,000 Hz	-160 dB

POWER

Operating Voltage	120/240 VAC, $\pm 15\%$
Power	< 10 W
DC Input (Optional)	22 to 56 VDC, 10W
Fuses (AC Input)	0.2 A, 250 V, fast acting, 5x20 mm (e.g., Littlefuse P/N 239.200)

MECHANICAL

Height	1.75" (1 U)
Width	19" (including rack mount ears)
Depth	10"



ENVIRONMENT

Operating Temperature	0 to 50°C
Relative Humidity	0 to 95%, non-condensing

ALARM INDICATION

Summary alarm indicates failure of any output signal.

Front Panel	Red LED	
Relay	Energized (short pins 1 & 3):	No failure
	Deenergized (short pins 1 & 2):	Failure

CONTROLS AND INDICATORS

POWER	Green LED indicates power is connected
ALARM	Red LED indicates a signal output failure



Addendum

The Datum 6520A Telecom Distribution module is now available with RJ45 connectors for all input and output signal connections. The ALARM connector is not changed. Figures 1 and 2 shown below illustrate the front and rear panels of this new configuration. Figure 3 shows the pin locations of the RJ45 connector.

FIGURE 1. 6520A TELECOM DISTRIBUTION FRONT PANEL



FIGURE 2. 6520A TELECOM DISTRIBUTION REAR PANEL





FIGURE 3. RJ45 CONNECTORS (VIEWED FROM REAR OF CHASSIS)



Input Connectors

Pin No	Value
3	Input Signal
6	Input Signal
1,2,4,5,7,8	NC

Output Connectors

Pin No	Value
1	Output Signal
2	Output Signal
3,4,5,6,7,8	NC

Except for the information given above, all other aspects of this configuration of the Datum 6520A are the same as provided in the basic operating manual.

Limited Warranty

DATUM - TT&M guarantees its products to be free from defects in material and workmanship for a period of one year from the date of shipment. Datum - TT&M shall, at its option, either repair or replace hardware products which prove to be defective.

DATUM - TT&M software and firmware products designed to be used and installed in Datum - TT&M hardware products are warranted not to fail to execute their programming instructions due to defects in material or workmanship. If Datum - TT&M receives notice of such defects during the warranty period, Datum - TT&M will repair or replace software media and firmware which do not execute their programming instructions due to such defects. Datum - TT&M does not warrant that operation of the software, firmware or hardware shall be uninterrupted or error free.

All warranty service will be carried out at the Datum - TT&M – TT&M facilities at 34 Tozer Rd, Beverly, MA 01915. The purchaser shall prepay shipping charges and shall pay all duties and taxes for products returned for warranty service. Datum - TT&M will pay for the return of products to the purchaser except for products returned from another country.

LIMITATION OF WARRANTY: The above warranty does not apply to defects of, or resulting from the following:

1. End items included as part of a system or product selected by, but not designed by, Datum - TT&M are subject only to warranty as may be obtained from the original manufacturers. Such items include, but are not limited to, test equipment, accessories, batteries, computers, printers, software, etc.
2. Items manufactured by Datum - TT&M pursuant to detailed designs furnished by purchaser or specific components, accessories, support equipment and software specified by purchaser.
3. Improper or inadequate maintenance by purchaser.
4. Unauthorized modifications, misuse or mishandling.
5. Operation outside of the environmental specifications of the product.
6. Purchaser's supplied software or interfacing.

THIS WARRANTY IS EXCLUSIVE AND NO OTHER WARRANTY, WHETHER WRITTEN OR ORAL, IS EXPRESSED OR IMPLIED. DATUM - TT&M SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

The remedies set forth above are the purchaser's sole and exclusive remedies. In no circumstances shall Datum - TT&M assume liability for loss, damage, or consequential expense (including loss of profits) whether based on contract, tort, or any other legal theory, arising directly or indirectly from the use of its equipment separately or in combination with other equipment.