

**Caution:**

Do not use this version of the ASPI layer in Windows 95. Use ASPI version 4.60 found under the EZ-SCSI 5.x downloads for Windows 95.

Adaptec provides this software without charge and as a courtesy to Adaptec product users but offers **no technical support** regarding this software.

**Installation Instruction:**

This file extracts by default to the c:\adaptec\aspi directory. If you have changed this directory, please note the directory you have chosen.

For Windows 98, NT 4.0, Me and 2000, use the enclosed ASPIINST.EXE file to install the ASPI layer.

For Windows XP, select Start - Run from the menu, and then the Browse button. Locate the INSTALL.BAT file in the directory the files extracted to and select the OPEN button. In the command box, add a space and either XP32 for Pentium I/II/III/IV processors or XP64 for Itanium processors. The command should look like: **c:\adaptec\aspi\install.bat XP32** or **c:\adaptec\aspi\install.bat XP64**. Then select the OK button to run the XP installer.

**Notes:**

At this time Adaptec is allowing the download of this file without regard to ownership of retail Adaptec Products.

This ASPI layer is available via a licensing agreement to any company who wishes to distribute it with their product.

If you are the owner of a 3rd party device that requires an ASPI layer to be installed in your operating system, Adaptec suggests that you contact your peripheral manufacturer for a product specific version of the ASPI layer. The version you are about to download is a generic version and not designed to work with every device.

Adaptec provides this software without charge and as a courtesy to Adaptec product users but offers **no technical support** regarding this software.