



Upgrading Agilent Medalist i5000 version 06.00pa to 06.01p

Log On to Windows as administrator

1. Click on Start -> Control Panel -> Add or Remove Programs and remove following software's in the order:
 - a. Agilent Medalist i5000 In-Circuit Test System Patch06.00pa [Select upgrade/remove option from un-installation dialog box]
 - b. Agilent Medalist i5000 In-Circuit Test System

Reboot the machine once above software's have been removed from the system.

Insert the "Agilent Medalist i5000 06.01 Software" CD into the CD/DVD-ROM drive

- **Once you enter the CD, it will automatically start the installation. If installation is not started, do following :**

Click **Start** then Run

Type: D: \setup.exe [D: is CD/DVD-ROM drive]

Click **OK**

- **Welcome to the Install Shield Wizard for Agilent Medalist i5000 In-Circuit Test System**
Click **Next**
- **License Agreement**
Read it and Click **Yes**
- **Choose Destination Location**
Destination folder: **C:\Agilent_ ICT** ["Agilent Medalist i5000 doesn't allow white spaces in destination folder"]
Click **Next**
- **Agilent In-Circuit Test System Software requires display resolution of at least 1024x768.** Do you agree to modify your screen resolution before running this software?
Click **Yes**
Note: if display is already set to 1024x768, this message will not appear
- **This software requires display colors to be at least 16-bit (65536) color.** You are currently in %d colors. Some programs may not display properly with your current settings. Do you agree to modify your display settings before continuing?
Click **Yes**
Note: if display colors are already at least 16-bit (65536) color, this message will not appear



Agilent Technologies

- **"Fast User Switching is enabled on this computer. Fast User Switching is incompatible with Agilent In-Circuit Test software. Press yes to disable Fast User Switching and continue with the installation."**

Click **Yes**

Note: if fast User Switching is already disabled on this computer, this message will not appear

- You will get a dialog message saying **"This software requires RAM to be at least 512 MB"** if your machine has less than 512 MB RAM

- **Agilent System License File**

Enter/browse the License file to continue and press next [This is the location of the license file, if you have licenses in the floppy, please insert the floppy and select the location]

Note: If you are upgrading and were using Agilent ICT before, it will automatically skip this step

- **Select Components**

All items should be check marked except ScanWorks

Click **Next**

- You will get a dialog message saying **"There is not enough space on selected drive, do you want to select again?"**, if the space required for installing software is not enough.

- Agilent Medalist i5000 In-Circuit Test System is performing the requested operations

- **Do you want to reboot machine?**

- Please save your work and reboot the machine to continue the installation and leave the CD in CD/DVD-ROM drive and click **YES**.

Computer will reboot

Logon to Windows [use the same login account as in the previous step]

User name: Administrator

Password: [leave blank]

Click **OK**

It will start making digital libraries, please wait for some time. It could take between 1-10 minutes depending upon system performance.

Agilent Medalist i5000 Software Installation Complete

- Do you want to reboot machine? - Please save your work and reboot the machine to finish the installation.

You can set your display to 1024x768 now by:

Right click mouse button on desktop and select properties. Click settings tab and choose screen resolution to 1024x768 and clicking on apply OR go to control panel and click on display.