

Index

Alphabetical

A

Adapters

Metrology Grade	13, 14
Instrument Grade	13, 15
General Purpose Grade	16
Network Analyzer Test Port	77, 78
Selection Guide	13
Waveguide	119, 120

Amplifiers

General Purpose	21-28
Instrumentation	29-31, 83
Power Supplies and Cables	21-28

Attenuators

Applications and Key Specifications	33, 34
Cables	47
Drivers	47
Fixed	35-37
Interconnect/Rack Mount Support Kits	47
Programmable and Manual Step	38-46
Waveguide	119, 121

B

Bead

7-mm Connector	17
----------------------	----

Blocking Capacitor

Directional	84
-------------------	----

Bridges

RF	67
----------	----

C

Cables

Amplifier	21-28
Attenuator	47
General Purpose	17
Network Analyzer	77, 78
Switch	109

Calibration Kits, Network Analyzer

Capacitor, Blocking	78
---------------------------	----

Connectors

General	18, 19
Torque Values	19
7-mm Bead	17

Couplers. *See Directional Couplers*

D

Detectors

Applications and Key Specifications	49-52
Directional	58
Low-Barrier Schottky Diode (LBSD)	53, 55-57
Planar-Doped Barrier Diode (PDBD) ...	53, 54, 56, 57
LBSD Replaceable Elements	55
Waveguide	119, 122

Directional Bridge

Directional Couplers

Applications and Key Specifications	59, 60
Single and Dual	61-66
90 Degree Hybrid	61, 63, 66
Waveguide	119, 122

Directional Detectors

Dividers, Power

Drivers, Attenuator/Switch

F

Filters

Fixed Attenuators

Fixed Terminations (Loads)

Fixed Terminations (Loads), Waveguide

Flanges, Waveguide

Frequency Meter

H

HP DIRECT

HP-IB

HP Local Sales Offices

HP Test and Measurement Call Centers

HP QuickShip

I

Instrumentation Amplifiers

Insulator Bead Assembly, 7-mm

Interconnect Kits, Attenuator

ISO 9000 Quality Management

Isolators, Waveguide

L

Limiters

Loads

Fixed and Sliding

Waveguide

Index

Alphabetical

M

Manual and Programmable Step Attenuators 38-46
 Matching Transformer 84
 Matrixes
 Switch 111-113
 Drivers and Interface Modules 110, 111
 Mixers
 Waveguide 73, 74
 MMS, Interface Modules and Drivers 110, 111
 Multiport Switches
 High Performance 88, 89, 105-108
 Low Profile 87, 89, 99-104

N

Network Analyzer Accessories
 Calibration Kits 75, 76
 Verification Kits 75, 76
 Test Port Cables and Adapters 77, 78
 New Product Highlights 4

O

Ordering Information
 General 5, 131
 Attenuators 37, 46
 Switches 95, 98, 104, 108

P

Power Dividers 79, 80
 Power Splitters 80, 81
 Power Supplies, Amplifiers 21-28
 Preamplifiers 21, 22, 26, 31, 83
 Probes 84
 Programmable Step Attenuators 38-46

Q

QuickShip 5

R

Rack Mount Support Kit, Attenuators 47

S

Sales Offices, Local HP 5, 133
 Shipping 131
 Single Pole Double Throw Switches 87, 89, 90-95
 Sliding Loads 117, 125
 Spectrum Analyzer Accessories 83, 84
 Splitters, Power 80, 81

Step Attenuators

Manual and Programmable 38-46
 Drivers 47, 110

Switches

Applications & Key Specifications 85, 86
 Drivers 110, 111
 Cables 109
 Matrixes 111-113
 Multiport, Low Profile 87, 89, 99-104
 Multiport, High Performance 88, 89, 105-108
 Selection Guide 89
 Single Pole Double Throw 87, 89-95
 Transfer 87, 89, 96-98

T

Terminations

Fixed and Sliding 115-117
 Waveguide 119, 125

Terms of Sale 131

Transfer Switches 87, 89, 96-98

Transformer, Matching 84

V

Variable Attenuators, Waveguide 119, 121

Verification Kits, Network Analyzer 75, 76

VEE 110

VXI Attenuator and Switch Drivers 111

W

Warranty 131

Waveguide

Adapters 119, 120

Attenuators, Variable 119, 121

Calibration Kits, Network Analyzer 75, 76

Detectors 119, 122

Directional Couplers 119, 123

HP Flange Data 128, 129

Frequency Band Data 128

Isolators 119, 124

Terminations (Loads) Fixed and Sliding 119, 125

Mixers 73, 74

HP Products Data 126, 127

Selection Guide 119

Stands and Holders 119, 124

Verification Kits, Network Analyzer 75, 76

Index

HP Model Number

200

281 Series Waveguide Adapters 119, 120

300

355 Series Step Attenuators 38

365A Series Waveguide Isolators 119, 124

382A Series Waveguide Variable Attenuators ... 119, 121

400

422C Series Waveguide Detectors 119, 122

423B LBSD Detector 53, 55-57

500

537A Frequency Meter 71

700

752 Series Waveguide Directional Couplers 119, 123

772/3/5/6/7/8/9D Directional Couplers 61-66

900

909 Series Fixed Terminations 115, 116

910 Series Waveguide Fixed Terminations 119, 125

911 Series Sliding Loads 117

914 Series Waveguide Sliding Load 119, 125

1000

E1368/69/70A Attenuator and Switch Drivers 111

E1700A Switch Driver 88

3000

3235A Switch Driver 88

3488A Switch Driver 88

8000

8347/48A Instrumentation Amplifiers 29

8349B Instrumentation Amplifier 29

8447 Series Instrumentation Amplifiers 30, 83

8449B Preamplifier 31, 83

8470/72/73 Series LBSD Detectors 53, 55-57

8474 Series PDBD Detectors 53, 54, 56, 57

8490/91/92/93/98 Series Fixed Attenuators 35-37

8494/95/96/97 Series Step Attenuators 38, 42, 44-46

8721A Directional Bridge 84

8761/62 Series SPDT Switches 87, 89-95

8763/64 Series Transfer Switches 87, 89, 96-98

8765 Series SPDT Switches 87, 89-92, 94, 95

8766/67/68/69K Multiport Switches 87, 89, 99-104

11000

11500 Series Cable Assemblies 17

11501A Cable Assembly 17

11524/525A Adapter 13, 16

11533/534A Adapter 13, 16

11540A Waveguide Stand 119, 124

11545/546/547/548A Waveguide Holders 119, 124

11581/582/583 Series Fixed Attenuator Sets 35

11636 Series Power Dividers 79

11644A Series Waveguide Calibration Kits 76

11645A Series Waveguide Verification Kits 76

11667 Series Power Splitters 80

11668A High Pass Filter 69

11691/692D Directional Couplers 62, 63, 66

11693A Limiter 69

11694A Transformer 84

11713A Attenuator/Switch Driver 40, 47, 110

11716 Series Attenuator Interconnect Kits 47

11717A Attenuator/Switch Rack Mount Kit 47

11742A Blocking Capacitor 78

Index

HP Model Number

11761A Switch Driver Cable	109	83050/051A Amplifiers	21-25, 28
11764 Series Attenuator Interconnect Cables	47	83059 Series Adapters	13, 15
11850 Series Power Splitter	81	84904/906/907 Series Step Attenuators	39, 43, 44, 46, 47
11852B Adapter	13, 15	84940A Expansion Driver Card	111
11867A Limiter	69	84941A Distribution Card	47, 109, 111
11900/901/902/903/904 Series Adapters	13, 14	85024A Probe	84
11969A Mixer Carrying Case	74	85029/051/053/055/057B Verification Kits	76
11970 Series Harmonic Mixers	73, 74	85031/032/033/036/039/	
11974 Series Preselected Mixers	73, 74	050/052/054/056/058 Series Calibration Kits	76
11975A Amplifier	83	85060/062/064A Electronic Calibration Modules	76
30000		85130/131/132/133/134/135 Series	
33330 Series LBSD Detectors	53, 55-57	Test Port Adapters	78
33330D PDBD Detectors	53, 54, 56, 57	86205/207A Bridges	67
33391C 7-mm Connector Bead	17	86211A Adapter Kits	78
40000		86213A Attenuator Set	35
41800A Probe	84	87104/106 Series Multiport Switches	88, 89, 105-109
70000		87204/206 Series Multiport Switches	88, 89, 105-109
70611A MMS Attenuator/Switch Driver	40, 110, 111	87130A Attenuator/Switch Driver	40, 110, 111
70612/613 Series MMS Interface Modules	110, 111	87300/301 Series Directional Couplers	61, 63, 65, 66
80000		87310B 90 Degree Hybrid Coupler	61, 63, 66
83006/017/018/020A Amplifiers	21-25, 28	87302/303/304C Hybrid Power Dividers	79, 80
83036C Directional Detector	58	87405A Preamplifier	21, 22, 26, 28
		87415A Amplifiers	21-23, 26, 28
		87421/422A Amplifier Power Supplies	21, 22, 27, 28

Index

HP Part Number

0955-0751/52 Power Splitters	81	1250-1462 Adapter	13, 16
0955-0759/60 Filters	69	1250-1472 Adapter	13, 16
0955-0765/66/67/68 Attenuators	35	1250-1473 Adapter	16
1250-0076 Adapter	16	1250-1474 Adapter	16
1250-0077 Adapter	16	1250-1475 Adapter	13, 16
1250-0080 Adapter	16	1250-1476 Adapter	16
1250-0082 Adapter	16	1250-1477 Adapter	16
1250-0176 Adapter	13, 16	1250-1528 Adapter	13, 16
1250-0216 Adapter	16	1250-1529 Adapter	13, 16
1250-0559 Adapter	13, 16	1250-1533 Adapter	16
1250-0591 Adapter	16	1250-1534 Adapter	16
1250-0595 Adapter	16	1250-1535 Adapter	16
1250-0597 Adapter	13, 16	1250-1536 Adapter	16
1250-0670 Adapter	16	1250-1562 Adapter	13, 16
1250-0671 Adapter	16	1250-1636 Adapter	13, 16
1250-0672 Adapter	16	1250-1698 Adapter	13, 16
1250-0674 Adapter	16	1250-1743 Adapter	13, 16
1250-0675 Adapter	16	1250-1744 Adapter	13, 16
1250-0777 Adapter	13, 16	1250-1745 Adapter	13, 15
1250-0778 Adapter	13, 16	1250-1746 Adapter	13, 15
1250-0780 Adapter	16	1250-1747 Adapter	13, 15
1250-0781 Adapter	16	1250-1748 Adapter	13, 15
1250-0813 Adapter	16	1250-1749 Adapter	13, 15
1250-0827 Adapter	16	1250-1750 Adapter	13, 15
1250-0831 Adapter	16	1250-1772 Adapter	13, 16
1250-0832 Adapter	16	1250-1787 Adapter	16
1250-0837 Adapter	16	1250-1830 Adapter	16
1250-0838 Adapter	16	1250-1857 Adapter	16
1250-0846 Adapter	13, 16	1250-2015 Adapter	16
1250-1023 Adapter	16	11764-60005/006 Attenuator Cables	47
1250-1113 Adapter	16	11764-60007/008 Switch Cables	109
1250-1152 Adapter	16	00423-60003/004/005/007 Detector Elements	55
1250-1153 Adapter	16	08470-60012/014/016 Detector Elements	55
1250-1158 Adapter	13, 16	08473-80001/002/003/004/005/006 Detector Elements	55
1250-1159 Adapter	13, 16	33330-80003/004/005/006/007/008 Detector Elements	55
1250-1236 Adapter	16	5061-0969 Switch Cable	109
1250-1237 Adapter	16	70611-60008 Switch Cables	109
1250-1249 Adapter	13, 16	70612-60017/018 Attenuator Cables	47
1250-1250 Adapter	13, 16	83006-60004 Power Supply Cable	23, 28
1250-1286 Adapter	16	83006-60005 Power Supply Cable	28
1250-1287 Adapter	16	83020-60004 Power Supply Cable	25, 28
1250-1288 Adapter	16	85058-60007/008/009 Adapters	13, 15
1250-1391 Adapter	16	87422-60001 Power Supply Cable	28
1250-1397 Adapter	13, 16		