

# Technical Publication Change Instructions

Updated replacement pages and/or drawings are attached to this Technical Publication Change Instructions. Please follow the directions under **Publication Update Requirements** and replace corresponding pages with the attached pages provided. Failure to make these replacements may result in loss of product efficiency and possible failure. Please note that page numbers no longer have alpha suffixes, and now the revision level on newer publications adds a numerated suffix denoting its difference from the core revision. Most specific changes are identified by change bars in the corresponding margins. A replacement page with no numerated suffix means a change has not occurred, but the page is included because its page is double-sided.

Replacement pages will become standard pages at the next printing cycle. The Front Matter (excluding Cover page), Table of Contents, List of Illustrations and Tables, Preface (in most cases) and Index will be updated at this cycle. For record purposes you are encouraged to retain this TPCI as a permanent part of the publication. Record changes in your publication's Preface section (Under newer Giga-tronics publications, "Record of Publication Changes", in older, "Record of Manual Changes").

| Publication                                         | Former P/N, Revision & Date | Updated P/N, Revision & Date |
|-----------------------------------------------------|-----------------------------|------------------------------|
| Series 12000A Microwave Synthesizers Service Manual | 31232, Rev. A3, April 2002  | 31232, Rev. A4, June 2002    |

| Publication Update Requirements |     |     |                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|---------------------------------|-----|-----|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Change Originator               |     |     | Replace Old Page(s)/<br>Add New Page(s)                       | Remarks                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| ECO                             | CAR | QIR |                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| N/A                             |     |     | Replace old first 2 pages of the Front Matter with new.       | Update to revision level on front matter to Rev. A4, Date June 2002.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| PCN 8203 - A3 Errata Only       |     |     | Replace old Chapters 1, 2 and 3 (in their entirety) with new. | Updates to Chapter 1 based on new specifications update to the Series 12000A from document 31836 Rev. U. Chapter 2 updated with new AM Modulation Test Section; other inaccuracies corrected and an update to FM Modulation Test has been implemented. A title change has occurred for Chapter 2 from "Performance Tests" to "Performance Verification". Chapter 3 has title change from "Adjustments" to "Calibration" to reflect uniformity of Giga-tronics publications and the Series 12000A Operation Manual.<br><br>Section 2.2.9a moved now Section 3.7. "Monitor Functions" is now Section 3.8. |
| N/A                             |     |     | Replace old 6-7 to 6-16 with new 6-7 to 6-24.                 | Update to Chapter 6 occurs because of incorporation of new Series 12000A format from Operation manual. Error Codes have also been added. A complete update to this chapter will occur in Revision B.                                                                                                                                                                                                                                                                                                                                                                                                    |



**NOTE: Erratas 31232-A1 through 31232-A3 no longer need to be shipped. The 31232-A4 errata takes care of re-issuing Erratas 31232-A1 through 31232-A3. Chapter 3 does not have a new tab update because of the new name. The tab updates and new formatting will not occur until the next main revision level, Rev. B.**


## Technical Publication Change Instructions

---

This Page will be left intentionally blank in most cases, due to continuity issues

# Giga-tronics

www.gigatronics.com



Series 12500A/12700A Models

Series 12400A Models

## Series 12000A Microwave Synthesizers

### Service Manual

Publication 31232, Rev. A4, June 2002

Giga-tronics Incorporated ♦ 4650 Norris Canyon Road, San Ramon, CA 94583  
925.328.4650/800.726.4442/925.328.4700 (Fax) ♦ Customer Service: 800.444.2878/925.328.4702 (Fax)



All technical data and specifications in this publication are subject to change without prior notice and do not represent a change without prior notice and do not represent a commitment on the part of Giga-tronics Incorporated.

© 2002 Giga-tronics Incorporated. All rights reserved. Printed in the USA

## **WARRANTY**

Giga-tronics Series 12000A instruments are warranted against defective materials and workmanship for three years from date of shipment. Giga-tronics will at its option repair or replace products that are proven defective during the warranty period. This warranty DOES NOT cover damage resulting from improper use, nor workmanship other than Giga-tronics service. There is no implied warranty of fitness for a particular purpose, nor is Giga-tronics liable for any consequential damages. Specification and price change privileges are reserved by Giga-tronics.

## **MODEL NUMBERS**

The Series 12000A has model numbers for each instrument with a specific frequency range as described in Chapter 1. All models are referred to in this manual by the general term 12000A, except where it is necessary to make a distinction between the models. In these cases, the specific model number(s) will be used.

# Specifications

## 1.1 Introduction

| Specifications (Introduction)          | Model  |                   |
|----------------------------------------|--------|-------------------|
|                                        | 124XXA | 125XXA/<br>127XXA |
| <b>1.1.1 - Environmental Standards</b> | √      | √                 |

The Series 12000A are Microwave Synthesizers with Step, Ramp (Series 127XXA Only) and List Sweep capability; the instruments operate over a wide range of microwave frequencies, power levels and in a variety of modulation modes. The 12000A can generate output signals over a frequency range of 10 MHz to 20 GHz; the frequency range is dependent on the specific model number. Table 1-1 lists the models with their respective frequency range. The RF output can be Fixed (CW), Step, Ramp or List Sweep with External Frequency, Amplitude or Pulse Modulation. The Series 124XXA is a CW ONLY Microwave Synthesizer. Option 29 (Scan Modulation) and Option 24 (Internal Modulation Generator) are only available on Series 125XXA/127XXA models.

**Table 1-1: Series 12000A Model Numbers**

| Series 12400A<br>(CW Generator) | Series 12500A<br>(Signal Generator) | Series 12700A<br>(Swept Signal Generator) | Frequency Range  |
|---------------------------------|-------------------------------------|-------------------------------------------|------------------|
| (Step Sweep, No Modulation)     | (Step Sweep, Modulation)            | (Step and Ramp Sweep Modulation)          |                  |
| 12408A                          | 12508A                              | 12708A                                    | 10 MHz to 8 GHz  |
| 12428A                          | 12528A                              | 12728A                                    | 2 GHz to 8 GHz   |
| 12420A                          | 12520A                              | 12720A                                    | 10 MHz to 20 GHz |
| 12422A                          | 12522A                              | 12722A                                    | 2 GHz to 20 GHz  |

Observe the publication's legend header sections as a way to assist in the operability of the Series 12000A purchased. Operation from the instrument's front panel is detailed in Chapter 2 of the Operation Manual. Instructions on how to operate the instrument from a remote host computer over the GPIB (General Purpose Interface Bus) can be obtained from Chapter 3 of the Operation manual.

### 1.1.1 Environmental Standards

All Series 12000A models are environmentally tested for compliance with MIL-PRF-28800F, Class 3.

1.2

Specifications  
(Signal Parameters & Operational Modes)

| Specifications               | Model  |                   |
|------------------------------|--------|-------------------|
|                              | 124XXA | 125XXA/<br>127XXA |
| 1.2.1 - CW Operation         | √      | √                 |
| 1.2.2 - RF Output            | √      | √                 |
| 1.2.3 - Spectral Purity      | √      | √                 |
| 1.2.4 - Step Frequency Sweep | √      | √                 |
| 1.2.5 - Step Power Sweep     | √      | √                 |

The following are specifications for the Series 12000A Microwave Synthesizers.

1.2.1

CW Operation

| Ranges                                                                    |                                                                                                                       |        |        |
|---------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|--------|--------|
|                                                                           | Model                                                                                                                 |        |        |
| 10 MHz to 8 GHz                                                           | 12408A                                                                                                                | 12508A | 12708A |
| 2 GHz to 8 GHz                                                            | 12428A                                                                                                                | 12528A | 12728A |
| 10 MHz to 20 GHz                                                          | 12420A                                                                                                                | 12520A | 12720A |
| 2 GHz to 20 GHz                                                           | 12422A                                                                                                                | 12522A | 12722A |
| Resolution                                                                |                                                                                                                       |        |        |
| 0.1 Hz (Standard)<br>1 kHz (Optional)                                     |                                                                                                                       |        |        |
| Accuracy & Stability (Identical to Timebase Oscillator)                   |                                                                                                                       |        |        |
| Timebase (Internal)                                                       | 10 MHz                                                                                                                |        |        |
| Aging Rate                                                                | $< 5 \times 10^{-10}$ /day after 72 hours continuous oven operation                                                   |        |        |
| Temperature Stability                                                     | $< \pm 2 \times 10^{-10}$ / °C (0 to +55°C)                                                                           |        |        |
| Timebase (External)                                                       | 5 or 10 MHz ( $\pm 1 \times 10^{-6}$ or better) (Software selected)<br>0.5 to 5 V <sub>p-p</sub> into 100 Ω (Nominal) |        |        |
| Switching Time, List Mode                                                 |                                                                                                                       |        |        |
| < 500 μs to within 1 kHz of set frequency (Typical)                       |                                                                                                                       |        |        |
| Switching Time, CW Mode                                                   |                                                                                                                       |        |        |
| 35 ms to within 1 kHz of set frequency (Includes IEEE overhead) (Typical) |                                                                                                                       |        |        |

## Residual FM During Switching

Refer to FM Table, Wide Mode Residual Column, Section 1.5.3

---

## Phase Offset Mode

|                   |                                                                                            |
|-------------------|--------------------------------------------------------------------------------------------|
| <b>Range</b>      | -180 to +180 degrees                                                                       |
| <b>Resolution</b> | .01 degrees, maximum                                                                       |
| <b>Step Size</b>  | .01 to 180 degrees                                                                         |
| <b>Accuracy</b>   | Not specified. This is relative mode of operation and is designed to be used interactively |

## 1.2.2 RF Output

### Maximum Leveled Output (0 to 35°C)

| Frequency Range (GHz) | Output Power (dBm) | Option 26 (dBm) |
|-----------------------|--------------------|-----------------|
| 0.01 to 2             | + 15 dBm           | + 14 dBm        |
| > 2 to < 8            | + 15 dBm           | + 15 dBm        |
| 8 to 15               | + 15 dBm           | + 13 dBm        |
| > 15 to 20            | + 15 dBm           | + 12 dBm        |

### Incremental Level Range

-20 (Typical) to +25 dBm; -120 to +25 dBm (Option 26)

### Resolution

-0.01 dB, entry and display

### Minimum Calibrated Output Level

-120 dBm with attenuator Option 26  
-10 dBm without attenuator Option 26  
RF Off: Attenuates the output to < -140 dBm at the output connector

### Flatness

$\pm 0.5$  dB (-10 dBm to maximum specified power) at  $25 \pm 10^\circ\text{C}$  (Internally Leveled, CW or Frequency Step or Ramp Mode)

Add  $\pm 0.1$  dB/10 dB with attenuator option ( $\pm 2.5$  dB with Option 20\*)

At 35 to 55°C, maximum output power is +13 dBm, flatness  $\pm 1$  dB, Typical temperature coefficient is -0.025 dB per degree C

(\*See Section 1.3.3 for Option 20 limitations involving use with the 124XXA)

### Resolution

-Add 0.2 dB to Flatness (Internally Leveled, CW, Frequency Step or Ramp)

### Maximum Slope of Level Variation

< 0.5 dB/MHz

### Output Switching Time

< 500  $\mu\text{s}$ ; 20 ms with attenuator change

### Output Impedance

50  $\Omega$ , nominal

**Output SWR**

---

< 2.0:1 (Typical)

---

**Level Drift**

---

< 0.05 dB/hour. Max 0.1 dB/24 hours

---

# Series 12000A Microwave Synthesizers

## 1.2.3 Spectral Purity

### Harmonics

| Frequency (GHz) | Harmonic (dBc) | Power (dBm) |
|-----------------|----------------|-------------|
| 0.01 to 0.10    | -30            | +6          |
| 0.10 to 2       | -50            | +6          |
| > 2 to 20       | -55            | +6          |

### Subharmonics

None, 0.01 - 2 GHz

0.01 - 2 GHz  
55 dBc > 2 GHz

A subharmonic is defined as any  $\frac{1}{4}$ ,  $\frac{1}{2}$ , or  $\frac{3}{4}$  multiple of the fundamental RF Output

### Nonharmonics

< -60 dBc from 0.01 to 16 GHz (offsets > 300 Hz)  
< -55 dBc from > 16 to 20 GHz (offsets > 300 Hz)

### Single-Sideband Phase Noise (dBc/Hz, CW mode, all power levels)

| Freq. (GHz) | Offset from Carrier |       |        |         |       |
|-------------|---------------------|-------|--------|---------|-------|
|             | 100 Hz              | 1 kHz | 10 kHz | 100 kHz | 1 MHz |
| 0.25        | -101                | -101  | -109   | -122    | -129  |
| 0.5         | -95                 | -95   | -103   | -122    | -124  |
| 2           | -87                 | -92   | -94    | -120    | -125  |
| 4           | -81                 | -86   | -88    | -110    | -130  |
| 6           | -81                 | -83   | -83    | -110    | -130  |
| 8           | -75                 | -80   | -80    | -105    | -130  |
| 10          | -75                 | -80   | -80    | -105    | -125  |
| 18          | -68                 | -73   | -73    | -97     | -120  |
| 20          | -68                 | -73   | -73    | -97     | -120  |

### Residual FM (Hz, rms, CW Mode)

| Frequency Range (GHz) | Post Detection Bandwidth (Hz)      |                                    |
|-----------------------|------------------------------------|------------------------------------|
|                       | 300 to 3000                        | 50 to 15000                        |
| < 2 GHz               | Decreases by $\frac{1}{2}$ per oct | Decreases by $\frac{1}{2}$ per oct |
| 2 to < 4              | < 6                                | < 45                               |
| 4 to < 8              | < 12                               | < 70                               |
| 8 to < 16             | < 24                               | < 160                              |
| 16 to 20              | < 32                               | < 280                              |

### AM Noise

< -130 dB/Hz from 0.01 to 2 GHz  
< -145 dBm/Hz at > 2 GHz

## 1.2.4 Step Frequency Sweep

### Range

FA (minimum frequency of instrument) to FB (maximum frequency of instrument)

### Step Size

Any increment within the frequency resolution

### Dwell Time

May be set in 1  $\mu$ s increments from approximately 1  $\mu$ s to 200 sec

### Setup Time

200  $\mu$ s (Typical)

### Accuracy & Stability

Same as in CW when locked at each step during dwell time

### Modes

|                                  |                                                                                                                                                                                |
|----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Start/Stop</b>                | $FA \leq [F1 \neq F2] \leq FB$<br>Sweeps up or down from a preset start frequency (F1) to a preset stop frequency (F2)                                                         |
| <b>Start/<math>\Delta</math></b> | $FA \leq [F1 \pm \Delta F] \leq FB$<br>Sweeps up or down from a preset start frequency (F1) through a preset sweep width ( $\Delta F$ )                                        |
| <b>CTR/<math>\Delta</math></b>   | $FA \leq [CF \pm (\Delta F/2)] \leq FB$<br>Sweeps up or down through a preset sweep width ( $\Delta F$ ) centered symmetrically about a preset center frequency (CF)           |
| <b>Start/Steps</b>               | $FA \leq [F1 \pm (\text{Step Size} \times \text{Number of Steps})] \leq FB$<br>Sweeps up or down from a preset start frequency (F1) through a preset number of frequency steps |

### Functions

|                 |                                                                                                                                                                                                   |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Auto</b>     | Continuous cycle of the preset sweep                                                                                                                                                              |
| <b>Single</b>   | A single cycle of the preset sweep or (with stop activated) a single preset step, initiated by the manual operation of the front panel push-button or reception of the corresponding GPIB command |
| <b>EXT</b>      | A single cycle of the preset sweep initiated by each trigger from an external source                                                                                                              |
| <b>EXT Step</b> | A single step of a preset step sweep initiated by each trigger input from an external source                                                                                                      |

1.2.5 Step Power Sweep

|                                                                      |                                                                                                                                                                                                   |
|----------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Range</b>                                                         |                                                                                                                                                                                                   |
| LA (minimum level of instrument) to LB (maximum level of instrument) |                                                                                                                                                                                                   |
| <b>Step Size</b>                                                     |                                                                                                                                                                                                   |
| Any increment within the instrument’s resolution                     |                                                                                                                                                                                                   |
| <b>Dwell Time</b>                                                    |                                                                                                                                                                                                   |
| May be set in 1 μs increments from approximately 1 μs to 200 sec     |                                                                                                                                                                                                   |
| <b>Setup Time</b>                                                    |                                                                                                                                                                                                   |
| 100 μs (Typical)                                                     |                                                                                                                                                                                                   |
| <b>Accuracy &amp; Stability</b>                                      |                                                                                                                                                                                                   |
| Same as in CW when locked at each step during dwell time             |                                                                                                                                                                                                   |
| <b>Modes</b>                                                         |                                                                                                                                                                                                   |
| Start/Stop                                                           | $LA \leq [L1 \neq L2] \leq LB$<br>Sweeps up or down from a preset start level (L1) to a preset stop level (L2)                                                                                    |
| Start/Δ                                                              | $LA \leq [L1 \pm \Delta L] \leq LB$<br>Sweeps up or down from a preset start level (L1) through a preset sweep width (ΔL)                                                                         |
| CTR/Δ                                                                | $LA \leq [CL \pm (\Delta L/2)] \leq LB$<br>Sweeps up or down through a preset sweep width (ΔL) centered symmetrically about a preset center level (LF)                                            |
| Start/Steps                                                          | $LA \leq [L1 \pm (\text{Step Size} \times \text{Number of Steps})] \leq LB$<br>Sweeps up or down from a preset start level (L1) through a preset number of level steps                            |
| <b>Functions</b>                                                     |                                                                                                                                                                                                   |
| Auto                                                                 | Continuous cycle of the preset sweep                                                                                                                                                              |
| Single                                                               | A single cycle of the preset sweep or (with stop activated) a single preset step, initiated by the manual operation of the front panel push-button or reception of the corresponding GPIB command |
| EXT                                                                  | A single cycle of the preset sweep initiated by each trigger from an external source                                                                                                              |
| EXT Step                                                             | A single step of a preset step sweep initiated by each trigger input from an external source                                                                                                      |

## 1.3 Supplemental Specifications

| Supplemental Specifications      | Model  |                   |
|----------------------------------|--------|-------------------|
|                                  | 124XXA | 125XXA/<br>127XXA |
| 1.3.1 - General Specifications   | √      | √                 |
| 1.3.2 - Weight & Dimensions      | √      | √                 |
| 1.3.3 - Option 20 Specifications | √      | √                 |

### 1.3.1 General Specifications

|                       |                                                             |                                                              |
|-----------------------|-------------------------------------------------------------|--------------------------------------------------------------|
| Remote Interfaces     | GPIB                                                        | IEEE STD 488.2 (GPIB), all parameters except AC power on/off |
|                       | Serial                                                      | EIA RS-232, Serial Interface, DB9 Connector                  |
| Operating Temperature | 0 to 55°C                                                   |                                                              |
| Environmental         | Complies with MIL-PRF-28800F, Class 3                       |                                                              |
| Approvals             | CE marked                                                   |                                                              |
| Power                 | 90-253 VAC, 47-64 Hz (400 Hz optional), 150 Watts (Nominal) |                                                              |
| Fuse Rating           | 2 A, SB                                                     |                                                              |

### 1.3.2 Weight & Dimensions

| Item   | Benchtop Model       | Packed for Air Shipment |
|--------|----------------------|-------------------------|
| Width  | 16.75 in. (42.5 cm.) | 24 in. (60.9 cm.)       |
| Depth  | 21 in.               | 21 in.                  |
| Height | 5.25 in. (13.3 cm.)  | 11.25 in. (28.6 cm.)    |
| Volume | 1850 cuin            | 1850 cuin               |
| Weight | 30 lbs.              | 40 lbs.                 |

1.3.3      **Option 20 (High Power) Specifications**  
(Apply from 0° to 35°C)

|                                                                                                                                   |                                             |
|-----------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------|
| <b>Output Power</b>                                                                                                               |                                             |
| + 20 dBm                                                                                                                          |                                             |
| <b>Flatness</b>                                                                                                                   |                                             |
| +/- 2.5 dB                                                                                                                        |                                             |
| <b>Harmonics</b>                                                                                                                  |                                             |
| < -5 dBc from 0.01 to 0.1 GHz<br>< -20 dBc for 0.1 to 20.0 GHz @ + 20 dBm Output Power                                            |                                             |
| <b>Pulse On/Off</b>                                                                                                               | (PULSE ON/OFF ONLY ON SERIES 12500A/12700A) |
| 60 dBc                                                                                                                            |                                             |
| <b>AM</b>                                                                                                                         | (AM ONLY ON SERIES 12500A/12700A)           |
| Functional, but not specified above 0 dBm                                                                                         |                                             |
| <b>Option Activity</b>                                                                                                            |                                             |
| When the option is not active the output power is reduced by 2.0 dB<br>When active, the High Power Option switches in at + 11 dBm |                                             |

## 1.4 Specifications (Series 12500A/12700A)

(Signal Parameters & Operational Modes)

| Specifications (Series 12500A/12700A) | Model  |                    |
|---------------------------------------|--------|--------------------|
|                                       | 124XXA | 125XXA/<br>127XXA  |
| 1.4.1 - Ramp Frequency Sweep          | N/A    | √<br>(127XXA Only) |
| 1.4.2 - Ramp Power Sweep              | N/A    | √<br>(127XXA Only) |

Refer to Section 1.2 for specifications that apply to all models. Use this section for native specifications to the Series 125XXA/127XXA models.

### 1.4.1 Ramp Frequency Sweep

A continuous sweep is generated within the instrument. The continuous sweep may be operated simultaneously with digital power sweep.

|                                          | Description                                                                                                           |
|------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|
| <b>Sweep Type</b>                        | Smooth frequency ramp progression sweep                                                                               |
| <b>Sweep Type</b>                        | Either up or down in frequency                                                                                        |
| <b>Sweep Direction</b>                   | Either up or down in frequency                                                                                        |
| <b>Sweep Ramp Shape</b>                  | Linear frequency ramp with respect to time                                                                            |
| <b>Sweep Range</b>                       | Linear frequency ramp with respect to time                                                                            |
| <b>Start Frequency Accuracy</b>          | Phase locked to timebase (via YIG tune coil)                                                                          |
| <b>Stop Frequency Accuracy</b>           | Phase locked to timebase (via YIG tune coil)                                                                          |
| <b>Halted Frequency Accuracy</b>         | Phase locked to timebase (via YIG tune coil)                                                                          |
| <b>Start &amp; Stop Freq. Resolution</b> | 0.1 Hz Standard (1 kHz, Option 36)                                                                                    |
| <b>Minimum Sweep Width</b>               | 100 Hz Standard (1 MHz, Option 36)                                                                                    |
| <b>Maximum Step Width</b>                | From the minimum frequency to the maximum. Frequency of the Series 12000A as configured                               |
| <b>Sweep Width Resolution</b>            | 0.1 Hz standard (1 kHz, Option 36)                                                                                    |
| <b>Sweep Time</b>                        | 1 ms to 200 sec                                                                                                       |
| <b>Sweep Time Resolution</b>             | 10 $\mu$ s                                                                                                            |
| <b>Minimum Sweep Rate</b>                | 100 kHz/sec                                                                                                           |
| <b>Maximum Sweep Rate</b>                | 8 ms/octave                                                                                                           |
| <b>Sweep Linearity</b>                   | Better than 0.03% of sweep width relative to the 0 V to 10 V Ramp Output BNC voltage (Swept time < 100 sec) (Typical) |
| <b>Sweep Modulation Formats</b>          | AM or Pulse Modulation                                                                                                |

# Series 12000A Microwave Synthesizers

## 0 to 10 V Ramp Output

$V_{out} = (10 \text{ V}) \left| \frac{(f_{out} - f_{start})}{(f_{stop} - f_{start})} \right|$  (Frequency Ramp sweep mode)

$V_{out} = (10 \text{ V}) \left| \frac{(P_{out} - P_{start})}{(P_{stop} - P_{start})} \right|$  (Power Ramp sweep mode)

$V_{out} = 0 \text{ to } 10 \text{ V ramp @ current set sweep rate}$  (Ramp during CW mode)

## 0.5 / GHz Output

$V_{out} = (0.5 \text{ V}) (F_{out} \text{ in GHz})$

## Sweep Modes

|                                  |                                                                                                                                                                      |
|----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Start/Stop</b>                | $FA \leq [F1 \neq F2] \leq FB$<br>Sweeps up or down from a preset start frequency (F1) to a preset stop frequency (F2)                                               |
| <b>Start/<math>\Delta</math></b> | $FA \leq [F1 \pm \Delta F] \leq FB$<br>Sweeps up or down from a preset start frequency (F1) through a preset sweep width ( $\Delta F$ )                              |
| <b>CTR/<math>\Delta</math></b>   | $FA \leq [CF \pm (\Delta F/2)] \leq FB$<br>Sweeps up or down through a preset sweep width ( $\Delta F$ ) centered symmetrically about a preset center frequency (CF) |
| <b><math>\Delta</math> MKR</b>   | $FA \leq [Mx \neq My] \leq FB$<br>Sweeps up or down from a preset start frequency (Mx) through a preset marker (My)                                                  |

## Sweep Functions

|               |                                                                                                                                                |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Auto</b>   | Continuous recycle of the preset sweep                                                                                                         |
| <b>Single</b> | A single cycle of the preset sweep initiated by manual operation of the front panel push-button or reception of the corresponding GPIB command |
| <b>EXT</b>    | A single cycle of reset sweep initiated by a trigger from an external source                                                                   |

## Frequency Markers

(Twelve intensity, video and/or amplitude markers, individually selected from either the front panel or via the GPIB)

|                          |                                                                                                                   |
|--------------------------|-------------------------------------------------------------------------------------------------------------------|
| <b>Resolution</b>        | Sweep width/4000                                                                                                  |
| <b>Accuracy</b>          | Same as Sweep linearity except the marker may vary $\pm 25 \text{ mV}$ relative to the linear 0 to +10 V RAMP OUT |
| <b>Amplitude Markers</b> | A -10 to +10 dB change in RF output during analog frequency sweep                                                 |
| <b>Video Markers</b>     | TTL level output or $\pm 5 \text{ V}$                                                                             |
| <b>Intensity Markers</b> | Provides a timed dwell of frequency sweep                                                                         |

## 1.4.2 Ramp Power Sweep

Continuous sweep, self generated within the instrument. Can be operated simultaneously with digital frequency sweep.

### Range

- 10 dBm to maximum power, up or down (-120 dBm is maximum power with Option 26)

### Sweep Time (Any Sweep Mode)

2 ms to 200 sec in five ranges. Minimum sweep time is determined by the sweep width and the maximum sweep speed

| Range             | Resolution  |
|-------------------|-------------|
| 2 ms to 20 ms     | 10 $\mu$ s  |
| 20 ms to 200 ms   | 100 $\mu$ s |
| 200 ms to 2 sec   | 1 ms        |
| 2 sec to 20 sec   | 10 ms       |
| 20 sec to 200 sec | 100 ms      |

### Minimum Sweep Width

.01 dB

### Maximum Sweep Speed

1 dB/ms

### Sweep Level Resolution (Any Sweep Mode)

0.01 dB

### Start Level Accuracy (Any Sweep Mode)

0.2 dB to Flatness

### Sweep Level Linearity (Any Sweep Mode)

$\pm 0.25$  dB

### Sweep Modes

|               |                                                                                                                                                 |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Auto</b>   | Continuous recycle of preset sweep                                                                                                              |
| <b>Single</b> | A single cycle of the preset sweep, initiated by manual operation of the front panel push-button or reception of the corresponding GPIB command |
| <b>EXT</b>    | A single cycle of the preset sweep, initiated by a trigger input from an external source                                                        |

### 1.5 Modulation Parameters & Operational Modes

| Modulation Parameters & Operational Modes | Model  |                   |
|-------------------------------------------|--------|-------------------|
|                                           | 124XXA | 125XXA/<br>127XXA |
| 1.5.1 - Amplitude Modulation (AM)         | N/A    | √                 |
| 1.5.2 - Scan Modulation                   | N/A    | √                 |
| 1.5.3 - Frequency Modulation (FM)         | N/A    | √                 |
| 1.5.4 - Phase Modulation ( $\phi$ M)      | N/A    | √                 |
| 1.5.5 - Pulse/Square Wave Modulation (PM) | N/A    | √                 |

AM, FM, Pulse and Option 29 (Scan Modulation) driven by external waveforms is standard only on the 125XXA/127XXA models. Option 24 (Internal Modulation Generator) provides two function generators for internally generated amplitude and frequency modulation envelope waveforms. A pulse generator is also provided.

#### 1.5.1 Amplitude Modulation (AM)

AM may be operated simultaneously with FM. AM Specifications apply with FM turned off.

##### 1.5.1.1 AM Envelope Parameters

###### Modulation Depth

0 to 90% @ 0 dBm output power (Settable to 95.0%)

###### Modulation Resolution

1%

###### Modulation Bandwidth

DC to 150 kHz,  $\pm 3$  dB @ 0 dBm output

###### Modulation Accuracy

$\pm 10\%$  of depth setting (e.g. A setting of 50% may be within a 40% to 60% reading)

## 1.5.1.2 Externally Supplied AM Envelope

### Waveform

Any waveform compatible with bandwidth considerations

### Scaling

0%/V to 95%/V

### Input Voltage

Minimum: -1 V, Maximum: +1 V<sub>p,p</sub> for 50% depth  $\pm$ 10% depth @ 1 kHz modulation rate

### Input Impedance

600  $\Omega$  (Nominal)

## 1.5.1.3 Internally Generated AM Envelope

See Option 24 specifications in Section 1.6.1

## 1.5.2 Scan Modulation

See Option 29 specifications in Section 1.6.2.

1.5.3      **Frequency Modulation (FM)**

Specifications apply with Scan/AM and PM off. FM may be operated simultaneously with Linear AM and or PM (PM & Linear AM not allowed simultaneously).

1.5.3.1      **Wide Mode Envelope Parameters**

|                                                                                                  |
|--------------------------------------------------------------------------------------------------|
| <b>Maximum Deviation</b>                                                                         |
| See table contained in Section 1.5.3.2                                                           |
| <b>Minimum Deviation</b>                                                                         |
| 10 kHz at 4 - 8 GHz (Other ranges proportionally)                                                |
| <b>Modulation Resolution</b>                                                                     |
| 1 kHz (Deviation < 1 MHz); 10 kHz (Deviation < 1 MHz) (at 4 - 8 GHz, other range proportionally) |
| <b>Flatness</b>                                                                                  |
| ±2 dB for rates from 100 Hz to 1 MHz; ±3 dB to 8 MHz                                             |
| <b>Residual FM</b>                                                                               |
| See table contained in Section 1.5.3.2                                                           |
| <b>Modulation Accuracy</b>                                                                       |
| ±5% at max deviation, 190 kHz modulation rate                                                    |
| <b>Distortion</b>                                                                                |
| < 5% (±1 MHz Deviation)                                                                          |
| <b>Incidental AM</b>                                                                             |
| < ±0.2%/MHz of Deviation                                                                         |

### 1.5.3.2 Narrow Mode Envelope Parameters

#### Maximum Deviation

See table below

#### Modulation Resolution

10 Hz (Deviation < 10 kHz)  
1 kHz (Deviation > 10 kHz) (at 4 - 8 GHz, other ranges proportional)

#### Flatness

±2 dB for rates from DC to 1 MHz  
±3 dB for 1 MHz to 8 MHz

#### Residual FM

Same as CW

#### Modulation Accuracy

±5% at max Deviation, 190 kHz modulation rate

#### Distortion

< ±0.2%/MHz of Deviation

#### Incidental AM

< 5% (±1 MHz deviation)  
< 1% @ 10 KHz (4 - 8 range)

| Frequency (GHz) | Max Wide Deviation (Pk) | Max Narrow Deviation (Pk) | Wide Mode Residual FM |
|-----------------|-------------------------|---------------------------|-----------------------|
| .010 to .016    | 40 kHz                  | 2 kHz                     | < 200 Hz              |
| > .016 to .032  | 80 kHz                  | 4 kHz                     | < 200 Hz              |
| > .032 to .064  | 160 kHz                 | 8 kHz                     | < 200 Hz              |
| > .064 to .125  | 320 kHz                 | 16 kHz                    | < 200 Hz              |
| > .125 to .25   | 640 kHz                 | 32 kHz                    | < 200 Hz              |
| > .25 to .5     | 1.25 MHz                | 64 kHz                    | < 200 Hz              |
| > .5 - 1        | 2.5 MHz                 | 125 kHz                   | < 375 Hz              |
| > 1 - 2         | 5 MHz                   | 250 kHz                   | < 750 Hz              |
| > 2 - 4         | 10 MHz                  | .5 MHz                    | < 1.5 kHz             |
| > 4 - 8         | 20 MHz                  | 1 MHz                     | < 3 kHz               |
| > 8 - 16        | 40 MHz                  | 2 MHz                     | < 6 kHz               |
| > 16 - 20       | 80 MHz                  | 4 MHz                     | < 12 kHz              |

1.5.3.3 Internally Generated FM Envelope

See Option 24 specifications in Section 1.6.1

1.5.3.4 Externally Supplied FM Envelope

**Waveform**

Any waveform compatible with bandwidth considerations

**Rate**

DC to 8 MHz

**Input Sensitivity, Settable**

1 V<sub>p,p</sub> for maximum Peak deviation (FM deviation control set to maximum)

**Input Impedance**

50 Ω (Nominal)

## 1.5.4 Phase Modulation ( $\phi M$ )

Specifications apply with SCAN/AM and PM off.  $\phi M$  may be operated simultaneously with Linear AM and or PM (PM & Linear AM not allowed simultaneously).

### 1.5.4.1 Wide Mode Envelope Parameter

| Maximum Deviation                                                     |
|-----------------------------------------------------------------------|
| See table contained in Section 1.5.4.2                                |
| Maximum Resolution                                                    |
| 10 kHz at 4 - 8 GHz (other ranges proportional)                       |
| Modulation Resolution                                                 |
| .01 radians (at 4 - 8 GHz, other ranges proportional)                 |
| Flatness                                                              |
| $\pm 2$ dB for rates from 100 Hz to 100 kHz                           |
| Modulation Accuracy                                                   |
| $\pm 5\%$ (relative to FM) at max. deviation, 100 kHz modulation rate |
| Distortion                                                            |
| $< 5\%$ ( $\pm 1$ MHz deviation)                                      |
| Incidental AM                                                         |
| $< \pm 0.2\%$ /MHz of deviation                                       |

### 1.5.4.2 Narrow Mode Envelope Parameters

| Maximum Deviation                                     |
|-------------------------------------------------------|
| See table is on next page                             |
| Modulation Resolution                                 |
| .01 radians (at 4 - 8 GHz, other ranges proportional) |
| Flatness                                              |
| $\pm 2$ dB for rates from 100 Hz to 1 MHz             |

# Series 12000A Microwave Synthesizers

## Modulation Accuracy

$\pm 5\%$  (relative to FM) at max deviation, 100 kHz modulation rate

## Distortion

$< 5\%$  ( $\pm 1$  MHz deviation)

## Incidental AM

$< \pm 0.2\%$ /MHz of deviation

| Frequency (GHz) | Max Wide Deviation | Max Narrow Deviation |
|-----------------|--------------------|----------------------|
| .010 to .016    | .40 radians        | .02 radians          |
| > .016 to .032  | .80 radians        | .04 radians          |
| > .032 to .064  | 1.6 radians        | .08 radians          |
| > .064 to .125  | 3.2 radians        | .16 radians          |
| > .125 to .25   | 6.4 radians        | .32 radians          |
| > .25 to .5     | 12.5 radians       | .64 radians          |
| > .5 to 1       | 25 radians         | 1.25 radians         |
| > 1 to 2        | 50 radians         | 2.5 radians          |
| > 2 to 4        | 100 radians        | 5 radians            |
| > 4 to 8        | 200 radians        | 10 radians           |
| > 8 to 16       | 400 radians        | 20 radians           |
| > 16 to 20      | 800 radians        | 40 radians           |

### 1.5.4.3 Internally Generated PM Envelope

See Option 24 specifications in Section 1.6.1

### 1.5.4.4 External Supplied FM Envelope

#### Waveform

Any waveform compatible with bandwidth considerations

#### Rate

10 Hz to 100 kHz

#### Input Sensitivity, Settable

1 V<sub>p,p</sub> for maximum peak deviation (FM deviation control set to Maximum)

#### Input Impedance

50  $\Omega$  (Nominal)

## 1.5.5 Pulse/Square Wave Modulation (PM)

Specifications apply with Scan/AM and FM off. PM may be operated with FM.

### 1.5.5.1 PM Basic Operation

#### On/Off Ratio

> 80 MHz

#### Rise Fall/Times:

| Rise Time | Frequency Range |
|-----------|-----------------|
| < 10 ns   | > 500 MHz       |
| < 50 ns   | 64 to 500 MHz   |
| < 350 ns  | 25 to 64 MHz    |
| < 500 ns  | < 25 MHz        |

#### Overshoot, Undershoot & Ringing

< 10%, > 500 MHz

#### Settling Time (to within 1 dB)

< 75 ns (for pulse width > 75 ns)

#### Level Pulsed Output Accuracy (Reference to CW Output Power) at $25 \pm 10^\circ \text{C}$

$\pm 0.5 \text{ dB}$ ,  $\geq 100 \text{ ns}$  pulse width ( $\pm 1 \text{ dB}$  pulse width, between 100 ns and 75 ns, Typical). (Requires a typical setup time of 100 ms after initial setting)

#### Typical Settling Time for a Series of Leveled Pulses

100  $\mu\text{s}$

| Demand Pulse Polarity | RF will be on with TTL level demand pulse at Pulse Modulation Input BNC either at high or low logic level, selectable |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------|
|-----------------------|-----------------------------------------------------------------------------------------------------------------------|

#### Time Between Start of Demand Pulse (Video In) & Start of RF Pulse

< 50 ns

#### Minimum Required RF OFF Time between Pulses

100 ns

# Series 12000A Microwave Synthesizers

| Delivered Minimum Pulse Widths |                 |
|--------------------------------|-----------------|
| Minimum Width                  | Frequency Range |
| 20 ns                          | > 500 MHz       |
| 100 ns                         | 64 to 500 MHz   |
| 1 $\mu$ s                      | < 64 MHz        |

## 1.5.5.2 Internally Generated PM Envelope

See Option 24 specifications in Section 1.6.1

## 1.5.5.3 Externally Generated PM Envelope

(One Envelope produced by each pulse)

| Repetition Rate                                                                                                                                                                   |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5 Hz to 5 MHz, leveled<br>DC to 10 MHz, unleveled                                                                                                                                 |
| Pulse Offset Delay (Output Envelope Leading Edge referenced to Input Pulse Leading Edge)                                                                                          |
| 50 ns, typical                                                                                                                                                                    |
| Input Pulse Required                                                                                                                                                              |
| Positive or negative-going TTL voltage Level trigger pulse, $\geq 75$ ns wide (leveled output)<br>$\geq 20$ ns wide (unleveled output). Pulse must be able to drive a 50 ohm load |
| Pulse Width                                                                                                                                                                       |
| Defined by external pulse width                                                                                                                                                   |

## 1.6 Supplemental Specifications (Series 12500A/12700A)

| Supplemental Specifications (Series 12500A/12700A) | Model  |                   |
|----------------------------------------------------|--------|-------------------|
|                                                    | 124XXA | 125XXA/<br>127XXA |
| 1.6.1 - Option 24 Specifications                   | N/A    | √                 |
| 1.6.2 - Option 29 Specifications                   | N/A    | √                 |

### 1.6.1 Option 24 (Internal Modulation Generator) Specifications

#### 1.6.1.1 Amplitude Modulation Source

**Waveform**

Sine, square, triangle, ramp (+ or –), Gaussian Noise

**Rate**

0.01 Hz to 1 MHz, all waveforms

**Resolution**

0.01 Hz

**Accuracy** $\pm 0.01 \text{ Hz} \pm \text{Timebase Accuracy}$ **THD**

1 % (Typical)

**AM Output**2 V<sub>p,p</sub>, into 1 M  $\Omega$

1.6.1.2 Frequency Modulation Source

|                                        |
|----------------------------------------|
| Waveform                               |
| Sine, square, triangle, ramp (+ or -)  |
| Rate                                   |
| 0.01 Hz to 1 MHz, all waveforms        |
| Resolution                             |
| 0.01 Hz                                |
| Accuracy                               |
| $\pm 0.01$ Hz $\pm$ Timebase Accuracy  |
| THD                                    |
| 1 % (Typical)                          |
| FM Output                              |
| 2 V <sub>p,p</sub> , into 1 M $\Omega$ |

1.6.1.3 Pulse Modulation Source

| Rate            |                   |                                                               |  |
|-----------------|-------------------|---------------------------------------------------------------|--|
| 1 Hz to 3 MHz   |                   |                                                               |  |
| Rate Resolution | Range             | Resolution                                                    |  |
|                 | 1 Hz to 1 kHz     | 1 Hz                                                          |  |
|                 | 1 kHz to 10 kHz   | 10 Hz                                                         |  |
|                 | 10 kHz to 100 kHz | 100 Hz                                                        |  |
|                 | 100 kHz to 1 MHz  | 1 kHz                                                         |  |
|                 | 1 MHz to 3 MHz    | 10 kHz                                                        |  |
|                 | Accuracy          | ±2.5% of range maximum value; f <sub>m</sub> < 100 KHz        |  |
|                 |                   | ±4% of range maximum value; f <sub>m</sub> 100 KHz to < 1 MHz |  |
|                 |                   | ±10% of range maximum value; f <sub>m</sub> > 1 MHz           |  |
|                 | Jitter            | Same as instrument timebase                                   |  |

## 1.6.1.4 Pulse Start Variable Delay

(Referenced to Sync Output)

### Range

0 to 1.67 seconds

### Resolution

10 ns

### Accuracy

$\pm 2.5\%$  of setting or  $\pm 20$  ns, whichever is greater

### Jitter

$\pm 0.01\%$  of setting or  $\pm 100$  ps, whichever is greater

## 1.6.1.5 Pulse Width

### Range

0 to 1.67 seconds

### Resolution

10 ns

### Accuracy

$\pm 2.5\%$  of setting or  $\pm 20$  ns, whichever is greater

### Jitter

$\pm 0.01\%$  of setting or  $\pm 100$  ps, whichever is greater

# Series 12000A Microwave Synthesizers

---

## 1.6.1.6

### Pulse Modes

(Triggered, Gated, Delayed, Singlet, Doublet, Triplet, or Quadlet and Free Running)

| Interval   |                                                       |
|------------|-------------------------------------------------------|
| Range      | 100 ns to 1.67 seconds                                |
| Resolution | 10 ns                                                 |
| Accuracy   | $\pm 2.5\%$ of setting or 20 ns, whichever is greater |
| Jitter     | 0.01% of setting or 100 ps, whichever is greater      |



**NOTE:** The interval between pulse one and pulse two, and the interval between triplets and quadlets are the same. The start delay for pulse one is independent.

## 1.6.1.7

### Externally Triggered PM Envelope

(One PM envelope produced by each trigger)

| Repetition Rate                                                                                    |  |
|----------------------------------------------------------------------------------------------------|--|
| 5 Hz to 5 MHz                                                                                      |  |
| Pulse Delay                                                                                        |  |
| Set by internal delay control                                                                      |  |
| Pulse Width                                                                                        |  |
| Set by internal width control                                                                      |  |
| Input Trigger Required                                                                             |  |
| Positive or negative-going TTL Level trigger pulse, >20 ns wide, unleveled or >75 ns wide, leveled |  |

## 1.6.1.8

### PM Sync Output

TTL levels into a 50  $\Omega$  load, 50 ns pulse coincident with start delay

## 1.6.1.9

### PM Video Output

TTL levels into a 50  $\Omega$  load

## 1.6.2 Option 29 (Scan Modulation) Specifications

Specifications apply with FM and PM turned off.

### 1.6.2.1 Envelope Parameters

#### Frequency of Operation

0.01 to 20 GHz

### 1.6.2.2 Scan Mode

#### Range

0 to 60 dB,  $\geq +10$  dBm (Settable to 65 dB)

#### Resolution

0.1 dB

#### Scaling

0 dB/V to 65 dB/V

#### Input Voltage

Minimum: 0 V, Maximum: +6 V

#### Step Response

< 1 microsecond for 50 dB change; < 10 ms, < 1 GHz

#### Frequency Response

DC to 150 kHz, sine wave

#### Input Impedance

600  $\Omega$  (Nominal)

#### Accuracy

$\pm 0.25$  dB plus  $\pm 5\%$  of depth in dB (For .01 to 2 GHz, specification applies only up to 30 dB)

Linearity  $\pm 0.6$  dB (0 - 20 dB),  $\pm 1$  dB (20 - 60 dB)

## Series 12000A Microwave Synthesizers

---

### 1.6.2.3 Internally Generated Scan/AM Envelope

See Specifications for Option 24 in section 1.6.1

### 1.6.2.4 Power

2 dB reduction in power, .01-20 GHz

# Performance Verification

## 2.1 Introduction

| Introduction (Performance Verification) | Model  |                   |
|-----------------------------------------|--------|-------------------|
|                                         | 124XXA | 125XXA/<br>127XXA |
| 2.1.1 - Recommended Equipment           | √      | √                 |

- This chapter provides step-by-step procedures to verify performance of the Series 12000A Microwave Synthesizers for all three models (Modulation related items are in Section 2.3 for the Series 125XXA/127XXA models)
- Sectional header page references are only provided for items pertaining directly to performance verification testing
- The required warm-up time before testing is 72 hours. The warm-up period can be reduced to 30 minutes if timebase accuracy is not to be tested for all three models
- In these procedures, the instrument being tested may be referred to as the 12000A or UUT (Unit Under Test) for all three models

### 2.1.1 Recommended Equipment

The following equipment is recommended before starting the performance test routines (the recommended equipment can be substituted provided the specifications are sufficiently compatible):

**Table 2-1: Series 12000A Recommended Equipment**

| Equipment                                 | Example                                                        |
|-------------------------------------------|----------------------------------------------------------------|
| Frequency Standard                        | 10 MHz Stanford Research FS 725                                |
| Oscilloscope                              | Tektronix TDS3052B or Equivalent                               |
| Microwave Frequency Counter               | XL Microwave 3260 or Equivalent                                |
| Power Meter and Sensor                    | Giga-tronics 8541C/Series 8650A w/ 80313A Sensor or Equivalent |
| Spectrum Analyzer                         | HP 8566B or Equivalent                                         |
| Detector                                  | Herotek Model DZ262-44 or Equivalent                           |
| Function (Audio) Generator                | Stanford Research DS-345 or Equivalent                         |
| Measuring Receiver                        | HP 8902A or Equivalent                                         |
| Distortion Analyzer                       | HP 339A or Equivalent                                          |
| L.O. Generator                            | Giga-tronics Microwave Synthesizer 12720A or Equivalent        |
| Universal Counter                         | Racal Dana 2201 or Equivalent                                  |
| Mixer IF Amplifier w/ Divide-by-40 Output | Giga-tronics Mixer/Divider (P/N 002CA04900)                    |
| Mixer (For Attenuator Test)               | Marki M40020MJ                                                 |
| Filter 21.4 MHz                           | Mini-Circuits SVP 21.4                                         |
| Fixed Attenuator 3 dB                     | Midwest ATT-0263-03-SMA-02                                     |
| Fixed Attenuator 10 dB                    | Midwest ATT-0263-10-SMA-02                                     |

## 2.2 Performance Tests

| Performance Tests                                         | Model  |                   | Page |
|-----------------------------------------------------------|--------|-------------------|------|
|                                                           | 124XXA | 125XXA/<br>127XXA |      |
| <b>2.2.1 - Introduction (Performance Tests)</b>           | √      | √                 | 2-2  |
| <b>2.2.2 - Frequency Range, Resolution &amp; Accuracy</b> | √      | √                 | 2-3  |
| <b>2.2.3 - Spurious Signals Tests</b>                     | √      | √                 | 2-4  |
| <b>2.2.4 - Signal Sideband Phase Noise</b>                | √      | √                 | 2-6  |
| <b>2.2.5 - RF Output Power Tests</b>                      | √      | √                 | 2-7  |

### 2.2.1 Introduction

The procedures in this section verify the electrical performance of the 12000A using the specifications in Chapter 1. Use Section 2.1 for features that are applicable to all three models. Use Section 2.3 for native specification data for the Series 125XXA/127XXA models.

Each of the performance tests includes a list of recommended test equipment. There is a consolidated list at the beginning of this chapter. Equivalent test equipment can be substituted provided that the accuracies and specifications are sufficiently compatible.

A test data sheet is included for entering the various readings taken. The specification and tolerance range is listed for ease of verification. It is suggested that copies be made of the manual sheets. When automated tests are run, a printed data sheet is produced.

Performance verification is recommended at least every two years, or more often when required to ensure proper operation of the instrument.

Each procedure specifies a required warm-up time if the procedure is to be done individually. Only one warm-up period is required for a sequence of tests. Test equipment must be warmed up according to specifications.

## 2.2.2 Frequency Range, Resolution & Accuracy

### 2.2.2.1 Description

Connect the 12000A RF output to the input of a frequency counter. The internal timebase of the counter is a reference for the 12000A to eliminate timebase errors from the measurements. This procedure does not check for timebase accuracy, and therefore the frequency in the 12000A display should agree with the counter, within the resolution of each instrument. It is possible for a fault in the 12000A to cause a frequency error even though the lock indicators show normal operation. For this reason a number of specific frequencies are tested. Test frequencies have been selected so that any defective circuits will be easily isolated.

### 2.2.2.2 Equipment Required

UUT • Frequency Counter • Coaxial Cable




Figure 2-1: Frequency Range, Resolution & Accuracy

### 2.2.2.3 Procedure

1. Connect the equipment as shown in Figure 2-1. Connect the 12000A RF Output to the 10 to 500 MHz counter input using the coaxial cable and the SMA to BNC adapter. Allow the equipment to warm up for at least 30 minutes. Because the 12000A and the counter use the same timebase, timebase errors are eliminated. The 12000A will automatically switch to the external reference when it is connected.
2. Set the 12000A to 10 MHz. Press **[LEVEL]** in the POWER field and enter **[-] [1] [0] [DBM]**. Press **[RF ON]** in the RF OUTPUT field to turn on the RF output.
3. Set the 12000A to each frequency listed on the data sheet and verify that the counter reads the set frequency plus or minus the counter resolution. This tests each divider stage.
4. Connect the 12000A RF Output to the 500 MHz to 26.5 GHz input on the counter and continue with the divider tests.
5. To check that the multipliers are functioning properly, refer to the test data sheet and program each of the listed frequencies into the 12000A by entering (for example) **[CW] [2] [0] [0] [1] [MHZ]**. For each listed frequency the counter should read the entered frequency  $\pm 1$  Hz, plus or minus the counter resolution. Ignore all frequencies outside the range of the instrument under test.

### 2.2.3 Spurious Signals Tests

#### 2.2.3.1 Description

The output of the 12000A is connected to a spectrum analyzer. Various frequencies are selected and the analyzer tuned to determine the presence of either harmonically or non-harmonically spurious signals.

#### 2.2.3.2 Equipment Required

UUT • Spectrum Analyzer • Coaxial Cable




Figure 2-2: Spurious Signals Tests

#### 2.2.3.3 Procedure

1. Connect the equipment as shown in Figure 2-2. Allow the equipment to warm up for at least 30 minutes. Press **[CW]** in the FREQUENCY field on the 12000A and enter the first test data sheet frequency within the range of the 12000A. The RF amplitude should be at +6 dBm. Press **[RF ON]** to turn on the RF output. Be certain that all modulation is OFF.
2. Set the spectrum analyzer to view the 12000A output signal. Adjust the analyzer reference level so that the peak of the displayed signal is at the top graticule line.
3. Set the spectrum analyzer to maximum span with the signal centered on the screen. Gradually narrow the span, keeping the signal centered, to observe any spurious signals. Use appropriate resolution and video bandwidths to allow sufficient dynamic range.
4. Repeat steps 2 and 3 for the other frequencies on the test data sheet which are within the operating range of the instrument.

Many spectrum analyzers have a tuned preselector when the frequency is above about 2 GHz. This reduces the likelihood of analyzer generated spurious signals, but does not eliminate the possibility. If in doubt, increase the RF attenuation of the analyzer by 10 dB. The signal in question should be reduced by exactly 10 dB. If not, it is analyzer generated. It is also important for frequencies below the range of the preselector that sufficient analyzer RF Attenuation be used (typically 30 dB) to avoid the analyzer generating harmonics of the input signal. The above attenuator shift technique will also allow verification of harmonic levels.

If a spurious signal appears to be out of specification, first check that the fundamental signal level is at +6 dBm. Next verify the analyzer accuracy by connecting a known amplitude signal (from the 12000A, for example) at the spurious frequency.

The adjusting knob on the 12000A may generate some noise spikes when it is rotated. The acquisition of the various phase lock loops in the instrument can also cause transients (within the specified settling time). Both of these effects will disappear when a steady state condition has been reached.

It is important to identify the particular class of spurious signal as the specifications may be different for each. If the spurious signal is an exact multiple of the 12000A RF output then the harmonic specification applies. Any other spurious signals must meet the non-harmonically related specification.

For frequencies above the fundamental range of the spectrum analyzer, either a mixer supplied with the spectrum analyzer or an external mixer and local oscillator may be used to downconvert the signal. Care must be taken to identify spurious signals which are inherently generated by the mixing process.

### 2.2.4 Single Sideband Phase Noise

#### 2.2.4.1 Description

The test in this procedure is limited by the measuring system and verifies only the majority of the phase noise specification. To completely test the phase noise specification requires a far more sophisticated measurement system. This test uses the spectrum analyzer to make all measurements from 100 Hz to 1 MHz offsets. The 100 Hz and 1 MHz offsets are particularly susceptible to measurement system limitations.

#### 2.2.4.2 Equipment Required

UUT • Spectrum Analyzer • Coaxial Cable




Figure 2-3: Single Sideband Phase Noise

#### 2.2.4.3 Procedure

1. Connect the 12000A RF output to the spectrum analyzer input. Place the 12000A on a foam pad to isolate it from any external mechanical vibrations, which could affect the phase noise measurement.
2. Turn off all modulation on the 12000A.
3. For the first frequency on the test data sheet within the range of the instrument, press **[CW]** and enter the frequency. Tune the spectrum analyzer to the generator frequency and adjust the 12000A RF level to obtain a reference of 0 dBm on the analyzer. This allows direct measurement of the phase noise by the analyzer.
4. Set the analyzer span such that the desired offset is at  $\pm 2$  divisions, select an appropriate bandwidth, activate the phase noise measurement and place the marker two divisions to the right of the carrier. Read the phase noise in dBc/Hz. Repeat for all offsets.
5. Repeat steps 3 and 4 for the other test data sheet frequencies which are within range of the 12000A.

## 2.2.5 RF Output Power Tests

### 2.2.5.1 Description

Although it is possible to make the following measurements manually, it is extremely tedious. It is recommended that an automated system be set up to take and record the data. Three tests are run. The first measures the maximum available output with the level control loop disabled. The second verifies the accuracy and flatness across the operating frequency range at a fixed output (0 dBm). The remaining test checks the step attenuator accuracy at a number of frequencies. This section outlines the general procedure followed by the automated system, a similar measurement could be done manually.

### 2.2.5.2 Equipment Required

UUT • Local Oscillator • Measuring Receiver & Sensor • Downconverter • Plotter • Computer & Programs




Figure 2-4: RF Output Power Test

### 2.2.5.3 Procedure (Output Power)


1. Connect the power sensor to the 12000A. Disable the leveling system of the 12000A. Step the frequency across the particular instrument operating range in 50 MHz increments. At each point measure the power, apply the appropriate sensor correction factor, and plot the result.
2. Using the above setup, set the 12000A to 0 dBm with the leveling enabled. Again, step the frequency across the operating range; measure, correct, and plot the power.
3. Repeat this procedure for the remaining test frequencies.



**NOTE:** When measuring the flatness and accuracy of the model 12000A, consideration must be given to the various measurement uncertainties in the test system. These include, but are not limited to, VSWR, Cal Factor uncertainty and calibration.

### 2.2.5.4 Procedure (Attenuator Test: Option 26)

1. Connect the 12000A to the measuring receiver via the downconverter. With the 12000A at 0 dBm and set to the first test frequency; set LO 21.4 MHz above UUT set frequency. Establish a reference on the receiver in a tuned RF level mode. Reduce the 12000A output in 10 dB steps, observing and recording the receiver reading. As needed, perform the recalibration requested by the receiver.



**Figure 2-5: RF Output Power Attenuator Test**

2. Repeat this procedure for the remaining test frequencies.



**NOTE:** When measuring the flatness and accuracy of the model 12000A, consideration must be given to the various measurement uncertainties in the test system. These include, but are not limited to, VSWR, Cal Factor uncertainty and calibration.

## 2.3 Performance Tests (Series 12500A/12700A)

| Performance Tests (Series 12500A/12700A)           | Model  |                   | Page |
|----------------------------------------------------|--------|-------------------|------|
|                                                    | 124XXA | 125XXA/<br>127XXA |      |
| 2.3.1 - Amplitude Modulation Test                  | N/A    | √                 | 2-10 |
| 2.3.2 - Frequency Modulation Test                  | N/A    | √                 | 2-12 |
| 2.3.3 - Pulse Modulation On/Off Ratio Test         | N/A    | √                 | 2-15 |
| 2.3.4 - Pulse Modulation Rise & Fall Time Test     | N/A    | √                 | 2-16 |
| 2.3.5 - Pulse Modulation Overshoot & Settling Time | N/A    | √                 | 2-17 |
| 2.3.6 - Pulse Modulation Accuracy Test             | N/A    | √                 | 2-18 |

Use the Performance Verification Test Data Sheet provided at the end to record your data. The data sheet is compatible with all three models.



**NOTE:** Units that have Option 24 will have these tests repeated using the internal generators.

### 2.3.1 Amplitude Modulation Test

#### 2.3.1.1 Description

The output from the 12000A is connected to a discriminator. The discriminator output is monitored on an oscilloscope to determine deviation and bandwidth.

#### 2.3.1.2 Equipment Required

UUT • Mixer/Divider • Oscillator • Measuring Receiver




Figure 2-6: Amplitude Modulation Test

#### 2.3.1.3 Procedure (AM Depth)

1. Set UUT to **1.5 GHz** with level set at 0 dBm. Connect UUT output to the Mixer Box RF input connector with a 10 dB pad.
2. Connect LO (Source) output to the Mixer Box LO input connector. Set LO frequency to 130 MHz higher than UUT and set source leveled output to 10 dBm.
3. Connect Direct output of Mixer Box to the HP 8902 Measuring Receiver RF input.
4. Connect Modulation Output/Audio Input to channel 2 of Oscilloscope.
  - a. Set to 500 mV per Division.
5. On Measuring Receiver press **[FREQUENCY]** and verify 130 MHz on receiver.
6. Select **AM**, set measuring receiver filters to 50 Hz and 15 KHz. Press **[ (PEAK-PEAK)/2 MODE ]**.
7. On UUT turn **AM** on. Set depth to 50%. Connect the DS-345 Function Generator at 1 KHz modulation to the AM input. Set scope to 50 Ohm termination and sinewave amplitude for a

- 2 V<sub>P-P</sub> signal. Press **[AM]** button on Measuring Receiver. Verify a reading of 40.0 to 60.0% on the measuring receiver.
8. Set external function to **SQR**. Turn off all filters on the measuring receiver. Verify a receiver reading of 40.0 to 60.0% (Typical).
  9. Set external function to **TRI** and verify that the measuring receiver reads 40.0 to 60.0%
  10. Set UUT to **10 GHz**. Repeat Steps 2 to 8.
  11. At 1.5 and 10 GHz, check AM Depth at 30, 90% modulation. Verify accuracy of +/- 10% of reading at each step.
  12. Enter data in the **AM Modulation Test - AM Depth** area of the Series 12000A Microwave Synthesizers Performance Verification Data Sheet, Section 2.3.1.3.

### 2.3.1.4 Procedure (AM Bandwidth)

1. Set UUT to **1.5 GHz** with level set at 0 dBm. Set AM Depth to **50% @ 1 KHz rate** (Sinewave).
2. Verify a 50% reading on HP 8902 with filters turned off. On receiver, press **[RATIO]**, then the **[LOG/LIN]** button, display indicates 0.00 dB.
3. Vary the frequency of the external DS-345 Function Generator from DC to 150 KHz. Verify that the amount of change is within the +/- 3 dB window.
4. Repeat steps 1 to 3 for 10 GHz.
5. Complete the **AM Modulation Test - AM Bandwidth** area of the Series 12000A Microwave Synthesizers Performance Verification Data Sheet, Section 2.3.1.4.

### 2.3.2 Frequency Modulation Test

#### 2.3.2.1 Description

The output from the 12000A is connected to a discriminator. The discriminator output is monitored on an oscilloscope to determine deviation and bandwidth.

#### 2.3.2.2 Equipment Required

UUT • Function Generator • Oscilloscope • Digital Voltmeter • FM Test Fixture




Figure 2-7: Frequency Modulation Test

#### 2.3.2.3 Delay Discriminator Description

In order to calibrate and test the frequency modulation circuits, a special test fixture must be assembled. The recommended FM test fixture includes an RF splitter, two lines of unequal length, and an RF mixer. The RF output of the 12000A is divided by the splitter into two signals, unequally delayed.

Different length cables determine the number of frequency nulls or 0 volt outputs found in the frequency band of interest. For the Frequency Modulation performance test, the frequency band of interest is 4 to 8 GHz.

The procedure does not identify a specific mixer for the discriminator circuit. There are two factors to consider when selecting a mixer.

1. The mixer RF and LO frequency range must be greater than 4 to 8 GHz.
2. A low conversion loss mixer will provide a higher output.

### Maximizing Delay Discriminator Output

Obtaining a six division change on a 5 mV scale may be difficult to obtain for a 1 MHz change in frequency. Increasing output power will improve the output of the discriminator. The output of the UUT can be adjusted to levels as high as +13 dBm or higher for the 4 to 8 GHz frequency band. The output performance of discriminator is improved with a very high cable length ratio. Cable length ratios of 16 to 1 (48 inches to 3 inches) will produce a large number of frequency nulls within the 4 to 8 GHz frequency band.



---

**NOTE:** Increasing the number of frequency nulls increases the rate of change of the output voltage per unit frequency as the output transitions through the frequency null.

---

### Optimal Test Performance Null Selection

The maximum deviation of the Frequency Modulation test is  $\pm 10$  MHz. The rate of change for the output voltage per unit frequency ( $\Delta V/\Delta F$ ) must remain constant (linear) for the  $\pm 10$  MHz deviation range. Rate changes within this deviation range will result in a non-symmetrical waveform and will produce invalid test results.

Identifying an optimal frequency null is achieved by sweeping the frequency through the frequency range of the test and observing the Delay Discriminator waveform on an oscilloscope.

### Recommended Test Equipment (FM)

- Delay Discriminator
- Digital Oscilloscope
- Pulse Generator with 1 shot Capability
- BNC Cables and Tee

### Recommended Configuration

1. Connect the input of the delay discriminator to the RF output of the 12000A and the output to the digital scope.
2. Set the 12000A to Sweep Mode with the following settings:
  - a. Start Frequency: 4 GHz
  - b. Stop Frequency: 8 GHz
  - c. Sweep Type: Ramp
  - d. Sweep Time: 900 msec
  - e. Repeat Mode: Single Sweep
  - f. Trigger Type: Trigger in BNC
  - g. Power: +10 dBm
3. Connect the output of the pulse generator to the External Trigger Input or second channel of the digital scope and the Trigger In of the 12000A.
4. Set the trigger selection of the digital scope to the port where the trigger signal will be detected (Use the BNC Tee at this port).

5. Adjust the time base of the digital scope to 1 second for the entire span of the X axis (100 mSec typical). Set the vertical scale to 100 mV per division.
6. Pulse the generator to initiate the RF sweep.

Repeat the sweep several times. The output of the Delay Discriminator should not vary from one sweep to another. Review the waveform and identify the nulls where the voltage transitions through the nulls are steeper and linear for a  $\pm 50$  mV range above and below the null. Perform the FM modulation tests at these frequency nulls.

For certain frequencies, which may be identified by experiment, the mixer will produce a DC voltage near zero. The number of null frequencies can be increased by making the delay lines longer in absolute terms or by increasing the ratio between their lengths. If the output becomes frequency modulated, the mixer output voltage will change, and the voltage variation will be proportional to FM deviation.

The polarity of the voltage change may be either directly or inversely related to the direction of frequency deviation. When voltage levels have been established for different frequencies, the mixer output can be monitored on an oscilloscope to provide a continuous display of FM deviation.

### 2.3.2.4 Procedure

1. Connect the FM test fixture to the RF OUT connector of the 12000A as shown in Figure 2-7. Monitor the mixer output with the oscilloscope (5 mV/div). Set the 12000A to any null frequency between 4.0 and 7.99 GHz (that is, at a frequency where the mixer output voltage is zero); +10 dBm out, no modulation.
2. Establish the voltage at 1 MHz above and 1 MHz below the null frequency. Adjust the oscilloscope gain and the 12000A output power level (near +5 dBm) to place the null point at the center of the screen and the 1 MHz deviation points at 3 divisions above and 3 divisions below the null point.
3. Set the 12000A to Narrow EXT FM with 1 MHz deviation. Connect the function generator, set to a 100 kHz rate SINE wave, 2 V<sub>P-P</sub>. Verify that the waveform is 6 divisions peak-to-peak.
4. Adjust the 12000A FM deviation for exactly a six division peak-to-peak display. Vary the function generator from 10 Hz to 1 MHz and verify that the display remains between five and seven divisions peak-to-peak.
5. Vary the function generator from 1 MHz to 8 MHz and verify that the display remains between 4 and 8 divisions.
6. Establish the voltage at 10 MHz above and below the null frequency. Adjust the oscilloscope gain and the 12000A output power level (near +5 dBm) to place the null point at the center of the screen and the 10 MHz deviation points at 3 divisions above and 3 divisions below the null point (terminate the Mixer output in 50  $\Omega$ ).
7. Set the 12000A to Wide EXT FM with 10 MHz deviation. Set the function generator to 100 kHz. Verify that the waveform is 6 divisions peak-to-peak.
8. Adjust the 12000A FM deviation for exactly a 6-division peak-to-peak display. Vary the function generator from 100 Hz to 1 MHz and verify that the display remains between 4.7 and 7.3 divisions.
9. Vary the function generator from 1 MHz to 8 MHz and verify that the display remains between 4 and 8 divisions.

## 2.3.3 Pulse Modulation On/Off Ratio Test

### 2.3.3.1 Description

The 12000A is set to a CW frequency at a power level of 0 dBm. A spectrum analyzer is used to view the signal. The pulse modulation is then enabled and the resulting waveform is measured.

### 2.3.3.2 Equipment Required

UUT • Spectrum Analyzer • Pulse Generator • Coaxial Cable




Figure 2-8: Pulse Modulation On/Off Ratio Test

### 2.3.3.3 Procedure

1. Connect the equipment as shown in Figure 2-8. Allow 30 minutes warm-up time.
2. Enter the first frequency on the test data sheet within the frequency range of the instrument. The RF power level should be at 0 dBm. Select external pulse modulation (PM) on the 12000A.
3. Tune the analyzer to the source frequency, select an analyzer span of 0 Hz and fine tune the analyzer to place the line at the top of the screen graticule (adjust analyzer reference level as needed).
4. Set the pulse generator for a 100 Hz square wave; press **[PULSE]** then use the softkey to turn on the pulse modulation.
5. Adjust the analyzer sweep time to display a few cycles of the waveform. Use internal triggering. Reduce resolution bandwidth and carefully retune the analyzer center frequency until the maximum resolution is achieved. Read and record the peak-to-peak value (use marker delta).
6. Repeat steps 3, 4 and 5 for all other test data sheet frequencies which are within the range of the instrument. Note that the dynamic range of the analyzer may limit its measurement capability.

## Series 12000A Microwave Synthesizers

---

### 2.3.4 Pulse Modulation Rise & Fall Time Test

#### 2.3.4.1 Description

A crystal detector is connected to the 12000A, terminated in 50  $\Omega$ , and monitored with an oscilloscope.



**NOTE:** It is very important to use either the specified detector or one with similar rise time characteristics. Even when terminated in 50  $\Omega$  with a short cable, the detector parameters can markedly influence the measurement.

---

#### 2.3.4.2 Equipment Required

UUT • Oscillator • Pulse Generator • Crystal Detector • Coaxial Cable




Figure 2-9: Pulse Modulation Rise/Fall Time Test

#### 2.3.4.3 Procedure

1. Connect the equipment as shown in Figure 2-9. The cable from the detector to the oscilloscope should be kept as short as possible.
2. Press **[PRESET]** on the 12000A and set the frequency to the first test data sheet frequency within the operating range of the instrument.
3. Enable external pulse modulation (at a 1 MHz rate and 0.5  $\mu$ s width) on the 12000A. Press **[PULSE]** and use the softkey to turn on pulse modulation.
4. Set the oscilloscope to 5 mV/div and using the RF Level control of the 12000A, adjust the peak to peak oscilloscope display to fall on the dotted lines on the screen (100% and 0%). Adjust the oscilloscope sweep time to 5 ns/div. Measure and record the rise and fall times between the 10% and 90% points.
5. Repeat Step 4 for each of the test data sheet frequencies within the operating range of the instrument.

## 2.3.5 Pulse Modulation Overshoot & Settling Time

### 2.3.5.1 Description

A crystal detector is connected to the 12000A, terminated in 50  $\Omega$  and monitored with an oscilloscope.



**NOTE:** It is very important to use either the specified detector or one with similar rise time characteristics. Even when terminated in 50  $\Omega$  with a short cable, the detector parameters can markedly influence the measurement.

### 2.3.5.2 Equipment Required

UUT • Oscillator • Pulse Generator • Crystal Detector • Coaxial Cable




Figure 2-10: PM Overshoot and Setting Time

### 2.3.5.3 Procedure

1. Connect the equipment as shown in Figure 2-10. The cable from the detector to the oscilloscope should be kept as short as possible.
2. Press **[PRESET]** on the 12000A and set the frequency to the first test data sheet frequency within the operating range of the instrument.
3. Enable external pulse modulation (at a 1 MHz rate and 0.5 ms width) on the 12000A. Press **[PULSE]** and use the softkey to turn on pulse modulation.
4. Set the oscilloscope to 5 mv/div and using the RF Level control of the 12000A and the vertical position of the oscilloscope, adjust the peak to peak oscilloscope display to be from the top of the screen (pulse off) to 2 divisions below the center line (pulse on). Adjust the oscilloscope sweep time to 50 ns/div. Change the level setting of the 12000A by plus and minus 1 dB and note the graticule position of the pulse on level. Return to the original value. Measure and record the time for the pulse to be within 1 dB of its final value.
5. Change the level setting of the 12000A by plus and minus 2 dB and note the graticule position of the pulse on level. Return to the original level. Measure and record any undershoot/overshoot of the signal.
6. Repeat Steps 4 and 5 for each of the test data sheet frequencies within the operating range of the instrument.

## Series 12000A Microwave Synthesizers

---

### 2.3.6 Pulse Modulation Accuracy Test

#### 2.3.6.1 Description

In this test the peak pulse level is compared to the level in the CW mode.

#### 2.3.6.2 Equipment Required

UUT • Oscilloscope • Pulse Generator • Crystal Detector • Coaxial Cable




Figure 2-11: Pulse Modulation Accuracy Test

#### 2.3.6.3 Procedure

1. Connect the equipment as shown in Figure 2-11. The oscilloscope input impedance should be 50  $\Omega$ . Allow 30 minutes warm-up.
2. Press **[PRESET]** on the 12000A and set the frequency to the first test data sheet frequency within the operating range of the instrument.
3. Set the oscilloscope to 5 mv/div and using the vertical position of the oscilloscope, adjust the trace to the centerline of the screen. Change the level setting of the 12000A by plus and minus 1 dB and note the trace position on the screen. Return to 0 dBm.
4. Enable external pulse modulation (at a 200 kHz rate and 0.1  $\mu$ s width) on the 12000A. Press **[PULSE]** and use the softkey to turn on pulse modulation.
5. Measure and record the difference between the CW reference level and the negative peak of the pulse.
6. Change the pulse width to 50 ns and again measure and record the difference between the CW reference level and the negative peak of the pulse.
7. Repeat Steps 3-6 for each test data sheet frequency within the operating range of the instrument.

## SERIES 12000A MICROWAVE SYNTHESIZERS

### Performance Verification Test Data Sheet (Page 1 of 2)

Under Test Result record measured values (if any). In the case of a function check or range check, write OK to indicate that the unit under test meets specifications.

|                |  |                    |  |
|----------------|--|--------------------|--|
| Serial Number: |  | Tested By:         |  |
| Date:          |  | Quality Assurance: |  |

#### Frequency Range, Resolution, Accuracy

| 2.2.2.3 | Frequency | Harmonics |
|---------|-----------|-----------|
|         | 12 MHz    |           |
|         | 24 MHz    |           |
|         | 48 MHz    |           |
|         | 100 MHz   |           |
|         | 200 MHz   |           |
|         | 400 MHz   |           |
|         | 750 MHz   |           |
|         | 1500 MHz  |           |
|         | 3 GHz     |           |
|         | 6 GHz     |           |
|         | 12 GHz    |           |
|         | 18 GHz    |           |

#### Spurious Signals Tests

| 2.2.3.3 | Frequency (MHz) | Harmonics | Non-Harmonics |
|---------|-----------------|-----------|---------------|
|         | 770.550         |           |               |
|         | 1513.425        |           |               |
|         | 4004.000        |           |               |
|         | 9182.433        |           |               |
|         | 17361.522       |           |               |

#### Single Sideband Phase Noise (dBc/Hz)

| 2.2.4.3 | Frequency (MHz) | Offset from Carrier |       |        |         |       |
|---------|-----------------|---------------------|-------|--------|---------|-------|
|         |                 | 100 Hz              | 1 kHz | 10 kHz | 100 kHz | 1 MHz |
|         | 1513.425        |                     |       |        |         |       |
|         | 4004.000        |                     |       |        |         |       |
|         | 9182.433        |                     |       |        |         |       |
|         | 17361.522       |                     |       |        |         |       |
|         | 23541.349       |                     |       |        |         |       |

#### RF Output Power

| 2.2.5.3 | Test Result                      |          |  |
|---------|----------------------------------|----------|--|
|         | Max. Power Level                 |          |  |
|         | Power Level                      |          |  |
| 2.2.5.4 | Step Attenuator Test Frequencies | 1.0 GHz  |  |
|         |                                  | 4.0 GHz  |  |
|         |                                  | 12.0 GHz |  |
|         |                                  | 17.0 GHz |  |

## Series 12000A Microwave Synthesizers

### SERIES 12000A MICROWAVE SYNTHESIZERS

#### Performance Verification Test Data Sheet (Page 2 of 2)

|                |  |                    |  |
|----------------|--|--------------------|--|
| Serial Number: |  | Tested By:         |  |
| Date:          |  | Quality Assurance: |  |

#### Amplitude Modulation Test (SERIES 12500A/12700A ONLY)

| AM Depth (+/- 10%)            |                   | 30%  |      | 50%  |      | 90%  |      |
|-------------------------------|-------------------|------|------|------|------|------|------|
| 2.3.1.3                       | Frequency 1.5 GHz | Int. | Ext. | Int. | Ext. | Int. | Ext. |
|                               | Sinewave          |      |      |      |      |      |      |
|                               | Square Wave       |      |      |      |      |      |      |
|                               | Triangle Wave     |      |      |      |      |      |      |
|                               | Frequency 10 GHz  | Int. | Ext. | Int. | Ext. | Int. | Ext. |
|                               | Sinewave          |      |      |      |      |      |      |
|                               | Square Wave       |      |      |      |      |      |      |
|                               | Triangle Wave     |      |      |      |      |      |      |
| AM Bandwidth (Spec. +/- 3 dB) |                   | Int. |      | Ext. |      |      |      |
| 2.3.1.4                       | Frequency 1.5 GHz |      |      |      |      |      |      |
|                               | Frequency 10 GHz  |      |      |      |      |      |      |

#### Frequency Modulation Test (SERIES 12500A/12700A ONLY)

| Parameter |                           | @1 GHz | @4 GHz | @12 GHz | @20 GHz |
|-----------|---------------------------|--------|--------|---------|---------|
| 2.3.2.3   | Deviation (5.7 - 6.3 div) |        |        |         |         |
|           | Bandwidth (5 - 7 div)     |        |        |         |         |
|           | Bandwidth (4 - 8 div)     |        |        |         |         |
|           | Deviation (5.7 - 6.3 div) |        |        |         |         |
|           | Bandwidth (5 - 7 div)     |        |        |         |         |
|           | Bandwidth (4 - 8 div)     |        |        |         |         |

#### Pulse Modulation Test (SERIES 12500A/12700A ONLY)

| Frequency (GHz) |                    | 1.0 | 4.0 | 12.0 | 20 |
|-----------------|--------------------|-----|-----|------|----|
| 2.3.3           | On/Off             |     |     |      |    |
| 2.3.4           | Rise/Fall          |     |     |      |    |
| 2.3.5           | Overshoot/Settling |     |     |      |    |
| 2.3.6           | Accuracy           |     |     |      |    |

# Calibration

## 3.1 Introduction

| Introduction (Calibration) | Model  |                   |
|----------------------------|--------|-------------------|
|                            | 124XXA | 125XXA/<br>127XXA |
|                            | √      | √                 |

The Series 12000A features completely 'closed case' calibration. There are no mechanical adjustments anywhere in the instrument and all calibration is done under computer program control. Prior to performing any of the calibration procedures, allow the instrument to operate for at least 30 minutes. The calibration process is divided into sections of related steps. Each section should be performed in its entirety.



**NOTE:** In order to verify performance after calibration, refer to Chapter 2.

The Calibration Control Program runs on a Pentium based Windows 95/98® PC. The computer may use either a Capital Equipment Corporation CEC488 IEEE 488 interface or a National Instrument IEEE 488 interface. Please refer to the instructions below on installing the program.

1. Insert CD-ROM into CD-ROM drive.
2. Open the Windows Explorer program by right clicking the **Start** button and selecting **Explore**.
3. Select **(D:)** drive for opening and reading the CD-ROM or the drive used on your PC for reading CD-ROMs.
4. Copy the 12000A Calibration folder, 31232.pdf, 31232.doc and the README.txt files to a directory of your choice.
5. Open the 12000A Calibration folder and click on **12000 Cal V\_3-38.exe** file. Drag the file onto your desktop to create the 12000A Calibration Program shortcut.



**NOTE:** Do not right click the file and use *Send to > Desktop (Create shortcut)* feature. It does not create a shortcut for this program.

6. Open and print the Calibration Procedure 31232.pdf or the 31232.doc prior to performing any calibration sequence.
7. Double click the 12000A Calibration program icon you created in Step # 5 to run the program.

3.2 Equipment & Documentation Required

| Equipment & Documentation Required | Model  |                       |
|------------------------------------|--------|-----------------------|
|                                    | 124XXA | 125XXA/<br>127XXA     |
|                                    | √      | √<br>(See Also 3.2.2) |

3.2.1 All Models

- Giga-tronics 12000 Cal Software CD (P/N 32464)
- Pentium™ PC with Windows 95/98™, Equipped with National Instrument IEEE 488™ Interface (Version NI-488/NI-488.2)
- Giga-tronics 8651A or 8652A Power Meter
- Giga-tronics 80313A Sensor
- Giga-tronics Series 12000A Microwave Synthesizer
- Giga-tronics Series 12000A Microwave Synthesizer Service Manual (P/N 31232)
- Male “N” to Female “K” Adapter (Only for Synthesizer Equipped with Option 23)
- 10 MHz Frequency Standard, Accuracy better than 1E-10, 5 to 5 V<sub>P-P</sub> into 100 ohms (Stanford Research FS 725 or Equivalent)


3.2.2 Additional Requirements (Series 125XXA/127XXA Only)

- DC Voltage Source 0-10 VDC, .5% Accuracy, 100 mA (Tektronix™ PS280 or Equivalent)
- Audio Oscillator, 10 Hz-200 kHz, 2 V<sub>P-P</sub> +/- .01 V into 50 ohm (Stanford Research™ DS-345 or equivalent)
- HP™ 8902A Measuring Receiver
- Giga-tronics Series 12520A or 12720A Synthesizer
- Giga-tronics Mixer/Divider (P/N 002CA04900)
- Digital Voltmeter 3 ½ digits (Fluke™ 8920A or Equivalent)

### 3.3 Calibration Program Initialization

| Calibration Program Initialization | Model  |                   |
|------------------------------------|--------|-------------------|
|                                    | 124XXA | 125XXA/<br>127XXA |
|                                    | √      | √                 |


Connect the 12000A to the computer IEEE 488 interface and start the “12000A Calibration Program”. The following window will display: Click **Connection** and select which GPIB Controller card to use.



1. Be sure that the 12000A address is set to the same value as the setting in the GPIB Address block. Similarly, set the power meter address. Leave the counter address set to 1 (At this time, a counter is not needed).
2. Click on **Connection** and select the PC GPIB controller which will be used: **National Instrument** or **CEC**.
3. Click on the “**Read Parameter Block**” bar and the program interrogates the 12000A. The 12000A display will be blank. The program puts the 12000A in ‘DU7’ mode which only displays communication errors.

# Series 12000A Microwave Synthesizers


- 4. When this process starts, a ‘timer’ window will appear to insure that the 12000A is fully stabilized before measurements are made. Click ‘OK’ button to see how much time remains.



A window will now appear that lists the dates for the current calibration. Note that the “Detector (CW)” and “Loop Gain” dates are always the same since this data is loaded from a generic table and is not instrument specific.

| Characterization Date, done by V-3.36      |                |
|--------------------------------------------|----------------|
| Modulator (AM/PM)                          | 11/12/99 10:47 |
| Detector (CW)                              | 11/12/99 11:07 |
| Loop Gain                                  | 11/12/99 11:24 |
| Frequency Comp. ( 0 dBm to 15 dBm)         | 02/08/00 16:27 |
| Frequency Comp. with Attenuator ( < 0 dBm) | Unknown        |
| Frequency Comp. High Power ( > 16 dBm)     | Unknown        |
| AM Linear Calibration                      | Unknown        |
| AM Scan                                    | Unknown        |
| FM Linearization                           | Unknown        |
| Attenuator serial# yyyyyyyyyyyyyyyyyyy     | Unknown        |

Another window is also displayed to allow viewing a variety of data. See the addendum in section 3.8 for a description of the monitor features.




When the Read Parameter process is complete, the main window will look approximately like this (after clicking on it) (The FM, AM or Modulator (Scan) Characterize buttons are not applicable to the Series

## Series 12000A Microwave Synthesizers

---

124XXA as depicted in the illustration below):



The window now has control 'buttons' to select which calibration process is to be performed. The Parameter block also changes and shows the serial number, frequency range and which options are present.

This completes the initialization of the Calibration Control Program. The various calibration processes may now be performed.

The top "button" allows calibrating the timebase and setting the contrast of the LCD, if desired. These functions may also be performed at any time from the 'Config' menu on the instrument. See the next page for a detailed description of the process to calibrate the timebase.



---

**NOTE:** The 'Modulator (Level Test)' must be performed prior to performing 'AM Calibration' or 'Frequency Response'.

---

## 3.4 Timebase Calibration

| Timebase Calibration | Model  |                   |
|----------------------|--------|-------------------|
|                      | 124XXA | 125XXA/<br>127XXA |
|                      | √      | √                 |

The timebase oscillator used in the 12000A operates at a frequency of 10 MHz and uses Electronic Frequency Control to adjust its output frequency. The calibration is performed entirely by the 12000A without the need for an external computer. Prior to performing this calibration the instrument should be connected to the mains for at least 24 hours. It is not necessary to have the instrument on. Note that calibration accuracy is directly related to the accuracy of the external standard.




**NOTE:** Updating firmware may clear the calibration data.



**NOTE:** Use the 'LCD/Timebase' button for units with firmware V073-B49-22 and higher. Otherwise, just perform the steps listed under 3 below.

1. Click on the LCD/Timebase button.
2. Per the action required window, set the timebase as described next.
3. To set the timebase:
  - a. Press the front panel **'Local'** button
  - b. Turn on the instrument and allow a **15 minute warm-up**.
  - c. Connect the frequency standard to the rear panel 'Ref In' BNC connector.
  - d. Press the **'Config'** softkey, then the **'Service'** softkey, then the **'Hardware Testing'** softkey. Either a 5 or a 10 MHz reference frequency may now be selected using the up/down buttons.
  - e. Now press the **'Time Base Cal'** softkey.
  - f. Press the **'Cal'** softkey to store the calibration.
4. The Contrast Adjustment window will now appear.



- a. Click on the window. Use the mouser (or the keyboard left and right arrow keys) to move the slider pointer. The word 'value' will change to a number showing the contrast value.
- b. Press Enter after a good viewing contrast is attained.

## Series 12000A Microwave Synthesizers

---

- c. A message window will show Characterization Complete. Click OK. Power the 12000A down and back up.
- d. After the Fixed Frequency screen is displayed on the 12000A, click the Read button under the parameter block to re-establish program control.


## 3.5 Output Amplitude Calibration

| Output Amplitude Calibration              | Model  |                   |
|-------------------------------------------|--------|-------------------|
|                                           | 124XXA | 125XXA/<br>127XXA |
| 3.5.1 - ALC Characterization Instructions | √      | √                 |

There are number of steps in this section. These steps provide data that the instrument ALC system needs to properly control the control output amplitude. The steps **must** be performed in the order specified. The entire process is managed by the Calibration Control Program running on the PC. Please read the section which describes the individual test for information on when re-calibration is necessary.



**NOTE:** Do not use Channel B on a 2 Channel Meter.



**Figure 3-1: Output Amplitude Calibration Connection**

1. Connect the sensor to the meter calibrator (use the 'N' to 'K' adapter) and allow at least 15 minutes for the sensor and meter to reach thermal equilibrium. Then perform a sensor calibration.
2. Now connect the equipment as shown above. The 80313A sensor connects to the 12000A RF out connector. If the 12000A has a type 'N' connector, use the 'N' to 'K' adapter. The 12000A should have its IEEE address at 6 (the default). The power meter should be at address 10.

If the 12000A has not been previously warmed up, allow 15 minutes of warm-up. When the 'Fixed Frequency' screen displays, press the **RF On** button.


3. Click on the 'Modulator (Level Test)' button to begin the process.
  - The 'Modulator' routine generates a curve of attenuation verses control voltage for the modulators at various frequencies. This section must be performed whenever the A3, A6 or A8 assemblies have been changed.

### 3.5.1 ALC Characterization Instructions

After clicking on the Modulator button, the main window will look like the following picture. The monitor screen will now show the power meter readings (if that mode is selected). In addition, the bottom lines of the main window will show the test being performed and the readings as they are taken. This process will take about 55 minutes for a .01 to 20 GHz instrument.



**NOTE:** When this process is finished, the instrument MUST be powered down to properly store the data (this occurs when it is powered back up) before any other calibrations are done or before the instrument is used.



1. After the power is cycled, click the Read button under Parameter Block prior to doing the frequency response to verify the new date and time (for the Modulator) in the Characterization window.

2. Now press the Detector Linearization button. The monitor screen will now show the power meter readings (if that mode is selected). In addition, the bottom lines of the main window will show the test being performed and the readings as they are taken. This process will take about 20 minutes for a .01 to 20 GHz instrument.
3. After the Detector Linearization is done, the frequency response calibrations may be performed. Instruments with Option 26 (Attenuator) require two calibration runs, one at +5 dBm, the other at -5 dBm. Instruments with Option 20 require an additional run at +16 dBm. The level is selected in the 'Setup' area of the main window. Measurements taken at +5 or -5 are known as "Low Power". The one at +16 is "High Power". For units without Option 26 (i.e. no Attenuator), enter '+1' in the RF Box under setup.



**NOTE:** You must press 'Enter' after changing the RF level parameter.

4. Now click on 'Frequency Response' button. Frequency Response stores correction factors as a function of output frequency. This calibration will be required if A6, A8, or the optional step attenuator has been changed. It is also recommended that this routine be run if any of the RF cables between A6 and the front/rear output or the output connector itself is changed. Be sure to do the 'Modulator' characterization first, if required.

## Series 12000A Microwave Synthesizers

---

While the Frequency Response calibration is running the window will look like the following illustration below. The monitor screen will now show the power meter readings (if that mode is selected). In addition, the bottom line of the main window will show the readings as they are taken. This process will take about 25 minutes (for each level) for a .01 to 20 GHz instrument. Repeat process with RF Low Power at -5 dB for units with attenuator (Option 26).

The screenshot shows a software window titled "12000A Cal version 3.17 10th July 2001". It has a menu bar with "View", "Check", and "Connection". The window is divided into several sections:

- Setup:** Contains fields for GPIB Addresses: 12000A Unit = 6, Power Meter = 10, Freq. Counter = 1. Below these are Pad (dB) = 0 and RF Low Power Unit = 5.
- Parameter Block:** Contains "Read" and "Write" buttons. It displays "Serial Number = 117018" and "Model = 12720 A". It has fields for "Min. Freq." = 10 MHz and "Max. Freq." = 20199 MHz. There are checkboxes for "Option 26", "Option 20" (checked), "Option 24", "Option 38", "Code > 34", and "Pulse Mod.". A status line says "System is in Giga-tronics mode".
- Buttons:** "Pause" and "Close" buttons are located to the right of the Parameter Block.
- Status Bar:** At the bottom, it shows "Start ....." and a row of numbers: 39, 49.000, 4.90, 0.10, 1.

When the process is finished, the window status lines will give a successful completion message.



**NOTE:** The instrument *MUST* be power cycled after the completion of each Frequency Response. Click the Read button after each power up and change the RF Level box prior to the next Frequency Response calibration.


## 3.6 Modulation Calibration

| Modulation Calibration                          | Model  |                   |
|-------------------------------------------------|--------|-------------------|
|                                                 | 124XXA | 125XXA/<br>127XXA |
| <b>3.6.1 - Frequency Modulation Calibration</b> | N/A    | √                 |
| <b>3.6.2 - Amplitude Modulation Calibration</b> | N/A    | √                 |
| <b>3.6.3 - Scan Modulation Calibration</b>      | N/A    | √                 |

There are three separate calibration routines for the modulation functions of the 12000A. Each requires a different test setup. See the following sections for a complete description of the test system and sequence. Modulation calibrations may be done in any order. The conditions requiring re-calibration are outlined in this description of the Characterization screen of the Calibration Control Program:

- 'FM Calibration' performs the necessary steps to calibrate the frequency modulation function. Calibrating the Frequency Modulation also calibrates the Phase Modulation. FM calibration must be done if the A1 synthesizer board is replaced.
- 'AM Calibration' performs the necessary steps to calibrate the amplitude modulation function. This calibration of the Scan mode is also performed at this time. This calibration should be performed whenever the A3, A6 or A8 assemblies are replaced. Be sure to do the 'Modulator' characterizations first, if required.
- 'Modulator (Scan)' linearizes the modulators to provide accurate attenuation levels for the open looped 'deep' AM (Scan Modulation). This calibration should be performed whenever the A3, A6 or A8 assemblies are replaced.

### 3.6.1 Frequency Modulation Calibration



**Figure 3-2: Frequency Modulation Calibration Connection**

Connect the UUT, computer and Modulation Analyzer to the IEEE 488 bus. The UUT should be at address 6 (the default), the modulation analyzer at 14 and the LO source at 7. Connect the UUT RF output to the mixer RF input and the LO source (shown as a second model 12000A) to the mixer LO input. If the LO source is a Giga-tronics model 12000A or a Giga-tronics model GT9000, the program will set the frequency and power. If the source is some other model, set the LO source to 5450 MHz at +10 dBm, CW mode and press 'Cancel' in the source prompt window. Connect the Mixer/Divider IF divide-by-40 output to the Modulation analyzer input.



**NOTE:** The Mixer/Divider is required since the 8902 is not capable of measuring the required FM deviation. The divider reduces the deviation by a factor of 40 allowing the 8902 to make the measurement. The step-by-step procedure below explains how to use the Audio Source, DC Source and Voltmeter. Operator actions are directed by screen prompts.



### 3.6.1.1 Frequency Modulation Instructions

If the 12000A has not been previously warmed up, allow 15 minutes of warm-up.

In the Characterize section, click on the 'FM Calibration' box. Follow the on-screen prompt windows for step-by-step instructions. The steps are outlined below for convenience.



1. The first step requests a zero volts input to the UUT FM connector. Simply leave the input open as there is an internal  $50\Omega$  resistor to ground. This test calibrates any zero offset errors. Since FM is DC coupled, any DC component (or zero error) will result in a frequency shift. Press 'OK' when ready.
2. When the prompt requests a 1.0 volt DC input, connect the DC source to the FM input connector and monitor the FM input connector with the voltmeter. Set the DC source to 1.00 volts  $\pm 0.005$  volts. It may be helpful to put a resistor of about 500 ohms in series with the source and the FM input. This will make setting the DC source less critical as it provides a 10:1 divider. Be sure to measure the voltage at the FM input connector with everything connected. This test calibrates the "inside the loop" portion of the FM (approximately DC to 15 kHz). Press 'OK' when ready.
3. The next step requires that the 8902 Modulation analyzer be connected to the 12000A. Since the test is run at a frequency of 5 GHz, it is necessary to use a special downconverter (mixer) that includes a divide-by-40. The LO is set to 5450 MHz at +10 dBm and connected to the mixer LO port.
4. Connect the 12000A to the mixer RF port.
5. Connect the mixer divide-by-40 IF out to the 8902 input.
6. Connect the audio source to the 12000A FM input. Set the source to 190 kHz at 2.00 Volts peak-to-peak  $\pm 0.01$  volts. An oscilloscope is **NOT** accurate enough to set this level. Use a calibrated source or a digital voltmeter which will accurately measure 150 kHz. Be sure to measure the voltage at the FM input connector with everything connected. This test calibrates the "outside the loop" portion of the FM (approximately 15 kHz to 8 MHz) Press 'OK' when ready.

The following windows will be displayed during the FM calibration process. In addition, prompt windows will appear to provide instructions for each step of the test. The monitor window display the data that is being sent.




## Series 12000A Microwave Synthesizers

---



### 3.6.2 Amplitude Modulation Calibration



**Figure 3-3: Amplitude Modulation Calibration Connection**

Connect the UUT and computer to the IEEE 488 bus. If the 12000A has not been previously warmed up, allow 15 minutes of warm-up.

In the Characterize section, click on the 'AM Calibration' box. Follow the on-screen prompt window for step by step instructions. The steps are outlined below for convenience.

1. The first step requests a zero volts input to the UUT AM connector. Simply leave the input open as there is an internal  $600\Omega$  resistor to ground. This test calibrates any zero offset errors. Since AM is DC coupled, any DC component (or zero error) will result in a level shift. Press 'OK' when ready.
2. When the prompt requests a 1.0 volt DC input, connect the DC source to the AM input connector and monitor the AM input connector with the voltmeter. Set the DC source to 1.00 volts  $\pm 0.005$  volts. It may be helpful to put a resistor of about 6000 ohms in series with the source and the AM input. This will make setting the DC source less critical as it provides a 10:1 divider. Be sure to measure the voltage at the AM input connector with everything connected. This test calibrates the 'full scale' of the AM. Press 'OK' when ready.
3. The next step will again request a zero volts input to the UUT AM connector. Simply leave the input open as there is an internal  $600\Omega$  resistor to ground. This test calibrates the 'Scan' mode. Press 'OK' when ready.
4. When the prompt requests a 6.0 volt DC input, connect the DC source to the AM input connector and monitor the AM input connector with the voltmeter. Set the DC source to 6.00 volts  $\pm 0.03$  volts. Be sure to measure the voltage at the AM input connector with everything connected. This test calibrates the 'full scale' of the Scan Modulation. Press 'OK' when ready.

## Series 12000A Microwave Synthesizers

---

The following window will be displayed during the AM calibration process. In addition, prompt windows will appear to provide instructions for each step of the test. The monitor window displays the data that is being sent.

The screenshot shows a software window titled "12000A Cal version 3.17 10th July 2001". It has a menu bar with "View", "Check", and "Connection". The window is divided into two main sections: "Setup" and "Parameter Block".

**Setup Section:**

- GPIB Addresses:
  - 12000A Unit = 6
  - Power Meter = 10
  - Freq. Counter = 1
- Pad (dB) = 0
- RF Low Power Unit = 5

**Parameter Block Section:**


- Buttons: "Read" and "Write"
- Serial Number = 117018
- Model = 12720 A
- Min. Freq. = 10 MHz
- Max. Freq. = 20199 MHz
- Option 26: ☐ Option 20: ☒
- Ramp Sweep: ☒ Option 24: ☐
- Code > 34: ☐ Option 38: ☐
- Pulse Mod.: ☒ ☐ ☐
- System is in Giga-tronics mode

At the bottom right of the Parameter Block section are two buttons: "Pause" and "Close".

Below the Parameter Block section are two status bars:

- A green bar with the text "Start ....."
- A yellow bar with the text "AM input voltage calibration ...."

### 3.6.3 Scan Modulation Calibration



1. Connect the sensor to the meter calibrator (use the 'N' to 'K' adapter) and allow at least 15 minutes for the sensor and meter to reach thermal equilibrium. Then perform a sensor calibration.
2. Now connect the equipment as shown above. The 80313A sensor connects to the 12000A RF out connector. If the 12000A has a type 'N' connector, use the 'N' to 'K' adapter. The 12000A should have its IEEE address at 6 (the default). The power meter should be at address 10.
3. If the 12000A has not been previously warmed up, allow 15 minutes of warm-up.
4. In the Characterize section, click on the 'Modulator (Scan)' box.

The purpose of this test is to build a table of correction values. These values, when applied during Scan Modulation operation, create a linear change in the output level (in dB) as the input voltage is varied from 0 to 6 volts. Scan Modulation is run open loop once the selected CW output level has been set. The correction factors are interpolated for frequencies between the calibration points. This routine will take 85 minutes for a .01 to 20 GHz instrument.

## Series 12000A Microwave Synthesizers

The following window will display during the calibration process. In addition, the monitor window may be placed in the 'Power Meter' mode to view the data as it is taken.

The screenshot shows a software window titled "12000A Cal version 3.17 10th July 2001". It has a menu bar with "View", "Check", and "Connection". The window is divided into two main sections: "Setup" and "Parameter Block".

**Setup Section:**

- GPIB Addresses:
  - 12000A Unit = 6
  - Power Meter = 10
  - Freq. Counter = 1
- Pad (dB) = 0
- RF Low Power Unit = 5

**Parameter Block Section:**

- Buttons: "Read" and "Write"
- Serial Number = 117018
- Model = 12720 A
- Min. Freq. = 10 MHz
- Max. Freq. = 20199 MHz
- Options:
  - ☐ Option 26
  - ☒ Option 20
  - ☒ Ramp Sweep
  - ☐ Option 24
  - ☐ Code > 34
  - ☐ Option 36
  - ☒ Pulse Mod.
  - ☐ ☐ ☐
- System is in Giga-tronics mode
- Buttons: "Pause" and "Close"

**Status Bar:**

- Green bar: # DACalc DACscan Power dBm, Freq. = 10.000 MHz
- Yellow bar: Freq. = 10.000 MHz, Max. Power = 20.0 dBm
- Right side of yellow bar: □□ # DAK

## 3.7 ModGen Pulse Modulation Calibration (Option 24)

### 3.7.1 Description

Perform calibration of the ModGen Pulse Modulation function in the Series 12000A Microwave Synthesizers.

Due to variation in components on the ModGen board, the delays for the three counters used in pulse modulation can be inaccurate. These inaccuracies can be minimized by the software in the ModGen device driver.

Each counter must be calibrated individually. Calibration is achieved by setting the counter of interest to a known value and allowing it to count down. At the same time, the number of clock cycles from the on-board 10 MHz reference is monitored. When the counter counts down to zero, the number of 10 MHz clock cycles is compared to an expected value. The difference between the original input value and the measured value is used to derive a calibration factor used by the ModGen device driver software.

### 3.7.2 Equipment Required

UUT

### 3.7.3 Software

Any version of the Series 12000A Microwave Synthesizer firmware greater than V072-B48-18 is sufficient. Note that the menus for calibrating the ModGen option will not be visible if the board is not installed.


### 3.7.4 Procedure

1. Turn on the Model 12000A Microwave Synthesizer.
2. Allow the boot process to complete.
3. Press the **[CONFIG]** key in the System group on the front panel.
4. Press the *Service* softkey.
5. Press the *Mod Gen Testing* softkey.
6. Press the *PM* softkey.
7. Using the cursor keys, highlight the delay counter (Start, Pulse, Interval) you wish to calibrate.
8. Press the *Start Cal* softkey. This completes the cal process for the selected delay counter.
9. Repeat 7-8 for each delay counter to be calibrated.

3.8 Monitor Functions


| Monitor Functions | Model  |                   |
|-------------------|--------|-------------------|
|                   | 124XXA | 125XXA/<br>127XXA |
|                   | √      | √                 |

The monitor window is provided to allow viewing data or IEEE 488 bus traffic. Since the calibration processes involve significant amounts of data, both the 8650A power meter and the unit under test are operated in modes that do not involve displaying any information on the instruments' displays. The monitor screen allows the user to see the data. The view below is a typical display with the bus traffic monitor turned on (See the following pages for more details).




This view shows the choices available for the monitor screen.

- 'GPIB send/receive in display' puts the information in the GPIB Display Window under the GPIB Address box (shown below). The GPIB Address box initially shows 'GPIB' until an address is selected.
- 'GPIB send/receive in memo' puts the information in the same block (the one on the left) as the data. This allows easily seeing what command produced a specific data point.
- 'Show Power Meter' puts the power meter readings in the left block.




# Series 12000A Microwave Synthesizers

This view illustrates the ability to 'filter' the GPIB traffic. A setting of 255 causes the display to show traffic to any GPIB device on the bus. Entering a specific address will show traffic for that device only.



## 6.1.7 Modulation Modes Continued (Series 125XXA/127XXA Only)



Formerly Figure 6-7: Fault Isolation Tree: Modulation Modes (Continued) in Rev. A through A3

# Series 12000A Microwave Synthesizers

## Notes

| Note # | Note Description for Series 12000A Fault Isolation Trees                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Model                    |                   |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|-------------------|
|        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 124XXA                   | 125XXA/<br>127XXA |
| 1      | The referenced LEDs are located on the edge of the A4 Distribution PC board away from the power supply assembly. Green LEDs indicate that the monitored power supply is on (they do not indicate that the supply is within tolerance). Monitors are provided for the +12 standby supply and the $\pm 6$ and $\pm 12$ volt main supplies. Red LEDs indicate that the corresponding power supply fuse is open. Monitors are provided for the $\pm 6$ and $\pm 12$ volt main supplies.                                                                                                                                                                                                                                                                                    | ✓                        | ✓                 |
| 2      | To isolate the power supply loads, unplug the 9 pin connectors which connect the power cables from the A4 Distribution board to the other PC assemblies. It will be necessary to remove the A1 Synthesizer assembly to access these connectors.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | ✓                        | ✓                 |
| 3      | The Peripheral Bus Cable is a 60 wire ribbon cable that connects the A4, A1, A11, A3 and A16 (if installed). It is recommended that this cable be verified first before replacing any of the PC assemblies.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | ✓                        | ✓                 |
| 4      | The "YIG Cal" sequence sets the YIG to 4.5 and 7.5 GHz and adjusts the tuning current to center the PLL. A failure at this point can be further isolated by removing the Instrument bottom cover then removing the coaxial cable from A1A1 J402. <i>This cable goes to the A6 Microwave Module. It is a .085 Semiflex about 4" long.</i> Connect a spectrum analyzer to J402. If a signal is present at about +10 dBm, then the YIG is working. If not, measure the voltage on the end of R724 closest to the board edge. It should be <i>approximately</i> 0.1 volts/GHz. If the voltage is outside the range of 0.4 to 0.85 volts, the oscillator may not operate and the A1 board should be serviced. A problem in A1A1 or A1A2 can also cause the YIG Cal to fail. | ✓                        | ✓                 |
| 5      | The ALC Offset calibration requires that the detectors in A6 and A8 (if installed) be functioning as well as the circuitry on A17 and A8 that amplifies the detector signals. If possible, verify the signal levels from A17 and/or A8 before replacing assemblies.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | ✓                        | ✓                 |
| 6      | This problem includes frequency errors, phase noise problems, and both harmonically and non-harmonically related spurious signals. It is appropriate to determine over what range of carrier frequencies and output amplitude levels the problem exists. This will often provide additional information to help isolate the cause.                                                                                                                                                                                                                                                                                                                                                                                                                                     | ✓                        | ✓                 |
| 7      | See the calibration section of this publication for the procedure.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | ✓                        | ✓                 |
| 8      | If available, exchange the A1A1/A1A2 assembly with a known good set and see if this fixes the problem. If so, determine which of the two is at fault. If not, replace the main A1 assembly. No re-calibration is needed if just A1A1 and/or A1A2 is replaced. FM re-calibration is needed if A1 is replaced (Reference to FM re-calibration does not apply to Series 124XXA Models).                                                                                                                                                                                                                                                                                                                                                                                   | ✓<br>(Limitations Apply) | ✓                 |
| 9      | Although the A1 assembly may be the point of entry for the spurious signals, poor connections on ground or power supply leads should be checked. The power supply itself may be producing ripple outside the specified levels. Also check if the spurious signal levels are affected by the amplitude setting. If so, the A3 ALC assembly or one of the RF modules may be at fault. Try looking at the output of A1A1 at J402 with a spectrum analyzer and see if the spur is still present.                                                                                                                                                                                                                                                                           | ✓                        | ✓                 |
| 10     | A 'Yes' answer here should be used only if the level is neither at minimum nor maximum.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | ✓                        | ✓                 |
| 11     | Check the input level at the FM input connector (the front and rear ones are tied together). Instrument calibration assumes that this level is 2 V <sub>p-p</sub> . Check the setting for the deviation by pressing the FM button. Note that since the instrument uses frequency multiplication and division, the maximum deviation is reduced as the frequency is reduced. If, for example, you set a deviation in narrow mode of 1 MHz at 4 GHz and then change the frequency to 1 GHz, the deviation will automatically change to 250 kHz.                                                                                                                                                                                                                          | N/A                      | ✓                 |
| 12     | The FM Narrow mode is DC coupled. Any DC component on the input signal will shift the carrier at the same scaling as the deviation. If, for example, the deviation is set to 1 MHz and there is 10 mV of offset, there will be 10 kHz of carrier shift.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | N/A                      | ✓                 |
| 13     | Check the input level at the AM input connector (the front and rear ones are tied together). Instrument calibration assumes that this level is 2 V <sub>p-p</sub> . Check the setting for the depth by pressing the AM button.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | N/A                      | ✓                 |
| 14     | The AM mode is DC coupled. Any DC component on the input signal will shift the carrier level as would the peak of an AC component.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | N/A                      | ✓                 |
| 15     | If the pulse shape (rise/fall time; overshoot, etc) is a problem below 2 GHz, then replace the A8 downconverter (all pulse shape determining circuits are on this assembly). If the problem is above 2 GHz the cause could be on either the A17 board (driver) or the A6 assembly (modulator).                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | N/A                      | ✓                 |
| 16     | Pulse level accuracy (when the RF is on) problems which occur above 2 GHz would most likely be caused by a fault on a the A3 assembly. It is possible, however, that a defect on the A17 assembly could cause a problem since the detector buffer amplifier is located here.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | N/A                      | ✓                 |
| 17     | Pulse level accuracy (when the RF is on) problems which occur below 2 GHz would most likely be caused by a fault on a the A3 assembly. It is possible, however, that a defect on the A8 assembly could cause a problem since the detector buffer amplifier is located here.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | N/A                      | ✓                 |
| 18     | Pulse on/of ratio problems could be caused by the amplifiers on the A3 assembly, the driver amplifiers on A17 or by the RF module A6.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | N/A                      | ✓                 |
| 19     | Pulse on/of ratio problems could be caused by the amplifiers on the A3 assembly or by the driver amplifiers and modulators on A8.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | N/A                      | ✓                 |

## 6.2 Series 12000A Disassembly/Assembly Instructions

| Series 12000A Disassembly/Assembly Instructions    | Model                    |                   |
|----------------------------------------------------|--------------------------|-------------------|
|                                                    | 124XXA                   | 125XXA/<br>127XXA |
| <b>6.2.1 - Top &amp; Bottom Covers</b>             | √                        | √                 |
| <b>6.2.2 - Side Covers</b>                         | √                        | √                 |
| <b>6.2.3 - Rear Panel</b>                          | √                        | √                 |
| <b>6.2.4 - A1 Synthesizer</b>                      | √                        | √                 |
| <b>6.2.5 - A15 Timebase</b>                        | √                        | √                 |
| <b>6.2.6 - A4 Distribution Board</b>               | √                        | √                 |
| <b>6.2.7 - A3 Automatic Level (ALC) Board</b>      | √<br>(Limitations Apply) | √                 |
| <b>6.2.8 - A16 Modulation Generator Board</b>      | N/A                      | √                 |
| <b>6.2.9 - A11 CPU Board</b>                       | √                        | √                 |
| <b>6.2.10 - A8 Downconverter</b>                   | √                        | √                 |
| <b>6.2.11 - A6/A7/A17 Microwave Assembly Board</b> | √                        | √                 |

The following instructions are provided to assist in the removal and replacement of the various subassemblies in the Series 12000A Microwave Synthesizers.

### 6.2.1 Top & Bottom Covers

1. Unplug the line cord from the instrument.
2. Remove the eight screws on each cover. Four at the front, four at the rear.
3. Lift the cover off. Note that the cover has a 'lip' on each side. Lift the cover from the front or rear edge.
4. When re-installing the covers, be sure to use the longer #4 screws at the corners.

### 6.2.2 Side Covers

1. Remove the top and the bottom covers (1).
2. Remove the four #10 flat head screws located at the front and rear edges. The front screws also mount the handles.
3. Remove the four #4 flat head screws located on the top and bottom edges of the cover.
4. Lift the cover off.
5. When replacing the side covers see the following notes:
  - a. For instruments without provision for rack slides, the side covers are identical. It is only necessary to be sure that the edge of the cover with the bent lip is at the top of the instrument.
  - b. The side covers for instruments that accept rack slides are different. When installed, the ventilation holes go toward the top of the instrument. There are three #10 press nuts to mount the slides. The pair with the closer spacing goes toward the rear of the instrument.

### 6.2.3 Rear Panel

1. Unplug the instrument line cord.
2. Remove the top and bottom covers (1).
3. Remove the two side covers (2).
4. If the instrument has rear panel RF output, disconnect the coaxial cable from the rear panel output connector.
5. Locate the two coaxial cables running from the rear panel "Ref In" and "Ref Out" connectors to the A15 Time Base Assembly. Release the connector on the A15 by pressing on the lock release while gently pulling on the connector. If necessary, remove the cables from any plastic clips that hold the cables to the chassis.
6. Remove the eight #10 flat head screws located at the four corners of the rear panel casting.
7. Remove the five #6 pan head screws on the rear panel. Four of these are located near the power entry connector, the other one is in the BNC connector area.
8. Carefully pull the panel loose from the four side rails. **Note that the panel will only have sufficient cable slack to move about 2 inches!**
9. To re-install the panel, carefully push the assembly onto the four side rails. Be sure no cables are pinched.
10. Fasten the five #6 pan head screws, then the eight #10 flat head screws. **Be sure to put the #10 screws in the 'outside' holes (closest to the covers).**
11. Re-connect the cable to the A15 board and, if necessary, the RF output.

### 6.2.4 A1 Synthesizer

**This assembly must be removed in a static controlled environment.**

1. Remove the bottom cover (1).
2. Disconnect the three coaxial cables from the A1A1 sub-assembly.
3. Disconnect the two power connectors (P401, P801), the YIG (P701) and FET (P702) connectors, and the peripheral buss connector (P101). When removing the peripheral buss connector, press the locking ears outward to release the connector.
4. Disconnect the two blue 10 MHz coax cables (J101, J102). When removing these use the proper removal tool or pull straight up with small tweezers held parallel to the board.
5. Disconnect the twisted pair cable connector at P103. Press the lock release on the cable connector to release.
6. Remove the seven #6 screws around the perimeter of the board. Note that one of these is accessible through the corner hole in the A1A2 assembly.
7. Carefully lift the board out of the instrument.
  - a. To remove the A1A1/A1A2 assemblies:
    - 1.) Disconnect the blue cable at J501 on the A1 synthesizer board.
    - 2.) Remove the four #4 screws closest to the four corners of the assembly. These screws are about 1.5 inches long.
    - 3.) **Carefully** lift both assemblies, as a unit. There is a multi-pin connector on the A1A2 which goes through a socket on the A1A1 and then into another socket on the A1 synthesizer board. It may be necessary to 'rock' the assembly slightly to ease removal.
    - 4.) If the A1A1 and A1A2 assemblies need to be separated from each other, carefully pry them apart with a pocket knife blade, or equivalent.
    - 5.) When replacing these assemblies, first plug A1A2 into A1A1, then plug the pair into A1, then fasten with the four #4 screws.
8. To replace the A1 assembly, reverse the above procedure. **Be certain that all connectors are properly aligned!** The 10 MHz (blue) cables are connected by pressing straight down over their sockets.
9. When tightening the three coaxial cables on A1A1, observe proper torque procedures.

### 6.2.5 A15 Timebase

**This assembly must be removed in a static controlled environment.**

1. Remove the bottom cover (1).
2. Remove the A1 synthesizer assembly (4).
3. Disconnect the 10 MHz coax cables (blue cables). When removing these use the proper removal tool or pull straight up with small tweezers held parallel to the board.
4. Disconnect the black cable connector. Press the lock release on the cable connector to release.
5. Disconnect the ribbon cable.
6. Using a 'nut driver' or similar tool, unscrew the four mounting fasteners. These are threaded onto studs on the chassis and pass through rubber vibration isolating grommets. They are often quite tight.
7. To replace the A15 assembly, reverse the above procedure. **Be certain that all connectors are properly aligned! Be certain that the 10 MHz cables are connected to the correct sockets!** The 10 MHz (blue) cables are connected by pressing straight down over their sockets.

### 6.2.6 A4 Distribution Board

**This assembly must be removed in a static controlled environment.**

1. Remove the bottom cover (1).
2. Remove the A1 Synthesizer assembly (4).
3. Disconnect any power connectors (P403-P410), the main power supply input connector (P401), the fan power connector (P302), and the standby power connector (P402).
4. Disconnect the peripheral buss connector (P101) and the module cables (P102 and P201). When removing these connectors, press the locking ears outward to release the connector.
5. Disconnect the cables to the A15 and A11 boards (P305 and P301).
6. Disconnect the connector on the wire going to the YIG oscillator. This connector is in line with the wire.
7. Disconnect the (optional) step attenuator ribbon cable at P303 and/or the (optional) cable to the high power assembly at P304.
8. Remove the five spacers (that are used to mount the A 1 assembly).
9. Lift the A4 assembly out of the instrument. Note that there is a locating pin on one corner of the board.
10. To re-install the assembly reverse the above procedure.
11. First align the hole in the corner of the board with the locating pin. Press the board onto the pin. Now install the five spacers.
12. Re-connect all the cables. **Be certain that the connectors are properly mated and aligned.**

### 6.2.7 A3 Automatic Level (ALC) Board

**This assembly must be removed in a static controlled environment.**

1. Remove the top cover (1).
2. Disconnect the two power connectors (P701, P702) and the peripheral buss connector (P101). When removing the peripheral buss connector, press the locking ear outward to release the connector.
3. Disconnect all of the blue cables. When removing these use the proper removal tool or pull straight up with small tweezers held parallel to the board.
4. Disconnect the twister pair/coaxial cable connector at P301. Press the lock release on the cable connector to release.
5. Remove the nine #6 screws around the perimeter of the board and the one #6 screw in the center.
6. Carefully lift the board out of the instrument.
7. To replace the A3 assembly, reverse the above procedure. **Be certain that all connectors properly aligned!** The blue cables are connected by pressing straight down over their sockets.

### 6.2.8 A16 Modulation Generator Board (Series 125XXA/127XXA Only)

**This assembly must be removed in a static controlled environment.**

1. Remove the top cover (1).
2. Disconnect the power connector (P400) and the peripheral buss connector (P100). When removing the peripheral buss connector, press the locking ears outward to release the connector.
3. Disconnect the blue 10 MHz cable. When removing this cable use the proper removal tool to pull straight up with small tweezers held parallel to the board.
4. Disconnect the twister pair connector at P101.
5. Disconnect the remaining twisted pair connectors. Press the lock release on the cable connector to release.
6. Remove the six #6 screws around the perimeter of the board and lift out the assembly.
7. To replace the A16 assembly, reverse the above procedure. **Be certain that all connectors are properly aligned!** The blue cable is connected by pressing straight down over its socket.

## 6.2.9 A11 CPU Board

**This assembly must be removed in a static controlled environment.**

1. Remove the top cover (1).
2. Remove the A3 ALC assembly (7).
3. Remove the shield plate by removing the nine #6 screws (with their lock and flat washers).
4. Disconnect the main power connector (P702), the backlight power connector (P503), and the peripheral buss connector (P402). When removing the peripheral buss connector, press the locking ears outward to release the connector.
5. Disconnect the blue 10 MHz cable (J101). When removing this cable use the proper removal tool or pull straight up with small tweezers held parallel to the board.
6. Disconnect the LCD flex cable (J501). When removing this cable, pull straight out, parallel to the board.
7. Disconnect the twisted pair connector (J601). Press the lock release on the cable connector to release.
8. Disconnect the remaining four ribbon cables.
9. Disconnect the back-up battery (P201).

### WARNING

**Disconnecting the battery will clear the non-volatile memory.**

If the A11 assembly is to be re-used in this instrument, do not disconnect the battery, unfasten it from the chassis instead.

10. Remove the five #6 screws and lift the assembly out of the instrument.
11. To replace the A11 assembly, reverse the above procedure. **Be certain that all connectors are properly aligned!**
12. The blue cable is connected by pressing straight down over its socket.
  - a. When re-connecting the LCD flex cable, grasp the cable near the end and press firmly and carefully into the socket. The cable should have the blue plastic strip toward the PC board (i.e. not visible after the cable is installed).

### 6.2.10 A8 Downconverter

**This assembly must be removed in a static controlled environment.**

1. Remove the top cover (1).
2. Remove the A16 Internal Modulation Generator assembly (8), if installed.
3. Remove the two white coaxial cables. One is located at the front edge of the assembly, the other on the inside edge near the peripheral bus cable.
4. Remove the five blue coaxial cables. When removing these use the proper removal tool or pull straight up with small tweezers held parallel to the board.
5. Remove the power/control ribbon cable. When removing this cable, press the locking ears outward to release the connector.
6. Remove the seven #6 screws around the perimeter (If the A16 board was installed, some of the screws are replaced with spacers, remove these) and lift the assembly out of the instrument.
7. To replace the A8 assembly, reverse the above procedure. **Be certain that all connectors are properly aligned!**
  - a. The blue cables are connected by pressing straight down over their sockets.

### 6.2.11 A6/A7/A17 Microwave Assembly

**This assembly must be removed in a static controlled environment.**

1. Remove the bottom cover (1).
2. Disconnect the RF input on the front of the assembly (Semi-flex) which comes from the A1 synthesizer assembly.
3. Disconnect the RF input on the rear of the assembly (white coax) which comes from the A8 downconverter (if installed).
4. Disconnect the RF output on the rear of the assembly (Semi-flex).
5. Disconnect the ribbon cable from P1. When removing this cable, press the locking ears outward to release the connector.
6. Disconnect the five blue coaxial cables. When removing these use the proper removal tool or pull straight up with small tweezers held parallel to the board.
7. Remove the four slotted head #6 screws from the top module (A7), if it is installed. If not, these screws are phillips head and are on the A17 PC assembly.
8. Remove the two #6 screws from the back end of the A17 PC assembly and lift the entire assembly out of the instrument.
9. To replace the A8 assembly, reverse the above procedure. **Be certain that all connectors are properly aligned!**
  - a. The blue cables are connected by pressing straight down over their sockets.
10. When tightening the three coaxial cables observe proper torque procedures.
11. To install the 12000A calibration program simply copy all the files in the 12000A Calibration directory to a directory on your PC.

6.3 Series 12000A CPU Initialization Error Messages

| Series 12000A CPU Initialization Error Messages | Model  |                   |
|-------------------------------------------------|--------|-------------------|
|                                                 | 124XXA | 125XXA/<br>127XXA |
|                                                 | √      | √                 |

 **NOTE:** The following error messages are listed in the order of (potential) occurrence.

1. **"Synth boot load timeout"**. Boot code has been transmitted to the Synthesizer, but after 650 microseconds, no response has been received.
2. **"Synth boot load err"**. Boot code has been transmitted to the Synthesizer, and the Synthesizer has responded with an error message. The contents of the Synthesizer DSP HIP status and data registers are displayed.
3. **"ALC boot load timeout"**. Boot code has been transmitted to the ALC board, but after 650 microseconds, no response has been received.
4. **"ALC boot load error"**. Boot code has been transmitted to the ALC board, and the ALC board has responded with an error message. The contents of the ALC board DSP HIP status and data registers are displayed.
5. **"Synth FPGA RdBck timeout"**. A byte of the Synthesizer FPGA program file has been transmitted to the Synthesizer, but after 65 microseconds, no response has been received.
6. **"Synth FPGA RdBck error"**. A byte of the Synthesizer FPGA program file has been transmitted to the Synthesizer, and the Synthesizer has responded with an error message and/or a non-matching data byte rather than an OP COMPLETE message and a matching data byte. The contents of the Synthesizer DSP HIP status and data registers are displayed.
7. **"Synth FPGA load opn timeout"**. The entire Synthesizer FPGA program file has been transmitted to the Synthesizer, but after 1300 microseconds, no response has been received.
8. **"Synth FPGA load opn error"**. The entire Synthesizer FPGA program file has been transmitted to the Synthesizer, and the Synthesizer has responded with an error message. The contents of the Synthesizer DSP HIP status and data registers are displayed.
9. **"Synth DSP code rdbck timeout"**. A byte of the Synthesizer DSP operational code file has been transmitted to the Synthesizer, but after 65 microseconds, no response has been received.
10. **"Synth DSP code rdbck err"**. A byte of the Synthesizer DSP operational code file has been transmitted to the Synthesizer, and the Synthesizer has responded with an error message and/or a non-matching data byte rather than an OP COMPLETE message and a matching data byte. The contents of the Synthesizer DSP HIP status and data registers are displayed.
11. **"Synth DSP code load opn timeout"**. The entire Synthesizer DSP operational code file has been transmitted to the Synthesizer, but after 65 microseconds, no response has been received.

12. **"Synth DSP code load opn err"**. The entire Synthesizer DSP operational code file has been transmitted to the Synthesizer, and the Synthesizer has responded with an error message. The contents of the Synthesizer DSP HIP status and data registers are displayed.
13. **"YIG Cal xx synth operation timeout"**. Data and strobe have been sent for one of the twelve Synthesizer YIG calibrations, but after 2.5 seconds, no response has been received.
14. **"YIG Cal xx synth operation error"**. Data and strobe have been sent for one of the twelve Synthesizer YIG calibrations, and the Synthesizer has responded with an error message. The contents of the Synthesizer DSP HIP status and data registers are displayed.
15. **"YIG Cal xx data readback timeout"**. One of the twelve Synthesizer YIG calibrations has completed successfully, and a request has been sent to retrieve the results, but after .75 seconds, no response has been received.
16. **"YIG Cal xx data readback error"**. One of the twelve Synthesizer YIG calibrations has completed successfully, a request has been sent to retrieve the results, but the Synthesizer has responded with an error message. The contents of the Synthesizer DSP HIP status and data registers are displayed.
17. **"A1A2 Cal xx operation timeout"**. Data and strobe have been sent for one of the 41 A1A2 calibrations, but no response has been received within the time allotted. For cal numbers 0 and 41, this is 5 msec; for the remaining calibrations, this is 640 msec.
18. **"A1A2 Cal xx operation error"**. Data and strobe have been sent for one of 41 A1A2 calibrations, and the Synthesizer has responded with an error message. The contents of the Synthesizer DSP HIP status and data registers are displayed.
19. **"A1A2 Cal xx DSP Word 0 data readback timeout"**. One of the 41 A1A2 calibrations has completed successfully, and a request has been sent to retrieve the results, but after 5 msec, no response has been received.
20. **"A1A2 Cal xx DSP Word 0 data readback error"**. One of the 41 A1A2 calibrations has completed successfully, a request has been sent to retrieve the results, but the Synthesizer has responded with an error message. The contents of the Synthesizer DSP HIP status and data registers are displayed.
21. **"A1A2 Cal xx DSP Word 1 data readback timeout"**. One of A1A2 calibrations 1 - 39 has completed successfully, and a request has been sent to retrieve the second word of results, but after 5 msec, no response has been received.
22. **"A1A2 Cal xx DSP Word 1 data readback error"**. One of A1A2 calibrations 1 - 39 has completed successfully, a request has been sent to retrieve the second word of results, but the Synthesizer has responded with an error message. The contents of the Synthesizer DSP HIP status and data registers are displayed.
23. **"ALC SP FPGA cfg ack timeout"**. The command has been sent to the ALC telling it to get ready for SP FPGA startup program file data, but after 500 msec, no response has been received.
24. **"ALC SP FPGA cfg error"**. The command has been sent to the ALC telling it to get ready for SP FPGA startup program file data, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
25. **"ALC SP FPGA load opn timeout"**. The entire ALC SP FPGA startup program file has been transmitted to the ALC, but after 1300 microseconds, no response has been received.

26. **"ALC SP FPGA load opn err"**. The entire ALC SP FPGA startup program file has been transmitted to the ALC, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
27. **"ALC PM FPGA cfg ack timeout"**. The command has been sent to the ALC telling it to get ready for PM FPGA program file data, but after 500 msec, no response has been received. **(SERIES 125XXA/127XXA ONLY)**.
28. **"ALC PM FPGA cfg error"**. The command has been sent to the ALC telling it to get ready for SP FPGA program file data, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed. **(SERIES 125XXA/127XXA ONLY)**.
29. **"ALC PM FPGA load opn timeout"**. The entire ALC PM FPGA program file has been transmitted to the ALC, but after 1300 microseconds, no response has been received. **(SERIES 125XXA/127XXA ONLY)**.
30. **"ALC PM FPGA load opn err"**. The entire ALC PM FPGA program file has been transmitted to the ALC, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed. **(SERIES 125XXA/127XXA ONLY)**.
31. **"ALC prog mem test timeout"**. The ALC board has been commanded to test program memory, but hasn't responded after 1 second.
32. **"ALC prog mem test err"**. The ALC board has been commanded to test program memory, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
33. **"ALC lin mem test timeout"**. The ALC board has been commanded to test detector linearization memory, but hasn't responded after 1 second.
34. **"ALC lin mem test err"**. The ALC board has been commanded to test detector linearization memory, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
35. **"ALC delin mem test timeout"**. The ALC board has been commanded to test modulator delinearization memory, but hasn't responded after 1 second.
36. **"ALC delin mem test err"**. The ALC board has been commanded to test modulator delinearization memory, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
37. **"ALC Analog test timeout"**. The ALC board has been commanded to test the analog input circuitry, but hasn't responded after 1 second.
38. **"ALC Analog test err"**. The ALC board has been commanded to test the analog input circuitry, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
39. **"ALC DSP code rdbck timeout"**. A byte of the ALC DSP internal memory operational code file has been transmitted to the ALC, but after 65 microseconds, no response has been received.

40. **"ALC DSP code rdbck err"**. A byte of the ALC DSP internal memory operational code file has been transmitted to the ALC, and the ALC has responded with an error message and/or a non-matching data byte rather than an OP COMPLETE message and a matching data byte. The contents of the ALC DSP HIP status and data registers are displayed.
41. **"ALC DSP code load opn timeout"**. The entire ALC DSP internal memory operational code file has been transmitted to the ALC, but after 10 msec, no response has been received.
42. **"ALC DSP code load opn err"**. The entire ALC DSP internal memory operational code file has been transmitted to the ALC, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
43. **"ALC DSP ext code rdbck timeout"**. A byte of the ALC DSP external memory operational code file has been transmitted to the ALC, but after 65 microseconds, no response has been received.
44. **"ALC DSP ext code rdbck err"**. A byte of the ALC DSP external memory operational code file has been transmitted to the ALC, and the ALC has responded with an error message and/or a non-matching data byte rather than an OP COMPLETE message and a matching data byte. The contents of the ALC DSP HIP status and data registers are displayed.
45. **"ALC DSP ext code load opn timeout"**. The entire ALC DSP external memory operational code file has been transmitted to the ALC, but after 5 seconds, no response has been received.
46. **"ALC DSP ext code load opn err"**. The entire ALC DSP external memory operational code file has been transmitted to the ALC, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
47. **"ALC init timeout"**. The entire ALC DSP operational code file has been transmitted to the ALC, but after .5 seconds, no response has been received.
48. **"ALC init error"**. The entire ALC DSP operational code file has been transmitted to the ALC, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
49. **"ALC mod delin table build timeout"**. The ALC modulator delinearization table coefficients have been transmitted to the ALC, but after 10 seconds, no response has been received.
50. **"ALC mod delin table build err"**. The ALC modulator delinearization table coefficients have been transmitted to the ALC, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
51. **"ALC A17 det lin table build timeout"**. The ALC A17 CW detector linearization table coefficients have been transmitted to the ALC, but after 10 seconds, no response has been received.
52. **"ALC A17 det lin table build error"**. The ALC A17 CW detector linearization table coefficients have been transmitted to the ALC, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
53. **"ALC A8 det lin table build timeout"**. The ALC A8 CW detector linearization table coefficients have been transmitted to the ALC, but after 10 seconds, no response has been received.
54. **"ALC A8 det lin table build error"**. The ALC A8 CW detector linearization table coefficients have been transmitted to the ALC, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.

55. **"ALC A5 det lin table build timeout"**. The ALC A5 CW detector linearization table coefficients have been transmitted to the ALC, but after 10 seconds, no response has been received.
56. **"ALC A5 det lin table build error"**. The ALC A5 CW detector linearization table coefficients have been transmitted to the ALC, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
57. **"ALC A17 det pulse table build timeout"**. The ALC A17 PULSE detector linearization table coefficients have been transmitted to the ALC, but after 10 seconds, no response has been received. **(SERIES 125XXA/127XXA ONLY)**.
58. **"ALC A17 det pulse table build error"**. The ALC A17 PULSE detector linearization table coefficients have been transmitted to the ALC, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed. **(SERIES 125XXA/127XXA ONLY)**.
59. **"ALC A8 det pulse table build timeout"**. The ALC A8 PULSE detector linearization table coefficients have been transmitted to the ALC, but after 10 seconds, no response has been received. **(SERIES 125XXA/127XXA ONLY)**.
60. **"ALC A8 det pulse table build error"**. The ALC A8 PULSE detector linearization table coefficients have been transmitted to the ALC, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed. **(SERIES 125XXA/127XXA ONLY)**.
61. **"ALC A5 det pulse table build timeout"**. The ALC A5 PULSE detector linearization table coefficients have been transmitted to the ALC, but after 10 seconds, no response has been received. **(SERIES 125XXA/127XXA ONLY)**.
62. **"ALC A5 det pulse table build error"**. The ALC A5 PULSE detector linearization table coefficients have been transmitted to the ALC, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed. **(SERIES 125XXA/127XXA ONLY)**.
63. **"ALC A17 CW det zero timeout"**. The ALC has been directed to find A17 CW detector zero, but after 5 seconds, no response has been received.
64. **"ALC A17 CW det zero error"**. The ALC has been directed to find A17 CW detector zero, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
65. **"ALC A17 PM det zero timeout"**. The ALC has been directed to find A17 PM detector zero, but after 5 seconds, no response has been received. **(SERIES 125XXA/127XXA ONLY)**.
66. **"ALC A17 PM det zero error"**. The ALC has been directed to find A17 PM detector zero, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed. **(SERIES 125XXA/127XXA ONLY)**.
67. **"ALC A8 CW det zero timeout"**. The ALC has been directed to find A8 CW detector zero, but after 5 seconds, no response has been received.
68. **"ALC A8 CW det zero error"**. The ALC has been directed to find A8 CW detector zero, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.

- 69. **"ALC A8 PM det zero timeout"**. The ALC has been directed to find A8 PM detector zero, but after 5 seconds, no response has been received. **(SERIES 125XXA/127XXA ONLY)**.
- 70. **"ALC A8 PM det zero error"**. The ALC has been directed to find A8 PM detector zero, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed. **(SERIES 125XXA/127XXA ONLY)**.
- 71. **"ALC A5 CW det zero timeout"**. The ALC has been directed to find A5 CW detector zero, but after 5 seconds, no response has been received.
- 72. **"ALC A5 CW det zero error"**. The ALC has been directed to find A5 CW detector zero, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed.
- 73. **"ALC A5 PM det zero timeout"**. The ALC has been directed to find A5 PM detector zero, but after 5 seconds, no response has been received. **(SERIES 125XXA/127XXA ONLY)**.
- 74. **"ALC A5 PM det zero error"**. The ALC has been directed to find A5 PM detector zero, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed. **(SERIES 125XXA/127XXA ONLY)**.
- 75. **"ALC AM zero timeout"**. The ALC has been directed to find AM input zero, but after .5 seconds, no response has been received. **(SERIES 125XXA/127XXA ONLY)**.
- 76. **"ALC AM zero error"**. The ALC has been directed to find AM input zero, and the ALC has responded with an error message. The contents of the ALC DSP HIP status and data registers are displayed. **(SERIES 125XXA/127XXA ONLY)**.

