

## 19" / 1U – High Voltage Power Supplies

### HPS-series 300 W and 800 W

#### Manual

1. Safety instructions
2. Description of operation
3. Technical Data
4. Description of CAN Interface
5. Description of RS232 Interface
6. Description of IEEE Interface
7. Command sets for RS232 and IEEE Interface
8. Description of analogue I/O
9. Trouble shooting



#### **Attention!**

The unit must not be operated with the cover removed to avoid the possibility of lethal shock to the operator!

We decline all responsibility for damages and injuries caused by an improper use of the module. It is strongly recommended to read the operators manual before operation!

#### **Note:**

All information in this document is subject to change without notice. We take no responsibility for any error in this document. We reserve the right to make changes in the product design without any notification to the users.

Filename HPx\_300-800W\_eng.\_\_\_\_; as of 2003-06-27

## 1. Safety instructions

This High Voltage Power Supply has to be installed by skilled persons only. Following instructions are made for the personal safety of the operator, the safe use of this product and the connected units.



### **Caution**



### **Dangerous Voltage**

This unit is supplied from line voltage of 230V and generates an output voltage of up to 30 kV.

The disregard of this voltage condition can cause death, heavy injuries or material damage.



### **Danger in case of missing connector at the HV output**

The **LEMO-HV** connector will be used for units which generate output voltages > 6kV. It is forbidden to switch on this unit without a suitable connector inclusive a cable which is connected to the output connector and the load.

Before connecting to the local mains it must be proofed that the nominal line voltage of this unit is equal to the local mains.

Caution: After system-assembly the guard connections have to be checked if they are connected correctly !

The guard connection has to be proofed through a correct mains cable. An additional guard connection is possible via the green-yellow guard connector next to the HV Output ( ^/PE-connector).

The shield of the HV output is always connected to the housing ( ^/PE-connector).

If this shield is intended to use as "reverse line" , then a jumper has to be plugged between the "0 V" (reverse current) and the " ^/PE" connector.

If this jumper has been removed, the "0 V" connector close to ground can be float to max.  $\pm 300$  V. In this case the user is responsible that - due to the voltage between "0 V" and " ^/PE" connector - no danger for the user may occur.


If the potential between "0 V" and " ^/PE" connector is > |300|V then - in order to avoid damages for the unit - the connections are short circuited with help of electronically protection circuits.

The unit is prepared to be mounted into a 19"-cabinet. In this case the necessary air flow conditions through the according air input and output slots have to be guaranteed.

If the unit will be used as desk top instrument then the enclosed unit bases have to be glued on the bottom sheet in order to guarantee a certain distance to the desk.

Before the cover of the unit will be removed the mains connection has to be disconnected, the discharge time of at least (> 15 s) of the output capacitance has to be kept and the discharge status has to be checked afterwards.

Only skilled and authorised people are allowed to do any service, repair or maintenance for this unit.



## 2. Description

The High Voltage PS of the HPx<sup>1</sup> - 300 W series provide an output voltage of 0 up to 30 kV-DC at max. 300 W output power.

The High Voltage PS of the HPx<sup>1</sup> - 800 W series provide an output voltage of 0 up to 15 kV-DC at max. 800 W output power.

Mains voltage is 85 - 264 V -AC 50/60 Hz (PFC is Standard).

The output voltage and current are limited due to the hardware circuitry. The polarity is factory fixed (<sup>1</sup>x=p: positive; <sup>1</sup>x=n: negative).

The shield of the HV output is always connected to the housing ( ^/PE-connector).

If this shield is intended to use as “reverse line“ , then a jumper has to be plugged between the “0 V“ (reverse current) and the “^/PE“ connector.

If this jumper has been removed, the “0 V“ connector close to ground can be float up to max.  $\pm 300$  V. In this case the user is responsible that - due to the voltage between “0 V“ and “^/PE“ connector - no danger for the user may occur.

If the potential between “0 V“ and “^/PE“ connector is  $> |300|$  V then - in order to avoid damages for the unit - the connections are short circuited with help of internal electronically protection circuits.

After “POWER ON“ the unit is ready to use, the displays are flashing.

The mode is “LOCAL“ now, the KILL-function is “disable“.

In “LOCAL“ mode the output voltage and the output current can be set via the 10 turn potentiometers on the front panel. The generation of High Voltage at the HV output (on front or rear side) is starting after pushing the button „ON/OFF“, the green LED “HV“ is flashing.

**CAUTION ! The High Voltage which has been selected with help of the 10-turn potentiometer is going to ramp with 3 kV/s to the chosen voltage, this ramp is a factory setting.**

After pushing the button “ON/OFF“ again the HV will be shut OFF, the LED is off.

There are 2 control modes:

1. Voltage control “CV“:  
Control of the output voltage according to the value “Voltage“ ( $I_{OUT} < \text{value “Current“}$ ), the LED “CV“ is flashing.
2. Current control “CC“  
Control of the output current according to the value „Current “ ( $V_{OUT} < \text{value “Voltage“}$ ), the LED “CC“ is flashing.

The KILL-function will be set with button “KILL“ .

Disable: The output voltage will be limited after reaching  $I_{OUTmax}$  .

Enable: The yellow LED “KILL ENABLE“ is flashing.  
The output voltage will be shut off permanently without ramp, if  $I_{OUT} \geq I_{OUTmax}$ .  
The re-setting of the output voltage is possible after pushing button “HV-ON“ again.

The Standard units of the HPx<sup>1</sup> - 300 W series are with CAN- and RS232-Interface.

As an option available is:

- IEEE-Interface additionally and
- indirect coupled analogue I/O with  $V_{\text{SET/MON}} = 0$  up to 5 V instead of RS232-Interface.

If an interface is existing the control via interface will be activated after pushing button "LOCAL", the yellow LED "REM" is flashing.

In menu "SET" under function 09 the existing or selected interface has to be selected before.

In menu "SET" further configurations are possible. The access is by pushing button "SET" into "OFF" mode.

With push button "SET" all function are available by scrolling. The desired function will be selected by pushing "SET" and "LOCAL" simultaneously  $\Rightarrow$  Function "ENTER".

The selected values will be stored and activated by the "ENTER" function. If this has been made successfully the unit is back in "HV-OFF" mode.

Pushing the button "ESC" is going back to menu "SET" without any change of the pre-selected values.

Pushing button "LOCAL" is always leading back to manual mode. In this case the HV will be shut off. ( $\Rightarrow$  HV-OFF).

Menu	Display	Description
Software limit voltage	F 01 ULt	Set software-voltage limit with pot. "Voltage". $V_{OUT}$ will be limited to this value ( $0.0 \cong V_{OUTmax}$ )
"SET"		"ENTER"
Software limit current	F 02 ILt	Set software-current limit with pot. "Current" $I_{OUT}$ will be limited to this value ( $0.0 \cong I_{OUTmax}$ )
"SET"		"ENTER"
Hardware limit $I_{max}$	F 03 HCLt	Not implemented
"SET"		"ENTER"
Pre-setting U-SET	F 04 USEt	Values > 0 with pot. "Voltage" will be set automatically with "HV-ON", LED at the pot. is off.
"SET"		"ENTER"
Pre-setting I-SET	F 05 ISEt	Values > 0 with pot. "Current" will be set automatically with "HV-ON", LED at the pot. is off.
"SET"		"ENTER"
Ramp set	F 06 rSEt	Set of Ramp with pot. "Voltage" in a range of 10 up to 3000 V/s ( $0.0 \cong 3000$ V/s, factory setting)
"SET"		"ENTER"
Polarity set	F 07 PSEt	Not implemented
"SET"		"ENTER"
Control with analogue I/O automatically	F 08 Auto	<p>"ON" with "SET": Control is in remote control mode via analogue I/O after "POWER-ON" and "HV-ON" automatically The INHIBIT signal on analog I/O has be priority! "INHIBIT" High to Low: HV switch off always, Low to High: HV switch on always, LOW static, HV=0 Activate/Switch on with „HV-ON“ or „INHIBIT“</p> <p>"OFF" with "SET": Control is in "LOCAL" control mode after "POWER-ON" and "HV-ON" "INHIBIT" High to Low: HV switch off always, LOW static, HV=0 Switch on with „HV-ON“ only</p>
"SET"		"ENTER"
Change interface	F 09 ChIF	<p>"CAN" remote control via CAN-Interface "SET" "r232" remote control via RS232-Interface "SET" "IEEE" remote control via IEEE-Interface "SET" "aIF" remote control via analogue I/O "SET" back to "CAN"</p>
"SET"		"ENTER"
Instruction set	F 10 InSt	<p>"SCPI" control under SCPI-command set (IEEE and RS232) "SET" "Et" control under command set of ET System electronic GmbH (IEEE and RS232) "SET" back to "SCPI"</p>
"SET"		"ENTER"
Address IEEE	F 11 AdrI	"SET" $\Rightarrow$ IEEE-bus unit address of 01 to 31
"SET"		"ENTER"
Address CAN	F 12 AdrC	"SET" $\Rightarrow$ CAN-bus unit address of 00 up to 63
"SET"		"ENTER"
Back to F 01		

### 3. Technical Data

19" / 1U - series HPx <sup>1</sup> 300 W	HPx <sup>1</sup> 10 307	HPx <sup>1</sup> 20 157	HPx <sup>1</sup> 30 107	HPx <sup>1</sup> 40 756	HPx <sup>1</sup> 60 506	HPx <sup>1</sup> 80 356	HPx <sup>1</sup> 120 256	HPx <sup>1</sup> 150 206	HPx <sup>1</sup> 200 156	HPx <sup>1</sup> 300 106
Output voltage $V_{OUTmax}$ [kV]	1	2	3	4	6	8	12	15	20	30
Output current $I_{OUT}$ [mA]	300	150	100	75	50	35	25	20	15	10
HV-connector	SHV front side (opt. rear side)					Lemo-HV-connector rear side				
						$V_{OUTmax} \leq 16kV$ : Lemo ERA.1Y.416.CLL $V_{OUTmax} > 16kV$ : Lemo ERA.3Y.425.CLL <b>Attention: Use with connected HV connector only !</b>				
Output power	max. 300 W									
Polarity	Factory fixed $\Rightarrow$ <sup>1</sup> x = p: positive $\Rightarrow$ <sup>1</sup> x = n: negative									
Ripple & noise	$< 1 * 10^{-4} * V_{OUTmax}$ (V <sub>P-P</sub> )									
Voltage stability	$< 1 * 10^{-4} * V_{OUTmax}$ (load to no load, $\Delta V_{IN}$ and repeatability) in the output voltage range: $5 V \leq V_{OUT} \leq V_{OUTmax}$									
Current stability	$< 2 * 10^{-3} * I_{OUTmax}$ ( $R_{Lmin} \leq R_L <$ no load and $\Delta V_{IN}$ ) in the output voltage range: $5 V \leq V_{OUT} \leq V_{OUTmax}$									
Display	4-digit LED-Display for current and voltage									
Resolution of voltage and current measurement	via Interface: $V_{OUTmax} / 50000$ via Display: limited to 4 digit $I_{OUTmax} / 50000$									
Resolution of settings	LOCAL	$V_{OUTmax} / 2000$ and $I_{OUTmax} / 2000$								
Voltage / Current	REmote	$V_{OUTmax} / 50000$ and $I_{OUTmax} / 50000$								
Switching of output voltage	with button "ON/OFF" or via remote control									
Control	LOCAL	10-turn potentiometer for voltage and current								
	(REmote)	CAN	via CAN-Interface (also for diagnosis / software update)							
		RS232	via RS232-Interface							
	optional:	aIF	via indirect coupled analogue I/O instead of RS232-Interface							
	optional:	IEEE	via IEEE-Interface additionally							
Supply	$V_{IN} = 85$ up to 264 V-AC with PFC $I_{IN} = 1,7$ A at 230V-AC / 3,5 A at 115 V-AC, via mains connector and switch "POWER", isolated from HV-output, fused with $2 * 6,3$ A / slow.									
Dimension / Weight	1U -19" compatible / depth: 450 mm / ca. 5,7 kg									
Cooling	Internal fan									
Protection	Over load and short circuit , voltage supply and temperature									
Environment conditions	Operating temperature: 5 up to 35 °C Humidity: 30% up to 80 %, no condensation									
Storage temperature	0 up to 60 °C									

19" / 1U - series HPx <sup>1</sup> 800 W	HPx <sup>1</sup> 10 807	HPx <sup>1</sup> 20 407	HPx <sup>1</sup> 30 257	HPx <sup>1</sup> 40 207	HPx <sup>1</sup> 60 137	HPx <sup>1</sup> 80 107	HPx <sup>1</sup> 120 656	HPx <sup>1</sup> 150 506	
Output voltage $V_{OUT\ max}$ [kV]	1	2	3	4	6	8	12	15	
Output current $I_{OUT}$ [mA]	800	400	250	200	130	100	65	50	
HV-connector	SHV front side (optional rear side)					Lemo-HV-connector			
	rear side: Lemo ERA.1Y.416.CLL <b>Attention: Use with connected HV connector only !</b>								
Output power	max. 800 W								
Polarity	Factory fixed $\Rightarrow$ <sup>1</sup> x = p: positive $\Rightarrow$ <sup>1</sup> x = n: negative								
Ripple & noise	$< 1 * 10^{-4} * V_{OUT\ max}$ (V <sub>P-P</sub> )								
Voltage stability	$< 1 * 10^{-4} * V_{OUT\ max}$ (load to no load, $\Delta V_{IN}$ and repeatability) in the output voltage range: $5\ V \leq V_{OUT} \leq V_{OUT\ max}$								
Current stability	$< 2 * 10^{-3} * I_{OUT\ max}$ ( $R_{L\ min} \leq R_L < \text{no load}$ and $\Delta V_{IN}$ ) in the output voltage range: $5\ V \leq V_{OUT} \leq V_{OUT\ max}$								
Display	4-digit LED-Display for current and voltage								
Resolution of voltage and current measurement	via Interface: $V_{OUT\ max} / 50000$ via Display: limited to 4 digit $I_{OUT\ max} / 50000$								
Resolution of settings	LOCAL	$V_{OUT\ max} / 2000$ and $I_{OUT\ max} / 2000$							
Voltage / Current	REmote	$V_{OUT\ max} / 50000$ and $I_{OUT\ max} / 50000$							
Switching of output voltage	with button "ON/OFF" or via remote control								
Control	LOCAL	10-turn potentiometer for voltage and current							
	(REmote)	CAN	via CAN-Interface (also for diagnosis / software update)						
		RS232	via RS232-Interface						
	optional:	aIF	via indirect coupled analogue I/O instead of RS232-Interface						
	optional:	IEEE	via IEEE-Interface additionally						
Supply	$V_{IN} = 85$ up to 264 V-AC with PFC $I_{IN} = 4,5$ A at 230 V-AC / 9 A at 115 V-AC via mains connector and switch "POWER", isolated from HV-output, fused with $2 * 10$ A / slow.								
Dimension / Weight	1U -19" compatible / depth: 450 mm / ca. 5,7 kg								
Cooling	Internal fan								
Protection	Over load and short circuit , voltage supply and temperature								
Environment conditions	Operating temperature: 5 up to 35 °C Humidity: 30% up to 80 %, no condensation								
Storage temperature	0 up to 60 °C								

#### **4. Description of the CAN Interface.**

The integrated CAN-Interface of the HPS series offers 2 functions.

Either the interface gives access to the implemented firmware of the processor controlled unit, this is important for the service outside and for the update of software generally

or a remote control can be established via this robust and simple industry interface for up to 64 HV units at one serial CAN-Bus line. A Command structure according to the CAN-Open version (CAL-based Draft Standard 301 / Ver. 3.0) has been used.

#### **Function of the CAN-Interface**

The use of the CAN-Interface can be selected by menu "F09" "CAN" and than with push button "LOCAL".

The electrical transmission of all CAN-commands is indirect coupled under signal CAN\_L and CAN\_H, related to CAN\_GND.

The pin assignment of the D-Sub-9 connector on the rear side of the unit is written in following table.

The CAN-Bus on the first and last unit has to be connected between CAN\_H and CAN\_L with an impedance of 120 Ω.

PIN	2	3	5	7
Signal	CAN_L	CAN_GND (GND)	CAN_SHLD (shield)	CAN_H

During Power ON-Reset the HPS-unit is in CAN-Status "INIT" mode , afterwards it changes to CAN-Status "Operational".

The bit rate can be selected between 20, 50, 100 and 125 kBit/s ( factory fixed 125 kBit/s ).

Only through the global command "STOP" the CAN-Interface can be switched to CAN-Status "Pre-operational" .

Only in "INIT" or "Pre-operational" mode the access to the service of the Network-Management (NMT) and Distribution-Management (DBT) is possible.

The global command "ADJUST" is able to change ADC-, DAC- , SUB-Identifier and Inhibit-time in EEPROM in the DBT.

After using "Adjust" the global command „ADJUST“ has to be locked again.

Only in status "Operational" the HPS unit can be controlled via CAN-Bus (read values and status, set values).

After Power ON-Reset or after global command "START" the interface of the unit is automatically in status "Operational".

**Table 1.0**

Services	ID (with RTR=0)	DLC	DATA_1
<b>Network - Management (NMT)</b>			
START / STOP / RESET/ADJUST global	0	1	Bit 0 = 1 ⇒ Start Bit 1 = 1 ⇒ Stop Bit 2 = 1 ⇒ Reset CAN-Interf.  Bit 4 = 1 ⇒ Adjust Bit 5 = 1 ⇒ INIT

These identifiers have been fixed via the ID - Distribution (DBT) Service:

**Table 2.0**

ID – Distribution (DBT) Service	ID	DLC	DATA_1	DATA_n	Remarks
DBT – Master - Request	2024d 7E8h (RTR=1)	0			Request from host only <b>at one connected module</b> : message address and ID´s of modules
DBT - Slave - Service	2023d 7E7h (RTR=0)	8	Mod.-Adr.	2   3   4   5   6   7   8	Message with module address and the according ID´s
DBT - Master - Service	2024d 7E8h (RTR=0)	8	Mod.-Adr.	ADC -ID   DAC -ID   Sub-ID   t	Allocate new ID´s t <sub>N</sub> ... Inhibit-time: t <sub>N</sub> ≈ 15 * (ADC mux) * t <sub>ms</sub>
DBT - Master - Service ↓	2024d 7E8h (RTR=0)	2	0x80	Mod.-Adr.	Request from Host to module address message of ID´s on address.
DBT - Slave - Service	2023d 7E7h (RTR=0)	8	Mod.-Adr.	2   3   4   5   6   7   8	Message with module address and the according ID´s

Table 3.0

Sub-Identifier (Sub-ID)

E-command	ID	R	D	r	command										DATA_n	remarks	
		T	L	/													
		R	C	w													
Multiplex-commands	Sub-ID	0	x	x	0	x	x	x	x	x	x	x					Work on multiplexed DAC/ADC – channels of the selected modules (Sub-ID)
DAC	Sub-ID	0	1	1	0	0	0	0	0	0	0	0	2 Byte DAC-value				Set voltage read
	Sub-ID	0	1	1	0	0	0	0	0	0	0	1	2 Byte DAC-value				Set current read
	Sub-ID	0	3	0	0	0	0	0	0	0	0	0	2 Byte DAC-value				Write for voltage channel 1
	Sub-ID	0	3	0	0	0	0	0	0	0	0	1	2 Byte DAC-value				Write for current channel 1
ADC	Sub-ID	0	3	1	0	0	0	0	1	0	0	2 Byte ADC-value					Read output voltage (Vmeas1)
	Sub-ID	0	3	1	0	0	0	0	1	0	1	2 Byte ADC-value					Read output current (Cmeas1)
Status	Sub-ID	0	2	0	0	0	0	1	0	0	0	1 Byte Status					Set status
	Sub-ID	0	3	1	0	0	0	1	0	0	0	2 Byte Status					Read status
Ramp	Sub-ID	0	3	1	0	0	0	1	1	0	0	2 Byte value					Read ramp
	Sub-ID	0	3	0	0	0	0	1	1	0	0	2 Byte value					Set ramp
Status	Sub-ID	0	2	0	0	0	0	1	0	0	0	1 Byte Status					Set status
	Sub-ID	0	3	1	0	0	0	1	0	0	0	2 Byte Status					Read status
Module command	Sub-ID	0	x	x	1	x	x	x	x	x	x						
EEPROM	Sub-ID	0	2	1	1	0	0	0	0	0	0	EEPROM-Address					Read / Write Access, ( Request from host)
	Sub-ID	0	3	1	1	0	0	0	0	0	0	Data_1: EEPROM-Address					Read data of EEPROM-address
	Sub-ID	0	3	0	1	0	0	0	0	0	0	Data_2: Data on address					Write data on EEPROM-address only in CAN-status "Initialisation" !
Bit rate	Sub-ID	0	2	1	1	0	0	0	0	1	1	old Bit-rate					Read Bit-Rate
	Sub-ID	0	2	0	1	0	0	0	0	1	1	new rate					Only values of 20, 50, 100, 125 for Bit rate
																	in kBit/s accepted
Unit-ID	Sub-ID	0	6	1	1	0	0	0	1	1	0	3 byte serial no. and 2 byte software-release					

## 5. Description of the RS232-Interface

The RS232-Interface is also connected to a D-Sub-connector on the rear side of the unit. Before working under RS232-Interface the menu „F09“ „r232“ has to be selected and the push button „LOCAL“ has to be switched to interface control.

The data transfer is character oriented, while the synchronisation in direction "Computer to HV PS unit" (Input direction) is made by echoes. The transfer direction "HV-PS to computer" (Output direction) is free running. Programmable delay breaks can be set between the transfer code , so that enough time is available for data taking and data interpretation.

The factory setting is 3 ms.

The RS232-Interface is set to 9600 Bit/s, 8 Bit/character, no parity, 1 Stop-Bit.

The electrical transfer is working indirectly coupled via RxD and TxD related to GND. The pin assignment of the D-Sub 9 is in the following table .

The cable connection to the computer is 1:1 (no zero modem-cable !). If no 9-pole cable is available , then the bridges mentioned in the table have to be made.

Signal RS 232	HV-PS		PC DSUB9	PC DSUB25	Connection 3-pol. cable
	DSUB9	Intern			
RxD	2		2	3	
TxD	3		3	2	
GND	5		5	7	
	4		4	20	
	6		6	6	
	8		8	5	

### Syntax

The transfer of commands works in ASCII-code. The end of a set of characters is made by <CR><LF> (\$0D \$0A or 13 10). On input side the leading zeros are useless, the output side is in fixed format. In order to establish the synchronisation between the computer and the HV unit at first <CR><LF> have to be sent.

## 6. Description of the IEEE-Interface

The IEEE 488.2 bus interface was implemented with an IEEE controller compatible to the NEC 7210 controller. The following functions are available according IEC 625:

SH1	Source Handshake	:	all functions
AH1	Acceptor Handshake	:	all functions
T6	Talker	:	standard equipment
L4	Listener	:	standard equipment

The IEEE-Interface is connected to the 24-pin connector according IEEE 488.2 standard on the rear. Before working under IEEE-Interface the menu "F09" "IEEE" has to be selected and the menu "F11" "Adr1" has to be set the IEEE unit address. Please switch off the unit with the POWER switch following! After POWER-ON the push button „LOCAL“ has to be switched to interface control.

## 7. Command sets

### 7.1 ET-command set

The menu „F10“ „ET“ has to be selected.

#### Setting commands:

Command to set the HV:

U,<voltage>kV                      example                      U,1.000kV

Command to set the output current limit:

I,<current>mA                      example                      I,1000mA

Command to set the ramp speed of the output voltage:

RAMP,<rampspeed>V/s      example                      RAMP,3000V/s

Command to set the ON and OFF switch of the HV.

HV,ON  
HV,OFF

Command to set the KILL-Function of „ Enable“ and „Disable“

KILL,ENable  
KILL,DISable

Command for „Emergency OFF“

EMCY OFF

The HV generation will be switched OFF permanently and the values of voltage and current set to 0.

### Read out of the setting commands

Read out of set HV:

STATUS,U                      response example                      U, RANGE=3.000kV, VALUE=2.458kV

Read out of set current limits:

STATUS,I                      response example                      I, RANGE=5000mA, VALUE=1739mA

Read out of set ramp speed:

STATUS,RAMP                      response example                      RAMP, RANGE=3000V/s, VALUE=1000V/s

## Commands to read the actual measurement values

Measuring of the actual output voltage

STATUS,MU      response example      *UM, RANGE=3000V, VALUE=2.458kV*

Measurement of the output current:

STATUS,MI      response example      *IM, RANGE=5000mA, VALUE=1739mA*

## Read out of unit status

STATUS,DI	response	<i>DI, b<sub>15</sub> b<sub>14</sub> b<sub>13</sub> b<sub>12</sub> b<sub>11</sub> b<sub>10</sub> b<sub>9</sub> b<sub>8</sub> b<sub>7</sub> b<sub>6</sub> b<sub>5</sub> b<sub>4</sub> b<sub>3</sub> b<sub>2</sub> b<sub>1</sub> b<sub>0</sub></i>		
			<i>0</i>	<i>1</i>
<i>#define</i>	<i>IpErr</i>	<i>b15</i>	<i>no input error</i>	<i>input error</i>
<i>#define</i>	<i>Ramp</i>	<i>b14</i>	<i>no ramp</i>	<i>ramp</i>
<i>#define</i>	<i>CutOut</i>	<i>b13</i>	<i>-</i>	<i>emergency off</i>
<i>#define</i>	<i>TpErr</i>	<i>b12</i>	<i>no trip error</i>	<i>trip error</i>
<i>#define</i>	<i>F3</i>	<i>b11</i>	<i>reserved</i>	
<i>#define</i>	<i>F2</i>	<i>b10</i>	<i>reserved</i>	
<i>#define</i>	<i>menu1</i>	<i>b9</i>	<i>submenu off</i>	<i>submenu on</i>
<i>#define</i>	<i>menu0</i>	<i>b8</i>	<i>menu off</i>	<i>menu on</i>
<i>#define</i>	<i>err</i>	<i>b7</i>	<i>no error</i>	<i>error</i>
<i>#define</i>	<i>Creg</i>	<i>b6</i>	<i>no current control</i>	<i>current control</i>
<i>#define</i>	<i>Vreg</i>	<i>b5</i>	<i>no voltage control</i>	<i>voltage control</i>
<i>#define</i>	<i>pol</i>	<i>b4</i>	<i>negative</i>	<i>positive</i>
<i>#define</i>	<i>inh</i>	<i>b3</i>	<i>no ext. inhibit</i>	<i>external inhibit</i>
<i>#define</i>	<i>local</i>	<i>b2</i>	<i>remote</i>	<i>local</i>
<i>#define</i>	<i>killena</i>	<i>b1</i>	<i>kill disable</i>	<i>kill enable</i>
<i>#define</i>	<i>on</i>	<i>b0</i>	<i>off</i>	<i>high voltage is ON</i>

## Read of LAM Status

STATUS,LAM	response	LAM,ERROR	(Inhibit during Kill enable, no voltage and no current loop is locked)
LAM,INHIBIT	(external inhibit has been scanned)	LAM,TRIP ERROR	(software current trip occurred)
		LAM,INPUT ERROR	(wrong input string has been scanned from interface)
		LAM,OK	(no Look At Me status has been found)

## Read of unit identifier

ID      response example      *ID, iseg Spezialelektronik r1.00 Type HPN 30 107*

## 7.2 SCPI-set of commands

In menu „F10“ „SCPI“ has to be selected.

### Setting commands:

Command to set the HV:

:VOLTage\_<voltage>\_kV                      example                      :VOLT 1.000kV

Command to set the output current:

:CURRent\_<current>\_mA                      example                      :CURR 1000mA

Command to set the ramp speed of output voltage:

:CONFigure:RAMP\_<ramp speed>\_V/s      example                      RAMP 3000V/s

Command to switch the HV ON and OFF:

:VOLTage\_ON  
:VOLTage\_OFF

Command for „Emergency OFF“

:VOLTage\_EMCY\_OFF

(The HV generation has been shut off permanently and the Set-values for voltage and current have been set to 0.)

Command to set the KILL-Function on „Enable“ or „Disable“

:CONFigure:KILL\_ENable  
:CONFigure:KILL\_DISable

### Read out of the settings commands

Read out of SET HV:

:READ:VOLTage?      Response example      U, RANGE=3.000kV, VALUE=2.458kV

Read out of SET current limit:

:READ:CURRent?      Response example      I, RANGE=5000mA, VALUE=1739mA

Read out of unit identifier:

:READ:IDNT?              Response example      ID, iseg Spezialelektronik 1.00 Type HPN 30 107

### Commands to read the actual measurement values

Measurement of the output voltage:

:MEASure:VOLTage?      Response example UM, RANGE=3.000kV, VALUE=2.458kV

Measurement of the output current:

:MEASure:CURRent?      Response example IM, RANGE=5000mA, VALUE=1739mA

### Read out of the unit Status

	<code>:READ:STATUs</code>	response	$DI, b_{15} b_{14} b_{13} b_{12} b_{11} b_{10} b_9 b_8 b_7 b_6 b_5 b_4 b_3 b_2 b_1 b_0$	
			0	1
<code>#define</code>	<code>IpErr</code>	<code>b15</code>	<code>no input error</code>	<code>input error</code>
<code>#define</code>	<code>Ramp</code>	<code>b14</code>	<code>no ramp</code>	<code>ramp</code>
<code>#define</code>	<code>CutOut</code>	<code>b13</code>	-	<code>emergency off</code>
<code>#define</code>	<code>TpErr</code>	<code>b12</code>	<code>no trip error</code>	<code>trip error</code>
<code>#define</code>	<code>F3</code>	<code>b11</code>	<code>reserved</code>	
<code>#define</code>	<code>F2</code>	<code>b10</code>	<code>reserved</code>	
<code>#define</code>	<code>menu1</code>	<code>b9</code>	<code>submenu off</code>	<code>submenu on</code>
<code>#define</code>	<code>menu0</code>	<code>b8</code>	<code>menu off</code>	<code>menu on</code>
<code>#define</code>	<code>err</code>	<code>b7</code>	<code>no error</code>	<code>error</code>
<code>#define</code>	<code>Creg</code>	<code>b6</code>	<code>no current control</code>	<code>current control</code>
<code>#define</code>	<code>Vreg</code>	<code>b5</code>	<code>no voltage control</code>	<code>voltage control</code>
<code>#define</code>	<code>pol</code>	<code>b4</code>	<code>negative</code>	<code>positive</code>
<code>#define</code>	<code>inh</code>	<code>b3</code>	<code>no ext. inhibit</code>	<code>external Inhibit</code>
<code>#define</code>	<code>local</code>	<code>b2</code>	<code>remote</code>	<code>local</code>
<code>#define</code>	<code>killena</code>	<code>b1</code>	<code>kill disable</code>	<code>kill enable</code>
<code>#define</code>	<code>on</code>	<code>b0</code>	<code>off</code>	<code>high voltage is on</code>

### Read out of the LAM Status

<code>:READ:LAM?</code>	response	<code>LAM,ERROR</code>	<i>(Inhibit during Kill enable, no voltage and no current loop is locked)</i>
		<code>LAM,INHIBIT</code>	<i>(extern Inhibit has been scanned)</i>
		<code>LAM,TRIP ERROR</code>	<i>(software current trip occurred)</i>
		<code>LAM,INPUT ERROR</code>	<i>(wrong input string has been scanned from interface)</i>
		<code>LAM,OK</code>	<i>(no Look At Me status has been found)</i>

### Connection errors

<code>*RST</code>		<i>all Set Values are deleted</i>
<code>*IDN?</code>	<i>Response example</i>	<i>ID, iseg Spezialelektronik 1.00 Typ HPN 30 107</i>
<code>*GTL</code>		<i>go to local, local-button is enabled</i>
<code>*LLO</code>		<i>local logout, Local-Button is disabled</i>
<code>*CLS</code>		<i>clear Status</i>
<code>*TST?</code>		<i>check the system</i>

## 8. Description of analogue I/O

<b>ATTENTION !</b>	All control inputs and outputs are indirect-coupled to the HV-OUT.
--------------------	--

All control inputs and outputs are available at the connector on the rear side of the unit (instead RS232 connector). You must choose the analogue interface "aIF" in the menu 09 "Change interface".

Analogue I/O with male SUB - D - 9 connector								
Pin 1	Pin 2	Pin 3	Pin 4	Pin 5	Pin 6	Pin 7	Pin 8	Pin 9
@GND	V <sub>I-MON</sub>	INHIBIT	V <sub>I-SET</sub>	n.c.	@GND	V <sub>V-MON</sub>	V <sub>V-SET</sub>	V <sub>REF</sub>
	Current monitor	TTL-level, <b>Low</b> = active: ⇒ V <sub>OUT</sub> = 0 <b>High</b> or <b>open</b> : ⇒ V <sub>OUT</sub> = according setting	Current control			Voltage monitor	Voltage control	internal reference voltage V <sub>REF</sub> = 5 V

### Control Inputs

Remote Control Voltage (CV):  $V_{V-SET} = 0$  to 5 V

The output voltage is proportionally to the external control voltage of 0 to 5 V DC. For this purpose following connections have to be provided: control voltage pos. (+) to pin 8 (V<sub>V-SET</sub>), control voltage GND to pin 6 (@GND-analogue indirect-coupled to GND-HV and metal box) .

Example: HPp 40 357

Maximum voltage = 4 kV

5.0 V	control voltage corresponds to	4 kV	output voltage
2.5 V	control voltage corresponds to	2 kV	output voltage
1.0 V	control voltage corresponds to	0,8 kV	output voltage

Remote Control Current (CC):  $V_{I-SET} = 0$  to 5 V

The output current can be set proportionally to an external control voltage of 0 to 5 V DC. For this purpose following connections have to be provided: control voltage pos. (+) to pin 4 (V<sub>I-SET</sub>), control voltage GND to pin 6 (@GND-analogue indirect-coupled to GND-HV and metal box).

Example: HPp 40 357

Maximum current = 350 mA

5.0 V	control voltage corresponds to	350 mA	output current ("KILL" must be disable!)
2.5 V	control voltage corresponds to	175 mA	output current
1.0 V	control voltage corresponds to	70 mA	output current

INHIBIT TTL-Level

High voltage generation will be **shut off** with help of the TTL-level **LOW** on pin 3 related to GND - analogue (@GND-analogue indirect-coupled with GND-HV and metal box).

High voltage generation will be **started** according to the TTL-level **High** or **open** on pin 3 in case of "KILL" is disabled. If "KILL" is enabled also the push button "HV-ON" has to be pushed.

## Control Outputs

### Monitor-output voltage

$$V_{V-MON} = 0 \text{ to } 5 \text{ V}$$

An analogue output monitor signal is available proportionally to the output voltage. The monitor voltage is connected to pin 7 ( $V_{V-MON}$ ) and pin 6 (@GND-analogue indirect-coupled with GND-HV and metal box).

Example: HPp 40 357

Maximum voltage = 4 kV

5.0 V	monitor voltage corresponds to	4 kV	output voltage
2.5 V	monitor voltage corresponds to	2 kV	output voltage
1.0 V	monitor voltage corresponds to	0,8 kV	output voltage

### Monitor-output current

$$V_{I-MON} = 0 \text{ to } 5 \text{ V}$$

An analogue monitor voltage according to the real output current is also available. This voltage is connected to pin 2 ( $V_{I-MON}$ ) and pin 6 (@GND-analogue indirect-coupled with GND-HV and metal box).

Example: HPp 40 357

Maximum current = 350 mA

5.0 V	monitor voltage corresponds to	350 mA	output current
2.5 V	monitor voltage corresponds to	175 mA	output current
1.0 V	monitor voltage corresponds to	70 mA	output current

## 9. Trouble shooting

Unit does not provide output voltage, and the displays are not flashing	⇒	- check mains voltage and connection
Unit does not provide output voltage but the displays are flashing.	⇒	- Check of environmental temperature ( $T_u \leq 35^\circ\text{C}$ ) - Check of Control
During switch ON external fuses are blowing	⇒	- Replace to slow blow fuse (switch ON current peak 25 A)

If these provisions do not lead to a good result this unit has to be checked from an authorised agent or must be shipped to the factory.